



# Preface

---

**Revised: June 5, 2013, OL-23420-01**

This book describes the procedures you perform to assemble the Cisco TelePresence System 500-32”, to configure it for first-time use, and to replace Field-Replaceable Units (FRUs) for the system.

## Conventions

This document uses the following conventions to convey information and alert the user to conditions requiring special awareness.

  
**Warning**

---

**This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, you must be aware of the hazards involved with electrical circuitry and familiar with standard practices for preventing accidents.**

---

  
**Caution**

---

Means reader be careful. In this situation, you might do something that could result in equipment damage or loss of data.

---

  
**Note**

---

Means reader take note. Notes contain helpful suggestions or references to material not covered in the publication.

---

  
**Tip**

---

Means the information contains useful tips.

---

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

---

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.