



Preface vi

New in Cisco TelePresence Content Server Release 6.2.1 vi

Related Documentation vii

Obtaining Documentation and Submitting a Service Request vii

CHAPTER 1

The Management Tab 1-1

Server Overview 1-2

Cluster Overview 1-6

Server Logs 1-7

Transcoding Queue 1-8

Edit Recordings 1-9

Edit Recording 1-9

 Open Content Editor 1-15

Manage Outputs 1-17

Import Recordings 1-25

Create Recording 1-27

Recording Aliases 1-33

 Adding or Editing Recording Aliases 1-34

Categories 1-40

 Adding and Editing Categories 1-41

Templates 1-41

 Adding or Editing Templates 1-42

Media Server Configurations 1-49

 Windows Media Streaming Server 1-51

 QuickTime or Darwin Streaming Server 1-54

 Wowza Media Server for Flash 1-58

 Cisco Video Streamer Server 1-61

 Media Experience Engine 3500 Server 1-61

 Show and Share Server 1-62

 Podcast Producer Server 1-63

 iTunes U Server 1-64

Call Configurations 1-65

- Adding and Editing Call Configurations 1-66
- Site Settings 1-67
 - View all gatekeeper registrations 1-81
 - View all SIP registrations 1-82
 - Upload language pack 1-84
- Groups and Users 1-85
 - Adding and Editing Groups and Users 1-88
 - Creating Automatic Personal Recording Aliases 1-90
- Windows Server 1-91

CHAPTER 2

Cisco TelePresence Content Server Integration with VBrick 2-1

- Integration Overview 2-1
 - What is the Cisco TelePresence Content Server 2-1
 - What is VBrick DME 2-2
- Prerequisites 2-2
- Limitations 2-2
- Configuring Cisco TelePresence Content Server 2-3
 - Configuring Media Server for VBrick VoD 2-3
 - Configuring Template for VBrick VoD 2-4
 - Configuring Recording Alias for VBrick VoD 2-5
- Configuring Media Server for VBrick Live 2-6
 - Configuring Template for VBrick Live 2-8
 - Configuring Recording Alias for VBrick Live 2-10
- Installing vBrick DME (Software only version) 2-11
- Related Documentation 2-12
- Disclaimers and Notices 2-12
- Obtaining Documentation and Submitting a Service Request 2-13
 - 2-14

CHAPTER 3

Configuring a Cisco Unified Communications Manager SIP Trunk with a Cisco TelePresence Content Server 3-15

- CUCM Integration with Content Server 6.2 3-15
 - Cisco Content Server Standalone 3-15**
 - SIP Route pattern Configuration Setting: 3-20
 - Configuring Route Patterns Using Route Group/ Route List 3-24
 - Cisco Content Server Cluster Configuration 3-33
 - Region configuration on CUCM 3-35
 - CUCM Configuration Setting on Content Server 3-36

CHAPTER 4**Content Server VM with BE6K 4-1**

- Introduction 4-1
 - Content Server VM with BE6K Features: 4-1
- UI changes on Content Server for BE6K solution 4-2
 - Management Tab 4-2

APPENDIX 5**Supported Platforms, Browsers, and Plug-ins 5-1****CHAPTER 6****Creating and Managing a Content Server Cluster 6-1**

- About Content Server Clusters 6-2
- System Requirements 6-4
- Important Guidelines 6-5
- Setting up a Content Server Cluster 6-6
 - Overview of the Process 6-6
 - Content Server Cluster Prerequisites 6-6
 - Configure the External SQL Server Database 6-7
 - Add an SQL Server Instance 6-7
 - Configure the SQL Server Instance 6-8
 - Create a Special User on the SQL Server 6-10
 - Configure the NAS 6-11
 - Manage the Windows Active Directory Domain 6-11
 - Choose or Create a Domain Account to Access the NAS Share 6-11
 - Set up a Share on the NAS 6-11
 - Set Permissions and Security Settings on the Share 6-12
- About Creating a Content Server Cluster 6-13
 - The Order of Content Servers Added to the Cluster 6-13
 - Content Server Wizard Options 6-14
 - User Accounts for the Content Server Wizard 6-14
 - Before Running the Content Server Wizard 6-15
- Create a New Content Server Cluster 6-15
- Add a Content Server to an Existing Cluster 6-17
- Configure Gatekeeper Registration for H.323 Cluster 6-18
- Configure Gatekeeper Registration for SIP Cluster 6-19
- Configure Domain Authentication 6-19
- Configure Network Load Balancing (NLB) 6-19
 - Configure a Load Balancer 6-21
 - Set up a Loopback Adapter on Each Content Server in Cluster 6-22
 - Enter the Cluster Virtual IP Address as the Frontend Address on the Content Server 6-22

- Managing a Content Server Cluster 6-23
 - Access Cluster Administrative Pages 6-23
 - View Cluster Status 6-24
 - Edit Information for Each Content Server in Cluster 6-25
 - Edit Information Common to All Content Servers in Cluster 6-25
 - Generate a Cluster Settings File 6-27
 - Update Load Balancer Configuration 6-27
 - Update Cluster Settings 6-28
 - Update the Password for MYDOMAIN\Content Server_NAS_USER Account 6-28
 - Change the MYDOMAIN\Content Server_NAS_USER Account to Another Domain Account 6-29
 - Change the Location of the Media Files to a Different NAS Share 6-29
- Removing a Content Server from the Cluster 6-30
- Using TMS to Schedule Calls on a Content Server Cluster 6-31
- Backing Up and Restoring the Content Server Cluster 6-32
 - Backing Up Clustered Content Servers 6-32
 - Backing Up the External MS SQL Database 6-32
 - Backing Up Media on the NAS/External Streaming Server 6-32
- Upgrading the Cluster to a New Software Version 6-33
- Upgrading the External Microsoft SQL Server 6-33

CHAPTER 7

- The My Recordings Tab 7-1**
 - Edit Recordings 7-1
 - Edit Recording 7-2
 - Open Content Editor 7-5
 - Manage Outputs 7-8
 - Create Recording 7-16
 - Edit Recording Aliases 7-17

CHAPTER 8

- Understanding Distribution Outputs 8-1**
 - Configuring Automatic Upload to Cisco Media Experience Engine 3500, Cisco Show and Share, Podcast Producer or iTunes U 8-1
 - Uploading Existing Recordings to Cisco Media Experience Engine 3500, Cisco Show and Share, Podcast Producer or iTunes U 8-2
 - Understanding the Difference between Distribution Outputs and Streaming Servers 8-3

CHAPTER 9

- Maintaining the Content Server 9-1**
 - Backing Up the Content Server 9-1

Before Backing Up	9-1
Performing a Manual Backup	9-2
Configuring a Scheduled Backup	9-2
Restoring Files	9-3
Before Restoring	9-3
Restoring from a Backup	9-3
Performing a Software Reimage	9-4
Reimage Instructions	9-5
Task 1: Clear the hard drive and install the software	9-5
Task 2: Install the license files	9-6
Task 3: Configure the basic settings	9-8
Restoring Files After a Software Reimage	9-8
Restore Files on a Reimaged Standalone Content Server	9-8
Restore Files on a Reimaged Content Server with Network Attached Storage	9-9
Restore Files on a Reimaged Content Server in a Cluster	9-10
Shutting Down and Powering Off the Content Server	9-11
Securing the Content Server	9-12

APPENDIX 10**Port Information** 10-1**CHAPTER 11****Premium Resolution** 11-1

Configuring and Using the Premium Resolution Features	11-1
---	------

CHAPTER 12**Understanding Recording Aliases** 12-1**CHAPTER 13****Setting Up External Media Storage** 13-1

Changing the Local Storage Location to NAS	13-1
Reverting NAS Storage Location to the Default	13-3
Changing NAS Storage to New Location	13-3
Managing the Domain Account for NAS Access	13-4

CHAPTER 14**Using Cisco TMS with the Content Server** 14-1

Configuring the Content Server for Use by TMS	14-1
Using TMS to Schedule Recording Sessions	14-2

CHAPTER 15**The View Recordings Tab** 15-1

Watching a Recording in the Content Server Web Interface	15-1
--	------

[Watching a Downloaded Output on Your Computer](#) 15-2

[Watching a Downloaded Recording on a Portable Device](#) 15-3

[Sending a Link to the Recording to Others](#) 15-3