



Preface

This preface includes the following sections:

- [About this document, page iii](#)
- [Audience, page iii](#)
- [Conventions, page iv](#)
- [Cisco UCS Communities, page v](#)
- [Related Cisco UCS Documentation, page v](#)
- [Documentation Feedback, page v](#)
- [Obtaining Documentation and Submitting a Service Request, page v](#)

About this document

This document covers the features and functionalities of the Cisco UCS Manager Integration Pack. It also guides you on how to install and use the Cisco UCS Manager Integration Pack in a typical scenario. This document does not cover:

- All the scenarios or ways in which the Cisco UCS Manager Integration Pack can be used.
- Information on System Center Configuration Manager, its installation, or features and functionalities. For details on System Center Configuration Manager, see the Microsoft TechNet site at technet.microsoft.com.

Audience

This guide is intended primarily for data center administrators with responsibilities and expertise in one or more of the following:

- Server administration
- Storage administration
- Network administration
- Network security

Conventions

This document uses the following conventions:

Convention	Indication
bold font	Commands and keywords and user-entered text appear in bold font .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[]	Elements in square brackets are optional.
{ x y z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<code>courier font</code>	Terminal sessions and information the system displays appear in <code>courier font</code> .
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Tip

Means *the following information will help you solve a problem*. The tips information might not be troubleshooting or even an action, but could be useful information, similar to a Timesaver.



Caution

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.



Timesaver

Means *the described action saves time*. You can save time by performing the action described in the paragraph.



Warning

IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that

accompanied this device.

SAVE THESE INSTRUCTIONS

Cisco UCS Communities

[Cisco UCS Communities](#) is a platform to discuss, share and learn about the Cisco UCS products and technologies. For blogs, discussion forums and documents related to UCS integrations with partner ecosystem, visit <https://communities.cisco.com/ucsintegrations>.

Related Cisco UCS Documentation

Documentation Roadmaps

For a complete list of all B-Series documentation, see the *Cisco UCS B-Series Servers Documentation Roadmap* available at the following URL: [Cisco UCS B-Series Servers Documentation Roadmap](#)

For a complete list of all C-Series documentation, see the *Cisco IMC Servers Documentation Roadmap* available at the following URL: [Cisco UCS C-Series and Cisco C880 Series Documentation Roadmap](#).

For a complete list of all E-Series documentation, see the *Cisco IMC Servers Documentation Roadmap* available at the following URL: [Documentation Guide for Cisco UCS E-Series Servers](#)

Other Documentation Resources

An ISO file containing all B and C-Series documents is available at the following URL: <http://www.cisco.com/cisco/software/type.html?mdfid=283853163&flowid=25821>. From this page, click **Unified Computing System (UCS) Documentation Roadmap Bundle**.

The ISO file is updated after every major documentation release.

Follow [Cisco UCS Docs on Twitter](#) to receive document update notifications.

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to ucs-docfeedback@cisco.com. We appreciate your feedback.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation* at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>.

Subscribe to *What's New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation, as an RSS feed and deliver content directly to your desktop using a reader application. The RSS feeds are a free service.

