Send document comments to ucs-docfeedback@cisco.com

CHAPTER 5

Viewing Server Health

This chapter provides information on viewing the health of your servers.

Using the Server Health functionality you can view the health of all the subsystems of your server (like memory, processor, power supply, hard disk, fans, chipset and CIMC) along with the status and message of a specific subsystem.

To view the health of your server, follow these steps:

Step 1 Click the **Server health** tab in the left navigation pane. The server health displays in the right hand content pane, along with the status and message for a specific subsystem.

Step 2 To view the latest status of the subsystem, click **Probe Server** from the toolbar. Click on server health again to refresh the page after clicking on probe server

Step 3 Click the line corresponding to a subsystem to view details of your server health in the Server Health Details pane.

Note The message column in the server health pane displays the first issue corresponding to the subsystem. In case the subsystem has multiple issues, they will show up below in the Server Health Details pane.

Send document comments to ucs-docfeedback@cisco.com