



Viewing Logs

This chapter includes the following sections:

- [Viewing System Logs, page 1](#)
- [Viewing System Event Logs, page 1](#)

Viewing System Logs

By viewing system logs, you can determine if any error has occurred and take the required corrective action.

The system log file displays events that are logged by the operating system components. These events are often predetermined by the operating system itself. System log files display information about device changes, device drivers, system changes, events, operations, and more.

To view the system logs, follow these steps:

Procedure

- Step 1** Click **Logs** on the left navigation pane.
 - Step 2** Click **System Logs**.
 - Step 3** Select a filter from the filter drop-down list.
 - Step 4** Click **Go**.
The system log is displayed.
-

Viewing System Event Logs

By viewing system event logs, you can determine if any error has occurred and take the required corrective action.

The system event log file displays events that are logged by your server.

To view the system event logs, follow these steps:

Procedure

Step 1 Click **Logs** on the left navigation pane.

Step 2 Click **System Event Log**.

Step 3 Select from either the **Description** or **Severity** filter from the drop-down list.

- If you select the Description filter and click **Go**, all the system event logs with a description and severity are displayed.
- If you select the Severity filter and click **Go**, a list with the logs of the specified severity type is displayed.

Step 4 Click **Clear Filter** to clear the filter you applied.
