



Configuring Big Data IP Pools

This chapter contains the following sections:

- [Big Data IP Pools, on page 1](#)
- [Adding a Big Data IP Pool, on page 1](#)
- [Managing Big Data IP Pools, on page 2](#)

Big Data IP Pools

Big Data IP pools contain blocks of IP addresses that Cisco UCS Director Express for Big Data uses during the creation of Hadoop clusters. The IP addresses in each block must belong to the same subnet mask, default gateway, primary domain name server (DNS), and secondary DNS.



Note All IP addresses in a Big Data IP pool must be IPv4 addresses.

Adding a Big Data IP Pool

Step 1 Choose **Solutions > Big Data > Settings**.

Step 2 Click **Big Data IP Pools**.

Step 3 Click **Add**.

Step 4 In the **IP Pool Management Specification** page of the **Create an IP Pool** wizard, complete the following fields:

Name	Description
IP Pool Name field	A unique name for the IP Pool.
Description field	A short description that identifies the purpose of the pool.

Name	Description
Assignment Order drop-down list	The assignment order. Choose one of the following: <ul style="list-style-type: none"> • Default—A random identity is selected from the pool. • Sequential—The lowest available identity is selected from the pool.
Domain Name field	Enter the domain name. For example, cisco.com.

Step 5 Click **Next**.

Step 6 In the **IPv4 Addresses** page of the **Create an IP Pool** wizard, complete the following fields:

- In the IPv4 Blocks table, click **Add (+)**.
- On the **Add Entry to IPv4 Blocks** screen, enter the IPv4 addresses to be included in the IP pool in the **Static IP Pool** field.

This can be a range of IP addresses, or a series of IP addresses separated by commas (,).
- Enter the subnet mask.
- Enter the default gateway.
- Enter the primary DNS server IPv4 address.
- Enter the server DNS server IPv4 address.
- Click **Submit** to save and exit.

Step 7 Click **Submit**.

Managing Big Data IP Pools

Step 1 Choose **Solutions > Big Data > Settings**.

Step 2 Click **Big Data IP Pools**. The following buttons are displayed.

Name	Description
Refresh	Refreshes the current page.
Add	Adds a new IP pool.

Step 3 For the following actions, choose an IP Pool from the table:

Name	Description
Edit	Modifies the IP pool specification.
Delete	Deletes the IP pool specification.

Name	Description
View Details	Allows you to view the IPv4 addresses in the IP pool and to view more reports. Note If you see a License Status tab, it indicates a licensing issue.

Step 4 With an IP Pool selected, click **View Details**.

Step 5 Click **IPv4 Addresses** to display the IP Addresses associated with the selected IP Pool.

Step 6 Select an IP Address from the table. The following buttons are displayed.

Name	Description
Release IP Address	The IP address is made available to be assigned against any bare metal server.
Release Multiple IP Addresses	Enables you to choose and release more than one IP address from the Release Multiple IP Addresses dialog box.
