



# New and Changed Information for this Release

This chapter contains the following sections:

- [New and Changed Information in this Release, on page 1](#)

## New and Changed Information in this Release

### New Features and Changed Information in Cisco UCS Director, Release 6.6

The following table provides an overview of the significant changes to this guide for this current release. The table does not provide an exhaustive list of all changes made to this guide or of all new features in this release.

*Table 1: New Features and Changed Behavior in Cisco UCS Director, Release 6.6*

Feature	Description	Where Documented
<b>Modify LIF and Modify Status</b> added to NetApp accounts	Allows you to modify the logical interface values and status of the existing LIF.	<a href="#">Managing Logical Interfaces</a>

### New Features and Changed Information in Cisco UCS Director, Release 6.6.1.0

The following table provides an overview of the significant changes to this guide for this current release. The table does not provide an exhaustive list of all changes made to this guide or of all new features in this release.

**Table 2: New Features and Changed Behavior in Cisco UCS Director, Release 6.6.1.0**

Feature	Description	Where Documented
<b>Migrating LUNs, FlexGroup Volumes, Enabling and Disabling Data Compression, and User and Group Quotas</b> , added to NetApp accounts	Allows you to do the following: <ul style="list-style-type: none"><li>• Move a LUN from one volume to another within the same Storage Virtual Machine (SVM) without causing any disruption in data</li><li>• Create FlexGroup volumes</li><li>• Enable and disable data compression within a volume to reduce the storage capacity</li><li>• Create user quotas and group quotas on a volume or a QTree</li></ul>	<a href="#">Monitoring and Reporting for a Cluster Mode Account</a>