



Cisco C880 M4 Tasks

This chapter contains the following sections:

- [Change Boot Order, on page 2](#)
- [Get IOU MAC Address, on page 3](#)
- [Location LED Off, on page 4](#)
- [Location LED On, on page 5](#)
- [Power Off Device, on page 6](#)
- [Power On Device, on page 7](#)
- [Power Reset Device, on page 8](#)

Change Boot Order

Summary

Change Boot Order of Cisco C880 M4 Device

Description

This task is used to change the boot order of selected Cisco C880 M4 device.

Inputs

Input	Description	Mappable To Type	Mandatory
Cisco C880 M4 Account	Choose the Cisco C880 M4 account	CiscoC880M4SystemIdentity	Y
Boot Order	Choose a boot order	CiscoC880M4BootOrder	Y

Outputs

Output	Description	Type
OUTPUT_C880M4_SYSTEM_IDENTITY	C880 M4 System Identity	CiscoC880M4SystemIdentity

Get IOU MAC Address

Summary

Get MAC address of IOU

Description

This task is used to fetch the MAC address of selected IOU for a selected Cisco C880 M4 device.

Inputs

Input	Description	Mappable To Type	Mandatory
Cisco C880 M4 Account	Choose the Cisco C880 M4 account	CiscoC880M4SystemIdentity	Y
IOU	Choose an IOU	CiscoC880M4IOUIdentity	Y

Outputs

Output	Description	Type
OUTPUT_C880M4_MAC_IDENTITY	C880 M4 MAC Address Identity	CiscoC880M4MACAddress Identity

Location LED Off

Summary

Location LED Off Cisco C880 M4 Device

Description

This task is used to Location LED Off the selected Cisco C880 M4 device.

Inputs

Input	Description	Mappable To Type	Mandatory
Cisco C880 M4 Account	Choose the Cisco C880 M4 account	CiscoC880M4SystemIdentity	Y
Location LED	Choose the location LED	CiscoC880M4LEDIdentity	Y
Do you want to turn the LED OFF?	Do you want to turn the location LED off?		Y

Outputs

Output	Description	Type
OUTPUT_C880M4_SYSTEM_IDENTITY	C880 M4 System Identity	CiscoC880M4SystemIdentity
OUTPUT_C880M4_LED_IDENTITY	C880 M4 LED Identity	CiscoC880M4LEDIdentity

Location LED On

Summary

Location LED On Cisco C880 M4 Device

Description

This task is used to Location LED On the selected Cisco C880 M4 device.

Inputs

Input	Description	Mappable To Type	Mandatory
Cisco C880 M4 Account	Choose the Cisco C880 M4 account	CiscoC880M4SystemIdentity	Y
Location LED	Choose the location LED	CiscoC880M4LEDIdentity	Y
Do you want to turn the Location LED ON?	Do you want to turn the location LED on?		Y

Outputs

Output	Description	Type
OUTPUT_C880M4_SYSTEM_IDENTITY	C880 M4 System Identity	CiscoC880M4SystemIdentity
OUTPUT_C880M4_LED_IDENTITY	C880 M4 LED Identity	CiscoC880M4LEDIdentity

Power Off Device

Summary

Power Off Cisco C880 M4 Device

Description

This task is used to Power OFF the selected Cisco C880 M4 device.

Inputs

Input	Description	Mappable To Type	Mandatory
Cisco C880 M4 Account	Choose the Cisco C880 M4 account	CiscoC880M4System Identity	Y
Do you want to turn the Power OFF?	Do you want to turn the power off?		Y

Outputs

Output	Description	Type
OUTPUT_C880M4_SYSTEM_IDENTITY	C880 M4 System Identity	CiscoC880M4SystemIdentity
OUTPUT_C880M4_POWER_STATUS	C880 M4 Power Identity	CiscoC880M4PowerIdentity

Power On Device

Summary

Power On Cisco C880 M4 Device

Description

This task is used to Power ON the selected Cisco C880 M4 device.

Inputs

Input	Description	Mappable To Type	Mandatory
Cisco C880 M4 Account	Choose the Cisco C880 M4 account	CiscoC880M4SystemIdentity	Y
Do you want to turn the device Power ON?	Do you want to turn the power on?		Y

Outputs

Output	Description	Type
OUTPUT_C880M4_SYSTEM_IDENTITY	C880 M4 System Identity	CiscoC880M4SystemIdentity
OUTPUT_C880M4_POWER_STATUS	C880 M4 Power Identity	CiscoC880M4PowerIdentity

Power Reset Device

Summary

Power Reset Cisco C880 M4 Device

Description

This task is used to Power Reset the selected Cisco C880 M4 device.

Inputs

Input	Description	Mappable To Type	Mandatory
CiscoC880M4 Account	Choose the Cisco C880 M4 account	CiscoC880M4System Identity	Y
Do you want to reset the device Power?	Do you want to reset the device Power?		Y

Outputs

Output	Description	Type
OUTPUT_C880M4_SYSTEM_IDENTITY	C880 M4 System Identity	CiscoC880M4SystemIdentity
OUTPUT_C880M4_POWER_STATUS	C880 M4 Power Identity	CiscoC880M4PowerIdentity