



## New and Changed Information

- [New and Changed Information for This Release, on page 1](#)

### New and Changed Information for This Release

The following table provides an overview of the significant changes to this guide for this current release. The table does not provide an exhaustive list of all changes made to this guide or of all new features in this release.

**Table 1: New Features and Changed Behavior in Cisco UCS Manager, Release 4.2(2)**

Feature	Description	Where Documented
Configuring Fabric Interconnect using GUI	<p>During the initial Fabric Interconnect setup using graphical user interface (GUI), you can select Fabric interconnect managed mode to either Cisco UCS Manager (UCSM) or Cisco Intersight Managed Mode (IMM).</p> <p><b>Note</b> This is applicable for Cisco UCS 6400 Series Fabric Interconnects only.</p>	See <a href="#">Configure the Primary Fabric Interconnect Using GUI</a> and <a href="#">Configure the Subordinate Fabric Interconnect Using GUI</a>

