

Transient Faults

- Troubleshooting Transient Faults, on page 1
- Initial Setup and Discovery Faults, on page 1
- Virtual Machine Startup Faults, on page 5

Troubleshooting Transient Faults

Transient faults can occur during initial set up and discovery or when a server or virtual machine starts up. You can typically ignore these transient faults, as Cisco UCS Manager clears them automatically.

Initial Setup and Discovery Faults

The table describes the transient faults that you may see during the initial setup and discovery process. The Cisco UCS Manager clears these faults. If you see them during the initial setup or discovery process, you can safely ignore these faults.

Table 1: Transient Faults that Occur during Initial Setup and Discovery Process

Fault Code	Fault Text	Description
F16581	[FSM:STAGE:RETRY:]: user configuration to sandy[SVSIACEsntheAd.stF]. [pdd.stF]. [state.stF].	The FSM could not send the user configuration to the subordinate fabric interconnect during the initial cluster configuration or the setup.
F16745	[FSM:STAGE:RETRY:]: QoS Classification Definition classification configuration on santa(SVSIATsuth Qsls Dfb Coff lls QSSIA)	The FSM could not send the quality of the service configuration to the subordinate fabric interconnect during the initial cluster configuration or the setup.
F16725	[FSM:STAGE:RETRY:]: VM profile configuration on external VM naugh SVSIACE and the Mile (SV) (SV) (SV) (SV) (SV) (SV) (SV) (SV)	The FSM could not send the VM profile configuration to the the subordinate fabric interconnect during the initial cluster configuration or the setup.

Fault Code	Fault Text	Description
F16580	[FSM:STAGE:RETRY:]: realm configuration to sacrabates (SVSIACEs nutro-Variabate) for the configuration of the conf	The FSM could not send the security configuration to the subordinate fabric interconnect during the initial cluster configuration or the setup.
F16724	[FSM:STAGE:RETRY:]: external VM manager configuration on local thir(FSMSIAGE:mthrExtmnFpConfeStLoca)	The FSM could not send the VM manager configuration to the primary fabric interconnect during the initial cluster configuration or the setup.
F16579	[FSM:STAGE:RETRY:]: external aaa server configuration to scorts/FSMSIACE:anthr/AaFji.[pttfjfsfffRet)	The FSM could not send the security configuration to the subordinate fabric interconnect during the initial cluster configuration or the setup.
F16749	[FSM:STAGE:RETRY:]: Uplink eth port configuration on BESMSIACEsmhuSvHlaBulDpbyLinkCondis)	The FSM could not send the eth-uplink configuration to the fabric interconnects during the initial cluster configuration or the setup.
F16749	[FSM:STAGE:RETRY:]: internal network configuration on BESVETAGE anthe Swaces Denit Deby Light Condit)	The FSM could not send the internal network configuration to the fabric interconnects during the initial cluster configuration or the setup.
F16749	[FSM:STAGE:RETRY:]: Uplink fc port configuration on BESMSIACEsantheSMSsiBudDphy. Julia Condit)	The FSM could not send the fibre channel uplink configuration to the fabric interconnects during the initial cluster configuration or the setup.
F16680	[FSM:STAGE:RETRY:]: Enable virtual interface on local fabric iteored[FSMSIACE:archeVgnffidt][Aca]	The FSM could not send the virtual interface configuration to the fabric interconnects during the initial cluster configuration or the setup.
F16579	[FSM:STAGE:RETRY:]: keyring configuration on seconds/FSV/SIACFsmthtHFILINHFISKS/Right)	The FSM could not send the security configuration to the subordinate fabric interconnect during the initial cluster configuration or the setup.

Fault Code	Fault Text	Description
F16539	[FSM:STAGE:RETRY:]: Fabric interconnect mode configuration to progressive and the configuration of the configurati	The FSM could not send the end-host mode configuration on to the primary fabric interconnect during the initial cluster configuration or the setup.
F0429	Fabric Interconnect A, HA functionality not ready	The cluster configuration cannot be completed until the chassis discovery is completed.
F0400	Chassis 1 connectivity configuration: un-acknowledged	Cisco UCS Manager discovered the chassis with only one link in the first attempt although the chassis discovery policy is configured for four links. Cisco UCS Manager reacknowledges the chassis to activate the other links.
F0401	IOM 1/2 (B) current connectivity does not match discovery policy: unsupported-connectivity	Cisco UCS Manager discovered the chassis with only one link in the first attempt although the chassis discovery policy is configured for four links.
		Cisco UCS Manager can clear this fault when the communication is established between the chassis and the fabric interconnect with that link.
F0440	Chassis discovery policy conflict: Link IOM 1/2/2 to fabric interconnect B:1/1 not configured	Cisco UCS Manager discovered the chassis with only one link in the first attempt although the chassis discovery policy is configured for four links. Until the discovery is successful with that link, the remaining links cannot be marked as active.
		Cisco UCS Manager can clear this fault when the communication is established between the chassis and the fabric interconnect with that link.
F0332	AssociatePnuOSLocalDiskConfig fails with Service-Unavailable	During discovery, the server association failed due to an error when configuring the local disk controller. The associated remote invocation error code is 4106.

Fault Code	Fault Text	Description
F0277	ether port 1 on fabric interconnect B oper state: link-up, reason: FEX not configured	Cisco UCS Manager discovered the chassis with only one link in the first attempt although the chassis discovery policy is configured for four links. Until the discovery is successful with that link, the remaining links cannot be marked as active.
F0276	ether port 4 on fabric interconnect B oper state: link-down, reason: Link failure or not-connected	One or more of the links on the chassis flapped during the initial discovery. This fault is generated when the link is down during the flapping.
F0206	Adapter 1/2/1 is unreachable	During discovery, the adapter information cannot be accessed from the server. This fault clears as soon as the information is available.
F0283	VIF 1 / 2 B-42/44 down, reason: Bound Physical Interface Down	The internal VIF that Cisco UCS Manager uses during discovery failed.
F0367	No link between IOM port 1/1/2 and fabric interconnect A:1/2	The ethernet server ports flapped on the fabric interconnect during the initial discovery, because the discovery policy was configured for more than one link.
		Cisco UCS Manager clears this fault when the initial discovery succeeds with one link and the other links can be marked as active.
F0399	Current connectivity for chassis 1 does not match discovery policy: unsupported-connectivity	Cisco UCS Manager discovered the chassis with only one link in the first attempt although the chassis discovery policy is configured for four links. Until the discovery is successful with that link, the remaining links cannot be marked as active.
F16520	[FSM:STAGE:RETRY:]: Identify pre-boot environment agent on server [2[FMSIACEsmthsComptPtdDkoodh(Nth)]	The FSM failed to identify the pre-boot environment on the server during discovery.

Fault Code	Fault Text	Description
F77960	[FSM:STAGE:REMOTE-ERROR]: Result: end-point-unavailable Code: unspecified Message: Waiting for BIOS POST Completion information from EMCantheComptBulDacodEnRaCompletin)	The FSM did not receive a response from the server during discovery and is waiting for the BIOS POST completion information.
F0320	Server 1/1 (service profile:) has an invalid FRU: mismatch-identity-unestablishable	Cisco UCS Manager could not identify the FRUs from the servers during initial discovery.
F77959	[FSM:STAGE:REMOTE-ERROR]: Result: unidentified-fail Code: ERR-0505-IBMC-fru-retrieval-error Message: Could not get Fru from 7f060101, dn=fabric/server/chassis-1/slot-1 (smchreFabicComputSdFpklanfyExcutd coa)	Cisco UCS Manager could not identify the FRUs from the servers during initial discovery.
F16406	[FSM:STAGE:RETRY:]: triggering chassis discovery via IOM Light SMSIATs and diport Cate Confusion Class)	In a cluster configuration, after Cisco UCS Manager discovers the chassis through the I/O module connected to the primary fabric interconnect, it raises discovery through the I/O module connected to the secondary fabric interconnect. F0401

Virtual Machine Startup Faults

When you power on a virtual machine on a server that has network adaptors connected to a distributed virtual wwitch through a port profile, the Events tab of the VMware vCenter may display the following event:

Virtual machine powered On with vNICs connected to dvPorts that have a port level configuration, which might be different from the dvPort group configuration.

If you see this event, you can safely ignore it.

Virtual Machine Startup Faults