



**Preface** xv

Document Revision History	xv
Audience	xv
Document Organization	xvi
Document Conventions	xvi
Related Documentation	xvii
Obtaining Documentation and Submitting a Service Request	xvii

---

**CHAPTER 1**

**Command-Line Interface Command Summary** 1-1

Using VDS-IS Device Modes	1-1
Using Command-Line Processing	1-1
Using Command Modes	1-2
Using EXEC Mode	1-3
Using Global Configuration Mode	1-3
Using Interface Configuration Mode	1-4
Using Other Configuration Modes	1-4
Checking the Command Syntax	1-5
System Help	1-6
Filtering Output Using Output Modifiers	1-6
Saving Configuration Changes	1-6

---

**CHAPTER 2**

**Cisco Videoscape Distribution Suite, Internet Streamer Software Commands** 2-1

aaa	2-23
access-lists	2-27
acquirer (EXEC)	2-30
acquirer (Global configuration)	2-33
acquisition-distribution	2-35
alarm	2-37
area nssa	2-39
area stub	2-40
asset	2-41
authsvr	2-42

bandwidth (Global configuration)	2-45
bandwidth (interface configuration)	2-48
banner	2-50
bitrate	2-53
blink	2-56
bootstrap-node	2-57
cache	2-59
capability	2-64
cd	2-65
cdn-select	2-66
cdnfs	2-67
cdsm	2-70
clear cache	2-73
clear content	2-75
clear ip	2-77
clear ipv6	2-79
clear isis	2-80
clear logging	2-82
clear service-router	2-83
clear srp database offline	2-84
clear srp descriptor	2-85
clear srp neighbor	2-87
clear srp resource	2-90
clear srp route	2-92
clear statistics	2-94
clear transaction-logs	2-99
clear users	2-100
clear wmt	2-101
clock (EXEC)	2-102
clock (Global configuration)	2-104
cms (EXEC)	2-107
cms (Global configuration)	2-111
configure	2-114
contentmgr	2-115
content-mgr disk-info force-reset	2-118

content-origin 2-119  
copy 2-120  
cpfile 2-123  
debug 2-124  
debug ip bgp 2-135  
debug ip ospf 2-137  
debug ip proximity 2-140  
debug ip rib 2-141  
debug isis 2-143  
debug srp 2-145  
delfile 2-147  
deltree 2-148  
device 2-149  
dir 2-151  
direct-server-return 2-152  
disable 2-153  
disk (EXEC) 2-154  
disk (Global configuration) 2-159  
distribution 2-163  
dnslookup 2-167  
domain 2-168  
enable 2-169  
enable password 2-170  
end 2-171  
exec-timeout 2-172  
exit 2-173  
expert-mode password 2-174  
external-ip 2-175  
find-pattern 2-177  
flash-media-streaming 2-179  
flooding 2-182  
geo-location-server 2-183  
gulp 2-185  
help 2-188  
hostname 2-189

install	2-190
interface	2-191
ip (Global configuration)	2-196
ip (Interface configuration)	2-202
ip access-list	2-205
ip ospf priority	2-213
ip rib route	2-214
ip router isis	2-216
ipv6	2-217
isis	2-221
is-type	2-224
kernel	2-226
key	2-227
key-string	2-228
key chain	2-229
lACP	2-231
line	2-233
lls	2-234
limit memory	2-235
location community	2-236
log-adjacency-changes	2-239
logging	2-240
log-neighbor-changes	2-244
ls	2-245
lsp-mtu	2-246
mkdir	2-247
mkfile	2-248
model	2-249
movie-streamer	2-251
mtu	2-254
multicast (Global Configuration)	2-255
multicast (EXEC Configuration)	2-258
neighbor	2-265
net	2-268
netmon	2-269

netstatr 2-270  
network area 2-271  
no (Global configuration) 2-273  
no (interface configuration) 2-275  
ntp 2-276  
ntpdate 2-278  
ping 2-279  
ping srp 2-280  
ping6 2-281  
port-channel 2-282  
primary-interface 2-284  
proximity algorithm bgp 2-286  
proximity engine enable 2-292  
pwd 2-295  
radius-server 2-296  
rcp 2-300  
reload 2-301  
rename 2-302  
restore 2-303  
rmdir 2-306  
router bgp 2-307  
router isis 2-308  
router ospf 2-310  
router srp 2-312  
rtsp 2-313  
rule 2-316  
script 2-327  
service 2-328  
service-router 2-330  
setup 2-346  
show aaa 2-347  
show access-lists 300 2-350  
show acquirer 2-351  
show alarms 2-353  
show arp 2-356

show authentication	2-357
show authsvr	2-358
show bandwidth	2-359
show banner	2-361
show bitrate	2-362
show cache	2-363
show cache-router	2-365
show capability	2-366
show cdn-select	2-367
show cdnfs	2-368
show clock	2-370
show cms	2-373
show content	2-375
show content-mgr	2-378
show content-origin	2-382
show debugging	2-384
show debugging srp	2-387
show device-mode	2-388
show direct-server-return	2-390
show disks	2-391
show distribution	2-396
show flash	2-409
show flash-media-streaming	2-411
show ftp	2-413
show hardware	2-414
show hosts	2-420
show interface	2-421
show inventory	2-426
show ip access-list	2-428
show ip bgp	2-430
show ip bgp all	2-432
show ip bgp community	2-433
show ip bgp ipv4 unicast	2-435
show ip bgp memory	2-436
show ip bgp neighbors	2-437

show ip bgp nexthop-database	2-439
show ip bgp summary	2-440
show ip interface	2-441
show ip ospf	2-442
show ip ospf border-routers	2-444
show ip ospf database	2-445
show ip ospf interface	2-451
show ip ospf memory	2-453
show ip ospf neighbor	2-455
show ip ospf request-list	2-457
show ip ospf retransmission-list	2-458
show ip ospf route	2-459
show ip ospf rspf route	2-461
show ip ospf traffic	2-463
show ip proximity algorithm	2-465
show ip proximity interface	2-466
show ip proximity servers	2-467
show ip rib clients	2-468
show ip rib memory	2-469
show ip rib recursive-next-hop	2-471
show ip rib route	2-472
show ip rib unresolved-next-hop	2-474
show ip routes	2-475
show ip static route	2-477
show ipv6	2-478
show isis adjacency	2-480
show isis clns route	2-482
show isis database	2-483
show isis hostname-table	2-487
show isis interface	2-488
show isis ip route	2-491
show isis ip rspf route	2-493
show isis memory	2-495
show isis process	2-496
show isis rrm	2-497

show isis spf-log	2-498
show isis srm	2-500
show isis ssn	2-501
show key chain	2-502
show lacp	2-503
show limit memory	2-505
show logging	2-506
show movie-streamer	2-508
show multicast	2-510
show ntp	2-511
show processes	2-513
show programs	2-515
show radius-server	2-521
show rcp	2-523
show rtsp	2-524
show rule	2-525
show running-config	2-527
show service-router	2-531
show services	2-537
show snmp	2-539
show srp database	2-543
show srp leafset	2-550
show srp memory	2-552
show srp multicast database	2-553
show srp neighbor	2-556
show srp process	2-559
show srp replica-set	2-560
show srp route	2-561
show srp subscribers	2-563
show ssh	2-564
show standby	2-565
show startup-config	2-566
show statistics aaa	2-569
show statistics access-lists 300	2-570
show statistics acquirer	2-571



show statistics admission	2-574
show statistics authsvr	2-576
show statistics cdn-select	2-579
show statistics cdnfs	2-580
show statistics content-mgr	2-582
show statistics distribution	2-585
show statistics flash-media-streaming	2-588
show statistics icmp	2-597
show statistics ip	2-603
show statistics isis	2-607
show statistics movie-streamer	2-609
show statistics netstat	2-612
show statistics radius	2-613
show statistics replication	2-614
show statistics service-router	2-618
show statistics services	2-624
show statistics snmp	2-625
show statistics srp	2-627
show statistics tacacs	2-628
show statistics tcp	2-629
show statistics transaction-logs	2-638
show statistics udp	2-640
show statistics web-engine	2-641
show statistics wmt	2-650
show tacacs	2-656
show tech-support	2-658
show telnet	2-664
show transaction-logging	2-665
show url-signature	2-669
show user	2-670
show users	2-671
show version	2-672
show web-engine	2-674
show wmt	2-676
shutdown (interface configuration)	2-682

shutdown (EXEC) 2-683

snmp-server community 2-691

snmp-server contact 2-692

snmp-server enable traps 2-693

snmp-server group 2-695

snmp-server host 2-697

snmp-server location 2-700

snmp-server notify inform 2-701

snmp-server trap-source 2-703

snmp-server user 2-705

snmp-server view 2-707

splunk-uf-monitor 2-709

ss 2-713

sshd 2-715

streaming-interface 2-717

sysmon 2-718

sysreport 2-719

tacacs 2-720

tcpdump 2-724

tcpmon 2-729

tcp timestamp 2-731

telnet 2-732

tcp tw-recycle 2-733

tcp tw-reuse 2-734

telnet enable 2-735

terminal 2-736

test-url 2-737

top 2-741

traceroute 2-742

traceroute srp 2-745

traceroute6 2-746

transaction-log force 2-747

transaction-logs 2-749

type 2-765

type-tail 2-767

undebug 2-770  
url-signature 2-772  
username 2-776  
web-engine (EXEC) 2-779  
web-engine (Global configuration) 2-783  
whoami 2-789  
wmt 2-790  
write 2-804

---

**APPENDIX A****Acronyms** A-1

---

**APPENDIX B****Standard Time Zones** B-1

---

**INDEX**

