



INDEX

A

- application deployment
 - deploying to a shared location [2-4](#)
 - described [2-4](#)
 - using a software deployment tool [2-4](#)
 - using the client computer installer [2-4](#)
- application log file location [2-6](#)

B

- BAT, for updating phones to support video [1-6](#)

C

- camera drivers
 - deploying [2-4](#)
 - deploying with command-line options [2-5](#)
 - installer package names [2-1](#)
- CDR analysis and reporting, using [4-7](#)
- Cisco Unified Communications Manager
 - configuring for Cisco Unified Video Advantage [1-4](#)
 - configuring the phone for Cisco Unified Video Advantage [1-5](#)
- Cisco Unified IP Phones, setting up on Cisco Unified Communications Manager [1-5](#)
- Cisco Unified Video Advantage
 - application log file location [2-6](#)
 - collecting diagnostic and log information [4-8](#)
 - described [1-1](#)
 - installation log file location [2-6](#)
 - network, server, PC requirements [1-3](#)
 - server and application interactions [1-3](#)
 - software components [2-2](#)

- supported protocols [1-1](#)

- Cisco VT Camera
 - installation log file location [2-6](#)
 - technical specifications [A-1](#)
- command-line options, deploying with [2-5](#)
- configuration settings
 - for Cisco Unified Communications Manager [1-4](#)
 - for Cisco Unified IP Phones [1-5](#)
- CPU utilization, resolving high usage [4-5](#)

D

- deploying the application
 - described [2-4](#)
 - installer package names [2-1](#)
 - software components [2-2](#)
 - software download site [2-3](#)
 - with command-line options [2-5](#)
- detailed logs, described [4-9](#)
- Diagnostics Tool, described [4-8](#)
- diagnostic tools
 - using CDR analysis and reporting [4-7](#)
 - using Real-Time Monitoring Tool [4-6](#)
 - using serviceability troubleshooting traces [4-6](#)
- disconnected calls on H.323 endpoints, resolving [4-4](#)

E

- elevated privileges [2-4](#)

I

- information needed by users [3-1](#)

installation log location
 for Cisco VT Camera [2-6](#)
 for CUVA [2-6](#)

installer packages [2-1](#)

installing the application. See user guide

L

logs

capturing detailed [4-9](#)
 collecting when the application crashes [4-10](#)
 location of [2-6](#)

M

mobile workers, resolving bandwidth issues [4-4](#)

N

network protocols

CAST [1-2](#)
 CDP [1-2](#)
 IP [1-2](#)
 RTP [1-2](#)
 SCCP [1-2](#)
 TCP [1-2](#)

P

performance degraded from detailed logs [4-9](#)

privileges, required for updating [2-7](#)

Problem Reporting Tool

capturing logs automatically [4-10](#)
 described [4-10](#)
 enabling detailed logs [4-9](#)
 log file location [2-6](#)

protocols, supported [1-1](#)

R

Real-Time Monitoring Tool, using [4-6](#)

restricted permissions, Vista [2-4](#)

S

server and application interactions [1-3](#)

serviceability troubleshooting traces, using [4-6](#)

shared location deployment [2-4](#)

Software Center, URL for [2-8](#)

software deployment tools [2-4](#)

T

telecommuters, resolving bandwidth issues [4-4](#)

troubleshooting, resolving

bandwidth issues for mobile workers or telecommuters [4-4](#)

CUVA not associating with IP phone [4-3](#)

disconnected calls on H.323 endpoints [4-4](#)

no-video icon appears [4-2](#)

no video icon appears on phone screen [4-3](#)

no video in video windows [4-2](#)

no video on multi-party conferences [4-1](#)

PC CPU utilization at 100 percent [4-5](#)

poor audio and video lip synchronization [4-2](#)

video bandwidth unavailable message appears on IP phone [4-3](#)

video problem icon appears in system tray [4-3](#)

video problems [4-1](#)

U

updating

manually [2-7](#)

obtaining software for [2-7](#)

privileges for [2-7](#)

software deployment tool [2-7](#)

- uninstalling previous version [2-7](#)
- URL for downloading latest software [2-8](#)
- user information, providing [3-1](#)
- users
 - access to documentation and online help [3-2](#)
 - contact names to provide assistance [3-2](#)
 - how to report problems [3-2](#)
 - required information for [3-1](#)

V

- Vista, restricted permissions [2-4](#)

