



Preface

This Preface contains the following sections:

- [Audience and Use, page 9](#)
- [Documentation Conventions, page 9](#)
- [Cisco Unity Connection Documentation, page 10](#)
- [Obtaining Documentation and Submitting a Service Request, page 10](#)
- [Cisco Product Security Overview, page 10](#)

Audience and Use

This document provides instructions for setting up an integration between Cisco Unity Connection and supported phone systems using PIMG units. For a list of phone systems that are qualified to integrate with Unity Connection through PIMG units, see the “[Introduction](#)” chapter.

Documentation Conventions

The *PIMG Integration Guide for Cisco Unity Connection Release 10.x* uses the following conventions.

Table 1 *PIMG Integration Guide for Cisco Unity Connection Release 10.x Conventions*

Convention	Description
boldfaced text	Boldfaced text is used for: <ul style="list-style-type: none">• Key and button names. (Example: Select OK.)• Information that you enter. (Example: Enter Administrator in the User Name box.)
< > (angle brackets)	Angle brackets are used around parameters for which you supply a value. (Example: In the Command Prompt window, enter ping <IP address> .)

Table 1 PIMG Integration Guide for Cisco Unity Connection Release 10.x Conventions

Convention	Description
- (hyphen)	Hyphens separate keys that must be pressed simultaneously. (Example: Press Ctrl-Alt-Delete .)
> (right angle bracket)	A right angle bracket is used to separate selections that you make on menus. (Example: On the Windows Start menu, select Programs > Cisco Unified Serviceability > Real-Time Monitoring Tool .) In the navigation bar of the Cisco Unity Connection Administration. (Example: In the Cisco Unity Connection Administration, expand System Settings > Advanced .)

The *PIMG Integration Guide for Cisco Unity Connection Release 10.x* also uses the following conventions:



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the document.



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Cisco Unity Connection Documentation

For descriptions and URLs of Unity Connection documentation on Cisco.com, see the *Cisco Unity Documentation Guide*. The document is shipped with Unity Connection and is available at http://www.cisco.com/en/US/products/ps6509/products_documentation_roadmaps_list.html.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

Cisco Product Security Overview

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors

and users are responsible for compliance with U.S. and local country laws. Using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

Further information regarding U.S. export regulations can be found at http://www.access.gpo.gov/bis/ear/ear_data.html.

