



Numerics

10/100 PC port [2-3](#)

10/100 SW port [2-3](#)

A

abbreviations, time zone [3-8](#)

accessing [3-12](#), [5-6](#)

access port [2-3](#)

Audit Connection command [3-2](#)

Audit Endpoint command [3-2](#)

B

book objectives [viii](#)

buttons [1-3](#), [1-4](#), [3-11](#)

C

call forward [1-7](#)

call transfer [1-7](#)

call waiting [1-7](#)

character support [1-8](#)

conventions, document [ix](#)

Create Connection command [3-2](#)

D

debug command [5-2](#)

default configuration file [3-2](#), [3-9](#)

Delete Connection command [3-2](#)

dialing pad [1-4](#)

DNS description [1-7](#)

documentation conventions [ix](#)

Domain Name System (DNS) [1-6](#), [1-7](#)

DTMF [1-6](#)

DTMF payload [3-4](#)

Dynamic Host Configuration Protocol (DHCP) [1-7](#), [3-1](#),
[3-11](#)

E

Endpoint Configuration command [3-2](#)

F

features [1-2](#)

firmware

 updating [3-13](#)

firmware version, viewing [3-12](#)

footstand, adjusting [1-3](#)

function toggles [1-4](#)

G

G.711 a-law codec [1-6](#)

G.711 u-law codec [1-6](#)

G.729a codec [1-6](#)

H

handset [1-4](#)

headset [2-4](#), [4-1](#), [4-2](#)

|

ICMP, description [1-7](#)
 image_version configuration parameter [3-2](#)
 image upgrade [3-16](#)
 image version [3-5](#)
 Internet Control Message Protocol (ICMP) [1-7](#)
 Internet Protocol (IP) [1-7](#)
 IP description [1-7](#)
 ISO 8859-1 Latin1 characters [1-8](#)

|

language support [1-8](#)
 LCD screen [1-3, 4-2](#)
 Local Connection Options (LCOs) [1-6](#)

|

MAC address [3-2](#)
 messages, status [5-6](#)
 Message Waiting Indication [1-7](#)
 MGCDDefault.cnf file [3-2](#)
 MGCmacaddress.cnf file [3-2](#)
 MGCP commands [3-2](#)
 Modify Connection command [3-2](#)
 mute [4-2](#)

|

network
 connections [2-3](#)
 port [2-3](#)
 statistics [5-6](#)
 network address translation (NAT) [3-6](#)
 network connections, access port [2-3](#)
 Notification command [3-2](#)
 Notification Request command [3-2](#)

notify messages [1-7](#)

|

OS79XX.TXT file [3-2](#)

|

P
 parameters
 dtmf_avt_payload [3-4](#)
 image_version [3-5](#)
 SIP telnet_enable [3-6](#)
 tos_media [3-7](#)
 phone
 connections [2-3](#)
 features, physical [1-2](#)
 interfaces [1-2](#)
 prerequisites [2-2](#)
 supported protocols [1-7, 1-8](#)
 port [2-3](#)
 power source, Cisco Catalyst switches [2-3](#)
 power source, external [2-3](#)
 prerequisites [2-2](#)
 protocols [1-7, 1-8](#)
 TFTP [1-7](#)

|

Real-Time Transport Protocol (RTP) [1-7](#)
 remote reboot [3-16](#)
 resetting
 network statistics [5-7](#)
 Restart in Progress command [3-2](#)
 RFC [1-6, 1-7](#)
 RTP [1-7](#)

S

safety warnings [2-1](#)
 scroll key [1-4](#)
 SDP, description [1-7](#)
 Session Description Protocol (SDP) [1-7](#)
 show command [5-4](#)
 Simple Network Time Protocol (SNTP) [1-7](#)
 SNTP, description [1-7](#)
 specifying [3-5](#)
 DTMF payload [3-4](#)
 image version [3-5](#)
 specifying, TOS media [3-7](#)
 statistics, network [5-6](#)
 status information
 accessing [5-6](#)
 status information, accessing [3-12, 5-6](#)

T

TCP, description [1-7](#)
 telnet_enable parameter [3-6](#)
 Telnet sessions [5-1](#)
 TFTP, description [1-7](#)
 TFTP server, timeout [3-2, 3-3](#)
 three-way calling [1-7](#)
 time zone abbreviations [3-8](#)
 TOS media
 specifying [3-7](#)
 traceroute command [5-5](#)
 translated safety warnings [A-1](#)
 Transmission Control Protocol (TCP) [1-7](#)
 Trivial File Transfer Protocol (TFTP) [1-7](#)
 troubleshooting [5-1](#)
 tty command [5-6](#)
 type of service (ToS) bit [1-6](#)

U

UDP, description [1-8](#)
 updating
 firmware [3-13](#)
 upgrade [3-16](#)
 upgrade scenarios [3-13](#)
 release 5.0 and 5.1 [3-14](#)
 release 5.0 and release 5.1 [3-13](#)
 user configuration file [3-2](#)
 User Datagram Protocol (UDP) [1-8](#)

V

viewing firmware version [3-12](#)
 voice activity detection (VAD) [1-6](#)
 volume, adjusting [4-2](#)

W

what's new in this release
 release 5.0 [1-1](#)
 release 5.1 [1-1](#)

X

XML [1-6, 3-2](#)

