



# Cisco IP Conference Phone 8832 Release Notes for Firmware Release 12.8(1)SR1

**First Published:** 2020-12-17

**Last Modified:** 2021-03-18

## Cisco IP Conference Phone 8832 Release Notes for Firmware Release 12.8(1)SR1

These release notes support the Cisco IP Conference Phone 8832 running SIP Firmware Release 12.8(1)SR1.

The following table lists the support compatibility for the Cisco IP Phones.

*Table 1: Cisco IP Phones, Support, and Firmware Release Compatibility*

Cisco IP Phone	Support Requirements
8832	Cisco Unified Communications Manager 10.5(2) and later Cisco Unified Communications Manager time zone update 2016d or later SRST 8.0 (IOS load 15.1(1)T) and above Cisco Expressway 8.7
8832	Unified CME 12.3 (Cisco IOS XE Fuji 16.9.1 release)

### Related Documentation

Use the following sections to obtain related information.

#### Cisco IP Conference Phone 8832 Documentation

Refer to publications that are specific to your language, phone model, and call control system. Navigate from the following documentation URL:

<https://www.cisco.com/c/en/us/support/collaboration-endpoints/unified-ip-phone-8800-series/tsd-products-support-general-information.html>

#### Cisco Unified Communications Manager Documentation

See the *Cisco Unified Communications Manager Documentation Guide* and other publications that are specific to your Cisco Unified Communications Manager release. Navigate from the following documentation URL:

<https://www.cisco.com/c/en/us/support/unified-communications/unified-communications-manager-callmanager/tsd-products-support-series-home.html>

## New and Changed Features

This release contains no new or changed features.

## Installation

### Installation Requirements

Before you install the firmware release, you must ensure that your Cisco Unified Communications Manager is running the latest device pack. After you install a device pack on the Unified CM servers in the cluster, you need to reboot all the servers.



---

**Note** If your Cisco Unified Communications Manager doesn't have the required device pack to support this firmware release, the firmware may not work correctly.

---

For information on the Cisco Unified Communications Manager Device Packs, see [https://www.cisco.com/c/en/us/td/docs/voice\\_ip\\_comm/cucm/compat/matrix/CMDP\\_BK\\_CCBDA741\\_00\\_cucm-device-package-compatibility-matrix.html](https://www.cisco.com/c/en/us/td/docs/voice_ip_comm/cucm/compat/matrix/CMDP_BK_CCBDA741_00_cucm-device-package-compatibility-matrix.html).

### Install the Firmware Release on Cisco Unified Communications Manager

Before using the phone firmware release on the Cisco Unified Communications Manager, you must install the latest Cisco Unified Communications Manager firmware on all Cisco Unified Communications Manager servers in the cluster.

#### Procedure

---

- Step 1** Go to the following URL:  
<https://software.cisco.com/download/navigator.html?mdfid=284729655&flowid=75283>
- Step 2** Choose **IP Conference Phone 8832**.
- Step 3** Choose **Session Initiation Protocol (SIP) Software**.
- Step 4** In the Latest Releases folder, choose **12.8(1)SR1**.
- Step 5** Select the firmware file, click the **Download** or **Add to cart** button, and follow the prompts.  
The firmware filename is `cmterm-8832-sip.12-8-1-0101-482.k3.cop.sgn`
- Note** If you added the firmware file to the cart, click the **Download Cart** link when you are ready to download the file.
- Step 6** Click the + next to the firmware file name in the Download Cart section to access additional information about this file. The hyperlink for the readme file is in the Additional Information section, which contains installation instructions for the corresponding firmware.
- Step 7** Follow the instructions in the readme file to install the firmware.
-

## Install the Firmware Zip Files

If a Cisco Unified Communications Manager is not available to load the installer program, the following .zip file is available to load the firmware:

cmterm-8832.12-8-1-0101-482.zip

Firmware upgrades over the WLAN interface may take longer than upgrades using a wired connection. Upgrade times over the WLAN interface may take more than an hour, depending on the quality and bandwidth of the wireless connection.

### Procedure

- 
- Step 1** Go to the following URL:  
<https://software.cisco.com/download/navigator.html?mdfid=284729655&flowid=75283>
- Step 2** Choose **IP Conference Phone 8832**.
- Step 3** Choose **Session Initiation Protocol (SIP) Software**.
- Step 4** In the Latest Releases folder, choose **12.8(1)SR1**.
- Step 5** Download the relevant zip files.
- Step 6** Unzip the files.
- Step 7** Manually copy the unzipped files to the directory on the TFTP server. See *Cisco Unified Communications Operating System Administration Guide* for information about how to manually copy the firmware files to the server.
- 

## Limitations and Restrictions

### Phone Behavior During Times of Network Congestion

Anything that degrades network performance can affect phone audio and, in some cases, can cause a call to drop. Sources of network degradation can include, but are not limited to, the following activities:

- Administrative tasks, such as an internal port scan or security scan
- Attacks that occur on your network, such as a Denial of Service attack

### Firmware Limitation of Cisco IP Conference Phone 8832 with Cisco IP Conference Phone 8832 PoE Injector

The Cisco IP Conference Phone 8832 PoE Injector is supported on phones running firmware release 12.0(1)SR2 and later. Confirm that the latest firmware release is installed on the Cisco Unified Communications Manager before you connect the Cisco IP Conference Phone 8832 with the PoE injector to the network.

If you are not using the latest firmware release, then your phone may downgrade to an earlier firmware release, and lose the network connectivity.

To recover a phone that has lost network connectivity, update Device Defaults for the Cisco IP Conference Phone 8832 to **8832-sip.12-0-1SR2-2.k3.cop.sgn** or later in Cisco Unified Communications Manager Administration. Then, perform one of the following steps:

- Force the phone to reboot from the alternate software image that supports the PoE Injector. To reboot your phone from the backup image, see **Boot Up the Conference Phone from the Alternate Partition** section in the *Cisco IP Conference Phone 8832 Administration Guide for Cisco Unified Communications Manager*.
- Install and use the Cisco IP Conference Phone 8832 Ethernet Injector on the phone. This allows you to regain network connectivity. After the phone has upgraded to the latest firmware, you can again use the Cisco IP Conference Phone 8832 PoE Injector.

## Health-Care Environment Use

This product is not a medical device and uses an unlicensed frequency band that is susceptible to interference from other devices or equipment.

## Language Limitation

There is no localized Keyboard Alphanumeric Text Entry (KATE) support for the following Asian locales:

- Chinese (China)
- Chinese (Hong Kong)
- Chinese (Taiwan)
- Japanese (Japan)
- Korean (Korea Republic)


The default English (United States) KATE is presented to the user instead.

For example, the phone screen will show text in Korean, but the **2** key on the keypad will display **a b c 2**  
**A B C**.

## Wireless Microphone Battery Limitation

When you press the **Show detail** softkey, the Cisco IP Conference Phone 8832 occasionally displays a false **Bad battery** warning. This issue occurs when you quickly reseal the wireless microphone 20 consecutive times or more.

To recover from this issue, perform the following steps in order:

- Remove the microphone from the charging cradle.
- Press the Mute  button for approximately 10 seconds or until the microphone LED stops blinking white. Then, reseal the microphone on the charging cradle.
- Restart the phone by disconnecting and reconnecting the Cisco IP Conference Phone 8832 Power Adapter.

The **Bad battery** warning on the phone screen disappears and the current battery status appears. If you do not see the battery status, then the microphone battery has deteriorated and you must replace it.

## Caveats

### View Caveats

You can search for caveats using the Cisco Bug Search.

Known caveats (bugs) are graded according to severity level, and can be either open or resolved.

### Before you begin

To view caveats, you need the following items:

- Internet connection
- Web browser
- Cisco.com user ID and password

### Procedure

- 
- Step 1** Perform one of the following actions:
- To find all caveats for this release, use this URL:  
[https://bst.cloudapps.cisco.com/bugsearch/search?kw=\\*&pf=prdNm&pfVal=284729655&rls=12.8\(1.\\*\),12.8\(1\)&sb=anfr&svr=3nH&bt=custV](https://bst.cloudapps.cisco.com/bugsearch/search?kw=*&pf=prdNm&pfVal=284729655&rls=12.8(1.*),12.8(1)&sb=anfr&svr=3nH&bt=custV)
  - To find all open caveats for this release, use this URL:  
[https://bst.cloudapps.cisco.com/bugsearch/search?kw=\\*&pf=prdNm&pfVal=284729655&rls=12.8\(1\)&sb= afr&sts=open&svr=3nH&bt=custV](https://bst.cloudapps.cisco.com/bugsearch/search?kw=*&pf=prdNm&pfVal=284729655&rls=12.8(1)&sb= afr&sts=open&svr=3nH&bt=custV)
  - To find all resolved caveats for this release, use this URL:  
[https://bst.cloudapps.cisco.com/bugsearch/search?kw=\\*&pf=prdNm&pfVal=284729655&rls=12.8\(1.\\*\),12.8\(1\)&sb=anfr&svr=3nH&bt=custV](https://bst.cloudapps.cisco.com/bugsearch/search?kw=*&pf=prdNm&pfVal=284729655&rls=12.8(1.*),12.8(1)&sb=anfr&svr=3nH&bt=custV)
- Step 2** When prompted, log in with your Cisco.com user ID and password.
- Step 3** (Optional) To look for information about a specific problem, enter the bug ID number in the Search for field, and press **Enter**.
- 

### Open Caveats

The following list contains severity 1, 2, and 3 defects that are open for the Cisco IP Conference Phone 8832 for Firmware Release 12.8(1)SR1.

For more information about an individual defect, access the Bug Search toolkit and search for the defect using the Identifier. You must be a registered Cisco.com user to access this online information.

Because defect status continually changes, the list reflects a snapshot of the defects that were open at the time this report was compiled. For an updated view of open defects, access Bug Toolkit as described in [View Caveats, on page 4](#).

- CSCvq55980 - Network name still displayed ssid when no wifi radio available

### Resolved Caveats

The following list contains severity 1, 2, and 3 defects that are resolved for the Cisco IP Conference Phone 8832 for Firmware Release 12.8(1).

For more information about an individual defect, access the Bug Search toolkit and search for the defect using the Identifier. You must be a registered Cisco.com user to access this online information.

Because defect status continually changes, the list reflects a snapshot of the defects that were open at the time this report was compiled. For an updated view of open defects, access Bug Toolkit as described in [View Caveats, on page 4](#).

- CSCvt27644 - Cisco IP Phone Call Log Information Disclosure Vulnerability
- CSCvu43767 - Missing RTP stream when Built-in-Bridge Recording through MRA is used for iPhone
- CSCvu05618 - Missing SRST information on Phone webpage
- CSCvu59349 Multiple BufferOverflow + Out of Bounds Read for LLDP and CDP
- CSCvu84549 - remote log profile settings on CUCM do not take effect on phone
- CSCvv66008 - CP-88xx sends corrupted SIP messages when debugs are enabled
- CSCvv58736 - 88xx phone can't conference/transfer external pstn phone when the jtapi application
- CSCvw30093 - Cisco IP Phone 8800 Series, CDP packets ignored if switch hostname starts with SEP
- CSCvw45287 - 8851 phone over MRA phone stuck after losing connectivity

## Cisco Unified Communication Manager Public Keys

To improve software integrity protection, new public keys are used to sign cop files for Cisco Unified Communications Manager Release 10.0.1 and later. These cop files have “k3” in their name. To install a k3 cop file on a pre-10.0.1 Cisco Unified Communications Manager, consult the README for the `cisco.com.version3-keys.cop.sgn` to determine if this additional cop file must first be installed on your specific Cisco Unified Communications Manager version. If these keys are not present and are required, you will see the error “The selected file is not valid” when you try to install the software package.

## Unified Communications Manager Endpoints Locale Installer

By default, Cisco IP Phones are set up for the English (United States) locale. To use the Cisco IP Phones in other locales, you must install the locale-specific version of the Unified Communications Manager Endpoints Locale Installer on every Cisco Unified Communications Manager server in the cluster. The Locale Installer installs the latest translated text for the phone user interface and country-specific phone tones on your system so that they are available for the Cisco IP Phones.

To access the Locale Installer required for a release, access <https://software.cisco.com/download/navigator.html?mdfid=286037605&flowid=46245>, navigate to your phone model, and select the Unified Communications Manager Endpoints Locale Installer link.

For more information, see the documentation for your particular Cisco Unified Communications Manager release.




---

**Note** The latest Locale Installer may not be immediately available; continue to check the website for updates.

---

## Cisco IP Phone Documentation Updates on Cisco Unified Communications Manager

The Cisco Unified Communications Manager Self Care Portal (Release 10.0 and later) and User Options web pages (Release 9.1 and earlier) provide links to the IP Phone user guides in PDF format. These user guides are stored on the Cisco Unified Communications Manager and are up to date when the Cisco Unified Communications Manager release is first made available to customers.

After a Cisco Unified Communications Manager release, subsequent updates to the user guides appear only on the Cisco website. The phone firmware release notes contain the applicable documentation URLs. In the web pages, updated documents display “Updated” beside the document link.



---

**Note** The Cisco Unified Communications Manager Device Packages and the Unified Communications Manager Endpoints Locale Installer do not update the English user guides on the Cisco Unified Communications Manager.

---

You and your users should check the Cisco website for updated user guides and download the PDF files. You can also make the files available to your users on your company website.



---

**Tip** You may want to bookmark the web pages for the phone models that are deployed in your company and send these URLs to your users.

---

## Cisco IP Phone Firmware Support Policy

For information on the support policy for phones, see <https://cisco.com/go/phonefirmwaresupport>.

---

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment causes interference to radio or television reception, which can be determined by turning the equipment off and on, users are encouraged to try to correct the interference by using one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications to this product not authorized by Cisco could void the FCC approval and negate your authority to operate the product.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2021 Cisco Systems, Inc. All rights reserved.