



Managing the System Configuration

- [Restoring System Defaults](#)
- [Viewing the Configuration Results](#)
- [Previewing the Candidate Configuration](#)

Restoring System Defaults

Procedure

- Step 1** Choose **Administration > Manage Configuration > Restore Defaults / Rollback**.
- The system displays the Manage Configuration page.
- Step 2** To save or commit the configuration, which makes this configuration the new starting configuration, do the following:
- a. Click **Save/Commit Configuration**.
 - b. At the confirmation window, click **OK**.
- Step 3** To restore the configuration to how it was when it was delivered from the factory, which means that you will lose all changes you have made and will reload the module, do the following:
- a. Click **Restore Factory Defaults**.
 - b. At the confirmation window, click **OK**.
- Step 4** To roll back the system to the most recent configuration, which replaces the current configuration and reloads the module, do the following:
- a. Click **Rollback Active Configuration**.
 - b. At the confirmation window, click **OK**.
-

Related Topics

Back to the [Managing the System Configuration](#) menu page

Viewing the Configuration Results

After you save and commit the configuration, the system displays this web page that presents the result (either success or failure) of the save operation.

Related Topics

Back to the [Managing the System Configuration](#) menu page

Previewing the Candidate Configuration

The system displays the code for the candidate configuration.



Note

If there have not been any changes, the system displays a message stating this.

Procedure

- Step 1** Choose **Administration > Manage Configuration > Candidate Preview**.
- The system displays the Candidate Configuration Preview page.
- Step 2** To save or commit the configuration, which makes this configuration the new starting configuration, do the following:
- Click **Save/Commit Configuration**.
 - At the confirmation window, click **OK**.
- Step 3** To clear the system of the candidate configuration, which discards all uncommitted changes, do the following:
- Click **Clear Candidate Configuration**.
 - At the confirmation window, click **OK**.
-

Related Topics

Back to the [Managing the System Configuration](#) menu page