



Cisco VVB Uninstallation on KVM

- [Cisco VVB Uninstallation on KVM, on page 1](#)

Cisco VVB Uninstallation on KVM

Uninstall Cisco VVB on KVM

Step 1 Deactivate virtual-service from the virtual-service config mode by running:

no activate

Example:

```
router# configure
Configuring from terminal, memory, or network [terminal]?
Enter configuration commands, one per line. End with CNTL/Z.
router(config)#
router(config)# virtual-service vvb
router(config-virt-serv)# no activate
router(config-virt-serv)# ^Z
router# show virtual-service list
Virtual Service List:
```

Name	Status	Package Name
-----	-----	-----
vvb	Deactivating	VVB_12_5_1_ISR4K.ova
Name	Status	Package Name
-----	-----	-----
vvb	Deactivated	VVB_12_5_1_ISR4K.ova

Note This can take around 5-10 minutes.

Step 2 In the privileged EXEC mode, run:

virtual-service uninstall name <name>

Example:

```
router# virtual-service uninstall name vvb
```

Note The virtual-service name is case-sensitive and must match the name given in Step 2 of the preceding procedure.

Step 3 To verify the VVB instance was successfully deactivated/uninstalled, run:

a) **show log**

Example:

```
router# show log
```

```
-----  
show log
```

```
*Aug 1 08:51:48.845: %VIRT_SERVICE-5-ACTIVATION_STATE: Successfully deactivated virtual service  
vzb
```

```
*Aug 1 08:52:45.418: %VIRT_SERVICE-5-INSTALL_STATE: Successfully uninstalled virtual service vzb
```

b) **show virtual-service list**

Example:

```
router# show virtual-service list
```

```
Virtual Service List:
```

Note The output of the command must be empty.
