cisco.



Migration Guide for Cisco Virtualized Voice Browser, Release 12.6(2)

First Published: 2023-04-28 Last Modified: 2023-04-28

Americas Headquarters

Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA http://www.cisco.com Tel: 408 526-4000 800 553-NETS (6387) Fax: 408 527-0883 THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: https://www.cisco.com/c/en/us/about/legal/trademarks.html. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 1994-2023 Cisco Systems, Inc. All rights reserved.



CONTENTS

PREFACE	Preface v
	Change History v
	About This Guide v
	Audience v
	Related Documents v
	Communications, Services, and Additional Information vi
	Documentation Feedback vi
CHAPTER 1	System Requirements 1
	System Requirements 1
CHAPTER 2	Installation and Configuration 3
	Installation and Configuration 3
CHAPTER 3	Features Comparison 5
	Feature Comparison 5
CHAPTER 4	Understanding the Difference 9
	Differences 9
CHAPTER 5	Migration Process 11
	Migration Process 11
	Service and Dial-Peer Configuration 11
	Comprehensive Service or Application 12
	Standalone Service or Application 12
	Ringtone Service or Application 13

	MRCP Configuration 14
	Call Throttling 14
	SIP RAI 14
	Adding Cisco-VVB to Deployment 15
CHAPTER 6	High Availability Consideration 17
	High availability Consideration 17
	Comprehensive Model 17
	Standalone Model 17

I

I

CHAPTER 7

Sizing 19 Sizing 19

Migration Guide for Cisco Virtualized Voice Browser, Release 12.6(2)



Preface

- Change History, on page v
- About This Guide, on page v
- Audience , on page v
- Related Documents, on page v
- · Communications, Services, and Additional Information, on page vi
- Documentation Feedback, on page vi

Change History

Change	See	Date
Added custom SIP header passing to VXML as part of 12.6(2) ES updates.	Features Comparison	August 2023
Initial Release of Document for Release 12.6(2)		April 2023

About This Guide

This document outlays the guidelines for migrating Cisco IOS based Voice Browser to Cisco Virtualized Voice Browser (Cisco VVB) in a Contact Center deployment. Review all the installation instructions carefully before you install Cisco VVB.

Audience

This guide is intended for administrators who are migrating from Cisco IOS based Voice Browser to Cisco Virtualized Voice Browser.

Related Documents

Cisco VVB provides the following documentation:

- Solution Design Guide for Cisco Unified Customer Voice Portal
- Configuration Guide for Cisco Unified Customer Voice Portal
- Installation and Upgrade Guide for Cisco Virtualized Voice Browser
- Developer Guide for Cisco Virtualized Voice Browser
- Solution Port Utilization Guide for Cisco Virtualized Voice Browser
- Operations Guide for Cisco Virtualized Voice Browser

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at Cisco Profile Manager.
- To get the business impact you're looking for with the technologies that matter, visit Cisco Services.
- To submit a service request, visit Cisco Support.
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit Cisco Marketplace.
- To obtain general networking, training, and certification titles, visit Cisco Press.
- To find warranty information for a specific product or product family, access Cisco Warranty Finder.

Cisco Bug Search Tool

Cisco Bug Search Tool (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.

Documentation Feedback

To provide comments about this document, send an email to contactcenterproducts_docfeedback@cisco.com



System Requirements

• System Requirements, on page 1

System Requirements

For details on system requirements, refer to Virtualization page at:https://www.cisco.com/c/dam/en/us/td/ docs/voice_ip_comm/uc_system/virtualization/virtualization-cisco-virtualized-voice-browser.html.

I



Installation and Configuration

• Installation and Configuration, on page 3

Installation and Configuration

For more details on installation, see Installation and Upgrade guide https://www.cisco.com/c/en/us/support/ customer-collaboration/virtualized-voice-browser/products-installation-guides-list.html.

For more details on configurations, see Configuration Guide for Cisco Unified Customer Voice Portal https://www.cisco.com/c/en/us/support/customer-collaboration/unified-customer-voice-portal/products-installation-and-configuration-guides-list.html.



Features Comparison

• Feature Comparison, on page 5

Feature Comparison

The Feature Comparison table lists the features that are available on Cisco IOS and Cisco VVB.

Feature	Cisco IOS	Cisco VVB
Comprehensive Call Model	Supported	Supported
Standalone Call Model	Supported	Supported
VRU-only Call Model	Supported	Supported
WAAG	Supported	Supported
ССВ	Supported	Supported
Sigdigit	Supported	Supported
Codec: G.711 a law / u law	Supported	Supported
Codec: G.729	Supported	Supported
HTTPS	Supported	Supported
Transfer	Blind and Consultative Transfer in Standalone Call Model	Blind Transfer in Standalone Call Model. (Uses REFER method)
MRCPv1 and v2	Supported	Supported
Local Prompts	Supported	Supported
Hostname Resolution	Supported	Supported
Rest API for Configuration	Not supported	Supported
CLIs	Vast	Platform, Call summary, Cache, HTTP client, MRCP statistics

I

Feature	Cisco IOS	Cisco VVB
Real Time Reporting	Not supported	Supported
RTMT Support	Not supported	Supported
Prime Support	Limited	Supported
TLS	1.0, 1.1	1.2
Cisco VXML Tags (CVP Call Studio)	Supported	Supported
Hardware Platforms	See https://www.cisco.com/c/en/us/ support/customer-collaboration/ unified-contact-center-enterprise/ products-device-support-tables-list.html	Spec based hardware, see https://www.cisco.com/c/dam/en/us/td/ docs/voice_ip_comm/uc_system/ virtualization/ virtualization-cisco-virtualized-voice-browser.html
RTSP Streaming	Supported	Not supported
Video in Queue	Supported	Not supported
RSM	Supported	Not supported
Grammar Types	Supported	Supported types: <i>application/srgs+xml</i> , <i>application/grammar+xml</i> , and <i>application/grammar+regex</i>
Digit Element	Grammar accepts only digits from 0 – 9	Grammar accepts digits from $0-9$, "#", and "*". "#" is the default termination character. You can mark any digit or DTMF character as termination character by adding it in custom VXML property.
HTTP Streaming	Not Supported	Supported
		For more information, see the Audio chapter in Element Specifications Guide for Cisco Unified CVP VXML Server and Call Studio at https://www.cisco.com/c/ en/us/support/customer-collaboration/ unified-customer-voice-portal/ tsd-products-support-series-home.html
Custom SIP header passing	Supported	Supported
to a VXML server		For more information, see Custom SIP header passing to a VXML server in Solution Design Guide for Cisco Unified Contact Center Enterprise and Solution Design Guide for Cisco Packaged Contact Center Enterprise.

To know whether any script changes are required while migrating from IOS VXML to VVB for Conformance 2.0 and Conformance 2.1, refer to CSCvk32060.

I



Understanding the Difference

• Differences, on page 9

Differences

The following table lists the feature and configuration differences between Cisco IOS-VB and Cisco VVB.

Feature	Cisco IOS-VB Configuration	Cisco VVB Configuration
Service/Application	Service Configuration	Application configuration in Cisco VVB
Dial-Peer	Dial peer Configuration	Trigger configuration in Cisco VVB
TCL Scripts	CVP OAMP downloaded TCL scripts: • bootstrap.tcl • CVPSelfService.tcl • cvp_ccb_poll.tcl • ringtone.tcl • ccb tcl scripts	 AEF applications. By default, Cisco VVB includes the following prepackaged applications: CVPComprehensive.aef Ringtone.aef Error.aef SelfService.aef VRUComprehensive.aef Note You can't modify these applications.
CVP VXML documents	CVP OAMP downloaded VXML scripts: • bootstrap.vxml • CVPSelfServiceBootstrap.vxml • recovery.vxml	Cisco VVB has prepackaged the VXML document files for various AEF applications. Note You can't modify these applications.

I

Feature	Cisco IOS-VB Configuration	Cisco VVB Configuration	
Codec config	Codec defined at dial-peer level	Codec defined at System level	
MRCP Interface and Configuration	ASR/TTS configuration. • voice class uri • Using Dial-Peer to load balance ASR/TTS	ASR/TTS server configuration by specifying the hostname or IP Address of speech servers. Load balancing is done on a	
	Maximum sessions that can be set for a server	round-robin basis. No such configuration	
	Weight-based load balancing between various servers configured	Weight-based load balancing isn't supported.	
	CVP microapps dependency on MRCP v1	No dependency of CVP microapps on MRCP v1	
	Option to configure MRCP client timers	No option to configure MRCP client timers	
HTTP cache Configuration	Various CLIs for HTTP Cache Configuration	Equivalent CLI commands to configure HTTP cache for media files	
HTTP timers	Can be configured	Can be configured	
Call Throttling	Based on RAI parameters (CPU and memory utilization, DSO, DSP)	Max calls supported by OVA profile.	
		Cisco VVB supports sending RAI information. For more details, see SIP RAI, on page 14 section.	
Audio prompts	All prompts are played from start to end.	Cisco VVB is compliant with VoiceXML, so prompts are queued instead of being played when the Audio element is run. The queued prompts are played:	
		• When the browser reaches a waiting state such as recognition.	
		• When the browser fetches a resource while the fetchaudio attribute is set on the corresponding fetch element.	
		• When the browser has reached the end of the application.	



Migration Process

• Migration Process, on page 11

Migration Process

To migrate from a Cisco-IOS-VB to Cisco-VB, the first step is installation and configuration of Cisco-VVB followed by adding the Cisco-VVB to the CVP deployment. This will require some configuration on CVP OAMP and Egress routing routes.

Service and Dial-Peer Configuration

- 1. For comprehensive, standalone and ringtone service, create equivalent application in Cisco-VVB.
- 2. For each corresponding dial-peer on Cisco-IOS-VB, add corresponding trigger on the Cisco-VVB.
- **3.** For SigDigit is defined at dial-peer level in Cisco-IOS-VB, configure SigDigit at corresponding application of the trigger, for example:

```
dial-peer voice 60001 voip
description CVP VRU LABEL, SIGDIGITS 555XXX
preference 1
service bootstrap
incoming called-number 555....1111119999T
voice-class sip rel1xx disable
dtmf-relay rtp-nte
codec g711ulaw
param sigdigits 4
no vad
```

Service and Dial-Peer

Name *	Comprehensive
Maximum Number of Sessions*	600
Script*	SSCRIPT[CVPComprehensive.aef] -
Secured	false
Sigdigit	4
Description	Comprehensive Applicatio
Enabled	• Yes No

Comprehensive Service or Application

In a comprehensive call model administrator needs to add application and set various parameters.

SigDigit is defined as	parameter at the service level in Cisco-IOS-
• example:	
paramspace english i paramspace english 1 paramspace english 1 paramspace english p param sigdigits 4 omprehensive Service Name	anguage en ocation flash
	20 177577728
Maximum Number of Sessions*	600
Script*	SSCRIPT[CVPComprehensive.aef] -

4

C	4			C		. 🗛		4
<u> </u>	tann	la l	inne	Serv	ice or	'дпп	IICA	rinn
U	runu	u		UCIVI	166 01	n pp	пьа	uvn

Enabled

Sigdigit

Description

In a standalone call model, the administrator has to add application and set various parameters like VXML application name, primary/secondary server, port and other related.

510012

Comprehensive Applicatic

Yes No

For example:

```
service standalone flash:CVPSelfService.tcl
paramspace english language en
param CVPPrimaryVXMLServer 10.78.26.38
paramspace english location flash:
param CVPSelfService-port 7000
param CVPSelfService-app AgeIdentification
```

Service standalone

Name	standalone
Maximum Number of Sessions*	600
Script*	SSCRIPT[SelfService.aef]
ApplicationName	"HelloWorld"
Port	"7000"
PrimaryVXMLServer	"10.78.26.156"
BackupVXMLServer	107 :
Secured	false
Description	
Enabled	● Yes ◎ No

Ringtone Service or Application

For ringtone service, add application and set various parameters, VXML application name, primary/secondary server, and port.

For example:

```
service ringtone flash:ringtone.tcl
paramspace english index 0
paramspace english language en
paramspace english location flash
paramspace english prefix en
```

Ringtone

Ringtone	
600	
SSCRIPT[Ringtone.aef]	•
Ringtone Application	
• Yes No	
	600 SSCRIPT[Ringtone.aef] Ringtone Application

MRCP Configuration

- 1. If ASR and TTS are configured in Cisco-IOS-VB, then add these in the Cisco-VVB for the following scenarios:
 - **a.** Multiple servers are configured for ASR or TTS, for load balancing, using dial-peer. In this case multiple servers can be configured on Cisco VVB. These will be used in round robin configuration. You cannot set a maximum session limit on CiscoVVB for the configured servers.
 - **b.** IOS-VB has single server and a corresponding backup server configured. You can add multiple servers and these can be used in round-robin basis.



Note Cisco VVB does not use the concept of backup server.

- 2. For Cisco VVB the client timeout timers are not configurable. Cisco VVB uses optimized values for the client timeout for connect, disconnect etc.
- 3. For Microapps, when the url (rtsp://tts-en-us:4900/synthesizer or rtsp://asr-en-us:4900/recognizer), is processed by Cisco VVB, only hostname or IP-address in the url is used by Cisco VVB. Hostname is matched to locally configured server and corresponding port name is used to setup the connection. Depending on MRCP v1 or v2 configured on the system, session is setup to the server. So practically, you can use MRCP v2 also to for Microapps.

Call Throttling

Cisco VVB throttles the call to prevent overload.

For maximum calls supported, see VVB virtualization https://www.cisco.com/c/dam/en/us/td/docs/voice_ip_ comm/uc_system/virtualization/virtualization-cisco-virtualized-voice-browser.html.

Each OVAs defines the maximum number of calls supported. The maximum concurrent calls count is aggregated call count of various types of calls in the system (IVR, ringtone, whisper etc.).

In a deployed VVB, if the concurrent calls reaches maximum supported calls, any new call requests received beyond this number will be rejected. Each OVA defines maximum calls per second (cps) that a specific OVA supports. Any higher call rate beyond this number will trigger overload (see Solution Design Guide for Cisco Unified Contact Center Enterprise for details). When migrating Cisco-IOS-VB to Cisco VVB, this factor should be considered in sizing.

SIP RAI

- 1. If SIP RAI is configured in the Cisco-IOS-VB to send the RAI report to the remote server every interval, then the RAI needs to be configured for the remote server on Cisco VVB.
- If the Remote server is using SIP OPTIONS method to get out the RAI data, then no additional configuration is required in the Cisco VVB. Cisco VVB will report system, cpu, memory, DS0 and DSPs like Cisco-IOS-VB. But given that Cisco VVB does not have DS0, the number of available ports will be reported on this.

DSP data can be ignored.

```
X-cisco-rai : SYSTEM; almost-out-of-resource=false
X-cisco-rai : CPU; almost-out-of-resource=false;total=100%;available=77
X-cisco-rai : MEM; almost-out-of-resource=false;total=100%;available=71
X-cisco-rai : DSO; almost-out-of-resource=false;total=600;available=148
X-cisco-rai : DSP; almost-out-of-resource=false
```

Adding Cisco-VVB to Deployment

Cisco VVB can be added to the deployment using any one of these methods:

- **1.** Comprehensive deployment model
 - **a.** After Cisco VVB is configured (through Cisco VVB AppAdmin or CVP-OAMP bulk configuration), add the newly configured Cisco VVB to the CVP 'Dialed Number Pattern' or 'SIP Server Group'.
 - b. CVP will initiate SIP Heartbeat with the Cisco VVB and if SIP RAI is configured
- 2. Standalone deployment model

After the Cisco VVB is configured (through Cisco VVB AppAdmin or CVP-OAMP bulk configuration), add the dial-peer in the Ingress-gateway (Cube or PSTN-GW) to point to the Cisco VVB.



High Availability Consideration

• High availability Consideration, on page 17

High availability Consideration

In Cisco VVB there are two types of high availability models:

- Comprehensive
- Standalone

Comprehensive Model

Cisco Virtualized Voice Browser is a single node and there is no high availability inbuilt for active redundancy. In order to improve level of availability and to eliminate single point of failure, deploy additional Cisco VVB(s) to build passive redundancy by including the additional Cisco VVB(s) in the CVP SIP Server group.

When CVP detects failure of one of the Cisco VVB's in the SIP Server group, CVP will continue to route calls to remaining active Cisco VVBs, thereby, allowing new calls to be accepted.



Note All active calls on the failed Cisco VVB will disconnect and all the call data is lost.

When the failed Cisco VVB recovers and is detected by CVP heartbeat mechanism, CVP will start routing calls to the recovered Cisco VVB. So by deploying redundant Cisco VVBs, you can manage unscheduled and scheduled downtime of one of the Cisco VVBs.

Standalone Model

For standalone call model, user can configure primary and secondary VXML servers for an application. On arrival of a new call, if the primary server fails to respond to new session request, Cisco VVB will attempt to establish new session with the secondary server. If VXML server goes down when a session is already established, Cisco VVB will play a critical error message as part of error handling.

In order to improve level of availability and to eliminate single point of failure, deploy additional Cisco VVB(s) to build passive redundancy. One of the methods by which this can be done is by including the additional Cisco VVB(s) in the Ingress GWs dial-peer configuration. For this create 'voice class uri' for 'VVB' and then

add dial-peers for various VVBs which define destination session target for the uri 'VVB' (refer to IOS-GW documentation for more details). This way the Ingress GW will load balance between the various deployed VVBs and if any of the VVB serving standalone call model fails, then Ingress-GW will continue to route new calls to remaining active VVBs.



Note

Survivability is currently unavailable for Standalone Model deployment.



Sizing

• Sizing, on page 19

Sizing

All sizing considerations in CVP are supported in Cisco VVB. For more information, see *Solution Design Guide for Cisco Unified Contact Center Enterprise* available at https://www.cisco.com/c/en/us/support/ customer-collaboration/unified-contact-center-enterprise/products-implementation-design-guides-list.html.

Sizing