Generic commands

help

This command displays help for the specified command.

Command syntax

help [*command*]

Parameters

command specifies the command for which help is required.

Requirements

Command privilege level: 0

Allowed during upgrade: Unknown

quit

This command exits the CLI.

Command syntax

quit

Parameters

None

Requirements

Command privilege level: 0

Allowed during upgrade: Unknown

quit