



Using Site Templates

Because many [sites](#) have common sets of information, Cisco Unified SRST Manager provides site templates. Use these templates to apply configuration settings to new sites.

By default, Cisco Unified SRST Manager includes the following site templates:

- default
You cannot change the name of this site template or delete it, but you can edit its values.
- ESRST_and_Dialplan
- ESRST_only
- SRST_and_Dialplan
- SRST_only

You can also create custom site templates. [Table 9](#) describes the features configured for the default set of site templates. For details about each feature, see [Table 10](#).

Table 9 *Default Site Template Parameters*

Site Template	Provision Site as Classic SRST	Auto-Learn Call Forward Settings	Enable Dial Plan configuration	Enable Music on Hold configuration	Enable Hunt Group configuration	Enable Call Park configuration	Enable Call Pickup configuration	Enable Calling Privileges configuration	Enable After Hours configuration	Enable Single Number Reach configuration
default	—	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
ESRST_and_Dialplan	—	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
ESRST_only	—	Yes	—	Yes	Yes	Yes	Yes	Yes	Yes	Yes
SRST_and_Dialplan	Yes	Yes	Yes	Yes	—	—	—	—	—	—
SRST_only	Yes	Yes	—	Yes	—	—	—	—	—	—

Procedure

Step 1 Select **Configure > Site Templates**.

The system displays the Site Templates page, containing a list of the [site](#) templates configured in Cisco Unified SRST Manager.

Step 2 To create a new site template, update an existing site template, or view the details of an existing site template, see [Creating, Changing, and Viewing a Site Template](#).

Step 3 To remove a site template, do the following:

- a. Select the site template to delete.
 - b. Click **Remove**.
 - c. Click **OK** at the warning message.
-

Related Topics

- [Creating, Changing, and Viewing a Site Template](#)