



## show connectedapps

This chapter describes the output of the **show connectedapps** command.

- [show connectedapps, on page 1](#)

## show connectedapps

**Table 1: show connectedapps Command Output Descriptions**

| Field                 | Description  |
|-----------------------|--|
| CA session userid     | Username for the current CA session.   |
| CA session password   | Password for the current CA session.   |
| CA session name       | Name assigned to the current CA session.   |
| CA session IP address | IP address of the current CA session   |
| HA chassis mode       | High Availability chassis mode: <ul style="list-style-type: none"> <li>• <b>Inter</b> – between ASR 9000 chassis</li> <li>• <b>Intra</b> – within an ASR 9000 VSM</li> <li>• <b>Standalone</b> – No HA (standalone VSM)</li> </ul> |
| HA network mode       | High Availability network mode: <ul style="list-style-type: none"> <li>• <b>L2</b> – Layer 2</li> <li>• <b>L3</b> – Layer 3</li> <li>• <b>NA</b> – Not Applicable (standalone VSM)</li> </ul>                                      |
| CA session Activation | YES (activated) or NO (not activated)  |
| CA SRP Status         | Current Session Recovery Protocol status (ICSR): <ul style="list-style-type: none"> <li>• INIT – Initializing</li> <li>• UP</li> <li>• DOWN</li> </ul>   |

| Field        | Description   |
|--------------|---|
| CA SRP State | Current Session Recovery Protocol state (ICSR): <ul style="list-style-type: none"><li>• INIT – Initializing</li><li>• UP</li><li>• DOWN</li></ul> |