



# Security Configuration Mode Commands

---

The Security configuration mode is a sub-mode of the Global Configuration mode. This sub-mode enables you to define or modify the connection with the Talos Intelligence content-filtering server and configure URL categorization parameters.

---

## Command Modes

Exec > Global Configuration > Security Configuration

**configure > security**

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-security) #
```



---

## Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

---

- [category, on page 2](#)
- [end, on page 3](#)
- [exit, on page 4](#)
- [server, on page 5](#)

# category

Adds or removes a URL categorization server.



## Important

This is a license-controlled feature. For more information, contact your Cisco account or support representative.

## Product

All

## Privilege

Security Administrator, Administrator

## Command Modes

Exec > Global Configuration > Security Configuration

**configure > security**

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-security)#
```

## Syntax Description

[ **no** ] **category server** *server\_name*

**no**

Removes the specified URL categorization server.

***server\_name***

Specifies the name of the URL categorization server. *server\_name* must be an alpha and/or numeric string from 1 through 31 characters that is case sensitive.

## Usage Guidelines

Use this command to create or remove a URL categorization server from the Security configuration mode.

# end

Exits the current configuration mode and returns to the Exec mode.

---

**Product**

All

---

**Privilege**

Security Administrator, Administrator

---

**Syntax Description**

**end**

---

**Usage Guidelines**

Use this command to return to the Exec mode.

# exit

Exits the current mode and returns to the parent configuration mode.

---

**Product** All

---

**Privilege** Security Administrator, Administrator

---

**Syntax Description** `exit`

---

**Usage Guidelines** Use this command to return to the parent configuration mode.

# server

This command creates or specifies a Talos Security Intelligence (TSI) server entry and enters the TSI Server Configuration mode.



## Important

This is a license-controlled feature. For more information, contact your Cisco account or support representative.

## Product

All

## Privilege

Security Administrator, Administrator

## Command Modes

Exec > Global Configuration > Security Configuration

**configure > security**

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-security)#
```

## Syntax Description

**[ no ] server talos-intelligence** *server\_name*

**no**

Removes the specified Talos Security Intelligence server.

***server\_name***

Specifies the name of the Talos Security Intelligence server to create, configure, or remove. *server\_name* must be an alpha and/or numeric string from 1 through 31 characters that is case sensitive.

## Usage Guidelines

Use this command to create, configure, or remove a Talos Security Intelligence server from the Security configuration mode.

Entering this command results in the following prompt:

```
[local]host_name(config-server-tsi)#
```

The various parameters available for configuration of a TSI server entry are defined in the *TSI Server Configuration Mode Commands* chapter.

