



## show connectedapps

This chapter describes the output of the **show connectedapps** command.

- [show connectedapps, on page 1](#)

## show connectedapps

*Table 1: show connectedapps Command Output Descriptions*

Field	Description
CA session userid	Username for the current CA session.
CA session password	Password for the current CA session.
CA session name	Name assigned to the current CA session.
CA session IP address	IP address of the current CA session
HA chassis mode	High Availability chassis mode: <ul style="list-style-type: none"> <li>• <b>Inter</b> – between ASR 9000 chassis</li> <li>• <b>Intra</b> – within an ASR 9000 VSM</li> <li>• <b>Standalone</b> – No HA (standalone VSM)</li> </ul>
HA network mode	High Availability network mode: <ul style="list-style-type: none"> <li>• <b>L2</b> – Layer 2</li> <li>• <b>L3</b> – Layer 3</li> <li>• <b>NA</b> – Not Applicable (standalone VSM)</li> </ul>
CA session Activation	YES (activated) or NO (not activated)
CA SRP Status	Current Session Recovery Protocol status (ICSR): <ul style="list-style-type: none"> <li>• INIT – Initializing</li> <li>• UP</li> <li>• DOWN</li> </ul>

Field	Description
CA SRP State	Current Session Recovery Protocol state (ICSR): <ul style="list-style-type: none"><li>• INIT – Initializing</li><li>• UP</li><li>• DOWN</li></ul>