



# MSISDN Group Configuration Mode Commands

The MSISDN Group Configuration Mode provides commands to configure discrete list and range of Mobile Station International Subscriber Directory Number (MSISDN) numbers.

## Command Modes

Exec > Global Configuration > MSISDN Group Configuration

**configure > msisdn-group *group\_name***

Entering the above command sequence results in the following prompt:

[*context\_name*] host\_name(msisdn-group) #



**Important** Available commands or keywords/variables vary based on platform type, product version, and installed license(s).



**Important** For information on common commands available in this configuration mode, refer to the [Common Commands](#) chapter.

- [msisdn cc, on page 1](#)
- [range, on page 2](#)

## msisdn cc

This command configures the discrete list of MSISDN numbers.

### Product

MME

SGSN

### Privilege

Administrator

## Command Modes

Exec > Global Configuration > MSISDN Group Configuration

**configure**

Entering the above command sequence results in the following prompt:

**range**

```
[local]host_name(msisdn-group) #
```

**Syntax Description**

```
msisdn cc cc_value number value
no msisdn cc cc_value number value
```

**no**

Deletes the specified MSISDN numbers.

**cc cc\_value**

**cc** is the country code of the subscriber. **cc\_value** is a three digit number between 1 and 999.

**number value**

This keyword allows up to 500 MSISDNs to be configured per group. **value** is 1 to 14 digit MSISDN number.

**Usage Guidelines**

Use this command to specify the discrete list of MSISDN numbers (Combination of discrete and range line is 20 per group).

**Example**

The following command configures the CC as 334 and MSISDN as 12345678901234:

```
msisdn cc 334 number 12345678901234
```

# range

This command configures the range of MSISDN numbers.

**Product**

MME

SGSN

**Privilege**

Administrator

**Command Modes**

Exec > Global Configuration > MSISDN Group Configuration

**configure**

Entering the above command sequence results in the following prompt:

```
[local]host_name(msisdn-group) #
```

**Syntax Description**

```
range cc cc_value number first start_range last end_range
no range cc cc_value number first start_range last end_range
```

**no**

Deletes the specified MSISDN numbers.

**cc cc\_value**

cc is the country code of the subscriber. *cc\_value* is a three digit number between 1 and 999.

**number first start\_range last end\_range**

Specifies the MSISDN range. *start\_range* and *end\_range* are 1 to 14 digit MSISDN numbers.

**Usage Guidelines**

Use this command to configure the MSISDN range.

**Example**

The following command configures the CC as 334 and MSISDN range as 12345678901234 and 23456789012341:

```
range cc 334 number first 12345678901234 last 23456789012341
```

range