



MSISDN Group Configuration Mode Commands

The MSISDN Group Configuration Mode provides commands to configure discrete list and range of Mobile Station International Subscriber Directory Number (MSISDN) numbers.

Command Modes

Exec > Global Configuration > MSISDN Group Configuration

configure > **msisdn-group** *group_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(msisdn-group) #
```



Important

Available commands or keywords/variables vary based on platform type, product version, and installed license(s).



Important

For information on common commands available in this configuration mode, refer to the [Common Commands](#) chapter.

- [msisdn cc](#), on page 1
- [range](#), on page 2

msisdn cc

This command configures the discrete list of MSISDN numbers.

Product

MME

SGSN

Privilege

Administrator

Command Modes

Exec > Global Configuration > MSISDN Group Configuration

configure

Entering the above command sequence results in the following prompt:

```
[local]host_name(msisdn-group)#
```

Syntax Description

msisdn cc *cc_value* **number** *value*
no msisdn cc *cc_value* **number** *value*

no

Deletes the specified MSISDN numbers.

cc *cc_value*

cc is the country code of the subscriber. *cc_value* is a three digit number between 1 and 999.

number *value*

This keyword allows up to 500 MSISDNs to be configured per group. *value* is 1 to 14 digit MSISDN number.

Usage Guidelines

Use this command to specify the discrete list of MSISDN numbers (Combination of discrete and range line is 20 per group).

Example

The following command configures the CC as 334 and MSISDN as 12345678901234:

```
msisdn cc 334 number 12345678901234
```

range

This command configures the range of MSISDN numbers.

Product

MME
SGSN

Privilege

Administrator

Command Modes

Exec > Global Configuration > MSISDN Group Configuration

configure

Entering the above command sequence results in the following prompt:

```
[local]host_name(msisdn-group)#
```

Syntax Description

range cc *cc_value* **number first** *start_range* **last** *end_range*
no range cc *cc_value* **number first** *start_range* **last** *end_range*

no

Deletes the specified MSISDN numbers.

cc *cc_value*

cc is the country code of the subscriber. *cc_value* is a three digit number between 1 and 999.

number first *start_range* last *end_range*

Specifies the MSISDN range. *start_range* and *end_range* are 1 to 14 digit MSISDN numbers.

Usage Guidelines

Use this command to configure the MSISDN range.

Example

The following command configures the CC as 334 and MSISDN range as 12345678901234 and 23456789012341:

```
range cc 334 number first 12345678901234 last 23456789012341
```

range