



Cisco Spaces

- [Cisco Spaces, on page 1](#)
- [Configuring Cisco Spaces, on page 1](#)
- [Verifying Cisco Spaces Configuration, on page 2](#)

Cisco Spaces

Cisco Spaces is the next generation indoor location services platform. The Network Mobility Services Protocol (NMSP) cloud-service of the wireless controller communicates with Cisco Spaces using HTTPS as a transport protocol.

Configuring Cisco Spaces

Follow the procedure given below to configure Cisco Spaces:

Before you begin

- **Configure DNS**—To resolve fully qualified domain names used by NMSP cloud-services, configure a DNS using the **ip name-server *server_address*** configuration command as shown in Step 2.
- **Import 3rd party root CAs**—The controller verifies the peer and the host based on the certificate that is sent by the CMX when a connection is established. However, root CAs are not preinstalled on the controller. You have to import a set of root CAs trusted by Cisco to the trustpool of the crypto PKI by using the **crypto pki trustpool import url <url>** configuration command as shown in Step 3.
- A successful registration to Cisco Spaces is required to enable **server url** and **server token** parameters configuration which is needed to complete this setup.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# <code>configure terminal</code>	Enters global configuration mode.

	Command or Action	Purpose
Step 2	ip name-server <i>namesvr-ip-addr</i> Example: Device(config)#ip name-server 10.10.10.205	Configures the DNS on the controller to resolve the FQDN names used by the NMSP cloud-services.
Step 3	crypto pki trustpool import url <i>url</i> Example: Device(config)#crypto pki trustpool import url http://www.cisco.com/security/pki/trs/ios.p7b	Imports the 3rd party root CA. The controller verifies the peer using the imported certificate.
Step 4	[no] nmosp cloud-services server url <i>url</i> Example: Device(config)# nmosp cloud-services server url https://cisco.com	Configures the URL used for cloud services. Use the no form of the command to delete the server url from the configuration.
Step 5	[no] nmosp cloud-services server token <i>token</i> Example: Device(config)# nmosp cloud-services server token test	Configures the authentication token for the NMSP cloud service. Use the no form of the command to delete the server token from the configuration.
Step 6	[no] nmosp cloud-services http-proxy <i>proxy-server port</i> Example: Device(config)# nmosp cloud-services http-proxy 10.0.0.1 10	(Optional) Configures HTTP proxy details for the NMSP cloud service. Use the no form of the command to disable the use of a HTTP proxy.
Step 7	[no] nmosp cloud-services enable Example: Device(config)# nmosp cloud-services enable	Enables NMSP cloud services. Use the no form of the command to disable the feature.

Verifying Cisco Spaces Configuration

Use the following commands to verify the Cisco Spaces configuration.

To view the status of active NMSP connections, use the following command:

Device# **show nmosp status**

MSE IP Address	Tx Echo Resp	Rx Echo Req	Tx Data	Rx Data	Transport
9.9.71.78	0	0	1	1	TLS
64.103.36.133	0	0	1230	2391	HTTPs

To view the NMSP cloud service status, use the following command:

Device# **show nmosp cloud-services summary**

CMX Cloud-Services Status

```
-----  
Server:                https://yenth8.cmxcisco.com  
IP Address:            64.103.36.133  
Cmx Service:           Enabled  
Connectivity:          https: UP  
Service Status:        Active  
Last Request Status:   HTTP/1.1 200 OK  
Heartbeat Status:      OK
```

To view the NMSP cloud service statistics, use the following command:

```
Device# show nmsp cloud-services statistics
```

```
CMX Cloud-Services Statistics  
-----
```

```
Tx DataFrames:          3213  
Rx DataFrames:          1606  
Tx HeartBeat Req:       31785  
Heartbeat Timeout:      0  
Rx Subscr Req:          2868  
Tx DataBytes:           10069  
Rx DataBytes:           37752  
Tx HeartBeat Fail:      2  
Tx Data Fail:           0  
Tx Conn Fail:           0
```

To view the mobility services summary, use the following command:

```
Device# show nmsp subscription summary
```

```
Mobility Services Subscribed:
```

```
Index Server IP Services  
-----
```

```
1 209.165.200.225 RSSI, Info, Statistics, AP Monitor, AP Info  
2 209.165.200.225 RSSI, Statistics, AP Info
```

