



Command Reference

This appendix contains some of the MSE commands that you use while deploying the virtual appliance.

MSE Commands

Use these commands to monitor tasks while deploying the MSE virtual appliance.

Table B-1 *MSE Commands*

Command	Explanation
service msed status	To determine the status of the MSE services.
service msed start	To start the MSE service manually.
service msed stop	To stop the MSE services.
rundiag	To perform diagnostics. You can use this command to view MSE UDI information that is required in order to obtain the license file for context-aware engine for clients.
ckkconfig msed on	To configure the MSE to automatically launch after boot up.
show udi	To get the Unique Device Identifier (UDI) from the virtual appliance.
getserverinfo	To verify the configuration.
reboot	To reboot the MSE.

