



Mobile Policy Infrastructure Commands

- [subversion](#), on page 1

subversion

Configures Subversion parameters.

Command Modes

Exec > Global Configuration

Syntax Description

```
subversion { polling-interval-secs monitor_svn_thread_polling_interval |  
max-data-chunk-size max_data_chunk_size }
```

max-data-chunk-size *max_data_chunk_size*

Specify the maximum chunk size, in bytes, to store in configmap.

Must be an integer in the range of 300000-550000.

Default Value: 550000.

polling-interval-secs *monitor_svn_thread_polling_interval*

Specify the monitor-svn thread polling interval in seconds.

Must be an integer.

Default Value: 120.

Usage Guidelines

Use this command to configure the Subversion parameters.

