



# PCF System KPI Diagnostics

- [PCF System KPI Diagnostics, on page 1](#)

## PCF System KPI Diagnostics

Configures PCF system KPI diagnostics parameters.

**Syntax Description** `pcf-system KpiDiagnostics start_time end_time interface_name operation_name status_Code`

### ***start\_time***

Specify the start time.

After the start\_time argument specify the value.

Must be a string.

### ***end\_time***

Specify the end time.

After the end\_time argument specify the value.

Must be a string.

### ***interface\_name***

Specify the interface name.

After the interface\_name argument specify the value.

Must be a string.

### ***operation\_name***

Specify the operation name.

After the operation\_name argument specify the value.

Must be a string.

***status\_Code***

Specify the status code.

After the `status_code` argument specify the value.

Must be a string.

---

**Usage Guidelines**

Use this command to configure KPI diagnostics parameters. Enters the PCF system KPI diagnostics Configuration mode.