

Message Prioritization and Overload Handling

- Feature Summary and Revision History, on page 1
- Feature Description, on page 1
- How it Works, on page 2
- Feature Configuration, on page 2
- OAM Support, on page 12

Feature Summary and Revision History

Summary Data

Table 1: Summary Data

Applicable Product(s) or Functional Area	PCF
Applicable Platform(s)	SMI
Feature Default Setting	Disabled – Configuration required to enable
Related Documentation	Not Applicable

Revision History

Table 2: Revision History

Revision Details	Release
First introduced.	2022.01.0

Feature Description

PCF supports the following message prioritizations:

• Message priority handling framework—Provides configuration to handle the incoming message rules with priority.

- Diameter configuration
- PCF configuration
- Inbound WPS Rx Message prioritization—During engine processing the WPS messages are prioritized over non-WPS messages.
- Inbound WPS SBI Message prioritization—During engine processing the 3gpp-Sbi-Message-Priority header messages are prioritized.

How it Works

This section describes how this feature works.

- Message Prioritization Handling Framework
 - Diameter Configuration—Use Message Handling Rules parameters (Diameter Client, Protocol, Command Code, Request Type, Priority, Per Instance TPS, and Discard Behavior) to identify and prioritize the diameter messages.
 - PCF Configuration—Use Message Handling Rules parameters (Request Type, Priority, Per Instance TPS, and Discard Behavior) to identify and prioritize the SBI messages.
- Inbound WPS Rx Message Prioritization—Use the Rx Message Prioritization parameters to mark the WPS specific MPS-Identifier and Reservation Priority. Rx message should be prioritized based on the MPS-Identifier and Reservation-Priority AVPs received in the request message.
- Inbound WPS SBI Message Prioritization—Based on the SBI Message Priority value in the incoming message, a user specified priority (Inbound SBI-Message-Priority prioritization table in PCF configuration) is assigned. SBI messages with higher priority are considered for processing earlier than the messages with lower priority.



Note

Currently, the priority queue and rate limiting for REST and Diameter messages are independent of each other.

Feature Configuration

To configure this feature, use the following configurations:

- Configuring Inbound Message Overload Handling
- Configuring SBI-Message-Priority Prioritization

Configuring Inbound Message Overload Handling

This section describes how to configure the Inbound Message Overload Handling for the diameter and PCF configurations.

Diameter Configuration

- 1. Log in into Policy Builder.
- 2. Select Reference Data tab.
- **3.** From the left pane, select **Systems**.
- 4. Select and expand your system name.
- 5. Select Diameter Configuration.
- 6. In the right pane, to add the parameters of the inbound message overload handling, check the Inbound Message Overload Handling check box.
- 7. In the Inbound Message Overload Handling area, define the following parameter details.

Table 3: Inbound Message Overload Handling Parameters

Parameter	Description
Default Priority	Default priority to be assigned to an incoming message if no specific priority is defined in the Message Handling Rules table.
	Default value is 0.
Message Sla Ms	Service Level Agreement (SLA) in milliseconds, defines the number of milliseconds that are associated with an incoming event or message. In case the configured duration times out, the Discard Behavior configured in the Message Handling Rules is applied else the Default Discard Behavior is used.
	Maximum time (in millisec) that a message has in an inbound message handling queue waiting for a worker thread. Configuring this value avoids processing a message to time out by a remote peer.
	Default value is 1500 ms.
Inbound Message Queue Size	Allows the maximum number of messages in the Inbound Message Queue. When the number of messages exceeds this value, messages are discarded as defined in the Message Handling Rules and the Default Discard Behavior.
	Default value is 1000.
Default Instance Rate Limit	This parameter is applied to messages that do not have an applicable overload handling rule configured in the Message Handling Rules table.
	Default value is 0.

Parameter	Description
Default Discard Behaviour	Default behavior to be applied to an incoming message if no specific discard behavior for that message is defined in the Message Handling Rules table.
	• MESSAGE_DROP: Discards the request.
	• DIAMETER_TOO_BUSY: Sends a response message havingResult-Code AVP value set to DIAMETER_TOO_BUSY (3004). Default value is MESSAGE_DROP
Rx Message Prioritization	Defines Rx eMPS message handling priority based on the Rx message MPS-Identifier and Reservation-Priority AVPs. For more information see Table 4: Rx Message Prioritization Parameters, on page 4.
Message Handling Rules	Defines specific inbound message overload handling rules based on different criteria. For more information, see Table 5: Message Handling Rules Parameters, on page 5.

Figure 1: Inbound Message Overload Handling Parameters

	Inbound Message	Overload Handling					
System-1	Defends Defends at						
a 🍿 cluster-1	Default Priority*						
Plugin Configurations	0						
Plugin Configurations	Message Sla Ms *						
Async Threading Configuration	1500						
 Balance Configuration 							
Custom Reference Data Configuration	Inbound Message Qu	eue Size *					
Diameter Configuration	1000						
Ldap Configuration	Default Instance Rate	Limit *					
Threading Configuration	0						
USuM Configuration		and the second se					
Voucher Configuration	Gx Emergency Mess	age Priority *					
	1						
	Default Discard Beha	vior *					
	MESSAGE DROP						
	*MPS Identifier		"Reservatio	n Priority		*Priority	
	NGN GETS		12	примиу		1300	
	NGN GETS		11			1200	
	NGN GETS		11			1200	
	NGN GETS		11 10			1200 1100	
	NGN GETS NGN GETS		11			1200	
	NGN GETS NGN GETS	6	11 10			1200	
	Add Remove a	i Dentanal	11 10	Descart Tops	8Delasik-	1200 1100	Princered Babwalar
	Add Remove A	Protocol av se teop	11 10 Command Code	Request Type	*Priority	*Per Instance Tps	*Discard Behavior
	Add Remove Message Handling R Diameter Client default	Protocol RX_SG_TGPP	11 10 Command Code 265 275	Request Type 0	*Priority 900	*Per Instance Tps	*Discard Behavior MESSAGE_DROP
	Add Remove Message Handling R	Protocol RX_SG_TGPP RX_SG_TGPP	11 10 Command Code 265 275	Request Type 0 0	*Priority 900 850	1200 1100 *Per Instance Tps 0	*Discard Behavior MESSAGE_DROP MESSAGE_DROP

Table 4: Rx Message Prioritization Parameters

Parameter	Description
MPS Identifier	MPS-Identifier indicates that an AF session relates to an MPS session. It contains the national variant forMPS service name. For example, NGN GETS.

Parameter	Description
Reservation Priority	The AF specifies the Reservation-Priority AVP at request level in the AA-Request in order to assign a priority to the AF session as well as specify the Reservation-Priority AVP at the media-component-description AVP level to assign a priority to the IP flow.
	The Reservation-Priority AVP available at the request level only is used under Rx Message Prioritization table.
	If Reservation priority is not found at the message level in Rx message, then best value of Reservation Priority is calculated from the MCD and used for lookup.
	Range: 1 to 15, where 15 is considered as the highest priority and 1 is considered as the least priority.
Priority	A user defined priority based on MPS-Identifier and Reservation-Priority combination.
	Higher Priority messages are processed before lower priority messages.

Table 5: Message Handling Rules Parameters

Parameter	Description
Diameter Client	This is used to configure different priorities for different clients based on realms.
Protocol	Specific application id value to be used for scoring. This value is used to match Auth-Application-Id AVP value.
Command Code	Specific command code value to be used for scoring. This value is used to match the Command-Code field. These command codes map to different types of Diameter messages.

Parameter	Description
Request Type	Specific request type value to be used for scoring. This value should match the value of the CC-Request-Type AVP for Gx CCR messages.
	• 0: Request Type not used for scoring
	• 1: INITIAL_REQUEST (1)
	• 2: UPDATE_REQUEST (2)
	• 3: TERMINATION_REQUEST (3)
	Default value is 0.
	Request type should match the value of the Rx-Request-Type AVP for Rx messages.
	• 0: INITIAL_REQUEST (0)
	• 1: UPDATE_REQUEST (1)
	Request type should match the value of SL-Request-Type AVP for Sy SLR messages. The possible values are:
	• INITIAL_REQUEST (0)
	• INTERMEDIATE_REQUEST (1)
	It has to be configured to zero if the incoming message does not have a request type AVP. For example, Rx STR does not have a request type AVP or Rx-Request-Type AVP is unavailable in Rx message as it is not a mandatory AVP per 3GPP TS 29.214.
Priority	Priority value assigned to the message. Higher numerical value has the higher priority.
	Default value is 0.
	For example, 10, 20, 100, 200, 300, 500 and so on.
Per Instance Tps	Transactions per second limit per process. This value is the TPS that these messages are limited to.
	The actual system's transaction per second limit can be calculated using the following formula:
	Per Instance Tps x Number of instances per VM x Number of VMs.
	Default value is 0.
	For example, 1000, 2000, 5000 and so on.

Parameter	Description
Discard Behavior	Behavior to be applied to an incoming message.
	• MESSAGE_DROP: Discards the request.
	• DIAMETER_TOO_BUSY: Sends a response message having Result-Code AVP value configured to DIAMETER_TOO_BUSY (3004).
	Default value is MESSAGE_DROP.

PCF Configuration

- 1. Log in into Policy Builder.
- 2. Select Reference Data tab.
- 3. From the left pane, select Systems.
- 4. Select and expand your system name.
- 5. Select PCF Configuration.
- 6. In the right pane, to add the parameters of the inbound message overload handling, check the **Inbound** Message Overload Handling check box.
- 7. In the Inbound Message Overload Handling area, define the following parameter details.

Table 6: Inbound Message Overload Handling Parameters

Parameter	Description
Default Priority	Default priority to be assigned to an incoming message if no specific priority is defined in the Message Handling Rules table.
	Default value is 0.
Message Sla Ms	Service Level Agreement (SLA) in milliseconds, defines the number of milliseconds that are associated with an incoming event or message. In case the configured duration times out, the Default Discard Behavior is applied.
	Maximum time (in millisec) that a message has in an inbound message handling queue waiting for a worker thread. Configuring this value avoids processing a message to time out by a remote peer.
	Default value is 1500 ms.

Parameter	Description
Inbound Message Queue Size	Allows the maximum number of messages in the Inbound Message Queue. When the number of messages exceeds this value, messages are discarded as defined in the Message Handling Rules and the Default Discard Behavior. Default value is 1000.
Default Instance Rate Limit	This parameter is applied to messages that do not have an applicable overload handling rule configured in the Message Handling Rules table. Default value is 0.
N7 Emergency Message Priority	Default priority assigned to messages related to an emergency session Emergency message priority is applied when the DNN matches an emergency DNN configured under PCF Configuration. Default value is 1.
Default Discard Behaviour	Default behavior to be applied to an incoming message if no specific priority is defined in the Message Handling Rules table. • MESSAGE_DROP: Discards the request. • SERVICE_UNAVAILABLE: Service is not available. Default value is MESSAGE_DROP.
Message Handling Rules	Defines specific inbound message overload handling rules based on different criteria. For more information, see Table 8: Message Handling Rules Parameters, on page 10

Figure 2: N5 Message Prioritization Rule

a 🗔 system-1			Remove	B
a 👝 Plugin Configurations				
Threading Configuration				
Async Threading Configuration	Inbound Message Ove	rload Handling		1
Custom Reference Data Configu	*Default Priority			
Balance Configuration	0			
Ldap Configuration				
USuM Configuration	*Message Sla Ms			
Diameter Configuration	1500			
Voucher Configuration	*Inbound Message Q	ueue Size		
PCF Configuration	1200			
a 🕥 cluster-1	the factor is the second second	to the literat		
Plugin Configurations	*Default Instance Ra	te Limit		
Account Balance Templates	0			
Custom Reference Data Tables	*N7 Emergency Mess	age Priority		
Diameter Agents	1			
Diameter Clients	*Default Discard Beb	avior		
Diameter Defaults	MESSAGE DROP			
Fault List	HE33NGE_DROP			
Ldap Server Sets	Apply Discard Beha	vior For Emergency Messages		
Policy Enforcement Points	NE Macroso Brighting	tion Bula		
Rule Retry Profiles	*MDC Identifier	*Decemption Priority	*Driority	
SBA Profiles	mos 1	PRIO 14	1200	
Subscriber Data Sources	mps_2	PRIO 13	1100	
Tariff Times				
				5
				9
				5
		0		4
	Add Kemove V	V		

The following tables provides the inputs for N5 Message Prioritization Parameters.

Table 7: N5 Message	Prioritization	Parameters
---------------------	----------------	------------

Parameter	Description
mpsId	mpsId indicates that an AF session relates to an MPS session. It contains the national variant for MPS service name. For example, NGN GETS.
resPrio	The AF specifies the Reservation-Priority (resPrio) attribute at request level in the N5 messages in order to assign a priority to the AF session as well as specify the Reservation-Priority attribute at the medComponents attribute level to assign a priority to the IP flow.
	The Reservation-Priority attribute available at the request level only is used under N5 Message Prioritization table.
	If Reservation-Priority is not found at the message level in N5 message, then best value of Reservation-Priority is calculated from the MCD and used for lookup.
	Range: 1 to 15, where 15 is considered as the highest priority and 1 is considered as the least priority.

Parameter	Description
Priority	A user defined priority based on mpsId and Reservation-Priority combination.
	Higher Priority messages are processed before lower priority messages.

Figure 3: Inbound Message Overload Handling Parameters

Filter	A PCF Configurat	ion 1 warning d	etected		
🟠 Summary					
🛛 🌄 system-1	N7 Stale Session Timer	Minutes Prefe	erred Bit Rate		
< 🕥 cluster-1	35000	nor	ne	*	
Plugin Configurations		Eme	rgency DNN List		
Async Threading Configuration		so	s.5g		
♦ Balance Configuration	N15 Stale Session Time	Minutes		Add	
Custom Reference Data Configuration	35000				
Diameter Configuration				Kemove	
Ldap Configuration		_			
PCF Configuration	Inbound Message (verload Handling	3		5
Threading Configuration	Defects Defects at				
USuM Configuration	Default Priority *				
 Voucher Configuration 	1000				
Oluster-Region-1	Message Sla Ms *				
Plugin Configurations	1500				
a 🗁 Plugin Configurations	Inbound Message Ou	eue Size *			
Async Threading Configuration	1200	de size			
Balance Configuration	1200				
Custom Reference Data Configuration	Default Instance Rate	Limit *			
🗉 💠 Diameter Configuration	0				
♦ Gx Stack	N7 Emergency Messa	ge Priority *			
Rx Stack	1310				
♦ Sy Stack	1010				
A & Ldap Configuration	Default Discard Beha	vior *			
Ldap Server Configuration	MESSAGE_DROP	*			
PCF Configuration	Apply Discard B	havior For Emerge	ency Messages		
Threading Configuration		indition for Enlarge	iney recording to		
Unified API Configuration	Message Handling Ru	lles			4
 USuM Configuration 	*Request Type	*Priority	*Per Instance Tps	*Discard Behavior	
 Voucher Configuration 	N/_DELETE	1000	0	SERVER_TOO_BUSY	1
	N7_UPDATE	800	0	SERVER_TOO_BUSY	ł.
	N7_CREATE	/50	5	SERVER_TOO_BUSY	1
	MT7 AI/OTTEV	700		CENTED TOO DUCV	

Table 8: Message Handling Rules Parameters

Parameter	Description
Request Type	Specifies request type value to be used for scoring.
	For example N7_CREATE, N28_NOTIFY, and so on.
Priority	Priority value assigned to the message. Higher numerical value has the higher priority. For example, 700, 800 and so on.
Per Instance Tps	Transactions per second limit per process. This value is the TPS that these messages are limited to. Default value is 0.

L

Parameter	Description
Discard Behavior	Behavior to be applied to an incoming message.
	 SERVER_TOO_BUSY: Sends a responsive message having result code attribute value with HTTP code 503. MESSAGE_DROP: Discards the request.

Configuring SBI-Message-Priority Prioritization

This section describes how to configure the SBI-Message-Priority Prioritization.

- 1. Log in into Policy Builder.
- 2. Select Reference Data tab.
- 3. From the left pane, select Systems.
- 4. Select and expand your system name.
- 5. Select PCF Configuration.
- 6. In the right pane, to add the parameters of the SBI-Message-Priority prioritization, check the **SBI-Message-Priority Prioritization** check box.
- 7. In the SBI-Message-Priority Prioritization area, define the following parameter details.

Table 9: SBI-Message-Priority Prioritization Parameters

Parameter	Description
Default Inbound Priority	The default value is used if priority value does not match a value in Inbound SBI-Message-Priority Prioritization table
Inbound SBI-Message-Priority Prioritization	A user defined priority based on SBI Message Priority and Priority combination. For more information, see Table 10: Inbound SBI-Message-Priority Prioritization Parameters, on page 12

Figure 4: SBI-N	lessage-Priority	Prioritization
-----------------	------------------	----------------

Voucher Configuration	Inbound Message Overload Handling	
duster-1	Policy Action Configuration	
Account Balance Templates		
Custom Reference Data Tables	SBI-Message-Priority Prioritization	1
Diameter Agents	*Default Inbound Priority	
Diameter Clients	0	
Diameter Defaults	Inbound SBI-Message-Priority Prioritization	
Fault List	*S B I Message Priority *Priority	
Ldap Server Sets		
Policy Enforcement Points		
Rule Retry Profiles		
SBA Profiles		
Subscriber Data Sources		4625
Tariff Times		\$
	Add Remove V	

Table 10: Inbound SBI-Message-Priority Prioritization Parameters

Parameter	Description
SBI Message Priority	The range of values allowed for SBI-Message-Priority are from $0-31$, where 0 is considered as the highest priority and 31 is considered as the least priority value.
Priority	It provides the queue priority value. A higher numerical priority value equates to a higher priority.

OAM Support

This section describes operations, administration, and maintenance information for this feature.

Bulk Statistics Support

The following statistics are supported for the message prioritization and overload handling feature.



Note

The following values apply to all the statistics:

- Unit Int64
- Type Counter
- Nodes Service

The following metrics track the counter information:

• input_queue_result - Captures the status of the message in the inbound queue whether it is dropped or rate limited.

The following labels are defined for this metric:

- appid
- message-type
- result
- wps_rx_priority Captures the Rx message queue priority.

The following labels are defined for this metric:

- command_code
- priority
- sbi_priority_total Captures the SBI message queue priority.

The following labels are defined for this metric:

- interface
- message_type
- priority