



cnSGW-C Metrics Reference

- [Overview, on page 1](#)
- [sgw Metrics Reference, on page 1](#)
- [gtpc-ep Metrics Reference, on page 16](#)
- [UDP-Proxy Metrics Reference, on page 25](#)

Overview

This section provides details of bulk statistics. Bulk statistics are divided in two types:

- Gauge - Snapshot value that shows the statistic at the reporting moment (for example, the number of current UE, current PDN connections). These statistics can increment or decrement continuously.
- Counter - Historic value accumulated over a period (for example, the total number of CSR requests received). These values get incremented except in the following two cases:
 - Rollover - where a counter exceeds its maximum value and rolls over to zero.
 - Reset - where a counter is manually reset to zero.

sgw Metrics Reference

CDL active sessions Category

db_records_total

Description: CDL active sessions. each label is prefix with SGW.

Sample Query: `avg(db_records_total{service_name=\"datastore-ep\"})by(session_type)`

Labels:

- Label: `emergency_call`

Label Description: Number of emergency calls in cnSGW

Example: `SGW:emergency_call:true`

- Label: `rat_type`
Label Description: Rat type of sessions. For cnSGW there is only one `rat_type` EUTRAN
Example: `SGW:rat_type:EUTRAN`
- Label: `state`
Label Description: Number of active or idle subscriber state.
Example: `SGW:state:active` , `SGW:state:idle`
- Label: `pdn_active`
Label Description: Number of active PDNs for that subscriber.
Example: `SGW:pdn_active:1` , `SGW:pdn_active:2`
- Label: `bearer_active`
Label Description: Number of active Bearers for that subscriber.
Example: `SGW:bearer_active:1` , `SGW:bearer_active:2`
- Label: `apn`
Label Description: Number of subscribers per apn.
Example: `SGW:apn:internet2` , `SGW:apn:ims2`
- Label: `colocated`
Label Description: Number of colocated or non-colocated subscriber.
Example: `SGW:colocated:true` , `SGW:colocated:false`
- Label: `total`
Label Description: Total number of sessions in CDL
Example: `total`

CDR container operations Category

sgw_charging_cdr_container

Description: CDR container operations total

Sample Query:

```
sgw_charging_cdr_container{gr_instance_id="1",action="close_final",change_condition="recordClosure",pdn_type="ipv4v6",pdn_plmn_type="visitor"}
```

Labels:

- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2
- Label: `action`
Label Description: Type of CDR operation

Example: close_final, close_interim, open

- Label: change_condition

Label Description: Reason for container close operation

Example: recordClosure,qoSChange,userLocationChange,apnAmbrChange

- Label: event

Label Description: Event that triggered CDR action

Example: StartAccounting,SGWChange,NormalRelease etc.

- Label: pdn_type

Label Description: The pdn_type indicates the address type of PDN

Example: ipv4, ipv6, ipv4v6, unknown

- Label: pdn_plmn_type

Label Description: The pdn_plmn_type indicates the plmn type

Example: homer,visitor,roamer,unknown

CDR operations Category

sgw_charging_cdr

Description: CDR operations total

Sample Query:

```
sgw_charging_cdr{gr_instance_id="1",action="close_final",cause="servingNodeChange",pdn_type="ipv4v6",pdn_plmn_type="visitor"}
```

Labels:

- Label: gr_instance_id

Label Description: GR instance ID

Example: 1, 2

- Label: action

Label Description: Type of CDR operation

Example: close_final, close_interim, open

- Label: cause

Label Description: Reason for CDR close operation

Example: maxChangeCond,servingNodeChange,volumeLimit,LTEservingNodeChange,abnormalRelease etc.

- Label: event

Label Description: Event that triggered CDR action

Example: StartAccounting,SGWChange,NormalRelease etc.

- Label: `pdn_type`

Label Description: The `pdn_type` indicates the address type of PDN

Example: `ipv4, ipv6, ipv4v6, unknown`

- Label: `pdn_plmn_type`

Label Description: The `pdn_plmn_type` indicates the plmn type

Example: `homer,visitor,roamer,unknown`

SGW usage report stats Category

sgw_sx_usage_report_stats

Description: Total Sx Session usage reports processed

Sample Query: `sgw_sx_usage_report_stats{gr_instance_id="1",status="success"}`

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: `1, 2`

- Label: `status`

Label Description: Processing status

Example: `success, ur_dropped_invalid_urr_seqNo, ur_dropped_bearer_not_found, ur_dropped_urrInfo_not_found, ur_dropped_acct_ctxt_not_found, ur_dropped_bearer_not_connected`

SGW Bearer Level counters Category

sgw_bearer_counters

Description: Bearer Level counters

Sample Query: `sgw_bearer_counters{gr_instance_id="1",status="active",qci="5"}`

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: `1, 2`

- Label: `status`

Label Description: Bearer Status

Example: `active`

- Label: `qci`

Label Description: Bearer QCI

Example: 1, 2, 3, 4, 5, 6, 7, 8, 9, 65, 66, 69, 70, 80, 82, 83, non-std-qci

SGW Bearer Level statistics Category

sgw_bearer_stats

Description: Bearer and Qci level statistics

Sample Query:

```
sgw_bearer_stats{gr_instance_id="1",status="attempted",qci="5",numBearer="2"}
```

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `status`

Label Description: Bearer Status

Example: attempted, setup, release, modified

- Label: `qci`

Label Description: Bearer QCI

Example: 1, 2, 3, 4, 5, 6, 7, 8, 9, 65, 66, 69, 70, 80, 82, 83, non-std-qci

SGW CDL update stats Category

sgw_cdl_update_stats

Description: SGW CDL update Counter

Sample Query:

```
sgw_cdl_update_stats{gr_instance_id="1",txn_type="S11ModifyBearerReqInitialAttach",status="success",cdl_update_type="full_cdl_update"}
```

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `txn_type`

Label Description: Transaction type

Example: ClearSubscriberSgwReq, N4SessionReportReq, NIntSgwSelfTxnBearerDisconnect, NIntSgwSelfTxnPagingStatusReq, NIntSgwSelfTxnPdnDisconnect, NIntSgwSelfTxnSxaSessRptReq, NSgwInternalTimerNotification, NSgwTimerNotificationReq, ReleaseAccessBearerReq, S11CreateSessReq, S11DeleteSessReq, S11ModifyBearerReq, S11ModifyBearerReqInitialAttach, S11ModifyBearerReqInterSystemHo, S11ModifyBearerReqIntraMMEX2S1HoNoSgwChange, S11ModifyBearerReqList, S11ModifyBearerReqListInterSystemHo,

S11ModifyBearerReqListIntraMMEX2S1HoNoSgwChange, S11ModifyBearerReqListOnlyForUliChange, S11ModifyBearerReqListS1HOSgwRelocation, S11ModifyBearerReqListServiceRequest, S11ModifyBearerReqListUnknownMBR, S11ModifyBearerReqOnlyForUliChange, S11ModifyBearerReqS1HOSgwRelocation, S11ModifyBearerReqServiceRequest, S11ModifyBearerReqUnknownMBR, S5CreateBearerReq, S5DeleteBearerReq, S5S8BearerResourceCmd, S5UpdateBearerReq, S11SuspendNotf, S11ResumeNotf

- Label: `status`

Label Description: Indicate whether transaction is success, aborted or timeout

Example: success, collision_abort, timeout

- Label: `cdl_update_type`

Label Description: Indicate CDL update type

Example: partial_cdl_update, full_cdl_update, no_cdl_update

SGW Collision Stats Category

`sgw_collision_stats`

Description: SGW Collision counters

Sample Query: `sgw_collision_stats{gr_instance_id="1",action_type="abort",new_proc="PDN Disconnect - UE initiated",old_proc="Create Bearer"}`

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `action_type`

Label Description: The pre-defined action taken to handle the collision. The action can be

Example: abort_new, abort_old, discard_new, discard_old

- Label: `new_proc`

Label Description: The new procedure and message type"

Example: Unknown, PDN Setup, PDN Modify, Create Bearer, Update Bearer, Delete Bearer, PDN Disconnect - UE initiated, PDN Disconnect - Admin initiated, PDN Disconnect - PGW initiated, PDN Disconnect - Self initiated, Modify Bearer Command, Delete Bearer Command, Release Access Bearer, Downlink Data Notification, Clear Subscriber - S5e Recovery Initiated, Clear Subscriber - Sx Recovery Initiated, Clear Subscriber - S11 Recovery Initiated, Clear Subscriber - S5e Path Failure Initiated, Clear Subscriber - Sx Path Failure Initiated, Clear Subscriber - S11 Path Failure Initiated, Clear Subscriber - S11 Path Failure Local Purge Initiated, Clear Subscriber - S11 Recovery Local Purge Initiated, Clear Subscriber - S5e Path Failure Local Purge Initiated, Clear Subscriber - S5e Recovery Local Purge Initiated, Clear Subscriber - Sx Association Release Initiated, Change Notification, PDN Disconnect - Upf Graceful Termination Initiated, PDN Disconnect - S5u Gtpu Error Local Purge Initiated, PDN Disconnect - S1u Gtpu Session replacement Initiated, PDN Disconnect - S5u Gtpu Session replacement Initiated, PDN Disconnect - S1u Gtpu Error Local Purge Initiated, PDN Disconnect - S5u Gtpu Error Local Purge

Initiated, PDN Disconnect - S1u Gtpu Session replacement Local Purge Initiated, PDN Disconnect - S5u Gtpu Session replacement Local Purge Initiated, Clear Subscriber - Sx Session Idle Timeout Initiated, Bearer Disconnect - S1u Gtpu Error Local Purge Initiated, Bearer Disconnect - S5u Gtpu Error Local Purge Initiated, Bearer Disconnect - S1u Gtpu Session replacement Local Purge Initiated, Bearer Disconnect - S5u Gtpu Session replacement Local Purge Initiated, Bearer Disconnect - S5u Gtpu Error Local Purge Initiated, Bearer Disconnect - S1u Gtpu Session replacement Initiated, Bearer Disconnect - S5u Gtpu Session replacement Initiated, Clear Subscriber - S1u Gtpu Path Failure Initiated, Clear Subscriber - S5u Gtpu Path Failure Initiated, Clear Subscriber - S1u Gtpu Path Failure Local Purge Initiated, Clear Subscriber - S5u Gtpu Path Failure Local Purge Initiated, Bearer Disconnect - S1u Gtpu Path Failure Initiated, Bearer Disconnect - S5u Gtpu Path Failure Initiated, Bearer Disconnect - S1u Gtpu Path Failure Local Purge Initiated, Bearer Disconnect - S5u Gtpu Path Failure Local Purge Initiated

- Label: `old_proc`

Label Description: Indicates the ongoing procedure at eGTP-C when a new message arrived at the interface which caused the collision. The Msg Type in brackets specifies which message triggered this ongoing procedure"

Example: Unknown, PDN Setup, PDN Modify, Create Bearer, Update Bearer, Delete Bearer, PDN Disconnect - UE initiated, PDN Disconnect - Admin initiated, PDN Disconnect - PGW initiated, PDN Disconnect - Self initiated, Modify Bearer Command, Delete Bearer Command, Release Access Bearer, Downlink Data Notification, Clear Subscriber - S5e Recovery Initiated, Clear Subscriber - Sx Recovery Initiated, Clear Subscriber - S11 Recovery Initiated, Clear Subscriber - S5e Path Failure Initiated, Clear Subscriber - Sx Path Failure Initiated, Clear Subscriber - S11 Path Failure Initiated, Clear Subscriber - S11 Path Failure Local Purge Initiated, Clear Subscriber - S11 Recovery Local Purge Initiated, Clear Subscriber - S5e Path Failure Local Purge Initiated, Clear Subscriber - S5e Recovery Local Purge Initiated, Clear Subscriber - Sx Association Release Initiated, Change Notification, PDN Disconnect - Upf Graceful Termination Initiated, PDN Disconnect - S5u Gtpu Error Local Purge Initiated, PDN Disconnect - S1u Gtpu Session replacement Initiated, PDN Disconnect - S5u Gtpu Session replacement Initiated, PDN Disconnect - S1u Gtpu Error Local Purge Initiated, PDN Disconnect - S5u Gtpu Error Local Purge Initiated, PDN Disconnect - S1u Gtpu Session replacement Local Purge Initiated, PDN Disconnect - S5u Gtpu Session replacement Local Purge Initiated, Clear Subscriber - Sx Session Idle Timeout Initiated, Bearer Disconnect - S1u Gtpu Error Local Purge Initiated, Bearer Disconnect - S5u Gtpu Error Local Purge Initiated, Bearer Disconnect - S1u Gtpu Session replacement Local Purge Initiated, Bearer Disconnect - S5u Gtpu Session replacement Local Purge Initiated, Bearer Disconnect - S5u Gtpu Error Local Purge Initiated, Bearer Disconnect - S1u Gtpu Session replacement Initiated, Bearer Disconnect - S5u Gtpu Session replacement Initiated, Clear Subscriber - S1u Gtpu Path Failure Initiated, Clear Subscriber - S5u Gtpu Path Failure Initiated, Clear Subscriber - S1u Gtpu Path Failure Local Purge Initiated, Clear Subscriber - S5u Gtpu Path Failure Local Purge Initiated, Bearer Disconnect - S1u Gtpu Path Failure Initiated, Bearer Disconnect - S5u Gtpu Path Failure Initiated, Bearer Disconnect - S1u Gtpu Path Failure Local Purge Initiated, Bearer Disconnect - S5u Gtpu Path Failure Local Purge Initiated

SGW DDN Stats Category

sgw_ddn_stats

Description: Total SGW DDN Stats

Sample Query: `sgw_ddn_stats{gr_instance_id="1",ddn_stats_type="high_priority_initiated"}`

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `ddn_stats_type`

Label Description: The pre-defined `ddn_stats_type`

Example: `high_priority_initiated`, `high_priority_suppressed`, `throttled`, `delayed`, `control_proc_triggered`, `data_triggered`, `gtpu_err_ind_triggered`

SGW PDN Disconnect Stats Category

`sgw_pdn_disconnect_stats`

Description: SGW PDN disconnects counters

Sample Query:

```
sgw_pdn_disconnect_stats{gr_instance_id="1",pdn_type="ipv4v6",rat_type="EUTRAN",reason="mme_init_pdn_sess_rel"}
```

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `pdn_type`

Label Description: The `pdn_type` indicates the address type of PDN

Example: `ipv4`, `ipv6`, `ipv4v6`, `unknown`

- Label: `rat_type`

Label Description: The `rat_type` indicates which Radio Access Technology is currently serving the UE"

Example: `EUTRAN`

- Label: `reason`

Label Description: The reason indicates the disconnect reason associate with the `pdn`"

Example: `admin_init_disconnect`, `remote_init_disconnect`, `pgw_init_pdn_sess_rel`, `mme_init_pdn_sess_rel`, `sx_request_rejected`, `sx_context_not_found`, `sx_msg_invalid_length`, `sx_no_resource_available`, `sx_no_response`, `sx_reason_unknown`, `no_response`, `s5_context_not_found`, `s11_context_not_found`, `local_disconnect`, `no_cause`, `userplane_info_not_available`, `setup_timeout`, `admin_init_local_purge`, `db_conflict_init_disconnect`, `context_replacement`, `userplane_session_idle_timeout`, `userplane_requested_graceful_termination`, `s1u_gtpu_error`, `s5u_gtpu_error`, `s1u_gtpu_session_replacement`, `s5u_gtpu_session_replacement`, `sx_recovery`, `sx_path_failure`, `s11_path_failure`, `s5e_path-failure`, `s11_path_failure_local_purge`, `s5e_path_failure_local_purge`, `s5e_recovery`, `s11_recovery`, `s5e_recovery_local_purge`, `s11_recovery_local_purge`, `s1u_gtpu_path_failure`, `s5u_gtpu_path_failure`, `stale_session_init_disconnect`, `mop_offline`

SGW PDN EMPS Counter Category

sgw_pdn_emps_counter

Description: Total number of active emps session

Sample Query: `sgw_pdn_emps_counters{gr_instance_id=\"1\",status=\"active\"}`

Labels:

- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2
- Label: `status`
Label Description: Active emps session
Example: active

SGW PDN EMPS Stats Category

sgw_pdn_emps_stats

Description: Total number of emps session

Sample Query: `sgw_pdn_emps_stats{gr_instance_id=\"1\",status=\"release\"}`

Labels:

- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2
- Label: `status`
Label Description: Status of emps session
Example: setup, release

SGW PDN Level Counters Category

sgw_pdn_counters

Description: Pdn level counters

Sample Query:

`sgw_pdn_counters{ratType=\"EUTRAN\",pdnConnType=\"ipv4\",plmnType=\"homer\",grInstanceID=\"1\"}`

Labels:

- Label: `rat_type`
Label Description: The `rat_type` indicates which Radio Access Technology is currently serving the UE"

Example: EUTRAN

- Label: `pdn_type`

Label Description: The `pdn_type` indicates the address type of PDN

Example: ipv4, ipv6, ipv4v6, unknown

- Label: `pdn_plmn_type`

Label Description: It indicates the plmn type for the subscriber

Example: homer, visitor, roamer, unknown

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SGW PDN Level statistics Category

sgw_pdn_stats

Description: Pdn level statistics

Sample Query:

```
sgw_pdn_stats{ratType="EUTRAN",status="setup",pdnConnType="ipv4",plmnType="homer",grInstanceID="1"}
```

Labels:

- Label: `rat_type`

Label Description: The `rat_type` indicates which Radio Access Technology is currently serving the UE"

Example: EUTRAN

- Label: `status`

Label Description: Subscriber status

Example: setup, release

- Label: `pdn_type`

Label Description: The `pdn_type` indicates the address type of PDN

Example: ipv4, ipv6, ipv4v6, unknown

- Label: `pdn_plmn_type`

Label Description: It indicates the plmn type for the subscriber

Example: homer, visitor, roamer, unknown

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `fail_reason`

Label Description: High level reason for failure status. For success and attempted it will be Empty

Example: `gtp_validation_fail, gtp_cause_fail, gtp_peer_not_responding, sx_validation_fail, sx_cause_fail, sx_peer_not_responding, timeout, internal_failure, userplane_selection_fail, gtp_partial_fail, sx_oci_throttling_reject, collision_abort, collision_discard, gtp_entity_in_congestion`

- Label: `sub_fail_reason`

Label Description: Incoming negative GTP/Sx Cause or type of TIMEOUT that led to the failure. For other failures it will be Empty

Example: `invalid_msg_format, version_not_supported, service_not_supported, imsi_imei_not_known, preferred_pdn_type_unsupported, mand_ie_missing, cond_ie_missing, invalid_len, mand_ie_incorrect, no_resource_available, temp_rejected_due_to_handover_in_progress, peer_not_responding, context_not_found, unable_to_page_ue, unable_to_page_ue_due_to_suspension, ue_already_reattached, temp_rejected_due_to_ho_in_progress, sx_req_rejected, invalid_fw_policy, invalid_fteid_alloc_opt, rule_creation_mod_fail, no_estab_sx_assoc, system_failure, pfcg_entity_in_congestion, procedure_timeout, ipc_timeout, transaction_timeout, missing_or_unknown_apn`

- Label: `reject_cause`

Label Description: In case of procedure failure it will be used to indicate the outgoing GTP/Sx cause being sent to the peer. In other cases it will be Empty.

Example: `invalid_msg_format, version_not_supported, invalid_len, mandatory_ie_missing, conditional_ie_missing, mandatory_ie_incorrect, service_not_supported, imsi_imei_not_known, preferred_pdn_type_unsupported, system_failure, no_resources_available, temp_rejected_due_to_handover_in_progress, service_denied, peer_not_responding, context_not_found, request_rejected, missing_or_unknown_apn, entity_in_congestion`

- Label: `svc_to_svc`

Label Description: In case of gtp bypass, i.e. service to service communication this is set as True, else False

Example: True, False

SGW Resource Management stats Category

sgw_resource_mgmt_stats

Description: It gives information about number of allocated/deallocated ID's from resource manager

Sample Query:

```
sgw_resource_mgmt_stats{label_id_type="id_alloc",status="success",grInstanceID="1"}
```

Labels:

- Label: `label_id_type`

Label Description: The `label_id_type` indicates if its ID allocation or deallocation"

Example: `id_alloc, id_dealloc`

- Label: `status`

Label Description: The status of ID allocation/deallocation

Example: attempted, success, failure

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SGW Sx session report stats Category

sgw_sx_session_report_stats

Description: Total Sx Session-Report-Requests processed

Sample Query:

```
sgw_sx_session_report_stats(gr_instance_id="1",sx_session_report_type="USAR",sx_usage_report_status="success")
```

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `sx_session_report_type`

Label Description: Type of the session-report

Example: USAR, DLDR, ERIR, UPIR, SPTER, SRIR, GTER, UPRR

- Label: `sx_usage_report_status`

Label Description: Processing status of usage report

Example: success, failure

SGW Timer Stats Category

sgw_tmr_stats

Description: SGW Timer Counter

Sample Query:

```
sgw_tmr_stats(gr_instance_id="1",timer_type="internal_ddn_delay",status="start")
```

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `timer_type`

Label Description: Timer type

Example: internal_ddn_delay

- Label: `status`

Label Description: Status of timer

Example: start, stop, expired

SGW UE Disconnect Stats Category

sgw_ue_disconnect_stats

Description: SGW UE disconnects counters

Sample Query: `sgw_ue_disconnect_stats{gr_instance_id="1",reason="admin_init_disconnect"}`

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `reason`

Label Description: The reason indicates the disconnect reason associated with the UE

Example: admin_init_disconnect, remote_init_disconnect, pgw_init_pdn_sess_rel, mme_init_pdn_sess_rel, sx_request_rejected, sx_context_not_found, sx_msg_invalid_length, sx_no_resource_available, sx_no_response, sx_reason_unknown, no_response, s5_context_not_found, s11_context_not_found, local_disconnect, no_cause, userplane_info_not_available, db_conflict_init_disconnect, userplane_session_idle_timeout, userplane_requested_graceful_termination, s1u_gtpu_error, s5u_gtpu_error, s1u_gtpu_session_replacement, s5u_gtpu_session_replacement, sx_recovery, sx_path_failure, s11_path_failure, s5e_path-failure, s11_path_failure_local_purge, s5e_path_failure_local_purge, s5e_recovery, s11_recovery, s5e_recovery_local_purge, s11_recovery_local_purge, s1u_gtpu_path_failure, s5u_gtpu_path_failure, stale_session_init_disconnect, mop_offline

SGW UE Level Counters Category

sgw_ue_counters

Description: UE level counter

Sample Query: `sgw_ue_counters{ratType="EUTRAN",state="idle",grInstanceID="1"}`

Labels:

- Label: `rat_type`

Label Description: The `rat_type` indicates which Radio Access Technology is currently serving the UE"

Example: EUTRAN

- Label: `state`
Label Description: Subscriber state
Example: idle, connected
- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

SGW UE Level statistics Category

sgw_ue_stats

Description: UE level statistics

Sample Query: `sgw_ue_stats{ratType="EUTRAN",status="setup",grInstanceID="1"}`

Labels:

- Label: `rat_type`
Label Description: The `rat_type` indicates which Radio Access Technology is currently serving the UE"
Example: EUTRAN
- Label: `status`
Label Description: Subscriber status
Example: setup, release
- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

SGW Volte session counter Category

sgw_voltesession_counter

Description: Total Sx Session usage reports processed

Sample Query: `sgw_voltesession_counter{gr_instance_id="1",state="VolteSession"}`

Labels:

- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2
- Label: `state`
Label Description: Session type

Example: VolteSession

SGW callflow optimization stats Category

sgw_callflow_optimization_stats

Description: SGW Callflow Optimization Counter

Sample Query:

```
sgw_callflow_optimization_stats{gr_instance_id="1",type="suppress_uli_reporting_on_s5"}
```

Labels:

- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2
- Label: `type`
Label Description: Callflow optimization type
Example: `suppress_uli_reporting_on_s5`, `rab_prepone_ack`

gtpc-ep Metrics Reference

GTPC BGP Routed Count Stats Category

gtpc_app_bgp_routes_count

Description: BGP routes add counter

Sample Query: `'gtpc_app_bgp_routes_count{status="success"}'`

Labels:

- Label: `status`
Label Description: status
Example: success, failed
- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

GTPC Roaming Peer Path Mgmt Stats Category

gtpc_roaming_peer_path_mgmt

Description: GTPC Roaming Peer Path Mgmt Stats

Sample Query: 'gtpc_roaming_peer_path_mgmt{service_name="gtpc-ep",status="suppressed"}'

Labels:

- Label: `gtpc_peer_type`
Label Description: Gtpc Peer type
Example: ROAMER, HOMER, VISITOR
- Label: `interface_type`
Label Description: Gtpc Interface type
Example: S5, S11, S5E, S2B, S8
- Label: `gtpc_msg_type`
description: Gtpc Message type
Example: NumEchoMsg, NumControlMsg
- Label: `status`
Label Description: Status
Example: suppressed
- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

GTPC Short Circuit Map Count Category

gtpc_short_circuit_map_count

Description: GTPC Short Circuit Map operation counter

Sample Query: 'gtpc_short_circuit_map_count{message_name="TxModifyBearerRes"}'

Labels:

- Label: `message_name`
Label Description: Message Name
Example: TxCreateBearerReq, TxUpdateBearerReq, TxDeleteBearerReq, TxModifyBearerRes, TxDeleteSessRsp, TxCreateSessionRsp, RecordExpired
- Label: `gtpc_short_circuit_map_operation`
Label Description: Gtpc short circuit counter type

Example: increment, decrement

- Label: `gtpc_short_circuit_map_teid_changed`

Label Description: Gtpc short circuit teid cache operation type

Example: added, updated, deleted

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

GTPC Short Circuit Message Stats Category

`gtpc_msg_short_circuit_stats`

Description: GTPC Short Circuit MBResp Stats

Sample Query: `'gtpc_msg_short_circuit_stats{gtpc_msg_type="RxModifyBearerReq"}'`

Labels:

- Label: `gtpc_msg_type`

Label Description: Gtpc Message type

Example: RxModifyBearerReq, SkippingShortCircuit

- Label: `gtpc_short_circuit_category`

Label Description: Category

Example: WithServingNetwork, WithIndication, WithBearerContext, MBREventExpired, SendSCMBResp, GetSCMBRespFailed, LastSequenceNumberSame

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

Processing Time of SMF GTPC Messages Category

`gtpc_msg_seconds`

Description: Time taken for GTPC message processing

Sample Query: `'gtpc_msg_seconds{message_name="S5S8_MSG_CREATE_SESSION_REQUEST"}'`

Labels:

- Label: `message_name`

Label Description: Message Name

Example: S5S8_MSG_CREATE_SESSION_REQUEST, S5S8_MSG_CREATE_SESSION_RESPONSE, S5S8_MSG_MODIFY_BEARER_REQUEST, S5S8_MSG_MODIFY_BEARER_RESPONSE,

S5S8_MSG_DELETE_BEARER_REQUEST, S5S8_MSG_DELETE_BEARER_RESPONSE,
S5S8_MSG_DELETE_SESSION_REQUEST, S5S8_MSG_DELETE_SESSION_RESPONSE

- Label: `message_direction`
Label Description: Direction
Example: inbound, outbound
- Label: `status`
Label Description: Status
Example: no_rsp_received_tx, accepted
- Label: `transport_type`
Label Description: Transport Type
Example: origin, retransmitted
- Label: `interface_type`
Label Description: Gtpc Interface type
Example: S5, S11, S5E, S2B, S8
- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

Processing time of GTPC messages Category

gtpc_app_events_seconds

Description: Total time taken by GTPC messages

Sample Query: `'gtpc_app_events_seconds{event_type="csreq}'`

Labels:

- Label: `event_type`
Label Description: Gtpc Event type
Example: csreq, mbreq, cbreq, ubreq, dbreq, dsreq, rabreq, cidftreq, didftreq, changenotfreq, mbreqlist
- Label: `interface_type`
Label Description: Gtpc Interface type
Example: S5, S11, S5E, S2B, S8
- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

SGW TEID Cache Operation Stats Category

sgw_teid_cache_total

Description: SGW TEID cache operation counter

Sample Query: 'sgw_teid_cache_total{action="create"}'

Labels:

- Label: `action`

Label Description: TEID cache operation type

Example: create, update, delete, cache_found, expired, no_cache, cache_full

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SMF GTPC Echo Stats Category

gtpc_echo_msg_stats

Description: GTPC Echo Req Rx and Echo Resp Tx

Sample Query: 'gtpc_echo_msg_stats{gtpc_msg_type="gtpc_echo_req_rx"}'

Labels:

- Label: `gtpc_peer_ip`

Label Description: Gtpc Peer IP of nodes like SGW,ePDG etc

Example: 1.2.3.4

- Label: `gtpc_msg_type`

Label Description: Gtpc Message type

Example: gtpc_echo_req_rx, gtpc_echo_res_tx

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SMF GTPC Golang Encode Decode Stats Category

gtpc_golang_enc_dec_stats

Description: Messages Encoded/Decoded using Golang

Sample Query: 'gtpc_golang_enc_dec_stats{gtpc_msg_type="RxModifyBearerReq"}'

Labels:

- Label: `gtpc_msg_type`

Label Description: Gtpc Message type

Example: NumRxEchoReq, NumTxEchoReq, NumRxEchoRes, NumTxEchoRes, NumRxCreateSessionReq, NumTxCreateSessionReq, NumRxCreateSessionRes, NumTxCreateSessionRes, NumRxDeleteSessionReq, NumTxDeleteSessionReq, NumRxDeleteSessionRes, NumTxDeleteSessionRes, NumRxModifyBearerReq, NumTxModifyBearerReq, NumRxModifyBearerRes, NumTxModifyBearerRes, NumRxDeleteBearerReq, NumTxDeleteBearerReq, NumRxDeleteBearerRes, NumTxDeleteBearerRes, NumTxCreateBearerReq, NumRxCreateBearerReq, NumTxCreateBearerRes, NumRxCreateBearerRes, NumTxUpdateBearerReq, NumRxUpdateBearerReq, NumTxUpdateBearerRes, NumRxUpdateBearerRes, NumRxModifyBearerCmd, NumTxModifyBearerCmd, NumRxModifyBearerFail, NumTxModifyBearerFail, NumRxDeleteBearerCmd, NumTxDeleteBearerCmd, NumRxDeleteBearerFail, NumTxDeleteBearerFail, NumTxChangeNotfReq, NumRxChangeNotfReq, NumRxChangeNotfRes, NumTxChangeNotfRes, NumRxSuspendNotf, NumTxSuspendNotf, NumRxSuspendAck, NumTxSuspendAck, NumRxResumeNotf, NumTxResumeNotf, NumRxResumeAck, NumTxResumeAck, NumTxReleaseAccessBearerRsp, NumRxReleaseAccessBearerReq, NumRxContextReq, NumTxContextReq, NumRxContextAck, NumTxContextAck, NumRxDDN, NumTxDDn, NumRxIDReq, NumTxIDReq, NumRxIDRsp, NumTxIDRsp, NumRxDDNFail, NumTxDDnFail, NumRxCreateIDFTRReq, NumTxCreateIDFTRsp, NumRxDeletIDFTRReq, NumTxDeletIDFTRsp, NumRxBearerResCmd

- Label: `gtpc_msg_len`

Label Description: Message Length

Example: 36, 24, 45

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: `gtpc_msg_operation`

Label Description: Operation

Example: encode, decode

- Label: `gtpc_msg_status`

Label Description: Status

Example: success, error

- Label: `gtpc_msg_status_cause`

Label Description: Error Cause

Example: HeaderDecodeFailure, ParseIEsFromPayloadFailure, MBRFromIEFailure

SMF GTPC Messages Total Category

gtpc_msg_total

Description: Total GTPC Messages

Sample Query: 'gtpc_msg_total{message_name="S5S8_MSG_CREATE_SESSION_REQUEST"}'

Labels:

- Label: `message_name`

Label Description: Message Name

Example: S5S8_MSG_CREATE_SESSION_REQUEST, S5S8_MSG_CREATE_SESSION_RESPONSE, S5S8_MSG_MODIFY_BEARER_REQUEST, S5S8_MSG_MODIFY_BEARER_RESPONSE, S5S8_MSG_DELETE_BEARER_REQUEST, S5S8_MSG_DELETE_BEARER_RESPONSE, S5S8_MSG_DELETE_SESSION_REQUEST, S5S8_MSG_DELETE_SESSION_RESPONSE

- Label: `message_direction`

Label Description: Direction

Example: inbound, outbound

- Label: `status`

Label Description: Status

Example: no_rsp_received_tx, accepted

- Label: `transport_type`

Label Description: Transport Type

Example: origin, retransmitted

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SMF GTPC Unexpected Messages Category

gtpc_app_total_unexpected_gtpc_msg_events

Description: Unexpected GTPC Messages received

Sample Query: 'gtpc_app_total_unexpected_gtpc_msg_events{service_name="gtpc-ep"}'

Labels:

- Label: `message_type`

Label Description: Gtpc Message type

Example: unexpected_gtpc_message

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SMF GTPC Validation Fail Stats Category

gtpc_app_validation_events

Description: Stats of Message decode failures

Sample Query: `'gtpc_app_validation_events{service_name="gtpc-ep}'`

Labels:

- Label: `message_type`

Label Description: Gtpc Message type

Example: csreq, csrsp, mbreq, mbrsp, cbreq, cbrsp, ubreq, ubrsp, dbreq, dbrsp, dsreq, dsrsp, mbcmd, mbcfi, dbcnd, dbcfi, ddnfi, ddnack, rabreq, upcreq

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: sgw_ingress, pgw_ingress, S5, S11, S5E, S2B, S8

- Label: `failure_type`

Label Description: Failure Type

Example: msg_validation_fail, hdr_decode_failure

- Label: `hdr_decode_fail_reason`

Label Description: Header Decode Fail Reason

Example: incorrect_gtp_version, unsupported_message, incorrect_msg_len, invalid_msg_format, invalid_seq_no, hdr_decode_fail_reason

- Label: `action_type`

Label Description: Action Type

Example: discarded, rejected

- Label: `reject_cause`

Label Description: Reject Cause

Example: invalid_msg_format, version_not_supported, invalid_len, mandatory_ie_missing, conditional_ie_missing, mandatory_ie_incorrect, service_not_supported, imsi_imei_not_known, preferred_pdn_type_unsupported, unknown

SMF GTPC messages Category

gtpc_app_events

Description: GTPC message counter

Sample Query: 'gtpc_app_events{service_name="gtpc-ep"}'

Labels:

- Label: event_type

Label Description: Gtpc Event type

Example: NumRxCreateSessionReq, NumTxCreateSessionRes, NumRxDeleteSessionReq, NumTxDeleteSessionRes, NumRxModifyBearerReq, NumTxModifyBearerRes, NumTxDeleteBearerReq, NumRxDeleteBearerRsp, NumTxCreateBearerReq, NumRxCreateBearerRes, NumTxUpdateBearerReq, NumRxUpdateBearerRes, NumTxModifyBearerFailureInd, NumModifyBearerTimeout, NumRxDeleteBearerCmd, NumCreateBearerFailure, NumCreateBearerSuccess, NumCreateSessionSuccess, NumCreateSessionFailure, NumDeleteSessionSuccess, NumDeleteSessionFailure, NumCreateBearerReqRetrans, NumUpdateBearerReqRetrans, NumDeleteBearerReqRetrans

- Label: interface_type

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: gtpc_msg_fail_cause

Label Description: Contains Gtpc message fail cause

Example: send_to_service_error, nil_raw_response, unmarshal_fail

- Label: gr_instance_id

Label Description: GR instance ID

Example: 1, 2

SMF GTPC priority messages Category

gtpc_app_priority_events

Description: GTPC priority message counter

Sample Query: 'gtpc_app_priority_events{service_name="gtpc-ep"}'

Labels:

- Label: event_type

Label Description: Gtpc Event type

Example: NumRxCreateSessionReq, NumTxCreateSessionRes, NumRxDeleteSessionReq, NumTxDeleteSessionRes, NumRxModifyBearerReq, NumTxModifyBearerRes, NumTxDeleteBearerReq, NumRxDeleteBearerRsp, NumTxCreateBearerReq, NumRxCreateBearerRes, NumTxUpdateBearerReq, NumRxUpdateBearerRes, NumTxModifyBearerFailureInd, NumModifyBearerTimeout, NumRxDeleteBearerCmd, NumCreateBearerFailure, NumCreateBearerSuccess, NumCreateSessionSuccess, NumCreateSessionFailure, NumDeleteSessionSuccess, NumDeleteSessionFailure, NumCreateBearerReqRetrans, NumUpdateBearerReqRetrans, NumDeleteBearerReqRetrans

- Label: `priority_msg`

Label Description: priority

Example: true

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

UDP-Proxy Metrics Reference

UDP-Proxy BGP Routes Count Category

`udp_proxy_bgp_routes_count`

Description: UDP Proxy BGP routes added count

Sample Query: `'udp_proxy_bgp_routes_count{service_name="udp-proxy", status="success"}'`

Labels:

- Label: `status`

Label Description: Status of message while sending or receiving

Example: success, failed

UDP-Proxy Messages Category

`udp_proxy_msg_total`

Description: UDP Proxy message counters being recieved or sent

Sample Query: 'udp_proxy_msg_total{message_name="radius_request", message_direction="inbound", status="success"}'

Labels:

- Label: `message_name`

Label Description: UDP messages coming via udp-proxy service

Example: `radius_request`, `radius_response`, `heartbeat_request`, `heartbeat_response`

- Label: `message_direction`

Label Description: Message being sent or being received

Example: `inbound`, `outbound`

- Label: `status`

Label Description: Status of message while sending or receiving

Example: `success`, `failed`