



cnSGW-C Metrics Reference

- [Overview, on page 1](#)
- [sgw Metrics Reference, on page 1](#)
- [gtpc-ep Metrics Reference, on page 17](#)
- [UDP-Proxy Metrics Reference, on page 26](#)

Overview

This section provides details of bulk statistics. Bulk statistics are divided in two types:

- Gauge - Snapshot value that shows the statistic at the reporting moment (for example, the number of current UE, current PDN connections). These statistics can increment or decrement continuously.
- Counter - Historic value accumulated over a period (for example, the total number of CSR requests received). These values get incremented except in the following two cases:
 - Rollover - where a counter exceeds its maximum value and rolls over to zero.
 - Reset - where a counter is manually reset to zero.

sgw Metrics Reference

CDL active sessions Category

db_records_total

Description: CDL active sessions. each label is prefix with SGW.

Sample Query: `avg(db_records_total{service_name=\"datastore-ep\"})by(session_type)`

Labels:

- Label: `emergency_call`

Label Description: Number of emergency calls in cnSGW

Example: `SGW:emergency_call:true`

- Label: `rat_type`
Label Description: Rat type of sessions. For cnSGW there is only one `rat_type` EUTRAN
Example: `SGW:rat_type:EUTRAN`
- Label: `state`
Label Description: Number of active or idle subscriber state.
Example: `SGW:state:active` , `SGW:state:idle`
- Label: `pdn_active`
Label Description: Number of active PDNs for that subscriber.
Example: `SGW:pdn_active:1` , `SGW:pdn_active:2`
- Label: `bearer_active`
Label Description: Number of active Bearers for that subscriber.
Example: `SGW:bearer_active:1` , `SGW:bearer_active:2`
- Label: `apn`
Label Description: Number of subscribers per apn.
Example: `SGW:apn:internet2` , `SGW:apn:ims2`
- Label: `colocated`
Label Description: Number of colocated or non-colocated subscriber.
Example: `SGW:colocated:true` , `SGW:colocated:false`
- Label: `total`
Label Description: Total number of sessions in CDL
Example: `total`

CDR container operations Category

sgw_charging_cdr_container

Description: CDR container operations total

Sample Query:

```
sgw_charging_cdr_container{gr_instance_id="1",action="close_final",change_condition="recordClosure",pdn_type="ipv4v6",pdn_plmn_type="visitor"}
```

Labels:

- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2
- Label: `action`
Label Description: Type of CDR operation

Example: close_final, close_interim, open

- Label: `change_condition`

Label Description: Reason for container close operation

Example: recordClosure,qoSChange,userLocationChange,apnAmbrChange

- Label: `event`

Label Description: Event that triggered CDR action

Example: StartAccounting,SGWChange,NormalRelease etc.

- Label: `pdn_type`

Label Description: The `pdn_type` indicates the address type of PDN

Example: ipv4, ipv6, ipv4v6, unknown

- Label: `pdn_plmn_type`

Label Description: The `pdn_plmn_type` indicates the plmn type

Example: homer,visitor,roamer,unknown

CDR operations Category

sgw_charging_cdr

Description: CDR operations total

Sample Query:

```
sgw_charging_cdr{gr_instance_id="1",action="close_final",cause="servingNodeChange",pdn_type="ipv4v6",pdn_plmn_type="visitor"}
```

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `action`

Label Description: Type of CDR operation

Example: close_final, close_interim, open

- Label: `cause`

Label Description: Reason for CDR close operation

Example: maxChangeCond,servingNodeChange,volumeLimit,LTEservingNodeChange,abnormalRelease etc.

- Label: `event`

Label Description: Event that triggered CDR action

Example: StartAccounting,SGWChange,NormalRelease etc.

- Label: `pdn_type`

Label Description: The `pdn_type` indicates the address type of PDN

Example: `ipv4, ipv6, ipv4v6, unknown`

- Label: `pdn_plmn_type`

Label Description: The `pdn_plmn_type` indicates the plmn type

Example: `homer,visitor,roamer,unknown`

SGW Bearer Level counters Category

sgw_bearer_counters

Description: Bearer Level counters

Sample Query: `sgw_bearer_counters{gr_instance_id="1",status="active",qci="5"}`

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: `1, 2`

- Label: `status`

Label Description: Bearer Status

Example: `active`

- Label: `qci`

Label Description: Bearer QCI

Example: `1, 2, 3, 4, 5, 6, 7, 8, 9, 65, 66, 69, 70, 80, 82, 83, non-std-qci`

SGW Bearer Level statistics Category

sgw_bearer_stats

Description: Bearer and Qci level statistics

Sample Query:

`sgw_bearer_stats{gr_instance_id="1",status="attempted",qci="5",numBearer="2"}`

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: `1, 2`

- Label: `status`

Label Description: Bearer Status

Example: attempted, setup, release, modified

- Label: qci

Label Description: Bearer QCI

Example: 1, 2, 3, 4, 5, 6, 7, 8, 9, 65, 66, 69, 70, 80, 82, 83, non-std-qci

SGW callflow optimization stats Category

sgw_callflow_optimization_stats

Description: SGW Callflow Optimization Counter

Sample Query:

```
sgw_callflow_optimization_stats{gr_instance_id="1",type="suppress_uli_reporting_on_s5"}
```

Labels:

- Label: gr_instance_id

Label Description: GR instance ID

Example: 1, 2

- Label: type

Label Description: Callflow optimization type

Example: suppress_uli_reporting_on_s5, rab_prepone_ack

SGW CDL update stats Category

sgw_cdl_update_stats

Description: SGW CDL update Counter

Sample Query:

```
sgw_cdl_update_stats{gr_instance_id="1",txn_type="S11ModifyBearerReqInitialAttach",status="success",cdl_update_type="full_cdl_update"}
```

Labels:

- Label: gr_instance_id

Label Description: GR instance ID

Example: 1, 2

- Label: txn_type

Label Description: Transaction type

Example: ClearSubscriberSgwReq, N4SessionReportReq, NIntSgwSelfTxnBearerDisconnect, NIntSgwSelfTxnPagingStatusReq, NIntSgwSelfTxnPdnDisconnect, NIntSgwSelfTxnSxaSessRptReq, NSgwInternalTimerNotification, NSgwTimerNotificationReq, ReleaseAccessBearerReq, S11CreateSessReq, S11DeleteSessReq, S11ModifyBearerReq, S11ModifyBearerReqInitialAttach, S11ModifyBearerReqInterSystemHo, S11ModifyBearerReqIntraMMEX2S1HoNoSgwChange, S11ModifyBearerReqList, S11ModifyBearerReqListInterSystemHo,

S11ModifyBearerReqListIntraMMEX2S1HoNoSgwChange, S11ModifyBearerReqListOnlyForUliChange, S11ModifyBearerReqListS1HOSgwRelocation, S11ModifyBearerReqListServiceRequest, S11ModifyBearerReqListUnknownMBR, S11ModifyBearerReqOnlyForUliChange, S11ModifyBearerReqS1HOSgwRelocation, S11ModifyBearerReqServiceRequest, S11ModifyBearerReqUnknownMBR, S5CreateBearerReq, S5DeleteBearerReq, S5S8BearerResourceCmd, S5UpdateBearerReq, S11SuspendNotf, S11ResumeNotf

- Label: `status`

Label Description: Indicate whether transaction is success, aborted or timeout

Example: success, collision_abort, timeout

- Label: `cdl_update_type`

Label Description: Indicate CDL update type

Example: partial_cdl_update, full_cdl_update, no_cdl_update

SGW Collision Stats Category

`sgw_collision_stats`

Description: SGW Collision counters

Sample Query: `sgw_collision_stats{gr_instance_id=\"1\",action_type=\"abort\",new_proc=\"PDN Disconnect - UE initiated\",old_proc=\"Create Bearer\"}`

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `action_type`

Label Description: The pre-defined action taken to handle the collision. The action can be

Example: abort_new, abort_old, discard_new, discard_old

- Label: `new_proc`

Label Description: The new procedure and message type"

Example: Unknown, PDN Setup, PDN Modify, Create Bearer, Update Bearer, Delete Bearer, PDN Disconnect - UE initiated, PDN Disconnect - Admin initiated, PDN Disconnect - PGW initiated, PDN Disconnect - Self initiated, Modify Bearer Command, Delete Bearer Command, Release Access Bearer, Downlink Data Notification, Clear Subscriber - S5e Recovery Initiated, Clear Subscriber - Sx Recovery Initiated, Clear Subscriber - S11 Recovery Initiated, Clear Subscriber - S5e Path Failure Initiated, Clear Subscriber - Sx Path Failure Initiated, Clear Subscriber - S11 Path Failure Initiated, Clear Subscriber - S11 Path Failure Local Purge Initiated, Clear Subscriber - S11 Recovery Local Purge Initiated, Clear Subscriber - S5e Path Failure Local Purge Initiated, Clear Subscriber - S5e Recovery Local Purge Initiated, Clear Subscriber - Sx Association Release Initiated, Change Notification, PDN Disconnect - Upf Graceful Termination Initiated, PDN Disconnect - S5u Gtpu Error Local Purge Initiated, PDN Disconnect - S1u Gtpu Session replacement Initiated, PDN Disconnect - S5u Gtpu Session replacement Initiated, PDN Disconnect - S1u Gtpu Error Local Purge Initiated, PDN Disconnect - S5u Gtpu Error Local Purge

Initiated, PDN Disconnect - S1u Gtpu Session replacement Local Purge Initiated, PDN Disconnect - S5u Gtpu Session replacement Local Purge Initiated, Clear Subscriber - Sx Session Idle Timeout Initiated, Bearer Disconnect - S1u Gtpu Error Local Purge Initiated, Bearer Disconnect - S5u Gtpu Error Local Purge Initiated, Bearer Disconnect - S1u Gtpu Session replacement Local Purge Initiated, Bearer Disconnect - S5u Gtpu Session replacement Local Purge Initiated, Bearer Disconnect - S5u Gtpu Error Local Purge Initiated, Bearer Disconnect - S1u Gtpu Session replacement Initiated, Bearer Disconnect - S5u Gtpu Session replacement Initiated, Clear Subscriber - S1u Gtpu Path Failure Initiated, Clear Subscriber - S5u Gtpu Path Failure Initiated, Clear Subscriber - S1u Gtpu Path Failure Local Purge Initiated, Clear Subscriber - S5u Gtpu Path Failure Local Purge Initiated, Bearer Disconnect - S1u Gtpu Path Failure Initiated, Bearer Disconnect - S5u Gtpu Path Failure Initiated, Bearer Disconnect - S1u Gtpu Path Failure Local Purge Initiated, Bearer Disconnect - S5u Gtpu Path Failure Local Purge Initiated

- Label: `old_proc`

Label Description: Indicates the ongoing procedure at eGTP-C when a new message arrived at the interface which caused the collision. The Msg Type in brackets specifies which message triggered this ongoing procedure"

Example: Unknown, PDN Setup, PDN Modify, Create Bearer, Update Bearer, Delete Bearer, PDN Disconnect - UE initiated, PDN Disconnect - Admin initiated, PDN Disconnect - PGW initiated, PDN Disconnect - Self initiated, Modify Bearer Command, Delete Bearer Command, Release Access Bearer, Downlink Data Notification, Clear Subscriber - S5e Recovery Initiated, Clear Subscriber - Sx Recovery Initiated, Clear Subscriber - S11 Recovery Initiated, Clear Subscriber - S5e Path Failure Initiated, Clear Subscriber - Sx Path Failure Initiated, Clear Subscriber - S11 Path Failure Initiated, Clear Subscriber - S11 Path Failure Local Purge Initiated, Clear Subscriber - S11 Recovery Local Purge Initiated, Clear Subscriber - S5e Path Failure Local Purge Initiated, Clear Subscriber - S5e Recovery Local Purge Initiated, Clear Subscriber - Sx Association Release Initiated, Change Notification, PDN Disconnect - Upf Graceful Termination Initiated, PDN Disconnect - S5u Gtpu Error Local Purge Initiated, PDN Disconnect - S1u Gtpu Session replacement Initiated, PDN Disconnect - S5u Gtpu Session replacement Initiated, PDN Disconnect - S1u Gtpu Error Local Purge Initiated, PDN Disconnect - S5u Gtpu Error Local Purge Initiated, PDN Disconnect - S1u Gtpu Session replacement Local Purge Initiated, PDN Disconnect - S5u Gtpu Session replacement Local Purge Initiated, Clear Subscriber - Sx Session Idle Timeout Initiated, Bearer Disconnect - S1u Gtpu Error Local Purge Initiated, Bearer Disconnect - S5u Gtpu Error Local Purge Initiated, Bearer Disconnect - S1u Gtpu Session replacement Local Purge Initiated, Bearer Disconnect - S5u Gtpu Session replacement Local Purge Initiated, Bearer Disconnect - S5u Gtpu Error Local Purge Initiated, Bearer Disconnect - S1u Gtpu Session replacement Initiated, Bearer Disconnect - S5u Gtpu Session replacement Initiated, Clear Subscriber - S1u Gtpu Path Failure Initiated, Clear Subscriber - S5u Gtpu Path Failure Initiated, Clear Subscriber - S1u Gtpu Path Failure Local Purge Initiated, Clear Subscriber - S5u Gtpu Path Failure Local Purge Initiated, Bearer Disconnect - S1u Gtpu Path Failure Initiated, Bearer Disconnect - S5u Gtpu Path Failure Initiated, Bearer Disconnect - S1u Gtpu Path Failure Local Purge Initiated, Bearer Disconnect - S5u Gtpu Path Failure Local Purge Initiated

SGW DDN Stats Category

`sgw_ddn_stats`

Description: Total SGW DDN Stats

Sample Query: `sgw_ddn_stats{gr_instance_id="1",ddn_stats_type="high_priority_initiated"}`

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `ddn_stats_type`

Label Description: The pre-defined `ddn_stats_type`

Example: `high_priority_initiated`, `high_priority_suppressed`, `throttled`, `delayed`, `control_proc_triggered`, `data_triggered`, `gtpu_err_ind_triggered`

SGW PDN Disconnect Stats Category

`sgw_pdn_disconnect_stats`

Description: SGW PDN disconnects counters

Sample Query:

```
sgw_pdn_disconnect_stats{gr_instance_id="1",pdn_type="ipv4v6",rat_type="EUTRAN",reason="mme_init_pdn_sess_rel"}
```

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `pdn_type`

Label Description: The `pdn_type` indicates the address type of PDN

Example: `ipv4`, `ipv6`, `ipv4v6`, `unknown`

- Label: `rat_type`

Label Description: The `rat_type` indicates which Radio Access Technology is currently serving the UE"

Example: `EUTRAN`

- Label: `reason`

Label Description: The reason indicates the disconnect reason associate with the `pdn`"

Example: `admin_init_disconnect`, `remote_init_disconnect`, `pgw_init_pdn_sess_rel`, `mme_init_pdn_sess_rel`, `sx_request_rejected`, `sx_context_not_found`, `sx_msg_invalid_length`, `sx_no_resource_available`, `sx_no_response`, `sx_reason_unknown`, `no_response`, `s5_context_not_found`, `s11_context_not_found`, `local_disconnect`, `no_cause`, `userplane_info_not_available`, `setup_timeout`, `admin_init_local_purge`, `db_conflict_init_disconnect`, `context_replacement`, `userplane_session_idle_timeout`, `userplane_requested_graceful_termination`, `s1u_gtpu_error`, `s5u_gtpu_error`, `s1u_gtpu_session_replacement`, `s5u_gtpu_session_replacement`, `sx_recovery`, `sx_path_failure`, `s11_path_failure`, `s5e_path-failure`, `s11_path_failure_local_purge`, `s5e_path_failure_local_purge`, `s5e_recovery`, `s11_recovery`, `s5e_recovery_local_purge`, `s11_recovery_local_purge`, `s1u_gtpu_path_failure`, `s5u_gtpu_path_failure`, `stale_session_init_disconnect`, `mop_offline`

SGW PDN EMPS Counter Category

sgw_pdn_emps_counter

Description: Total number of active emps session

Sample Query: `sgw_pdn_emps_counters{gr_instance_id=\"1\",status=\"active\"}`

Labels:

- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2
- Label: `status`
Label Description: Active emps session
Example: active

SGW PDN EMPS Stats Category

sgw_pdn_emps_stats

Description: Total number of emps session

Sample Query: `sgw_pdn_emps_stats{gr_instance_id=\"1\",status=\"release\"}`

Labels:

- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2
- Label: `status`
Label Description: Status of emps session
Example: setup, release

SGW PDN Level Counters Category

sgw_pdn_counters

Description: Pdn level counters

Sample Query:

`sgw_pdn_counters{ratType=\"EUTRAN\",pdnConnType=\"ipv4\",plmnType=\"homer\",grInstanceID=\"1\"}`

Labels:

- Label: `rat_type`
Label Description: The `rat_type` indicates which Radio Access Technology is currently serving the UE"

Example: EUTRAN

- Label: `pdn_type`

Label Description: The `pdn_type` indicates the address type of PDN

Example: ipv4, ipv6, ipv4v6, unknown

- Label: `pdn_plmn_type`

Label Description: It indicates the plmn type for the subscriber

Example: homer, visitor, roamer, unknown

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SGW PDN Level statistics Category

sgw_pdn_stats

Description: Pdn level statistics

Sample Query:

```
sgw_pdn_stats{ratType="EUTRAN",status="setup",pdnConnType="ipv4",plmnType="homer",grInstanceID="1"}
```

Labels:

- Label: `rat_type`

Label Description: The `rat_type` indicates which Radio Access Technology is currently serving the UE"

Example: EUTRAN

- Label: `status`

Label Description: Subscriber status

Example: setup, release

- Label: `pdn_type`

Label Description: The `pdn_type` indicates the address type of PDN

Example: ipv4, ipv6, ipv4v6, unknown

- Label: `pdn_plmn_type`

Label Description: It indicates the plmn type for the subscriber

Example: homer, visitor, roamer, unknown

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SGW Procedure Category

sgw_service_stats

Description: SGW call flow procedure counters

Sample Query: `sgw_service_stats{gr_instance_id=\"1\",sgw_procedure_type=\"create_bearer\"}`

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `sgw_procedure_type`

Label Description: The procedure type associated with the call flow procedure

Example: `initial_attach`, `secondary_pdn_creation`, `mme_initiated_deletion`, `pgw_initiated_deletion`, `update_bearer`, `create_bearer`, `downlink_data_notification`, `downlink_data_notification_retry`, `pgw_initiated_dedicated_bearer_deletion`, `release_access_bearer`, `inter_mme_intra_sgw_idle_mode`, `intra_mme_intra_sgw_idle_mode`, `service_request`, `modify_bearer_req_initial_attach`, `inter_mme_handover`, `intra_mme_handover`, `inter_system_handover`, `modify_bearer_req_uli_tz_change`, `admin_initiated_deletion`, `s5_cnf_initiated_deletion`, `s11_cnf_initiated_deletion`, `sx_cnf_initiated_deletion`, `local_initiated_deletion`, `setup_timeout_deletion`, `create_indirect_data_forwarding_tunnel`, `delete_indirect_data_forwarding_tunnel`, `indirect_data_forwarding_tunnel_guard_timer_expiry`, `db_conflict_initiated_deletion`, `s1_sgw_relocation_attach`, `context_replacement`, `modify_bearer_command`, `delete_bearer_command`, `inter_system_handover_attach`, `x2_gnnp_to_lte_relocation_attach`, `s1_gnnp_to_lte_relocation_attach`, `inter_system_handover`, `modify_bearer_req_x2_gnnp_to_lte_relocation`, `modify_bearer_req_s1_gnnp_to_lte_relocation`, `change_notification`, `upf_sess_idle_timeout_deletion`, `upf_sess_idle_timeout_renewal`, `upf_sess_idle_timeout_renewal_notify`, `upf_sess_idle_timeout_renewal_notify`, `s5u_gtpu_error_initiated`, `s1u_gtpu_session_replacement_initiated`, `s5u_gtpu_session_replacement_initiated`, `s1u_gtpu_path_failure_initiated`, `s5u_gtpu_path_failure_initiated`, `s5u_gtpu_error_initiated_bearer_deletion`, `s1u_gtpu_error_local_purge_initiated_bearer_deletion`, `s5u_gtpu_error_local_purge_initiated_bearer_deletion`, `s1u_gtpu_session_replacement_initiated_bearer_deletion`, `s5u_gtpu_session_replacement_initiated_bearer_deletion`, `s1u_gtpu_session_replacement_local_purge_initiated_bearer_deletion`, `s5u_gtpu_session_replacement_local_purge_initiated_bearer_deletion`, `s1u_gtpu_path_failure_initiated_bearer_deletion`, `s5u_gtpu_path_failure_initiated_bearer_deletion`, `s1u_gtpu_path_failure_local_purge_initiated_bearer_deletion`, `s5u_gtpu_path_failure_local_purge_initiated_bearer_deletion`, `stale_session_initiated_deletion`, `dbcfi_cnf_local_purge_initiated_bearer_deletion`, `suspend_notification`, `resume_notification`, `pdn_state_sync`

- Label: `interface`

Label Description: The interface type associated with the call flow procedure

Example: `interface_sgw_ingress`, `interface_sgw_egress`

- Label: `status`

Label Description: The status of the call flow procedure. In case of procedure failure it can indicate whether the message was rejected or was the message discarded.

Example: attempted, success, failure, rejected, discarded

- Label: `fail_reason`

Label Description: High level reason for failure status. For success and attempted it will be Empty

Example: `gtp_validation_fail, gtp_cause_fail, gtp_peer_not_responding, sx_validation_fail, sx_cause_fail, sx_peer_not_responding, timeout, internal_failure, userplane_selection_fail, gtp_partial_fail, sx_oci_throttling_reject, collision_abort, collision_discard, gtp_entity_in_congestion`

- Label: `sub_fail_reason`

Label Description: Incoming negative GTP/Sx Cause or type of TIMEOUT that led to the failure. For other failures it will be Empty

Example: `invalid_msg_format, version_not_supported, service_not_supported, imsi_imei_not_known, preferred_pdn_type_unsupported, mand_ie_missing, cond_ie_missing, invalid_len, mand_ie_incorrect, no_resource_available, temp_rejected_due_to_handover_in_progress, peer_not_responding, context_not_found, unable_to_page_ue, unable_to_page_ue_due_to_suspension, ue_already_reattached, temp_rejected_due_to_ho_in_progress, sx_req_rejected, invalid_fw_policy, invalid_fteid_alloc_opt, rule_creation_mod_fail, no_estab_sx_assoc, system_failure, pfc_p_entity_in_congestion, procedure_timeout, ipc_timeout, transaction_timeout, missing_or_unknown_apn`

- Label: `reject_cause`

Label Description: In case of procedure failure it will be used to indicate the outgoing GTP/Sx cause being sent to the peer. In other cases it will be Empty.

Example: `invalid_msg_format, version_not_supported, invalid_len, mandatory_ie_missing, conditional_ie_missing, mandatory_ie_incorrect, service_not_supported, imsi_imei_not_known, preferred_pdn_type_unsupported, system_failure, no_resources_available, temp_rejected_due_to_handover_in_progress, service_denied, peer_not_responding, context_not_found, request_rejected, missing_or_unknown_apn, entity_in_congestion`

- Label: `svc_to_svc`

Label Description: In case of gtp bypass, i.e. service to service communication this is set as True, else False

Example: True, False

SGW Resource Management stats Category

sgw_resource_mgmt_stats

Description: It gives information about number of allocated/deallocated ID's from resource manager

Sample Query:

```
sgw_resource_mgmt_stats{label_id_type=\"id_alloc\", status=\"success\", grInstanceID=\"1\"}
```

Labels:

- Label: `label_id_type`

Label Description: The `label_id_type` indicates if its ID allocation or deallocation"

Example: `id_alloc, id_dealloc`

- Label: `status`
Label Description: The status of ID allocation/deallocation
Example: attempted, success, failure
- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

SGW Resource Management stats Category

`sgw_resource_mgmt_stats`

Description: It gives information about number of allocated/deallocated ID's from resource manager

Sample Query:

```
sgw_resource_mgmt_stats{label_id_type="id_alloc",status="success",grInstanceID="1"}
```

Labels:

- Label: `label_id_type`
Label Description: The `label_id_type` indicates if its ID allocation or deallocation"
Example: `id_alloc`, `id_dealloc`
- Label: `status`
Label Description: The status of ID allocation/deallocation
Example: attempted, success, failure
- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

SGW Sx session report stats Category

`sgw_sx_session_report_stats`

Description: Total Sx Session-Report-Requests processed

Sample Query:

```
sgw_sx_session_report_stats{gr_instance_id="1",sx_session_report_type="USAR",sx_usage_report_status="success"}
```

Labels:

- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

- Label: `sx_session_report_type`
Label Description: Type of the session-report
Example: USAR, DLDR, ERIR, UPIR, SPTEP, SRIR, GTER, UPRR
- Label: `sx_usage_report_status`
Label Description: Processing status of usage report
Example: success, failure

SGW Timer Stats Category

sgw_tmr_stats

Description: SGW Timer Counter

Sample Query:

```
sgw_tmr_stats{gr_instance_id="1",timer_type="internal_ddn_delay",status="start"}
```

Labels:

- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2
- Label: `timer_type`
Label Description: Timer type
Example: `internal_ddn_delay`
- Label: `status`
Label Description: Status of timer
Example: start, stop, expired

SGW UE Disconnect Stats Category

sgw_ue_disconnect_stats

Description: SGW UE disconnects counters

Sample Query: `sgw_ue_disconnect_stats{gr_instance_id="1",reason="admin_init_disconnect"}`

Labels:

- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2
- Label: `reason`
Label Description: The reason indicates the disconnect reason associated with the UE

Example: admin_init_disconnect, remote_init_disconnect, pgw_init_pdn_sess_rel, mme_init_pdn_sess_rel, sx_request_rejected, sx_context_not_found, sx_msg_invalid_length, sx_no_resource_available, sx_no_response, sx_reason_unknown, no_response, s5_context_not_found, s11_context_not_found, local_disconnect, no_cause, userplane_info_not_available, db_conflict_init_disconnect, userplane_session_idle_timeout, userplane_requested_graceful_termination, s1u_gtpu_error, s5u_gtpu_error, s1u_gtpu_session_replacement, s5u_gtpu_session_replacement, sx_recovery, sx_path_failure, s11_path_failure, s5e_path-failure, s11_path_failure_local_purge, s5e_path_failure_local_purge, s5e_recovery, s11_recovery, s5e_recovery_local_purge, s11_recovery_local_purge, s1u_gtpu_path_failure, s5u_gtpu_path_failure, stale_session_init_disconnect, mop_offline

SGW UE Level Counters Category

sgw_ue_counters

Description: UE level counter

Sample Query: `sgw_ue_counters{ratType="EUTRAN", state="idle", grInstanceID="1"}`

Labels:

- Label: `rat_type`

Label Description: The `rat_type` indicates which Radio Access Technology is currently serving the UE"

Example: EUTRAN

- Label: `state`

Label Description: Subscriber state

Example: idle, connected

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SGW UE Level statistics Category

sgw_ue_stats

Description: UE level statistics

Sample Query: `sgw_ue_stats{ratType="EUTRAN", status="setup", grInstanceID="1"}`

Labels:

- Label: `rat_type`

Label Description: The `rat_type` indicates which Radio Access Technology is currently serving the UE"

Example: EUTRAN

- Label: `status`

Label Description: Subscriber status

Example: setup, release

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SGW usage report stats Category

sgw_sx_usage_report_stats

Description: Total Sx Session usage reports processed

Sample Query: `sgw_sx_usage_report_stats{gr_instance_id="1",status="success"}`

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `status`

Label Description: Processing status

Example: success, ur_dropped_invalid_urr_seqNo, ur_dropped_bearer_not_found, ur_dropped_urrInfo_not_found, ur_dropped_acct_ctxt_not_found, ur_dropped_bearer_not_connected

SGW Volte session counter Category

sgw_voltesession_counter

Description: Total Sx Session usage reports processed

Sample Query: `sgw_voltesession_counter{gr_instance_id="1",state="VolteSession"}`

Labels:

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

- Label: `state`

Label Description: Session type

Example: VolteSession

gtpc-ep Metrics Reference

GTPC BGP Routed Count Stats Category

gtpc_app_bgp_routes_count

Description: BGP routes add counter

Sample Query: 'gtpc_app_bgp_routes_count{status="success"}'

Labels:

- Label: `status`
Label Description: status
Example: success, failed
- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

GTPC Roaming Peer Path Mgmt Stats Category

gtpc_roaming_peer_path_mgmt

Description: GTPC Roaming Peer Path Mgmt Stats

Sample Query: 'gtpc_roaming_peer_path_mgmt{service_name="gtpc-ep",status="suppressed"}'

Labels:

- Label: `gtpc_peer_type`
Label Description: Gtpc Peer type
Example: ROAMER, HOMER, VISITOR
- Label: `interface_type`
Label Description: Gtpc Interface type
Example: S5, S11, S5E, S2B, S8
- Label: `gtpc_msg_type`
description: Gtpc Message type
Example: NumEchoMsg, NumControlMsg
- Label: `status`
Label Description: Status
Example: suppressed

- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

GTPC Short Circuit Map Count Category

gtpc_short_circuit_map_count

Description: GTPC Short Circuit Map operation counter

Sample Query: `'gtpc_short_circuit_map_count{message_name="TxModifyBearerRes"}'`

Labels:

- Label: `message_name`
Label Description: Message Name
Example: TxCreateBearerReq, TxUpdateBearerReq, TxDeleteBearerReq, TxModifyBearerRes, TxDeleteSessRsp, TxCreateSessionRsp, RecordExpired
- Label: `gtpc_short_circuit_map_operation`
Label Description: Gtpc short circuit counter type
Example: increment, decrement
- Label: `gtpc_short_circuit_map_teid_changed`
Label Description: Gtpc short circuit teid cache operation type
Example: added, updated, deleted
- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

GTPC Short Circuit Message Stats Category

gtpc_msg_short_circuit_stats

Description: GTPC Short Circuit MBRsp Stats

Sample Query: `'gtpc_msg_short_circuit_stats{gtpc_msg_type="RxModifyBearerReq"}'`

Labels:

- Label: `gtpc_msg_type`
Label Description: Gtpc Message type
Example: RxModifyBearerReq, SkippingShortCircuit
- Label: `gtpc_short_circuit_category`
Label Description: Category

Example: WithServingNetwork, WithIndication, WithBearerContext, MBREventExpired, SendSCMBResp, GetSCMBRespFailed, LastSequenceNumberSame

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

Processing Time of SMF GTPC Messages Category

gtpc_msg_seconds

Description: Time taken for GTPC message processing

Sample Query: `'gtpc_msg_seconds{message_name="S5S8_MSG_CREATE_SESSION_REQUEST"}'`

Labels:

- Label: `message_name`

Label Description: Message Name

Example: S5S8_MSG_CREATE_SESSION_REQUEST, S5S8_MSG_CREATE_SESSION_RESPONSE, S5S8_MSG_MODIFY_BEARER_REQUEST, S5S8_MSG_MODIFY_BEARER_RESPONSE, S5S8_MSG_DELETE_BEARER_REQUEST, S5S8_MSG_DELETE_BEARER_RESPONSE, S5S8_MSG_DELETE_SESSION_REQUEST, S5S8_MSG_DELETE_SESSION_RESPONSE

- Label: `message_direction`

Label Description: Direction

Example: inbound, outbound

- Label: `status`

Label Description: Status

Example: no_rsp_received_tx, accepted

- Label: `transport_type`

Label Description: Transport Type

Example: origin, retransmitted

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

Processing time of GTPC messages Category

gtpc_app_events_seconds

Description: Total time taken by GTPC messages

Sample Query: 'gtpc_app_events_seconds{event_type="csreq"}'

Labels:

- Label: `event_type`

Label Description: Gtpc Event type

Example: csreq, mbreq, cbreq, ubreq, dbreq, dsreq, rabreq, cidftreq, didftreq, changenotfreq, mbreqlist

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SGW TEID Cache Operation Stats Category

sgw_teid_cache_total

Description: SGW TEID cache operation counter

Sample Query: 'sgw_teid_cache_total{action="create"}'

Labels:

- Label: `action`

Label Description: TEID cache operation type

Example: create, update, delete, cache_found, expired, no_cache, cache_full

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SMF GTPC Echo Stats Category

gtpc_echo_msg_stats

Description: GTPC Echo Req Rx and Echo Resp Tx

Sample Query: 'gtpc_echo_msg_stats{gtpc_msg_type="gtpc_echo_req_rx"}'

Labels:

- Label: `gtpc_peer_ip`
Label Description: Gtpc Peer IP of nodes like SGW,ePDG etc
Example: 1.2.3.4
- Label: `gtpc_msg_type`
Label Description: Gtpc Message type
Example: `gtpc_echo_req_rx`, `gtpc_echo_res_tx`
- Label: `interface_type`
Label Description: Gtpc Interface type
Example: S5, S11, S5E, S2B, S8
- Label: `gr_instance_id`
Label Description: GR instance ID
Example: 1, 2

SMF GTPC Golang Encode Decode Stats Category

`gtpc_golang_enc_dec_stats`

Description: Messages Encoded/Decoded using Golang

Sample Query: `'gtpc_golang_enc_dec_stats{gtpc_msg_type="RxModifyBearerReq"}'`

Labels:

- Label: `gtpc_msg_type`
Label Description: Gtpc Message type
Example: `NumRxEchoReq`, `NumTxEchoReq`, `NumRxEchoRes`, `NumTxEchoRes`,
`NumRxCreateSessionReq`, `NumTxCreateSessionReq`, `NumRxCreateSessionRes`, `NumTxCreateSessionRes`,
`NumRxDeleteSessionReq`, `NumTxDeleteSessionReq`, `NumRxDeleteSessionRes`, `NumTxDeleteSessionRes`,
`NumRxModifyBearerReq`, `NumTxModifyBearerReq`, `NumRxModifyBearerRes`, `NumTxModifyBearerRes`,
`NumRxDeleteBearerReq`, `NumTxDeleteBearerReq`, `NumRxDeleteBearerRes`, `NumTxDeleteBearerRes`,
`NumTxCreateBearerReq`, `NumRxCreateBearerReq`, `NumTxCreateBearerRes`, `NumRxCreateBearerRes`,
`NumTxUpdateBearerReq`, `NumRxUpdateBearerReq`, `NumTxUpdateBearerRes`, `NumRxUpdateBearerRes`,
`NumRxModifyBearerCmd`, `NumTxModifyBearerCmd`, `NumRxModifyBearerFail`,
`NumTxModifyBearerFail`, `NumRxDeleteBearerCmd`, `NumTxDeleteBearerCmd`, `NumRxDeleteBearerFail`,
`NumTxDeleteBearerFail`, `NumTxChangeNotfReq`, `NumRxChangeNotfReq`, `NumRxChangeNotfRes`,
`NumTxChangeNotfRes`, `NumRxSuspendNotf`, `NumTxSuspendNotf`, `NumRxSuspendAck`,
`NumTxSuspendAck`, `NumRxResumeNotf`, `NumTxResumeNotf`, `NumRxResumeAck`, `NumTxResumeAck`,
`NumTxReleaseAccessBearerRsp`, `NumRxReleaseAccessBearerReq`, `NumRxContextReq`,
`NumTxContextReq`, `NumRxContextAck`, `NumTxContextAck`, `NumRxDDN`, `NumTxDDN`, `NumRxIDReq`,
`NumTxIDReq`, `NumRxIDRsp`, `NumTxIDRsp`, `NumRxDDNFail`, `NumTxDDNFail`, `NumRxCreateIDFTRReq`,
`NumTxCreateIDFTRsp`, `NumRxDeletIDFTRReq`, `NumTxDeletIDFTRsp`, `NumRxBearerResCmd`
- Label: `gtpc_msg_len`

Label Description: Message Length

Example: 36, 24, 45

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: `gtpc_msg_operation`

Label Description: Operation

Example: encode, decode

- Label: `gtpc_msg_status`

Label Description: Status

Example: success, error

- Label: `gtpc_msg_status_cause`

Label Description: Error Cause

Example: HeaderDecodeFailure, ParseIEsFromPayloadFailure, MBRFromIEFailure

SMF GTPC Messages Total Category

gtpc_msg_total

Description: Total GTPC Messages

Sample Query: `'gtpc_msg_total{message_name="S5S8_MSG_CREATE_SESSION_REQUEST"}'`

Labels:

- Label: `message_name`

Label Description: Message Name

Example: S5S8_MSG_CREATE_SESSION_REQUEST, S5S8_MSG_CREATE_SESSION_RESPONSE, S5S8_MSG_MODIFY_BEARER_REQUEST, S5S8_MSG_MODIFY_BEARER_RESPONSE, S5S8_MSG_DELETE_BEARER_REQUEST, S5S8_MSG_DELETE_BEARER_RESPONSE, S5S8_MSG_DELETE_SESSION_REQUEST, S5S8_MSG_DELETE_SESSION_RESPONSE

- Label: `message_direction`

Label Description: Direction

Example: inbound, outbound

- Label: `status`

Label Description: Status

Example: no_rsp_received_tx, accepted

- Label: `transport_type`

Label Description: Transport Type

Example: origin, retransmitted

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SMF GTPC Unexpected Messages Category

`gtpc_app_total_unexpected_gtpc_msg_events`

Description: Unexpected GTPC Messages received

Sample Query: `'gtpc_app_total_unexpected_gtpc_msg_events{service_name="gtpc-ep}'`

Labels:

- Label: `message_type`

Label Description: Gtpc Message type

Example: `unexpected_gtpc_message`

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SMF GTPC Validation Fail Stats Category

`gtpc_app_validation_events`

Description: Stats of Message decode failures

Sample Query: `'gtpc_app_validation_events{service_name="gtpc-ep}'`

Labels:

- Label: `message_type`

Label Description: Gtpc Message type

Example: `csreq, csrsp, mbreq, mbrsp, cbreq, cbrsp, ubreq, ubrsp, dbreq, dbrsp, dsreq, dsrsp, mbcmd, mbcfi, dbcmd, dbcfi, ddnfi, ddnack, rabreq, upcreq`

- Label: `interface_type`
Label Description: Gtpc Interface type
Example: `sgw_ingress`, `pgw_ingress`, `S5`, `S11`, `S5E`, `S2B`, `S8`
- Label: `failure_type`
Label Description: Failure Type
Example: `msg_validation_fail`, `hdr_decode_failure`
- Label: `hdr_decode_fail_reason`
Label Description: Header Decode Fail Reason
Example: `incorrect_gtp_version`, `unsupported_message`, `incorrect_msg_len`, `invalid_msg_format`, `invalid_seq_no`, `hdr_decode_fail_reason`
- Label: `action_type`
Label Description: Action Type
Example: `discarded`, `rejected`
- Label: `reject_cause`
Label Description: Reject Cause
Example: `invalid_msg_format`, `version_not_supported`, `invalid_len`, `mandatory_ie_missing`, `conditional_ie_missing`, `mandatory_ie_incorrect`, `service_not_supported`, `imsi_imei_not_known`, `preferred_pdn_type_unsupported`, `unknown`

SMF GTPC messages Category

gtpc_app_events

Description: GTPC message counter

Sample Query: `'gtpc_app_events{service_name="gtpc-ep"}'`

Labels:

- Label: `event_type`
Label Description: Gtpc Event type
Example: `NumRxCreateSessionReq`, `NumTxCreateSessionRes`, `NumRxDeleteSessionReq`, `NumTxDeleteSessionRes`, `NumRxModifyBearerReq`, `NumTxModifyBearerRes`, `NumTxDeleteBearerReq`, `NumRxDeleteBearerRsp`, `NumTxCreateBearerReq`, `NumRxCreateBearerRes`, `NumTxUpdateBearerReq`, `NumRxUpdateBearerRes`, `NumTxModifyBearerFailureInd`, `NumModifyBearerTimeout`, `NumRxDeleteBearerCmd`, `NumCreateBearerFailure`, `NumCreateBearerSuccess`, `NumCreateSessionSuccess`, `NumCreateSessionFailure`, `NumDeleteSessionSuccess`, `NumDeleteSessionFailure`, `NumCreateBearerReqRetrans`, `NumUpdateBearerReqRetrans`, `NumDeleteBearerReqRetrans`
- Label: `interface_type`
Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: `gtpc_msg_fail_cause`

Label Description: Contains Gtpc message fail cause

Example: `send_to_service_error`, `nil_raw_response`, `unmarshal_fail`

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

SMF GTPC priority messages Category

`gtpc_app_priority_events`

Description: GTPC priority message counter

Sample Query: `'gtpc_app_priority_events{service_name="gtpc-ep"}'`

Labels:

- Label: `event_type`

Label Description: Gtpc Event type

Example: `NumRxCreateSessionReq`, `NumTxCreateSessionRes`, `NumRxDeleteSessionReq`, `NumTxDeleteSessionRes`, `NumRxModifyBearerReq`, `NumTxModifyBearerRes`, `NumTxDeleteBearerReq`, `NumRxDeleteBearerRsp`, `NumTxCreateBearerReq`, `NumRxCreateBearerRes`, `NumTxUpdateBearerReq`, `NumRxUpdateBearerRes`, `NumTxModifyBearerFailureInd`, `NumModifyBearerTimeout`, `NumRxDeleteBearerCmd`, `NumCreateBearerFailure`, `NumCreateBearerSuccess`, `NumCreateSessionSuccess`, `NumCreateSessionFailure`, `NumDeleteSessionSuccess`, `NumDeleteSessionFailure`, `NumCreateBearerReqRetrans`, `NumUpdateBearerReqRetrans`, `NumDeleteBearerReqRetrans`

- Label: `priority_msg`

Label Description: priority

Example: `true`

- Label: `interface_type`

Label Description: Gtpc Interface type

Example: S5, S11, S5E, S2B, S8

- Label: `gr_instance_id`

Label Description: GR instance ID

Example: 1, 2

UDP-Proxy Metrics Reference

UDP-Proxy BGP Routes Count Category

udp_proxy_bgp_routes_count

Description: UDP Proxy BGP routes added count

Sample Query: 'udp_proxy_bgp_routes_count{service_name="udp-proxy", status="success"}'

Labels:

- Label: `status`

Label Description: Status of message while sending or receiving

Example: success, failed

UDP-Proxy Messages Category

udp_proxy_msg_total

Description: UDP Proxy message counters being recieved or sent

Sample Query: 'udp_proxy_msg_total{message_name="radius_request", message_direction="inbound", status="success"}'

Labels:

- Label: `message_name`

Label Description: UDP messages coming via udp-proxy service

Example: radius_request, radius_response, heartbeat_request, heartbeat_response

- Label: `message_direction`

Label Description: Message being sent or being received

Example: inbound, outbound

- Label: `status`

Label Description: Status of message while sending or receiving

Example: success, failed