



About this Book

Document Revision History

The following table lists the major changes made to this document each release, with the most recent changes listed first.

| Revision | Date | Change Summary |
|-------------|-------------------|--------------------|
| OL-19129-20 | June 2017 | WSG Release 4.4.8a |
| OL-19129-19 | January 2017 | WSG Release 4.4.8 |
| OL-19129-18 | June 2016 | WSG Release 4.4.7 |
| OL-19129-17 | January 2016 | WSG Release 4.4.6 |
| OL-19129-16 | October 2015 | WSG Release 4.4.5 |
| OL-19129-15 | March 2015 | WSG Release 4.4.3 |
| OL-19129-14 | November 2014 | WSG Release 4.4.1 |
| OL-19129-13 | October 2014 | WSG Release 4.4 |
| OL-19129-12 | June 2014 | WSG Release 4.3.2 |
| OL-19129-11 | April 2014 | WSG Release 4.3 |
| OL-19129-10 | August 2013 | WSG Release 4.2 |
| OL-19129-09 | July 2012 | WSG Release 4.0 |
| OL-19129-08 | March 2012 | WSG Release 3.1 |
| OL-19129-07 | 26 September 2011 | WSG Release 3.0 |
| OL-19129-06 | 1 February 2011 | WSG Release 2.2 |
| OL-19129-05 | 28 September 2010 | WSG Release 2.1 |
| OL-19129-04 | 30 July 2010 | WSG Release 2.0 |
| OL-19129-03 | 8 February 2010 | WSG Release 1.2 |
| OL-19129-02 | 14 August 2009 | WSG Release 1.0 |

Organization

This guide includes the following sections:

| Title | Description |
|--|--|
| Chapter 1, “Learning About the WSG” | Describes the Cisco Wireless Security Gateway (WSG) and the Cisco Service and Application Module for IP (SAMI). |
| Chapter 2, “Setting Up the WSG” | Describes WSG software and hardware requirements and tells you what to do on the Supervisor (SUP) Engine and SAMI processors before using a WSG. |
| Chapter 3, “Command Reference for the WSG” | Describes how to use WSG commands. |

Conventions

This guide uses the following conventions:

| Convention | Indication |
|---------------------------|---|
| bold font | Commands and keywords and user-entered text appear in bold font . |
| <i>italic font</i> | Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> . |
| [] | Elements in square brackets are optional. |
| { x y z } | Required alternative keywords are grouped in braces and separated by vertical bars. |
| [x y z] | Optional alternative keywords are grouped in brackets and separated by vertical bars. |
| string | A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks. |
| <code>courier font</code> | Terminal sessions and information the system displays appear in <code>courier font</code> . |
| < > | Nonprinting characters such as passwords are in angle brackets. |
| [] | Default responses to system prompts are in square brackets. |
| !, # | An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line. |



Note

Means *reader take note*.



Tip

Means *the following information will help you solve a problem*.



Caution

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.

**Timesaver**

Means *the described action saves time*. You can save time by performing the action described in the paragraph.

**Warning**

Means *reader be warned*. In this situation, you might perform an action that could result in bodily injury.

Finding Related Documentation

- *Release Notes for the Cisco 7600 Wireless Security Gateway Release 4.4.8a*
- *Cisco Service and Application Module for IP Memory Upgrade Installation Note*
- *Cisco Service and Application Module for IP Guide to User Documents*
- *Cisco Service and Application Module for IP User Guide*
- Cisco 7600 Series Router platform:
 - *Release Notes for Cisco IOS Release 12.2(33)SRC3 for the Cisco 7600 Series Routers*
 - *Cisco 7600 Series Router Installation Guide*
 - *Cisco 7600 Series Router Module Installation Guide*
 - *Cisco 7600 Series Router Cisco IOS Command Reference*
 - *Cisco 7600 Series Router Cisco IOS System Message Guide*
 - Application Control Engine Module Server Load-Balancing Configuration Guide, Software Version A2(1.0)
 - Configuring File Storage and the Remote Copy Protocol (RCP), see *Cisco Service and Application Module for IP User Guide*
http://www.cisco.com/en/US/docs/interfaces_modules/services_modules/ace/v3.00_A2/configuration/slb/guide/slbgd.html
 - Configuring Load Balancing, see ACE Configuration Guide
http://www.cisco.com/en/US/docs/interfaces_modules/services_modules/ace/v3.00_A2/configuration/slb/guide/slbgd.html
 - For information about MIBs, see
<http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>

The documents are located at:

- Cisco 7600 Series Router home page on Cisco.com at:
Products & Solutions > Products > Routers and Routing Systems > 7600 Series Routers
- Cisco 7600 Series Router technical documentation on Cisco.com at:
Products & Solutions > Products > Routers and Routing Systems > 7600 Series Routers > in the Technical Documentation & Tools box on the right of the page,
Cisco 7600 Series Routers

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.