SPA8000アナログ電話アダプタのリモート管理

目的

リモート管理では、インターネット経由でリモートロケーションからSPA8000を管理できます。リモート管理では、SPA8000に直接接続されていないコンピュータから管理Webサーバにアクセスできます。この記事の目的は、SPA8000アナログ電話アダプタでリモート管理を設定する方法を説明することです。

該当するデバイス

- ・ SPA8000アナログ電話アダプタ

[Software Version]

- ・6.1.12

リモート管理の設定

ステップ1：管理者またはユーザーとしてWeb構成ユーティリティにログインし、[Advanced] > [Network] > [WAN Status]を選択します。[WAN Status]ページが開きます。

The screenshot shows the WAN Status configuration page in the SPA8000 web interface. The page has a navigation bar at the top with tabs for Status, Wan Status (selected), Lan Status, and Application. There are also links for User Login, basic, and advanced. The main content area is divided into several sections:

- Internet Connection Settings:** Connection Type: DHCP (dropdown).
- Static IP Settings:** Static IP: [text input], NetMask: [text input], Gateway: [text input].
- PPPoE Settings:** PPPOE Login Name: [text input], PPPOE Login Password: [text input], PPPOE Service Name: [text input].
- Optional Settings:** HostName: [text input], Domain: [text input], Primary DNS: [text input], Secondary DNS: [text input], DNS Server Order: Manual (dropdown), DNS Query Mode: Parallel (dropdown), Primary NTP Server: 192.168.75.172, Secondary NTP Server: [text input], DHCP IP Revalidate Timer: 0 Minutes.
- MAC Clone Settings:** Enable MAC Clone Service: no (dropdown), Cloned MAC Address: [text input].
- Remote Management:** Enable WAN Web Server: yes (dropdown), WAN Web Server Port: 80.
- VLAN Settings:** Enable VLAN: no (dropdown), VLAN ID: 1 [text input] [0x000-0xFFFF].

At the bottom of the form, there are two buttons: "Undo All Changes" and "Submit All Changes".

ステップ2:[Remote Management]セクションまでスクロールします。

Remote Management

Enable WAN Web Server: WAN Web Server Port:

VLAN Settings

ステップ3:[Enable WAN Web Server]ドロップダウンリストから[yes]を選択し、WAN Webサーバを有効にします。これにより、電話アダプタに直接接続されていないコンピュータから管理Webサーバにアクセスできます。デフォルト値はyesです。

ステップ4:[WAN Web Server Port]フィールドにWAN Webサーバポートを入力します。WAN Webサーバポートは、ATAデバイスへのWANアクセスに使用されます。デフォルト値は 80 です。

ステップ5:[Submit All Changes]をクリックして設定を保存します。