

# Como identificar produtos que suportam o SLR

## Contents

[Introdução](#)

[Pré-requisitos](#)

[Identificação de produtos que suportam o SLR](#)

[Troubleshooting](#)

[Informações Relacionadas](#)

## Introdução

Este artigo descreve o processo de identificação de produtos que suportam reserva de licença específica (SLR).

## Pré-requisitos


Nenhum.

## Identificação de produtos que suportam o SLR

### Passo 1:

Vá para a página [Cisco Smart Licensing](#) e clique em **Famílias de produtos habilitadas para Smart Licensing**.

**Resultado da etapa:** o sistema baixa automaticamente o **arquivo Smart Licensing Feature Roadmap** para o seu computador.



## A new way to think about licensing

Use your Smart License with a Smart Account  
A Smart Account allows you to centrally organize and specific license agreements based on your

**Cisco Smart Software Manager (CSSM)**  
CSSM is an intuitive portal where you can activate Cisco licenses. An On-Prem version is available for customers.

[Product Docs](#) [Benefits](#) [Deployment](#) [Resources](#)

## View Smart License documentation by product

Choose product family: --

[Smart Licensing Enabled Product Families](#) - XLS Download

### Passo 2:

Abra o arquivo **Smart Licensing Feature Roadmap**, localize as colunas **SLR** ou **SLR Factory Pre-Install** e identifique se o produto para o qual você precisa executar a reserva de licença específica suporta esse recurso. Verifique também quais versões do sistema operacional (SO) são suportadas.

	A	K	L	M	N	O	P	Q	
	Product Family	SLR	SLR Factory Pre-Install	SLR Enforcement	CSSM On-Prem Supported (y/n)	Evaluation Mode	Initial Unidentified	Out of Compliance @ Initial Registration	
1	Adaptive Security Virtual Appliance (ASAv)	No	No	N/A	Yes	Prior to ASA version 9.14(1) Throughput throttled to 100 Kbps ASA version 9.14(1) and beyond. Throughput throttled to 100 Kbps	Prior to ASA version 9.14(1) Throughput throttled to 100 Kbps ASA version 9.14(1) and beyond. Throughput throttled to 100 Kbps	Prior to ASA version 9.14(1) Normal Functionality. Syslog/Alarm Notifications. ASA version 9.14(1) and beyond. Normal Functionality. Syslog/Alarm Notifications.	
2	Aggregation Services Router (ASR 901)	No	No	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
3	Aggregation Services Router (ASR 902)	No	No	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
4	Aggregation Services Router (ASR 903)	No	No	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
5	Aggregation Services Router 1000 (ASR 1000)	Yes, 16.11.1	Yes, 16.12.1 and above	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
6	Aggregation Services Router 9000 eXR	Yes	No	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
7	Aggregation Services Router 920 (ASR 920)	No	No	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
8	Aggregation Services Router Next NG (ASR-NG)	No	No	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
9	Aggregation Services Routers (ASR 9000)	Yes	No	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
10	Application Centric Infrastructure (ACI)	No	No	N/A	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
11	Catalyst 3650 Series Switches	Yes, 16.9.1	Yes, 16.9.1 and above	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
12	Catalyst 3850 Series Switches	Yes, 16.9.1	Yes, 16.9.1 and above	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
13	Catalyst 9200 MODULAR	Yes, 16.9.1	Yes, Available in all version	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
14	Catalyst 9200L FIXED	Yes, 16.9.1	Yes, Available in all version	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
15	Catalyst 9300	Yes, 16.9.1	Yes, 16.9.1 and above	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
16	Catalyst 9300 Fiber	Yes, 16.12.1	Yes, 16.9.1 and above	No	Yes	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	Normal functionality. syslog/alarm notifications.	
17									

## Troubleshooting

Se você tiver algum problema durante o processo de identificação de produtos que suportam o SLR, abra um caso [noSupport Case Manager \(SCM\)](#).

## Informações Relacionadas

[Como ativar o SLR pré-instalado de fábrica em uma Smart Account](#)

[Como identificar se a Smart Account está ativada para o SLR](#)

[Como obter o código de solicitação de reserva](#)

[Como instalar o código de autorização em um dispositivo](#)

[Como reservar licenças \(SLR\)](#)

[Como atualizar a reserva de licença \(SLR\)](#)

[Como transferir uma instância de produto \(SLR\)](#)

[Como transferir licenças entre Virtual Accounts \(SLR\)](#)

[Como hospedar novamente licenças de um produto com falha \(SLR\)](#)

[Como obter o código de retorno da reserva](#)

[Como remover uma instância de produto \(SLR\)](#)

Sobre esta tradução

A Cisco traduziu este documento com a ajuda de tecnologias de tradução automática e humana para oferecer conteúdo de suporte aos seus usuários no seu próprio idioma, independentemente da localização.

Observe que mesmo a melhor tradução automática não será tão precisa quanto as realizadas por um tradutor profissional.

A Cisco Systems, Inc. não se responsabiliza pela precisão destas traduções e recomenda que o documento original em inglês ([link fornecido](#)) seja sempre consultado.