

Configurando um Cisco 6400 para suporte a MUX-PPP, SNAP e utilização de uma subinterface atm ilmi-pvc-discovery

Índice

[Introdução](#)

[Pré-requisitos](#)

[Requisitos](#)

[Componentes Utilizados](#)

[Convenções](#)

[Configurar](#)

[Configuração](#)

[Verificar](#)

[Troubleshooting](#)

[Comandos para Troubleshooting](#)

[Informações Relacionadas](#)

[Introdução](#)

Este documento descreve uma configuração de exemplo para um concentrador de acesso universal (UAC) do Cisco 6400 que apoie o MUX-PPP e o protocolo de acesso de sub-rede de comunicação (PRESSÃO) e use uma subinterface da ILMI-PVC-descoberta atm.

[Pré-requisitos](#)

[Requisitos](#)

Não existem requisitos específicos para este documento.

[Componentes Utilizados](#)

Este documento não se restringe a versões de software e hardware específicas.

As informações neste documento foram criadas a partir de dispositivos em um ambiente de laboratório específico. Todos os dispositivos utilizados neste documento foram iniciados com uma configuração (padrão) inicial. Se a sua rede estiver ativa, certifique-se de que entende o impacto potencial de qualquer comando.

[Convenções](#)

Para obter mais informações sobre convenções de documento, consulte as [Convenções de dicas técnicas Cisco](#).

Configurar

Nesta seção, você encontrará informações para configurar os recursos descritos neste documento.

Note: Para localizar informações adicionais sobre os comandos usados neste documento, utilize a Ferramenta Command Lookup (somente clientes [registrados](#)).

Configuração

Este documento utiliza esta configuração:

Cisco 6400 NRP1

```
!  
version 12.0  
no service pad  
service timestamps debug datetime msec  
service timestamps log datetime msec  
no service password-encryption  
!  
hostname Access-6400-NRP1  
!  
enable password <password>  
!  
username <username> password 0 <password>  
username <username1> password 0 <password1>  
username <username2> password 0 <password2>  
!  
!  
!  
!  
redundancy  
  main-cpu  
    auto-sync standard  
  no secondary console enable  
ip subnet-zero  
ip domain-name cisco.com  
ip name-server 171.68.10.70  
!  
!  
!  
bridge irb  
!  
!  
process-max-time 200  
!  
interface Loopback1  
  ip address 10.1.1.1 255.255.255.0  
  no ip directed-broadcast  
!  
interface ATM0/0/0  
  no ip address  
  no ip directed-broadcast  
  no atm ilmi-keepalive
```

```

atm ilmi-pvc-discovery subinterface
pvc 0/16 ilmi
!
!
interface ATM0/0/0.1 multipoint
  !--- For VPI starting with number 1 (example: 1/34). no
ip directed-broadcast class-int bridgel bridge-group 1 !
interface ATM0/0/0.4 multipoint !--- For VPI starting
with number 4 (example: 4/33). no ip directed-broadcast
class-int router ! interface Ethernet0/0/1 no ip address
no ip directed-broadcast ! interface Ethernet0/0/0 ip
address 171.68.186.117 255.255.255.240 no ip directed-
broadcast ! interface FastEthernet0/0/0 no ip address no
ip directed-broadcast shutdown ! interface Virtual-
Templatel ip unnumbered Loopback1 no ip directed-
broadcast peer default ip address pool mypool ppp
authentication chap ! interface BVI1 mac-address ip
address 10.10.33.1 255.255.255.0 no ip directed-
broadcast ! ip local pool mypool 10.1.1.2 10.1.1.200 ip
classless ip route 0.0.0.0 0.0.0.0 171.68.186.113 no ip
http server ! ! vc-class atm bridgel encapsulation
aal5snap ! vc-class atm router encapsulation aal5mux ppp
Virtual-Templatel tacacs-server host 171.68.201.249
tacacs-server last-resort succeed tacacs-server
optional-passwords tacacs-server extended ! bridge 1
protocol ieee bridge 1 route ip ! line con 0 transport
input none line aux 0 line vty 0 4 password xxxxxx login
local ! end

```

Verificar

Esta seção fornece informações que você pode usar para confirmar se sua configuração está funcionando adequadamente.

A [Output Interpreter Tool \(somente clientes registrados\)](#) oferece suporte a determinados comandos show, o que permite exibir uma análise da saída do comando show.

Saída do comando show atm pvc

```

Access-6400-NRP1# show atm pvc
      VCD /                Peak Avg/Min Burst
Interface Name  VPI  VCI  Type  Encaps  SC  Kbps  Kbps  Cells  Sts
0/0/0          2    0   16   PVC     ILMI  UBR  155000
0/0/0.1        7    1   34   PVC-D   SNAP  UBR  155000
!--- Snap (bridge). !--- Subinterface 1 took VPI . 0/0/0.4 8 4 33 PVC-D MUX UBR 155000 UP !---
mux (ppp) !--- Subinterface 4 took VPI 4.

```

Troubleshooting

Esta seção fornece informações que podem ser usadas para o troubleshooting da sua configuração.

Comandos para Troubleshooting

A [Output Interpreter Tool \(somente clientes registrados\)](#) oferece suporte a determinados comandos show, o que permite exibir uma análise da saída do comando show.

Note: [Antes de emitir comandos de depuração, consulte as informações importantes sobre eles.](#)

Depurando eventos ATM

A seguinte saída mostra o identificador de caminho virtual/identificador de canal virtual (VPI/VCI) que o processador da rota de nó (NRP) aprende do processador de switch de nó (NSP).

```
Access-6400-NRP1# debug atm events
ATM events debugging is on

Shut/no Shut on main ATM0/0/0 interface
Access-6400-NRP1#
*Dec 16 15:51:43.667: ATM0/0/0 nrp_sarmgr_shutdown: state=0
*Dec 16 15:51:44.515: Resetting ATM0/0/0
*Dec 16 15:51:45.015: Resetting ATM0/0/0
*Dec 16 15:51:45.015: nrp_sarmgr_config(ATM0/0/0)
*Dec 16 15:51:45.015: nrp_sarmgr_enable(ATM0/0/0)
*Dec 16 15:51:45.215: nrp_sarmgr_enable(ATM0/0/0): restarting VCs: 0
*Dec 16 15:51:45.215: nrp_sarmgr_setup_vc(ATM0/0/0): vc:2 vpi:0 vci:16
*Dec 16 15:51:45.223: %SYS-5-CONFIG_I: Configured from console by console
*Dec 16 15:51:45.667: %LINK-3-UPDOWN: Interface ATM0/0/0, changed state to up
*Dec 16 15:51:46.667: %LINEPROTO-5-UPDOWN: Line protocol on Interface ATM0/0/0,
  changed state to up
*Dec 16 15:51:47.219: %LINK-3-UPDOWN: Interface BV11, changed state to up
*Dec 16 15:51:47.471: Reserved bw for 1/34 Available bw = 155000
*Dec 16 15:51:47.471: nrp_sarmgr_setup_vc(ATM0/0/0): vc:13 vpi:1 vci:34
*Dec 16 15:51:47.475: Reserved bw for 4/33 Available bw = 155000
*Dec 16 15:51:47.527: nrp_sarmgr_setup_vc(ATM0/0/0): vc:14 vpi:4 vci:33
*Dec 16 15:51:48.219: %LINEPROTO-5-UPDOWN: Line protocol on Interface BV11,
  changed state to up
*Dec 16 15:51:49.019: nrp_sarmgr_tearardown_vc(ATM0/0/0): vc:13 vpi:1 vci:34
*Dec 16 15:51:49.179: nrp_sarmgr_tearardown_vc(ATM0/0/0): vc:14 vpi:4 vci:33
*Dec 16 15:51:49.339: PPP-ATM(Virtual-Access1) deleting vaccess on VC 14
*Dec 16 15:51:49.351: %LANE-6-INFO: ATM0/0/0: ILMI prefix add event received
*Dec 16 15:51:49.659: Reserved bw for 1/34 Available bw = 155000
*Dec 16 15:51:49.659: nrp_sarmgr_setup_vc(ATM0/0/0): vc:15 vpi:1 vci:34
*Dec 16 15:51:49.659: Reserved bw for 4/33 Available bw = 155000
*Dec 16 15:51:49.715: nrp_sarmgr_setup_vc(ATM0/0/0): vc:16 vpi:4 vci:33
*Dec 16 15:51:55.419: %LINK-3-UPDOWN: Interface Virtual-Access1, changed state to up
Access-6400-NRP1#
```

Saída de Depuração PPP para Cisco 675 no IP Routing Mode

```
Access-6400-NRP1# debug atm events
ATM events debugging is on

Shut/no Shut on main ATM0/0/0 interface
Access-6400-NRP1#
*Dec 16 15:51:43.667: ATM0/0/0 nrp_sarmgr_shutdown: state=0
*Dec 16 15:51:44.515: Resetting ATM0/0/0
*Dec 16 15:51:45.015: Resetting ATM0/0/0
*Dec 16 15:51:45.015: nrp_sarmgr_config(ATM0/0/0)
*Dec 16 15:51:45.015: nrp_sarmgr_enable(ATM0/0/0)
*Dec 16 15:51:45.215: nrp_sarmgr_enable(ATM0/0/0): restarting VCs: 0
*Dec 16 15:51:45.215: nrp_sarmgr_setup_vc(ATM0/0/0): vc:2 vpi:0 vci:16
*Dec 16 15:51:45.223: %SYS-5-CONFIG_I: Configured from console by console
*Dec 16 15:51:45.667: %LINK-3-UPDOWN: Interface ATM0/0/0, changed state to up
*Dec 16 15:51:46.667: %LINEPROTO-5-UPDOWN: Line protocol on Interface ATM0/0/0,
  changed state to up
*Dec 16 15:51:47.219: %LINK-3-UPDOWN: Interface BV11, changed state to up
```

```

*Dec 16 15:51:47.471: Reserved bw for 1/34 Available bw = 155000
*Dec 16 15:51:47.471: nrp_sarmgr_setup_vc(ATM0/0/0): vc:13 vpi:1 vci:34
*Dec 16 15:51:47.475: Reserved bw for 4/33 Available bw = 155000
*Dec 16 15:51:47.527: nrp_sarmgr_setup_vc(ATM0/0/0): vc:14 vpi:4 vci:33
*Dec 16 15:51:48.219: %LINEPROTO-5-UPDOWN: Line protocol on Interface BV11,
  changed state to up
*Dec 16 15:51:49.019: nrp_sarmgr_teardown_vc(ATM0/0/0): vc:13 vpi:1 vci:34
*Dec 16 15:51:49.179: nrp_sarmgr_teardown_vc(ATM0/0/0): vc:14 vpi:4 vci:33
*Dec 16 15:51:49.339: PPP-ATM(Virtual-Access1) deleting vaccess on VC 14
*Dec 16 15:51:49.351: %LANE-6-INFO: ATM0/0/0: ILMI prefix add event received
*Dec 16 15:51:49.659: Reserved bw for 1/34 Available bw = 155000
*Dec 16 15:51:49.659: nrp_sarmgr_setup_vc(ATM0/0/0): vc:15 vpi:1 vci:34
*Dec 16 15:51:49.659: Reserved bw for 4/33 Available bw = 155000
*Dec 16 15:51:49.715: nrp_sarmgr_setup_vc(ATM0/0/0): vc:16 vpi:4 vci:33
*Dec 16 15:51:55.419: %LINK-3-UPDOWN: Interface Virtual-Access1, changed state to up
Access-6400-NRP1#

```

saída do comando show

```
Access-6400-NRP1# show user
```

Line	User	Host(s)	Idle	Location
* 0	con 0	idle	00:00:00	
Vil		Virtual PPP (ATM)	00:06:45	
Interface	User	Mode	Idle	Peer Address

```
Access-6400-NRP1# show interface atm 0/0/0 accounting
```

```
ATM0/0/0
Protocol      Pkts In   Chars In  Pkts Out  Chars Out
Trans. Bridge      0         0         3         222
Spanning Tree      0         0        1384      65048
PPP over ATM      358      6646         605      11657
```

```
Access-6400-NRP1# show interface atm 0/0/0
```

```

ATM0/0/0 is up, line protocol is up
Hardware is ATM-SAR
MTU 4470 bytes, sub MTU 4470, BW 156250 Kbit, DLY 80 usec,
  reliability 255/255, txload 1/255, rxload 1/255
Encapsulation ATM, loopback not supported
Keepalive not supported
Encapsulation(s): AAL5, PVC mode
2047 maximum active VCs, 3 current VCCs
VC idle disconnect time: 300 seconds
Last input 00:09:37, output 00:00:00, output hang never
Last clearing of "show interface" counters never
Queueing strategy: fifo
Output queue 0/40, 0 drops; input queue 0/75, 0 drops
5 minute input rate 0 bits/sec, 0 packets/sec
5 minute output rate 0 bits/sec, 0 packets/sec
  1307 packets input, 57832 bytes, 0 no buffer
  Received 0 broadcasts, 0 runts, 0 giants, 0 throttles
  0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
  2876 packets output, 123055 bytes, 0 underruns
  0 output errors, 0 collisions, 3 interface resets
  0 output buffer failures, 0 output buffers swapped out
Access-6400-NRP1#
Access-6400-NRP1#
Access-6400-NRP1#

```

```
Access-6400-NRP1# show interface atm 0/0/0.1
```

```
ATM0/0/0.1 is up, line protocol is up
```

```
Hardware is ATM-SAR
MTU 4470 bytes, BW 156250 Kbit, DLY 80 usec,
  reliability 255/255, txload 1/255, rxload 1/255
Encapsulation ATM
0 packets input, 0 bytes
1392 packets output, 59937 bytes
0 OAM cells input, 0 OAM cells output
```

```
Access-6400-NRP1# show interface atm 0/0/0.4
```

```
ATM0/0/0.4 is up, line protocol is up
Hardware is ATM-SAR
MTU 4470 bytes, BW 156250 Kbit, DLY 80 usec,
  reliability 255/255, txload 1/255, rxload 1/255
Encapsulation ATM
705 packets input, 11705 bytes
615 packets output, 9415 bytes
0 OAM cells input, 0 OAM cells output
```

```
Access-6400-NRP1# show atm vc 15
```

```
ATM0/0/0.1: VCD: 15, VPI: 1, VCI: 34
UBR, PeakRate: 155000
AAL5-LLC/SNAP, etype:0x0, Flags: 0xC20, VCmode: 0x0
OAM frequency: 0 second(s)
InARP frequency: 15 minutes(s)
InPkts: 0, OutPkts: 321, InBytes: 0, OutBytes: 13803
InPRoc: 0, OutPRoc: 321, Broadcasts: 0
InFast: 0, OutFast: 0, InAS: 0, OutAS: 0
OAM cells received: 0
OAM cells sent: 0
Status: UP
Access-6400-NRP1#
```

```
Access-6400-NRP1# show atm vc 16
```

```
ATM0/0/0.4: VCD: 16, VPI: 4, VCI: 33
UBR, PeakRate: 155000
AAL5-MUX, etype:0x9, Flags: 0xC23, VCmode: 0x0
OAM frequency: 0 second(s)
InARP DISABLED
InPkts: 6, OutPkts: 143, InBytes: 48, OutBytes: 2420
InPRoc: 3, OutPRoc: 143
InFast: 0, OutFast: 0, InAS: 3, OutAS: 0
OAM cells received: 0
OAM cells sent: 0
Status: UP
PPP: Virtual-Access1 from Virtual-Templat1
Access-6400-NRP1#
```

```
Access-6400-NRP1# show interface virtual-access 1
```

```
Virtual-Access1 is up, line protocol is down
Hardware is Virtual Access interface
Interface is unnumbered. Using address of Loopback1 (10.1.1.1)
MTU 1500 bytes, BW 100000 Kbit, DLY 100000 usec,
  reliability 255/255, txload 1/255, rxload 1/255
Encapsulation PPP, loopback not set
Keepalive set (10 sec)
DTR is pulsed for 5 seconds on reset
LCP REQsent
Closed: IPCP
Bound to ATM0/0/0.4 VCD: 16, VPI: 4, VCI: 33
Cloned from virtual-template: 1
```

Last input 00:12:07, output never, output hang never
Last clearing of "show interface" counters 00:12:18
Queueing strategy: fifo > Output queue 0/40, 0 drops; input queue 0/75, 0 drops
5 minute input rate 0 bits/sec, 0 packets/sec
5 minute output rate 0 bits/sec, 0 packets/sec
3 packets input, 18 bytes, 0 no buffer
Received 0 broadcasts, 0 runts, 0 giants, 0 throttles
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
158 packets output, 2675 bytes, 0 underruns
0 output errors, 0 collisions, 0 interface resets
0 output buffer failures, 0 output buffers swapped out
0 carrier transitions
Access-6400-NRP1#

[Informações Relacionadas](#)

- [Suporte técnico DSL](#)
- [Suporte de Produto](#)
- [Suporte Técnico - Cisco Systems](#)