

Faça login no Voiceview Express nos telefones IP SPA300/500 Series usando teclas de função

Objetivo

O VoiceView Express permite que os usuários naveguem, escutem, enviem mensagens e gerenciem suas mensagens de correio de voz a partir da interface do telefone.


Este documento explica como fazer login no voiceview express nos telefones IP SPA300 e SPA500 Series usando os botões de teclas virtuais.

Dispositivos aplicáveis


Telefones IP SPA300 Series
Telefones IP SPA500 Series

Fazer login no VoiceView Express


Etapa 1. Pressione o botão Setup (Configuração).



Etapa 2. Empurre a tecla virtual para Serviços CME.



Etapa 3. Pressione a tecla virtual do Voiceview Express.



VoiceView Express Login

Mailbox ID: XXX

PIN: ****

Enter Required Information

Submit << Clear Cancel

The image shows a login interface with a light blue background. At the top is a title bar with the text 'VoiceView Express Login' and a small icon of a telephone handset. Below this are two input fields: the first is labeled 'Mailbox ID: XXX' and the second is labeled 'PIN: ****'. To the right of these fields is a vertical bar with two telephone handset icons. Below the input fields is a section titled 'Enter Required Information'. At the bottom are four buttons: 'Submit', '<<', 'Clear', and 'Cancel'.

Etapa 4. Insira a ID da caixa de correio e o PIN nos campos.

Etapa 5. Pressione a tecla virtual em Enviar.