

SPA922持续重新启动

Contents

[Introduction](#)

[如何从重新启动终止SPA922 ?](#)

[Related Information](#)

Introduction

本文是一系列协助设置、排错和维护Cisco小型企业产品文档中的一篇。

Refer to [Cisco Technical Tips Conventions](#) for more information on document conventions.

Q. 如何从重新启动终止SPA922 ?

A. 如果SPA922继续重新启动，损坏的固件可以是原因。切记您使用最新的固件。检查此发现是否是：

Info | [System](#) | [SIP](#) | [Provisioning](#) | [Regional](#) | [Phone](#) | [Ext. 1](#) | [Ext. 2](#) | [User](#) | [User Login](#) | [basic](#) | [Advanced](#)
[Personal Directory](#) | [Call History](#)

System Information			
DHCP:	Static IP	Current IP:	10.10.10.78
Host Name:	SipuraSPA	Domain:	
Current Netmask:		Current Gateway:	10.10.10.1
Primary DNS:			
Secondary DNS:			
Product Information			
Product Name:	SPA922	Serial Number:	88019FA27084
Software Version:	5.2.5	Hardware Version:	1.0.0(279f)
MAC Address:	000200D0404F	Client Certificate:	Installed
Customization:	Open	Licenses:	None

Software Version is also the Firmware Version

点击此处关于关于如何的说明升级SPA922的[固件](#)。

Related Information

- [Technical Support & Documentation - Cisco Systems](#)