

创建或加入ESAs对集群，不用PTR记录

目录

[简介](#)

[先决条件](#)

[背景信息](#)

[配置](#)

简介

本文描述，当思科电子邮件安全工具(ESA)体验“如何计时了”错误，当尝试创建或参加集群，如果DNS命名指针(PTR)记录不是可用的，和到应急方案问题。

先决条件

本文档中的信息基于以下软件和硬件版本：

- 电子邮件安全版本8.0和以上的AsyncOS

背景信息

当使用团星通信安全性(CSS)时或安全壳SSH参加集群用IP地址，PTR记录要求，否则ESA将提示“被计时的”错误，并且集群加入将发生故障。

当DNS记录更改可能不可能或允许为了适当地创建PTR记录时，有时期。

以下情况可能应用：

- 设备的IP地址使用内部IP地址
- 没有两个设备的PTR记录
- 根DNS或本地DNS不能解析两本地主机主机名
- 不可能编辑或修改根DNS或本地DNS
- 端口22 (SSH)和端口2222 (CSS)在两边打开
- 获得“计时了”在两边的错误
- 不能配置在根DNS的NXDOMAIN那些IP地址的

配置

有使用本地ESA的应急方案，当DNS来源。从设备CLI，请添加本地DNS解决方法。例如，如果有设备esa1.example.com (192.168.10.1)和(192.168.10.2) PTR记录不可以是解决的esa2.example.com执行以下：

```
esa1.example.com> dnsconfig
```

Choose the operation you want to perform:

- NEW - Add a new server.
- EDIT - Edit a server
- DELETE - Remove a server
- SETUP - Configure general settings.

[> new

Currently using the local DNS cache servers:

1. Priority: 0 192.168.1.53

Do you want to add a new local DNS cache server or an alternate domain server?

1. Add a new local DNS cache server.
2. Add a new alternate domain server.

[> 2

Please enter the domain this server is authoritative for. (Ex: "com").

[> 2.10.168.192.in-addr.arpa [enter the in-addr-arpa which serves as PTR, in this example for esa2]

Please enter the fully qualified hostname of the DNS server for the domain

"1.10.10.10.in-addr.arpa".

(Ex: "dns.example.168.192.in-addr.arpa").

[> esa1.example.com [enter the hostname of the ESA you are configuring this on]

Please enter the IP address of machinea.example.com.

[> 192.168.10.1 [enter the IP of the ESA you are configuring this on]

esa2.example.com> dnsconfig

Choose the operation you want to perform:

- NEW - Add a new server.
- EDIT - Edit a server
- DELETE - Remove a server
- SETUP - Configure general settings.

[> new

Currently using the local DNS cache servers:

1. Priority: 0 192.168.1.53

Do you want to add a new local DNS cache server or an alternate domain server?

1. Add a new local DNS cache server.
2. Add a new alternate domain server.

[> 2

Please enter the domain this server is authoritative for. (Ex: "com").

[> 1.10.168.192.in-addr.arpa [enter the in-addr-arpa which serves as PTR, in this example esa1]

Please enter the fully qualified hostname of the DNS server for the domain

"1.10.10.10.in-addr.arpa".

(Ex: "dns.example.168.192.in-addr.arpa").

[> esa2.example.com [enter the hostname of the ESA you are configuring this on]

Please enter the IP address of machinea.example.com.

[> 192.168.10.2 [enter the IP of the ESA you are configuring this on]

点击<enter>，直到您达到主要提示并且运行进行保存和激活配置更改。

Note:在上述示例中，为请输入的以上域输入此服务器是授权为逆向DNS查找或IP地址192.168.10.1和192.168.10.2的域。确定IP地址在esa1.example.com和esa2.example.com配

置和可及的。