

在ESW2-550X交换机的系统设置

客观

交换机的基本信息例如系统说明，位置和联系为用户提供信息与关于协助的一个管理员联系用交换机。

此条款说明如何配置主机名-，位置和登录标识在ESW2-550X可堆叠的被管理的交换机。

可适用的设备

- ESW2-550X
- ESW2-550X-DC

软件版本

- v1.2.9.44

系统设置

步骤1. 登录到Web配置工具并且选择**管理>System设置**。系统设置页打开：

The screenshot displays the 'System Settings' configuration page. At the top, the title is 'System Settings'. Below it, the 'System Description' is '48-Port Gigabit with 4-Port 10-Gigabit Stackable Managed Switch'. The 'System Location' field contains 'SouthWest' with a character count of '(9/160 Characters Used)'. The 'System Contact' field contains 'Admin123' with a character count of '(8/160 Characters Used)'. Under 'Host Name', the 'Use Default' radio button is selected, and the 'User Defined' option is disabled. The 'Custom Login Screen Settings' section has a 'Login Banner' text area that is currently empty, with a character count of '(0/1000 Characters Used)'. At the bottom of the form, there are 'Apply' and 'Cancel' buttons.

步骤2. 输入设备的位置在System Location字段。

步骤3. 输入用户(admin)的名字接触，如果任何更改在System Contact字段的设备发生。

System Settings

System Settings

System Description: 48-Port Gigabit with 4-Port 10-Gigabit Stackable Managed Switch

System Location: (9/160 Characters Used)

System Contact: (8/160 Characters Used)

Host Name: Use Default
 User Defined (5/58 Characters Used, Default: switch8e5305)

Custom Login Screen Settings

Login Banner: (35/1000 Characters Used)

步骤4. 点击在主机名字段的期望单选按钮。可用的选项是：

- 使用默认值—保持默认主机名。
- 用户定义—进入期望主机名-在用户定义域。

登录标识用于通知管理员提供的重要信息。

步骤5. 送进登录标识在登录标识字段。在登录标识字段输入的详细资料在登录画面显示。

第6.步(可选)看到登录标识的预览，点击**预览**。交换机的 *Web配置工具* 登录页打开：

© 2010-2012 Cisco Systems, Inc. All Rights Reserved.
 Cisco, Cisco Systems, and the Cisco Systems logo are registered trademarks or trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

按ESC键返回到系统设置页。

System Settings

System Settings

System Description: 48-Port Gigabit with 4-Port 10-Gigabit Stackable Managed Switch

System Location: (9/160 Characters Used)

System Contact: (8/160 Characters Used)

Host Name: Use Default
 User Defined (5/58 Characters Used, Default: switch8e5305)

Custom Login Screen Settings

Login Banner:

(35/1000 Characters Used)

步骤7. 点击**适用**保存设置。