

# 访问SPA500系列IP电话上的基于Web的设置页

## 目标

所有设备都具有内置的设置页面，允许用户自定义设置并设置设备中的高级属性。设置页面可轻松配置设备的功能。本文档显示如何访问SPA500系列IP电话的设置页。

## 适用设备

·SPA 500系列IP电话

## 访问SPA设备设置页面的步骤。

**注意：**尽管本文也适用于所有SPA 500系列IP电话，但使用的设备是SPA509G。

**注意：**在访问SPA509G的设置页之前，请确保设备通过其SW端口连接到启用PoE（以太网供电）的路由器或交换机。

### 访问SPA509G的设置页

步骤1. IP电话打开后，会执行网络配置和设置配置。完成网络配置后，按“Setup（设置）”按钮（上面是纸质符号），如图所示。



步骤2.这将在IP电话的LCD上显示“设置”菜单，其中包含不同的选项。



步骤3.按3。这将在液晶屏上显示“设置”菜单。



步骤4.按5。这将打开液晶屏上的“网络配置”菜单。

步骤5.向下导航至选项3或按3。请注意，IP地址显示在“IP地址”下方。

步骤6.转到Web浏览器并输入IP地址。

**注意：**计算机和IP电话应位于同一网络上才能访问基于Web的实用程序。

192.168.137.162

Small Business  
cisco SPA509G Configuration Utility

Admin Login basic | advanced

Voice Call History Personal Directory Attendant Console Status

Info System Phone User

**System Information**

Connection Type:	DHCP	Current IP:	192.168.137.162
Host Name:	SEPC89C1D6E6F6F	Domain:	mshome.net
Current Netmask:	255.255.255.0	Current Gateway:	192.168.137.1
Primary DNS:	192.168.137.1		
Secondary DNS:			

**Product Information**

Product Name:	SPA509G	Serial Number:	CBT151508BR
Software Version:	7.4.8a	Hardware Version:	1.0.2(0001)
MAC Address:	C89C1D6E6F6F	Client Certificate:	Installed
Customization:	Open	Licenses:	None

**Phone Status**

Current Time:	1/1/2003 14:27:55	Elapsed Time:	02:13:56
Broadcast Pkts Sent:	21	Broadcast Bytes Sent:	2138
Broadcast Pkts Recv:	353	Broadcast Bytes Recv:	36800

Undo All Changes Submit All Changes

© 2009 Cisco Systems, Inc. All Rights Reserved. SPA509G IP Phone

步骤7.将显示基于Web的设置实用程序。如果没有显示，则计算机和IP电话可能未连接到同一网络。从计算机ping IP电话的IP地址以检查连接。