



*Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).*

## CHAPTER 11

# N Commands

---

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. Please see the Command Mode section to determine the appropriate mode for each command. For more information, see the *Cisco MDS 9000 Family Configuration Guide*.

- ntp

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

## ntp

To configure NTP settings on the switch, use the **ntp** command.

**ntp {peer *hostname* | server | tstamp-check}**

Syntax Description		
<b>peer</b> <i>hostname</i>	The hostname/IP address of the NTP peer (Max Size - 80).	
<b>server</b>	The hostname/IP address of the NTP server (Max Size - 80).	
<b>tstamp-check</b>	Enables or disables Riviera Timestamp Check.	

**Defaults** This command has no default settings.

**Command Modes** Configuration.

**Usage Guidelines** None.

**Examples** This example forms a server association with a server.

```
switch(config)# ntp server 10.10.10.10
switch(config)#
```

This example forms a peer association with a peer. You can specify multiple associations.

```
switch(config)# ntp peer 10.20.10.0
switch(config)#
```