



Send documentation comments to mdsfeedback-doc@cisco.com.

CHAPTER 20

U Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. See the “Command Modes” section to determine the appropriate mode for each command. For more information, refer to the *Cisco MDS 9000 Family Configuration Guide*.

- [use-profile](#), page 20-2
- [username](#), page 20-3

Send documentation comments to mdsfeedback-doc@cisco.com.

use-profile

To bind a profile to the FCIP interface, use the **use-profile** option. To disable a configured profile, use the **no** form of the option.

use-profile *profile-id*

no use-profile *profile-id*

Syntax Description	Command	Description
	use-profile	Configures the interface using an existing profile.
	<i>profile-id</i>	Enters the profile ID to be used from 1 to 255.

Defaults None.

Command Modes Configuration mode

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines Access this command from the `switch(config-if)#` submode.
Binds the profile with the FCIP interface.

Examples

```
switch# config t
switch(config)# interface fcip 50
switch(config-if)# use-profile 100
switch(config-if)# no use-profile 100
```

Related Commandss	Command	Description
	show interface fcip	Displays an interface configuration for a specified FCIP interface.
	show fcip	Displays information about the FCIP profile.

Send documentation comments to mdsfeedback-doc@cisco.com.

username

To define a user, use the **username** command in configuration mode.

```
username name [expire date] [role string] [update-snmpv3]
```

```
username string [password [0 | 5 user-password] [expire string] [role]=
```

Syntax Description

expire	Date when this user account expires (in YYYY-MM-DD format).
password	Password for the user.
role	Role which the user is to be assigned
update-snmpv3	Update SNMPv3 password also (provide old SNMPv3 password)
<i>name</i>	The name of the user. Maximum length is 32 characters.
<i>date</i>	The expiration date.
<i>string</i>	The role.
<i>user-password</i>	The password. Maximum length is 32 characters.
0	Password for the user (clear text)
5	Strongly encrypted password

Defaults

None.

Command Modes

Configuration mode.

Command History

This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines

None.

Examples

The following example shows how to define a user.

```
switch(config)# username knuckles password testpw role bodega
switch(config)# end
Jan 12 16:05:33 vshd: <<%LOG_VSHD-5-VSHD_SYSLOG_CONFIG_I>> Configuring console)

switch# show user-account
user:admin
    this user account has no expiry date
    roles:network-admin

user:knuckles
    this user account has no expiry date
    roles:bodega
```

■ username

Send documentation comments to mdsfeedback-doc@cisco.com.