



Initial Configuration Commands

```
switchname myswitch1
no switchname
snmp-server
no snmp-server
snmp-server contact NewUser
no snmp-server contact NewUser
snmp-server location SanJose
no snmp-server location SanJose
snmp-server name NewName
no snmp-server name NewName
show module
clock set <HH:MM:SS> <DD> <Month in words> <YYYY>
clock timezone
show timezone
clock summer-time
no clock summer-time
ntp timestamp-check 1
ntp server ipaddr
copy running-config startup-config
interface
ip address
no shutdown
show interface command.
ip default-gateway 1.1.1.4
no telnet server enable
telnet server enable
show running-config
show startup-config command:
copy <scheme> :// <server address> system: running-config
copy <scheme>://<url> nvram:startup-config
dir
cd
pwd
delete
```

