



## INDEX

---

### Symbols

\* (asterisk)

- autolearned entries [46-21](#)
- port security wildcard [46-17](#)
- port security wildcards [46-17](#)

---

### Numerics

- 12-port 4-Gbps switching modules
  - BB\_credit buffers [22-12](#)
  - configuration guidelines [22-20](#)
  - default settings [22-31](#)
  - See also switching modules
- 16-port switching modules
  - configuring BB\_credits [20-20](#)
  - LEDs [20-14](#)
  - See also switching modules
- 24-port 4-Gbps switching modules
  - bandwidth fairness [22-26](#)
  - configuration guidelines [22-19](#)
  - default settings [22-31](#)
  - example configurations [22-11](#)
  - oversubscription [22-23](#)
  - shared resources [22-7](#)
  - See also switching modules
- 32-port switching modules
  - configuring BB\_credits [20-20](#)
  - PortChannel configuration guidelines [23-2](#)
  - SPAN guidelines [62-6](#)
  - See also switching modules
- 3DES encryption
  - IKE [44-7](#)

IPsec [44-6](#)

- 48-port 4-Gbps switching modules
  - bandwidth fairness [22-26](#)
  - configuration guidelines [22-19](#)
  - default settings [22-31](#)
  - example configurations [22-10](#)
  - oversubscription [22-23](#)
  - shared resources [22-7](#)
  - See also switching modules
- 4-port 10-Gbps switching modules
  - BB\_credit buffers [22-13](#)
  - configuration guidelines [22-20](#)
  - default settings [22-31](#)
  - See also switching modules

---

### A

- AAA
  - authentication process [41-6](#)
  - authorization process [41-6](#)
  - configuring information [7-47](#)
  - default settings [41-30](#)
  - description [41-1](#)
  - DHCHAP authentication [45-10](#)
  - distributing with CFS (procedure) [41-24](#)
  - enabling server distribution [41-22](#)
  - local services [41-26](#)
  - remote services [41-4](#)
  - service configuration options [41-4](#)
  - setting authentication [41-26](#)
  - starting a distribution session [41-22](#)
- AAA authentication
  - configuring [50-28, 50-29](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- AAA servers
  - groups [41-4](#)
  - monitoring [41-5](#)
  - remote authentication [41-4](#)
- access control
  - enforcing iSCSI
    - enforcing access control [50-27](#)
  - iSCSI [50-26](#)
- Access Control Lists. See IPv4-ACLs; IPv6-ACLs
- access control zoning based access control iSCSI
  - zoning based access control [50-27](#)
- accounting
  - viewing lists [7-9](#)
- ACL based access control
  - configuring for iSCSI [50-26](#)
- ACLs
  - configuring for iSCSI [50-26](#)
- active zone sets
  - considerations [30-5](#)
  - enabling distribution [30-25](#)
- adapters
  - Fibre Channel-to-Ethernet [9-2](#)
- adminDown tooltip [69-13](#)
- administrative speeds
  - configuring [20-12](#)
- administrative states
  - description [20-7](#)
  - setting [20-11](#)
- administrator passwords
  - default [2-5](#)
  - recovering [39-19](#)
- Admin tab
  - description [7-38](#)
- Advanced Encrypted Standard encryption. See AES encryption
- advertised interfaces [50-12](#)
- advertisement packets
  - setting time intervals [51-11](#)
- AES encryption
  - description [40-4](#)
  - IKE [44-6](#)
  - IPsec [44-6](#)
  - SNMP support [40-4](#)
- AES-XCBC-MAC
  - IPsec [44-6](#)
- AFIDs
  - configuring [29-12, 29-13](#)
  - configuring default [29-12](#)
  - description [29-4, 29-7, 29-15](#)
- aliases
  - switching between global device aliases and FC aliases [31-6](#)
  - switching between global device aliases and fcalias [3-8](#)
  - using as enclosure names [5-20](#)
  - using with Fabric Manager [3-8](#)
- ALPA caches
  - clearing [B-2](#)
  - description [20-19](#)
  - displaying contents [B-2](#)
- ANSI T11 FC-GS-3
  - support [2-16](#)
- applications
  - management [2-17](#)
- application virtual targets. See AVTs
- ARP caches
  - clearing [B-2](#)
  - displaying [B-2](#)
- authentication
  - CHAP option [50-57](#)
  - configuring local with Device Manager [50-30](#)
  - Fabric Manager Web Services [4-5](#)
  - fabric security [45-1](#)
  - guidelines [41-4](#)
  - iSCSI setup [50-56](#)
  - local [41-3, 50-30](#)
  - MD5 [51-12](#)
  - mechanism [50-29](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- mutual CHAPmutual CHAP authentication [50-30](#)
  - remote [41-3, 41-4](#)
  - restricting iSLB initiatorinitiator authentication
    - restrictingiSLB
      - restricting iSLB initiators [50-43](#)
    - simple text [51-12](#)
    - user IDs [41-3](#)
  - See also MD5 authentication
  - See also simple text authentication
  - authentication, authorization, and accounting. See AAA
  - autogenerated iSCSI targetiSCSI
    - autogenerated target [50-28](#)
  - auto-negotiation
    - configuring Gigabit Ethernet interfaces [52-5, 53-3](#)
  - autonomous fabric ID
    - See AFIDs
  - autonomous fabric identifiers. See AFIDs
  - AutoNotify
    - description [64-2](#)
    - destination profile (note) [64-5](#)
    - registration requirements [64-2](#)
    - service contract requirements [64-3](#)
  - auto port mode
    - description [20-7](#)
    - interface configuration [20-3](#)
  - autosensing speed
    - Generation 2 switching modules [20-13](#)
  - auto-topology
    - configuration guidelines [29-10](#)
    - IVR [29-6](#)
    - modifying (procedure) [29-12](#)
  - AVTs
    - description [57-2](#)
- 
- B**
- bandwidth fairness
    - disabling [22-27](#)
    - enabling [22-26](#)
  - Generation 2 switching modules [22-26](#)
  - BB\_credit buffers
    - 12-port 4-Gbps switching module allocations [22-12](#)
    - 12-port 4-Gbps switching module considerations [22-13](#)
    - 24-port 4-Gbps switching module allocations [22-11](#)
    - 24-port 4-Gbps switching module considerations [22-11, 22-12](#)
    - 48-port 4-Gbps switching module considerations [22-9](#)
    - 4-port 10-Gbps switching module allocations [22-13](#)
    - 4-port 10-Gbps switching module considerations [22-13, 22-14](#)
    - allocation defaults (table) [22-9](#)
  - BB\_credits
    - configuring [20-20](#)
    - description [20-20](#)
    - FICON port swapping [36-32](#)
    - reason codes [20-9, C-1](#)
  - beacon modes
    - configuring [20-15](#)
    - description [20-15](#)
    - identifying LEDs [20-14](#)
  - Berkeley Packet Filter library. See BPF library
  - bit errors
    - reasons [20-15](#)
  - bit error thresholds
    - configuring [20-15](#)
    - description [20-15](#)
  - bitErrRTThresExceeded tooltip [69-13](#)
  - bootflash:
    - description [16-2, 16-3](#)
    - file system [15-2](#)
    - recovering from corruption [B-1](#)
    - space requirements [15-3](#)
    - system images [16-2](#)
  - boot variables
    - synchronizing [17-3](#)
  - border switches
    - description [29-4](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

IVR configuration guidelines [29-15](#)

BPF library

- description [68-21](#)
- See also libpcap freeware

B port mode

- description [20-6](#)
- interface modes [20-6](#)

B ports

- configuring [48-27](#)
- interoperability mode [48-25](#)
- SAN extenders [48-26](#)

bridge port mode. See B port mode

bridge ports. See B ports

broadcast

- in-band addresses default [19-13](#)
- routing [32-14](#)

Brocade

- native interop mode [37-8](#)

buffer pools

- Generation 2 switching modules [22-8](#)

buffer sizes

- configuring in FCIP profiles [48-21](#)

buffer-to-buffer credits. See BB\_credits

build fabric frames

- description [25-3](#)

bundleMisCfg tooltip [69-13](#)

## C

### Call Home

- alert groups [64-6 to 64-8](#)
- AutoNotify feature [64-2](#)
- CFS support [13-2](#)
- configuration distribution [64-14](#)
- configuring [64-3 to 64-15](#)
- configuring e-mail options [64-11](#)
- configuring for EMC [64-16](#)
- contact information [64-3](#)
- database merge guidelines [64-15](#)

- default settings [64-19](#)
- description [64-1](#)
- destination profiles [64-5 to 64-6](#)
- duplicate message throttle [64-13](#)
- enabling [64-13](#)
- features [64-2](#)
- inventory notifications [64-11](#)
- message format options [64-2](#)
- RMON-based alerts [64-10](#)
- syslog-based alerts [64-9](#)
- testing communications [64-16](#)

### Call Home alert groups

- configuring [64-6](#)
- customizing messages [64-7](#)
- description [64-6](#)

### Call Home destination profiles

- attributes [64-5](#)
- description [64-5](#)

### Call Home messages

- configuring levels [64-8](#)
- format options [64-2](#)

### Call Home notifications

- full-txt format for syslog [64-17](#)
- XML format for RMON [64-18](#)
- XML format for syslog [64-17](#)

### CAs

- authenticating [43-10](#)
- certificate download example [43-19](#)
- configuring [43-6 to 43-17](#)
- creating a trust point [43-8](#)
- default settings [43-37](#)
- deleting digital certificates [43-16](#)
- description [43-1 to 43-5](#)
- enrollment using cut-and-paste [43-4](#)
- example configuration [43-17 to 43-36](#)
- Fabric Manager Web Services [7-5](#)
- identity [43-2](#)
- maintaining [43-14](#)
- maximum limits [43-36](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- monitoring [43-14](#)
- multiple [43-4](#)
- multiple trust points [43-3](#)
- peer certificates [43-5](#)
- purpose [43-2](#)
- CDP
  - configuring [12-12 to 12-13](#)
  - configuring hold times [12-13](#)
  - configuring refresh time interval globally [12-13](#)
  - disabling globally [12-12](#)
  - disabling on interfaces [12-13](#)
  - packet transmission interval [12-12](#)
- certificate authorities. See CAs
- certificate revocation lists. See CRLs
- CFS
  - application requirements [13-5](#)
  - configuring for NTP [12-8](#)
  - default settings [13-19](#)
  - description [13-1 to 13-4](#)
  - disabling on a switch [13-4](#)
  - displaying configuration information [13-9](#)
  - distribution modes [13-4](#)
  - distribution over IP [13-10](#)
  - distribution scopes [13-3](#)
  - enabling on a switch [13-4](#)
  - example configuration using Device Manager [13-19](#)
  - example configuration using Fabric Manager [13-16](#)
  - example using Fabric Manager [12-8](#)
  - feature description [13-2](#)
  - iSLB config distribution [50-46](#)
  - merge support [13-9](#)
  - merge support (procedure) [13-18](#)
  - protocol description [13-3](#)
  - SAN-OS features supported [13-2](#)
  - saving configurations [13-8](#)
- CFS applications
  - clearing session locks [13-8](#)
  - committing changes [13-7](#)
  - discarding changes [13-8](#)
  - enabling [13-6](#)
  - enabling (procedure) [13-6](#)
  - fabric locking [13-7](#)
- CFS over IP
  - default settings [13-19](#)
  - description [13-10](#)
- CFS regions
  - assigning features [13-13](#)
  - creating [13-13](#)
  - deleting [13-15](#)
  - description [13-12](#)
  - moving a feature [13-14](#)
  - removing a feature [13-15](#)
  - using Fabric Manager [13-13](#)
- channelAdminDown tooltip [69-13](#)
- channelConfigurationInProgress tooltip [69-13](#)
- channelOperSuspended tooltip [69-13](#)
- CHAP authentication [50-28, 50-43, 50-57](#)
- CHAP challenge [50-30](#)
- CHAP response [50-30](#)
- CHAP user name [50-30](#)
- CIM
  - configuring [37-1, B-3](#)
  - description [37-1](#)
  - support [2-16](#)
- CIM servers
  - default settings [68-25](#)
- Cisco Access Control Server. See Cisco ACS
- Cisco ACS
  - configuring for RADIUS [41-26 to 41-30](#)
  - configuring for TACACS+ [41-26 to 41-30](#)
- cisco-av-pair
  - specifying for SNMPv3 [41-13](#)
- Cisco Discovery Protocol. See CDP
- Cisco Fabric Service. See CFS
- Cisco MDS 9000 Family
  - connecting a terminal [12-11](#)
  - description [1-1](#)
  - initial setup [2-2 to 2-12](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- starting a switch [2-1](#)
- Cisco MDS 9100 Series
  - Cisco MDS 9120 switches [1-4](#)
  - Cisco MDS 9124 switches [1-4](#)
  - Cisco MDS 9140 switches [1-4](#)
  - description [1-4](#)
  - high availability [17-1](#)
  - overview [1-4](#)
- Cisco MDS 9120 switches
  - description [1-4](#)
- Cisco MDS 9140 switches
  - description [1-4](#)
- Cisco MDS 9200 Series
  - Cisco MDS 9216A switches [1-3, 1-4](#)
  - Cisco MDS 9216i switches [1-3](#)
  - Cisco MDS 9216 switches [1-4](#)
  - connecting a terminal [12-11](#)
  - description [1-3](#)
  - high availability [17-1](#)
- Cisco MDS 9216
  - supervisor modules [19-2](#)
- Cisco MDS 9216A switches
  - description [1-3, 1-4](#)
- Cisco MDS 9216i switches
  - configuring extended BB\_credits [20-22](#)
  - description [1-3](#)
- Cisco MDS 9216 switches
  - description [1-4](#)
- Cisco MDS 9500 Series
  - Cisco MDS 9506 Directors [1-2](#)
  - Cisco MDS 9509 Directors [1-2](#)
  - Cisco MDS 9513 Directors [1-2](#)
  - description [1-2](#)
  - high availability [17-1](#)
- Cisco MDS 9506 Directors
  - description [1-2](#)
- Cisco MDS 9509 Directors
  - description [1-2](#)
  - supervisor modules [19-1](#)
- Cisco MDS 9513 Directors
  - description [1-2](#)
  - supervisor modules [19-1](#)
- Cisco MDS SAN-OS
  - software images [15-1](#)
- Cisco SAN-OS features
  - changed (table) [i-liii](#)
  - new (table) [i-liii](#)
- Cisco Traffic Analyzer
  - configuring with Performance Manager [60-9](#)
  - description [9-3](#)
  - installing (procedure) [9-3](#)
  - statistics reports [68-3](#)
  - troubleshooting tools [68-2](#)
  - using for troubleshooting [68-2](#)
  - using with Fabric Manager [9-2](#)
- Cisco Transport Controller. See CTC
- Cisco vendor ID
  - description [41-13](#)
- class maps
  - configuring for data traffic [66-6](#)
  - creating [66-7](#)
- CLI
  - accessing [D-2](#)
  - description [1-6](#)
  - Fabric Manager alternative [1-6](#)
  - firewall [4-2](#)
- clients
  - disconnecting [7-44](#)
  - viewing [7-44](#)
- clock modules
  - managing [B-2](#)
- cloud discovery. See iSNS cloud discovery
- code pages
  - FICON text string formatting [36-19](#)
- COM1 ports
  - configuring [B-1](#)
- command-line interface. See CLI
- command schedulers

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- configuring [B-2](#)
- command scripts
  - executing [B-2](#)
- Common Information Model. See CIM
- common roles
  - deleting (procedure) [39-3](#)
- communities
  - adding [7-45](#)
  - removing [7-46](#)
- CompactFlash
  - devices [16-3](#)
  - slot0: [15-2](#)
- company IDs
  - FC ID allocations [37-7, 68-24](#)
- configuration
  - overview [1-6 to 1-9](#)
  - saving automatically for FICON [36-23](#)
  - saving to NVRAM [16-8](#)
  - software tools [1-5](#)
- configuration files
  - backing up [16-9](#)
  - copying (procedure) [16-8](#)
  - displaying [B-2](#)
  - downloading [16-8](#)
  - FICON [36-29](#)
  - saving (procedures) [16-8](#)
  - saving across the fabric [16-9](#)
- configuration limits
  - description (table) [i-lxx, E-1](#)
- configurations
  - changing initial [2-12](#)
- configuring NPV [21-7](#)
- congestion control methods. See FCC; edge quench
- congestion control
- congestion window monitoring. See CWM
- connectivity
  - troubleshooting tool [5-22](#)
  - verifying [68-7](#)
- console logging
  - configuring [63-4](#)
- console ports
  - parameters [2-2](#)
- console sessions
  - message logging severity levels [63-4](#)
- console settings
  - configuring [B-1](#)
- Contiguous Domain ID Assignments
  - About [25-15](#)
- contract IDs
  - description [64-23](#)
- control traffic
  - disabling QoS [66-4](#)
  - enabling for QoS [66-4](#)
- Control Unit Port. See CUP in-band management
- control virtual targets. See CVTs
- core dumps
  - IPS modules [B-2](#)
- core files
  - clearing directory [70-4](#)
  - displaying information [70-3](#)
  - saving to CompactFlash [B-3](#)
- CRLs
  - configuring [43-15](#)
  - configuring revocation checking methods [43-12](#)
  - description [43-5](#)
  - downloading example [43-34](#)
  - generation example [43-33](#)
  - importing example [43-36, ?? to 43-36](#)
- crossbars
  - compatibility with Generation 1 modules [18-10](#)
  - description [18-8](#)
  - management [18-7](#)
  - removal considerations [18-8](#)
- crypto IPv4-ACLs
  - any keyword [44-25](#)
  - configuration guidelines [44-22](#)
  - creating [44-25](#)
  - mirror images [44-24](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

## crypto map entries

- global lifetime values [44-37](#)
- setting SA lifetimes [44-31](#)

## crypto maps

- auto-peer option [44-32](#)
- configuration guidelines [44-29](#)
- configuring perfect forward secrecy [44-35](#)
- entries for IPv4-ACLs [44-28](#)
- perfect forward secrecy [44-34](#)
- SA lifetime negotiations [44-30](#)
- SAs between peers [44-28](#)

## crypto map sets

- applying to interfaces [44-36](#)

## CTC

- description [48-18](#)
- launching [48-18](#)

## CUP in-band management

- blocking restriction [36-25](#)
- description [36-37](#)

## current VSANs

- description [29-3](#)

## custom reports

- creating a template [7-33](#)
- listing by template [7-35](#)
- modifying a template [7-36](#)

## Custom tab

- description [7-33](#)

## Cut-through routing mode [50-33](#)

## cut-thru routing mode [50-34](#)

## CVTs

- creating [57-4](#)
- deleting [57-5](#)
- description [57-2](#)

## CWM

- configuring in FCIP profiles [48-20](#)

default setting [68-25](#)

errors when setting [69-7](#)

modifying [68-15](#)

## data

management [2-17](#)

## database files

resolving lock errors [7-38](#)

Data Encryption Standard encryption. See DES encryption

## data traffic

- class maps [66-6](#)
- comparing VSANs and QoS [66-5](#)
- defining service policies [66-8](#)
- DWRR queues [66-8](#)
- enforcing service policies [66-8](#)
- example configuration [66-10](#)

data virtual targets. See DVTs

## dates

configuring [12-3](#)

## daylight saving time

adjusting for [B-1](#)

## dead time intervals

- configuring for FSPF [32-8](#)
- description [32-8](#)

## dedicated rate mode

- description [22-6](#)
- migrating from shared rate mode [22-19](#)
- migrating to shared rate mode [22-19](#)

default gateways. See IPv4 default gateways

## default networks

configuring [2-6, 2-10](#)

default networks. See IPv4 default networks

## default users

description [2-3](#)

## default VSANs

description [26-8](#)

## default zones

- configuring [30-20](#)
- configuring policies [30-35](#)
- configuring QoS priorities [30-34](#)

## D

### D\_S\_TOV



***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- description [30-19](#)
- interoperability [37-9](#)
- policies [30-19](#)
- deficit weighted round robin schedulers. See DWRR schedulers
- deniedDueToPortBinding tooltip [69-13](#)
- DES encryption
  - IKE [44-7](#)
  - IPsec [44-6](#)
- desktops
  - shortcuts not visible [69-4](#)
- destination IDs
  - exchange based [23-5](#)
  - flow based [23-4](#)
  - in-order delivery [32-15](#)
  - path selection [26-11](#)
- device alias database
  - committing changes [31-5](#)
  - discarding changes [31-5](#)
  - distribution to fabric [31-3](#)
  - merging [31-7](#)
- device aliases
  - CFS support [13-2](#)
  - clearing statistics [31-6](#)
  - comparison with zones (table) [31-2](#)
  - default settings [31-8](#)
  - description [31-1](#)
  - features [31-1](#)
  - modifying the database [31-2](#)
  - requirements [31-2](#)
  - zone alias conversion [31-5](#)
- device IDs
  - Call Home format [64-24](#)
- Device Manager
  - color definitions [6-6](#)
  - connection failures [69-10](#)
  - context menus [6-7](#)
  - description [1-6, 2-15, 6-1](#)
  - disk images not visible [69-7](#)
  - downgrading [69-4](#)
  - FAQs [69-1](#)
  - icons [6-4](#)
  - installation failures [69-6, 69-7](#)
  - label definitions [6-6](#)
  - launching (procedure) [6-2](#)
  - login failure recovery [69-6](#)
  - managing ports [6-7](#)
  - performance monitoring [60-1](#)
  - PortChannels [6-7](#)
  - preferences [6-8](#)
  - setting preferences [6-8](#)
  - tabs [6-5](#)
  - troubleshooting tools [68-1](#)
  - trunking [6-7](#)
  - upgrade failures [69-4](#)
  - upgrading [69-4](#)
  - using interface (figure) [6-3](#)
  - viewing license information [10-16](#)
  - viewing port status [6-6](#)
  - viewing supervisor modules [6-7](#)
  - viewing switch modules [6-7](#)
  - viewing system messages [63-11](#)
- devices
  - discovery [59-1](#)
  - management [2-17](#)
  - modifying groupings (procedure) [5-20](#)
  - searching in Fabric Manager [69-22](#)
- DH
  - IKE [44-6](#)
- DHCHAP
  - AAA authentication [45-10](#)
  - authentication modes [45-5](#)
  - compatibility with other SAN-OS features [45-3](#)
  - configuring [45-2 to 45-10](#)
  - configuring AAA authentication [45-10](#)
  - default settings [45-10](#)
  - description [45-2](#)
  - enabling [45-4](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- group settings [45-7](#)
- hash algorithms [45-6](#)
- licensing [45-2](#)
- passwords for local switches [45-7](#)
- passwords for remote devices [45-8](#)
- timeout values [45-9](#)
- See also FC-SP
- differentiated services code point. See DSCP
- Diffie-Hellman Challenge Handshake Authentication Protocol. See DHCHAP
- Diffie-Hellman protocol. See DH
- digital certificates
  - configuration example [43-17 to 43-19](#)
  - configuring [43-6 to 43-17](#)
  - default settings [43-37](#)
  - deleting from CAs [43-16](#)
  - description [43-1 to 43-5](#)
  - exporting [43-5, 43-14](#)
  - generating requests for identity certificates [43-12](#)
  - importing [43-5, 43-14](#)
  - installing identity certificates [43-13](#)
  - IPsec [44-7 to 44-10](#)
  - maintaining [43-14](#)
  - maximum limits [43-36](#)
  - monitoring [43-14](#)
  - peers [43-5](#)
  - purpose [43-2](#)
  - requesting identity certificate example [43-24](#)
  - revocation example [43-30](#)
- digital signature algorithm. See DSA key pairs
- DirectX
  - installing [69-6](#)
- Distributed Services Time Out Value. See D\_S\_TOV
- DNS
  - configuring [2-6, 2-10](#)
  - configuring IP addresses [2-7](#)
  - default settings [51-13](#)
- DNS servers
  - configuring [51-12](#)
- documentation
  - additional publications [i-lxxi](#)
  - related documents [i-lxxi](#)
- domainAddrAssignFailureIsolation tooltip [69-14](#)
- domain ID
  - CFS support [13-2](#)
- domain IDs
  - allowed lists [25-11](#)
  - assignment failures [20-10](#)
  - configuring allowed lists [25-11](#)
  - configuring CFS distribution [25-12 to 25-15](#)
  - configuring fcalias members [30-20](#)
  - contiguous assignments [25-15](#)
  - description [25-8](#)
  - distributing [25-2](#)
  - duplicates causing errors [69-12](#)
  - enabling contiguous assignments [25-15](#)
  - failures [C-2](#)
  - interoperability [37-9](#)
  - IVR configuration guidelines [29-14](#)
  - non-unique and IVR NAT [29-5](#)
  - preferred [25-10](#)
  - static [25-10](#)
  - unique [29-14](#)
- domainInvalidRCFReceived tooltip [69-14](#)
- domain manager
  - isolation [20-10](#)
- domainManagerDisabled tooltip [69-14](#)
- domainMaxReTxFailure tooltip [69-14](#)
- domain names
  - configuring [2-6](#)
- domainOtherSideEportIsolation tooltip [69-14](#)
- domainOverlapIsolation tooltip [69-14](#)
- domains
  - overlap isolations [C-2](#)
- DPVM
  - CFS support [13-2](#)
  - default settings [28-14](#)
  - description [28-1](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- enabling [28-2](#)
  - requirements [28-2](#)
  - using DPVM Setup Wizard (procedure) [28-2](#)
  - wizard [5-22](#)
  - DPVM databases
    - autolearned entries [28-7](#)
    - clearing [28-8](#)
    - comparing differences [28-13](#)
    - configuring CFS distribution [28-8 to 28-12](#)
    - copying [28-13](#)
    - description [28-3](#)
    - enabling autolearning [28-7](#)
    - merging guidelines [28-12](#)
  - drill down reports
    - description [7-1](#)
  - drivers
    - iSCSI [50-2](#)
  - drop latency time
    - configuring [32-18](#)
  - dsa key pairs
    - generating [39-15](#)
  - DSCP
    - configuring [48-28](#)
  - DVTs
    - creating [57-6, 57-9](#)
    - deleting [57-8](#)
    - description [57-2](#)
  - DWRR queues
    - changing weights [66-9](#)
  - DWRR schedulers
    - description [66-5](#)
  - dynamic bandwidth management
    - description [22-6](#)
  - dynamic iSCSI initiator
    - converting [50-40](#)
    - convert to staticiSCSI
      - convert dynamic initiator to static [50-19](#)
  - dynamic mapping [50-8, 50-39](#)
  - dynamic mappingiSCSI
    - dynamic mappingiSCSI
      - static mappingstatic mapping [50-7](#)
  - Dynamic Port VSAN Membership. See DPVM
- 
- ## E
- E\_D\_TOV
    - default setting [68-25](#)
    - errors when setting [69-7](#)
    - modifying [68-15](#)
  - EBCDIC
    - FICON string format [36-19](#)
  - edge quench congestion control
    - description [66-2](#)
  - edge switches
    - description [29-4](#)
  - edge VSANs
    - description [29-3](#)
  - EFMD
    - fabric binding [47-1](#)
  - EISLs
    - PortChannel links [23-1](#)
  - ELP
    - verifying using Device Manager (procedure) [48-17](#)
  - elpFailureClassFParamErr tooltip [69-14](#)
  - elpFailureClassNParamErr tooltip [69-14](#)
  - elpFailureInvalidFlowCTLParam tooltip [69-14](#)
  - elpFailureInvalidPayloadSize tooltip [69-14](#)
  - elpFailureInvalidPortName tooltip [69-14](#)
  - elpFailureInvalidTxBBCredit tooltip [69-14](#)
  - elpFailureIsolation tooltip [69-14](#)
  - elpFailureLoopbackDetected tooltip [69-14](#)
  - elpFailureRatovEdtovMismatch tooltip [69-14](#)
  - elpFailureRevMismatch tooltip [69-14](#)
  - ELP failures
    - reason codes [C-2](#)
  - elpFailureUnknownFlowCTLCode tooltip [69-14](#)
  - e-mail addresses
    - assigning for Call Home [64-4](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- e-mail notifications
  - Call Home [64-1](#)
- EMC
  - configuring Call Home [64-16](#)
- enclosure names
  - aliases [5-20](#)
- end devices
  - viewing storage port traffic and errors [7-14](#)
- end-to-end connectivity
  - troubleshooting [68-5](#)
- enhanced ISLs. See EISLs
- enhanced zones
  - advantages over basic zones [30-40](#)
  - changing from basic zones [30-41](#)
  - creating attribute groups [30-42](#)
  - default settings [30-45](#)
  - description [30-40](#)
  - enabling [30-42](#)
  - merging databases [30-42](#)
- enterprise package licenses
  - description [10-4](#)
- entity status inquiry. See ESI
- EPLD images
  - configuring [B-2](#)
- E port mode
  - classes of service [20-4](#)
  - description [20-4](#)
- ePortProhibited tooltip [69-14](#)
- E ports
  - 32-port guidelines [20-3](#)
  - 32-port switching module configuration guidelines [23-3](#)
  - configuring [20-12, 48-28](#)
  - fabric binding checking [47-2](#)
  - FCS support [65-1](#)
  - FSPF topologies [32-2](#)
  - isolation [20-10, C-2](#)
  - recovering from link isolations [30-27](#)
  - SPAN sources [62-3](#)
  - trunking configuration [24-3](#)
- eppFailure tooltip [69-14](#)
- Error Detect Time Out Value. See E\_D\_TOV
- errorDisabled tooltip [69-14](#)
- error messages
  - gen error messages [69-7](#)
- error reports
  - clearing previous [B-3](#)
- escFailureIsolation tooltip [69-15](#)
- ESC failures
  - reason codes [C-2](#)
- ESI
  - non-resp threshold [50-72](#)
- ESI retry count [50-72](#)
- Ethereal freeware
  - analyzer [68-18](#)
  - URL [68-17](#)
- Ethernet
  - reducing traffic [68-2](#)
- Ethernet PortChannels
  - adding Gigabit Ethernet interfaces [52-10](#)
  - configuring [52-10](#)
  - description [52-9](#)
  - iSCSI [50-55](#)
  - redundancy [48-6](#)
- evaluation
  - stop in Device Manager [10-17](#)
- events
  - displaying using Device Manager [59-4](#)
  - displaying using Fabric Manager [59-4](#)
  - displaying using Fabric Manager Web Services [59-4](#)
  - viewing [7-9](#)
- Exchange Fabric Membership Data. See EFMD [47-1](#)
- exchange IDs
  - in-order delivery [32-15](#)
  - path selection [26-11](#)
- exchange link parameter. See ELP
- exchange link parameter failures. See ELP failures
- expansion port mode. See E port mode

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- expiry alerts
    - licenses [10-15](#)
  - explicit fabric logout [50-16](#)
  - extended BB\_credits
    - configuring [20-23](#)
    - description [20-21](#)
    - Generation 2 switching modules [22-15](#)
    - licensing [22-15](#)
  - Extended Binary-Coded Decimal Interchange Code. See EBCDIC [36-19](#)
  - Extended Link Protocol. See ELP
  - external CompactFlash
    - formatting [B-2](#)
  - external loopback tests
    - description [70-7](#)
    - performing [70-7](#)
  - external RADIUS server
    - CHAP [50-57](#)
  - external RADIUS servers
    - CHAP [50-57](#)
- 
- F**
- fabric
    - editing monitoring [7-42](#)
  - Fabric Analyzer
    - configuring [68-19](#)
    - description [68-17](#)
    - Ethereal freeware [68-17](#)
    - libpcap freeware [68-17](#)
    - using display filters [B-3](#)
  - fabric binding
    - activation [47-4](#)
    - checking for Ex ports [47-2](#)
    - clearing statistics [47-6](#)
    - compatibility with DHCPAP [45-3](#)
    - configuration [47-3 to 47-6](#)
    - default settings [47-9](#)
    - deleting database [47-6](#)
    - description [47-1 to 47-2](#)
    - EFMD [47-1](#)
    - enforcement [47-2](#)
    - forceful activation [47-5](#)
    - licensing requirements [47-1](#)
    - port security comparison [47-1](#)
    - saving configurations [47-5](#)
    - verifying configuration [47-6 to 47-9](#)
  - fabricBindingDBMismatch tooltip [69-15](#)
  - fabricBindingDomainInvalid tooltip [69-15](#)
  - fabricBindingNoRspFromPeer tooltip [69-15](#)
  - fabricBindingSWWNNotFound tooltip [69-15](#)
  - Fabric Configuration Server. See FCS
  - Fabric Configuration Servers. See FCSs
  - Fabric-Device Management Interface. See FDMI
  - fabric lock
    - releasing [50-49](#)
  - fabric login. See FLOGI
  - fabric loop port mode. See FL port mode
  - Fabric Manager
    - authentication [4-1 to ??](#)
    - browser support [2-19](#)
    - Cisco Traffic Analyzer [9-2](#)
    - connection failures [69-10](#)
    - corrupted jar file errors [69-21](#)
    - description [1-6, 2-13](#)
    - detachable tables [5-12](#)
    - downgrading [69-4](#)
    - downloading software [2-18](#)
    - error recovery [69-7](#)
    - FAQs [69-1](#)
    - FCIP [69-19](#)
    - installation failures [69-6, 69-7](#)
    - installing [2-18](#)
    - integrating with other tools [2-38](#)
    - ISL statistics [60-3](#)
    - Java support [2-19](#)
    - launching troubleshooting [69-3](#)
    - login failure recovery [69-6](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- missing Information pane [69-9](#)
- mixed software environments [69-21](#)
- network discovery [5-19](#)
- preinstallation tasks [2-18](#)
- problems with map changes [69-8](#)
- running behind firewalls [2-38](#)
- running with multiple NICs [69-19](#)
- searching for devices [69-22](#)
- setting preferences [5-18](#)
- shows as disabled service [69-6](#)
- support operating systems [2-19](#)
- uninstalling [2-40](#)
- unlicensed features [3-2](#)
- upgrade failures [69-4](#)
- upgrading [2-36, 69-4](#)
- viewing license information [10-16](#)
- Fabric Manager authentication
  - description [4-1](#)
  - discovery best practices [4-3](#)
  - Web Server support [4-5](#)
- Fabric Manager Clients
  - advanced mode [5-2](#)
  - description [2-14, 5-1](#)
  - displaying physical attributes [5-10](#)
  - Fabric pane [5-12](#)
  - filtering [5-10](#)
  - Information pane [5-11](#)
  - launching [5-2](#)
  - main menu [5-7](#)
  - setting preferences [5-18](#)
  - status bar [5-18](#)
  - toolbar icons (table) [5-8](#)
  - troubleshooting tools [5-22](#)
  - using interface (figure) [5-6](#)
  - wizards [5-21](#)
- Fabric Manager features
  - changed (table) [i-iii](#)
  - new (table) [i-iii](#)
- Fabric Manager Server
  - authentication [4-2](#)
  - configuring preferences [7-45](#)
  - continuously monitoring fabrics [3-3](#)
  - database failed to start [69-10](#)
  - description [2-14, 3-1](#)
  - disk space requirements [3-1](#)
  - fabric discovery [4-3](#)
  - features [3-1](#)
  - full fabric rediscovery [3-8](#)
  - installation overview [3-2](#)
  - installing [3-2](#)
  - installing Fabric Manager Web Server (procedure) [3-3](#)
  - licensing [3-3, 10-17](#)
  - local host error messages [69-19](#)
  - modifying settings [3-6](#)
  - passwords [3-7](#)
  - performing administrative tasks [7-38](#)
  - performing configuration tasks [7-38](#)
  - polling periods [3-8](#)
  - properties files [3-5](#)
  - Red Hat Linux support [3-1](#)
  - Solaris support [3-1](#)
  - troubleshooting tools [68-1](#)
  - user names [3-7](#)
  - viewing logs [7-56](#)
  - Windows support [3-1](#)
- Fabric Manager Server package license
  - description [10-6](#)
- Fabric Manager Web Server
  - authentication [4-5](#)
  - configuring RADIUS authentication [4-5](#)
  - configuring TACACS+ authentication [4-5](#)
  - description [2-15](#)
  - viewing system messages [63-11](#)
- Fabric Manager Web Services
  - configuring communities [7-45](#)
  - configuring users [7-47](#)
  - description [7-1](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- exporting performance data [7-3](#)
- initial screen [7-8](#)
- installing [7-3](#)
- launching [7-7](#)
- navigating [7-2](#)
- printing [7-3](#)
- recovering passwords [7-39](#)
- TCP ports [7-4, 7-5](#)
- using with SSL [7-5](#)
- fabric port mode. See F port mode
- fabric pWWNs
  - zone membership [30-2](#)
- fabric reconfiguration
  - fcdomain phase [25-2](#)
- fabrics
  - discovery [5-19](#)
  - management [2-17](#)
  - monitoring [3-3](#)
  - See also build fabric frames
- fabrics. See RCFs; build fabric frames
- fabric security
  - authentication [45-1](#)
  - default settings [45-10](#)
- Fabric Shortest Path First. See FSPF
- FabricWare
  - events [D-2](#)
  - Fabric Manager support (table) [D-3](#)
  - Fibre Channel support [D-1](#)
  - installing Fabric Manager Web Services [7-3](#)
  - roles [D-2](#)
  - security [D-2](#)
  - SNMP traps [D-2](#)
  - syslog traps [D-2](#)
  - zoning support [D-2](#)
- fabric WWNs. See fWWNs
- fan module LEDs
  - failure status [18-11](#)
- fan modules
  - description [18-11](#)
  - displaying status [18-11](#)
  - failures [18-11](#)
- FAQs
  - Device Manager [69-1](#)
  - Fabric Manager [69-1](#)
- fault tolerant fabrics
  - example (figure) [32-2](#)
- fcaliases
  - adding members [30-21](#)
  - cloning [30-31](#)
  - configuring for zones [30-20](#)
  - creating [30-21](#)
  - renaming [30-30](#)
  - using with Fabric Manager [3-8](#)
- FCC
  - assigning priority [66-3](#)
  - benefits [66-1](#)
  - default settings [66-12](#)
  - description [66-1](#)
  - enabling [66-2](#)
  - frame handling [66-2](#)
  - logging facility [63-2](#)
  - process [66-2](#)
- fcdomains
  - autoreconfigured merged fabrics [25-7](#)
  - configuring CFS distribution [25-12 to 25-15](#)
  - default settings [25-22](#)
  - description [25-2](#)
  - disabling [25-6](#)
  - domain IDs [25-8](#)
  - displaying statistics [25-22](#)
  - enabling [25-6](#)
  - enabling autoreconfiguration [25-8](#)
  - incoming RCFs [25-6](#)
  - initiation [25-5](#)
  - overlap isolation [20-10](#)
  - restarts [25-3](#)
  - switch priorities [25-5](#)
- FC-GS-3 requests

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- device grouping support [5-20](#)
- FC ID allocation
  - FICON implementation [36-14](#)
- FC IDs
  - allocating [25-2, 37-7, 68-24](#)
  - allocating company IDs [68-24](#)
  - allocating default company ID lists [37-7](#)
  - allocating for FICON [36-14](#)
  - allocation for HBAs [37-7](#)
  - configuring fcalias members [30-20](#)
  - description [25-16](#)
  - persistent [25-17 to ??](#)
- FCIP [50-1](#)
  - advanced features [48-29](#)
  - checking trunk status (procedure) [48-17](#)
  - compatibility with DHCHAP [45-3](#)
  - compression [48-37](#)
  - configuring [48-7 to ??](#)
  - configuring using FCIP Wizard [48-8 to 48-15](#)
  - default parameters [48-38](#)
  - discarding packets [48-25](#)
  - enabling [48-8](#)
  - FICON support [36-5](#)
  - Gigabit Ethernet ports [52-4, 53-1](#)
  - high availability [48-4 to 48-7](#)
  - IPS modules [48-2](#)
  - IP storage services support [52-1](#)
  - link failures [48-5](#)
  - MPS-14/2 module [48-2](#)
  - reserving ports for FICON [36-13](#)
  - restrictions [69-19](#)
  - specifying number of TCP connections [48-25](#)
  - tape acceleration [48-32 to ??](#)
  - time stamps [48-25](#)
  - VE ports [48-2](#)
  - verifying ELP (procedure) [48-17](#)
  - verifying interfaces (procedure) [48-17](#)
  - virtual ISLs [48-2](#)
  - VRRP [48-6](#)
  - write acceleration [48-29](#)
- FCIP compression
  - configuring (procedure) [48-12](#)
  - description [48-37](#)
- FCIP interfaces
  - configuring advanced features [48-21 to 48-28](#)
  - configuring peers [48-22](#)
  - configuring QoS [48-28](#)
  - configuring special frames [48-24](#)
  - creating [48-22](#)
  - parameters [48-4](#)
  - SPAN sources [62-3](#)
- FCIP links
  - B port interoperability mode [48-25](#)
  - configuring [48-15](#)
  - configuring peers [48-22](#)
  - configuring QoS [48-28](#)
  - creating [48-16](#)
  - description [48-3](#)
  - endpoints [48-3](#)
  - initiating IP connections [48-25](#)
  - TCP connections [48-3](#)
- FCIP peers
  - configuring IP addresses [48-22](#)
  - enabling special frames [48-24](#)
  - fcipPortAdminCfgChange tooltip [69-15](#)
  - fcipPortKeepAliveTimerExpire tooltip [69-15](#)
  - fcipPortMaxReTx tooltip [69-15](#)
  - fcipPortPersistTimerExpire tooltip [69-15](#)
  - fcipPortSrcAdminDown tooltip [69-15](#)
  - fcipPortSrcLinkDown tooltip [69-15](#)
- FCIP profiles
  - configuring TCP parameters [48-19 to ??](#)
  - creating [48-16](#)
  - description [48-4](#)
  - fcipSrcModuleNotOnline tooltip [69-15](#)
  - fcipSrcPortRemoved tooltip [69-15](#)
- FCIP tape acceleration
  - configuring [48-36](#)



***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- description [48-32 to 48-36](#)
- FCIP TCP parameters
  - configuring buffer size [48-21](#)
  - configuring CWM [48-20](#)
  - configuring keepalive timeouts [48-19](#)
  - configuring maximum jitter [48-21](#)
  - configuring maximum retransmissions [48-19](#)
  - configuring minimum retransmit timeouts [48-19](#)
  - configuring PMTUs [48-20](#)
  - configuring SACKs [48-20](#)
  - configuring window management [48-20](#)
- FCIP write acceleration
  - configuring [48-31](#)
  - configuring (procedure) [48-12](#)
  - description [48-29](#)
- FC Logical Interface Tables [50-21](#)
- fcotChksumErr tooltip [69-15](#)
- fcotNotPresent tooltip [69-15](#)
- fcotVendorNotSupported tooltip [69-15](#)
- FCP
  - intermixing protocols [36-5](#)
  - routing requests [50-3](#)
- fcping. See Ping Tool
- FCS
  - description [65-1](#)
  - logging facility [63-2](#)
  - significance [65-2](#)
- FC-SP
  - authentication [45-1](#)
  - enabling [45-4](#)
  - enabling on ISLs [45-10](#)
  - See also DHCHAP
- fcspAuthenfailure tooltip [69-15](#)
- FCSs
  - default settings [65-6](#)
  - description [65-1](#)
  - displaying information [65-3 to ??](#)
- ftimers
  - CFS support [13-2](#)
  - configuring CFS [B-3](#)
  - distribution [37-4](#)
- fctrace. See traceroute
- FDMI
  - description [34-4](#)
  - displaying database information [34-4](#)
- Federal Information Processing Standards. See FIPS
- Fibre Channel [50-1](#)
  - configuring time out values [68-15](#)
  - iSCSI targets [50-7 to 50-13](#)
  - sWWNs for fabric binding [47-4](#)
  - time out values [37-2 to 37-5](#)
  - TOVs [37-2](#)
- Fibre Channel Analyzers
  - configuring using SPAN [62-12](#)
- Fibre Channel analyzers
  - capturing frames locally [B-3](#)
  - clearing configured information [B-3](#)
  - monitoring without SPAN [62-10](#)
  - sending frames to remote IP addresses [B-3](#)
- Fibre Channel Congestion Control. See FCC
- Fibre Channel domains. See fcdomains
- Fibre Channel interface
  - default settings [20-26](#)
- Fibre Channel interfaces
  - administrative states [20-7](#)
  - BB\_credits [20-20](#)
  - characteristics [20-2 to 20-11](#)
  - configuring beacon modes [20-15](#)
  - configuring bit error thresholds [20-15](#)
  - configuring frame encapsulation [20-13](#)
  - configuring port modes [20-12](#)
  - configuring receive data field sizes [20-13](#)
  - configuring speeds [20-12](#)
  - deleting from PortChannels [23-16](#)
  - disabling [20-11](#)
  - enabling [20-11](#)
  - extended BB\_credits [20-21](#)
  - graceful shutdown [20-11](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- modes [20-3 to 20-7](#)
- operational states [20-7](#)
- performance buffers [20-21](#)
- reason codes [20-8](#)
- states [20-7](#)
- taking out of service on Generation 2 switching modules [22-28](#)
- troubleshooting operational states [20-9](#)
- See also interfaces [20-7](#)
- Fibre Channel over IP. See FCIP
- Fibre Channel Protocol. See FCP
- Fibre Channel Security Protocol. See FC-SP
- Fibre Channel targets
  - dynamic importing [50-9](#)
  - dynamic mapping [50-9](#)
- Fibre Channel traffic
  - analyzing [68-2](#)
  - SPAN sources [62-3](#)
  - statistics [68-3](#)
- Fibre Channel write acceleration
  - default settings [56-3](#)
  - description [56-1](#)
  - enabling [56-2](#)
  - estimating number of write buffers [56-1](#)
  - licensing [56-1](#)
  - modifying number of write buffers [56-2](#)
- Fibre Channel zoning-based access control [50-27](#)
- Fibre Connection. See FICON
- FICON
  - advantages on MDS switches [36-3 to 36-7](#)
  - automatic configuration save [36-23](#)
  - basic configuration [36-16](#)
  - calculating flow load balance (procedure) [36-39](#)
  - cascading [36-7](#)
  - configuration files [36-28 to 36-31](#)
  - configuring [36-15 to 36-24](#)
  - configuring ports [36-24 to 36-28](#)
  - CUP in-band management [36-37](#)
  - default settings [36-42](#)
  - description [36-1 to 36-7](#)
  - displaying information [36-40 to 36-42](#)
  - fabric binding requirements [47-3](#)
  - Fabric Manager Client support [5-2](#)
  - FC4 protocols [36-2](#)
  - FC ID allocations [36-14](#)
  - FCIP support [36-5](#)
  - host timestamp control [36-22](#)
  - implemented ports [36-11](#)
  - installed ports [36-12](#)
  - manually enabling [36-18](#)
  - MDS-supported features [36-5](#)
  - PortChannel support [36-5](#)
  - port numbering [36-8 to 36-14](#)
  - port swapping [36-31 to 36-33](#)
  - RLIRs [36-27 to 36-28](#)
  - saving configuration changes [36-23](#)
  - suspending a VSAN [36-19](#)
  - sWWNs for fabric binding [47-4](#)
  - tape acceleration [36-33 to 36-37](#)
  - text string formatting codes [36-19](#)
  - unimplemented port [36-11](#)
  - VSAN offline state [36-19](#)
- ficonBeingEnabled tooltip [69-15](#)
- FICON configuration files
  - applying to running configuration [36-29](#)
  - copying [36-31](#)
  - description [36-29](#)
  - displaying [36-30](#)
  - editing [36-30](#)
  - view latest information [36-30](#)
- ficonNoPortnumber tooltip [69-15](#)
- ficonNotEnabled tooltip [69-15](#)
- FICON port numbers
  - assigning to slots [36-13](#)
  - default numbering scheme [36-8](#)
  - FCIP interfaces [36-13](#)
  - implemented addresses [36-11](#)
  - installed ports [36-12](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- logical interfaces [36-13](#)
- numbering guidelines [36-12](#)
- PortChannel interfaces [36-13](#)
- port swapping [36-11](#)
- reserved numbering scheme [36-11](#)
- unimplemented addresses [36-11](#)
- uninstalled ports [36-12](#)
- FICON ports
  - assigning address names using Device Manager [36-27](#)
  - blocking [36-25](#)
  - displaying address information [36-41](#)
  - prohibiting [36-26](#)
  - swapping configurations [36-33](#)
- FICON port swapping
  - configuring (procedure) [36-33](#)
  - guidelines [36-32](#)
- FICON tape acceleration
  - configuration considerations [36-35](#)
  - configuring [36-35](#)
  - description [36-33](#)
- ficonVsanDown tooltip [69-15](#)
- FICP
  - wizard [5-21](#)
- field replaceable units. See FRUs
- files
  - compressing [B-2](#)
  - displaying contents [B-1](#)
  - displaying last lines [B-2](#)
  - uncompressing [B-2](#)
- file systems
  - formatting [16-2](#)
  - volatile: [16-2](#)
- File Transfer Protocol. See FTP
- filtering
  - end port groups [5-16](#)
  - switch groups [5-16](#)
- filters
  - capture [68-21](#)
  - defining displays [68-21](#)
  - permitted [68-22](#)
  - selective viewing [68-20](#)
- FIPS
  - configuration guidelines [38-2](#)
  - self-tests [38-3](#)
- firewalls
  - configuring [2-14](#)
  - running with Fabric Manager [2-38](#)
- firstPortNotUp tooltip [69-15](#)
- firstPortUpAsEport tooltip [69-15](#)
- Flash devices
  - bootflash: [16-2](#)
  - formatting [16-2](#)
  - overview [16-1](#)
- FLOGI
  - description [34-1](#)
  - displaying details [34-1](#)
  - logging facility [63-2](#)
- flows
  - performance statistics [8-1](#)
  - viewing performance information [7-16](#)
- flow statistics
  - counting [8-4](#)
  - description [8-4](#)
- FL port mode
  - classes of service [20-5](#)
  - description [20-5](#)
- FL ports
  - configuring [20-12](#)
  - description [20-5](#)
  - DPVM support [28-7](#)
  - nonparticipating code [20-10](#)
  - nonparticipating codes [C-2](#)
  - persistent FC IDs [25-17](#)
  - SPAN sources [62-3](#)
  - See also Fx ports
- F port mode
  - classes of service [20-5](#)
  - description [20-5](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

## F ports

- configuring [20-12](#)
- description [20-5](#)
- DPVM support [28-7](#)
- SPAN sources [62-3](#)
- See also Fx ports

## FPSF

- load balancing (example) [48-5](#)

## frame encapsulation

- configuring [20-13](#)

## frames

- configuring MTU size [52-5, 53-3](#)
- viewing [68-20](#)

frequently asked questions. See FAQs

## FSPF

- computing link cost [32-7](#)
- configuring globally [32-4 to 32-6](#)
- configuring Hello time intervals [32-7](#)
- configuring link cost [32-6](#)
- configuring on interfaces [32-6 to 32-10](#)
- dead time intervals [32-8](#)
- default settings [32-19](#)
- description [32-2](#)
- disabling on interfaces [32-9](#)
- disabling routing protocols [32-6](#)
- displaying databases [32-10](#)
- fail-over with PortChannels [32-3](#)
- fault tolerant fabrics [32-2](#)
- flow statistics [8-3 to 32-19](#)
- in-order delivery [32-15 to 32-19](#)
- interoperability [37-10](#)
- link state record defaults [32-4](#)
- multicast root switches [32-14](#)
- path selection protocol [D-1](#)
- reconvergence times [32-2](#)
- redundant links [32-3](#)
- retransmitting intervals [32-8](#)
- routing services [32-1](#)
- support [2-16](#)

- topology examples [32-2 to 32-4](#)

## FSPF multicast roots

- configuring switches [32-14](#)

## FSPF routes

- configuring [32-12](#)
- description [32-12](#)

## FSPF routing

- multicast [32-14](#)

## FTP

- logging facility [63-2](#)
- support [2-15](#)

## full zone sets

- considerations [30-5](#)
- enabling distribution [30-25](#)

## fWWNs

- configuring fcalias members [30-20](#)

## Fx ports

- 32-port default [20-3](#)
- configuring [20-12](#)
- description [20-6](#)
- FCS [65-1](#)
- FCS support [65-1](#)
- interface modes [20-6](#)
- VSAN membership [26-4](#)
- See also F ports; FL ports [20-6](#)

---

## G

### Generation 1 switching modules

- combining with Generation 2 switching modules [?? to 22-18](#)
- extended BB\_credits [20-22](#)
- port index allocations [22-16](#)
- QoS behavior [66-8](#)

### Generation 2 switching modules

- buffer groups [22-8 to 22-14](#)
- combining with Generation 1 switching modules [?? to 22-18](#)
- configuring [22-18 to ??](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- configuring port speeds [22-21](#)
- configuring rate modes [22-22](#)
- default settings [22-31](#)
- description [22-1 to ??](#)
- dynamic bandwidth management [22-6](#)
- extended BB\_credits [20-23, 22-15](#)
- installing in Generation 1 chassis [15-15](#)
- out-of-service interfaces [22-7](#)
- port groups [22-2](#)
- port index allocations [22-16](#)
- port rate modes [22-4](#)
- QoS behavior [66-8](#)
- recovering from powered-down state [22-17](#)
- releasing shared resources [22-29](#)
- taking interfaces out of service [22-28](#)

Gigabit Ethernet

- IPv4 example configuration [52-4](#)

Gigabit Ethernet interface example [50-53](#)

Gigabit Ethernet interfaces

- configuring [52-4 to 52-10](#)
- configuring auto-negotiation [52-5, 53-3](#)
- configuring CDP [12-12](#)
- configuring high availability [52-8 to 52-10](#)
- configuring IPv4 [53-2](#)
- configuring IPv6 addresses [54-12](#)
- configuring MTU frame sizes [52-5, 53-3](#)
- configuring promiscuous mode [52-6, 53-4](#)
- configuring VRRP [52-9](#)
- default parameters [53-6](#)
- IPv4-ACL guidelines [53-6](#)
- subinterfaces [52-6, 53-5](#)
- subnet requirements [52-6, 53-5](#)
- viewing performance information [7-18](#)

Gigabit Ethernet subinterfaces

- configuring VLANs [53-5](#)

global keys

- assigning for RADIUS [41-8](#)

## H

hardware

- default settings [18-12](#)
- displaying inventory [18-1](#)
- displaying temperatures [18-11](#)
- overview [1-1](#)
- viewing list [7-9](#)

hardware failures

- configuring actions [B-3](#)

hard zoning

- description [30-25](#)

HA solution example [50-52](#)

HBA port [50-15, 50-20](#)

HBA ports

- configuring area FCIDs [25-19](#)

HBAs

- device aliases [31-1](#)
- FC ID allocations [37-7, 68-24](#)

Health tab

- description [7-8](#)

Hello time intervals

- configuring for FSPF [32-8](#)
- description [32-7](#)

high availability

- automatic synchronization [17-4](#)
- compatibility with DHCHAP [45-3](#)
- description [17-1](#)
- Ethernet PortChannel [50-55](#)
- Ethernet PortChannels [48-6](#)
- Fibre Channel PortChannels [48-7](#)
- licensing [10-8](#)
- process restartability [17-3](#)
- protection against link failures [17-1](#)
- software upgrades [15-5](#)
- supervisor module switchover mechanism [17-2](#)
- switchover characteristics [17-2](#)
- synchronizing supervisor modules [17-3](#)
- VRRP [48-6, 50-54](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- VRRPVRRP-based high availability [50-54](#)
  - historical data
    - preserving [69-18](#)
  - host control
    - FICON [36-21](#)
  - host names
    - configuring for digital certificates [43-6](#)
  - hosts
    - performance statistics [8-1](#)
  - HTTP
    - port used [2-39](#)
    - support [2-16](#)
  - HTTP proxy servers
    - configuring [69-20](#)
  - HTTPS
    - support [2-16](#)
  - hwFailure tooltip [69-15](#)
- 
- description [44-3](#)
    - initializing [44-13](#)
    - refreshing SAs [44-20](#)
    - terminology [44-5](#)
    - transforms for encryption [44-6](#)
    - viewing configuration (procedure) [44-11](#)
  - IKE domains
    - clearing [44-20](#)
    - description [44-13](#)
  - IKE initiators
    - configuring version [44-18](#)
  - IKE peers
    - configuring keepalive times [44-17](#)
  - IKE policies
    - configuring negotiation parameters [44-15](#)
    - negotiation [44-14](#)
  - IKE tunnels
    - clearing [44-20](#)
    - description [44-13](#)
  - images
    - See kickstart images; software images; system images
    - Software Installation Wizard [15-8](#)
  - images. See kickstart images; software images; system images
  - in-band access
    - configuring [2-9](#)
    - IPFC [2-12](#)
  - in-band management
    - configuring [2-8, 2-10](#)
    - CUP [36-37](#)
    - Ethernet connection [2-17](#)
    - IPFC [51-5](#)
    - IPFC connection [2-17](#)
    - logical interface [2-8](#)
  - incomAdminRxBBCreditPerBuf tooltip [69-16](#)
  - incompatibleAdminMode tooltip [69-16](#)
  - incompatibleAdminRxBBCredit tooltip [69-16](#)
  - incompatibleAdminRxBufferSize tooltip [69-16](#)
  - incompatibleadminSpeed tooltip [69-16](#)
- 
- IBM PPRC
    - FICON support [36-5](#)
  - ICMP
    - IPv6 [54-6](#)
  - ICMP packets
    - IPv6 header format, figure [54-6](#)
    - type value [42-4](#)
  - icons
    - Device Manager [6-4](#)
  - IDs
    - Cisco vendor ID [41-13](#)
    - contract IDs [64-23](#)
    - login IDs [2-5](#)
    - serial IDs [64-24, 64-26, 64-28](#)
    - server IDs [64-24](#)
    - site IDs [64-23](#)
  - IKE
    - algorithms for authentication [44-6](#)
    - default settings [43-37, 44-39](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- indirect link failures
  - recovering [67-1](#)
- initialization string
  - configuring [B-1](#)
- initializing tooltip [69-16](#)
- initiators
  - statically mapped iSCSI [50-35](#)
- in-order delivery
  - configuring drop latency time [32-18](#)
  - enabling for VSANs [32-18](#)
  - enabling globally [32-18](#)
  - guidelines [32-17](#)
  - reordering network frames [32-15](#)
  - reordering PortChannel frames [32-17](#)
- install all command
  - failure cases [15-7](#)
- Intelligent Storage Services
  - description [58-1](#)
  - disabling (procedure) [55-5, 58-3](#)
  - disabling with force option [55-6, 58-3](#)
  - enabling (procedure) [55-3, 58-2](#)
  - Fibre Channel write acceleration [56-1 to 56-3](#)
  - SCSI flow services [55-1 to 55-8](#)
  - SCSI flow statistics [55-1 to 55-8](#)
- interfaceRemoved tooltip [69-16](#)
- interfaces
  - adding to PortChannels [23-13, 23-14](#)
  - assigning to VSANs [26-8](#)
  - configuring data field size [20-13](#)
  - configuring fcalias members [30-20](#)
  - default settings [20-26](#)
  - deleting from PortChannels [23-16](#)
  - forced addition to PortChannels [23-15](#)
  - isolated states [23-14](#)
  - nonoperational reason codes [C-1](#)
  - reason codes [C-1](#)
  - SFP types [20-16](#)
  - suspended states [23-14](#)
  - VSAN membership [26-7](#)
- interface statistics
  - description [20-17](#)
  - gathering [20-17](#)
- internal bootflash:
  - Flash devicesFlash devices [16-3](#)
  - initializing [16-2](#)
  - kickstart images [16-2](#)
  - recovering from corruption [16-2](#)
- internal loopback tests
  - description [70-7](#)
  - performing [70-7](#)
- Internet Control Message Protocol. See ICMP
- Internet Explorer
  - Fabric Manager support [2-19](#)
- Internet Key Exchange. See IKE
- Internet Storage Name Service. See iSNS
- interoperability
  - configuring interop mode 1 [37-11](#)
  - description [37-8](#)
  - verifying status [37-12](#)
  - VSANs [26-12](#)
- interop modes
  - configuring mode 1 [37-11](#)
  - default settings [37-13](#)
  - description [37-8](#)
- Inter-VSAN Routing. See IVR
- Inter-VSAN Routing zones. See IVR zones
- Inter-VSAN Routing zone sets. See IVR zone sets
- invalidAttachment tooltip [69-16](#)
- invalidConfig tooltip [69-16](#)
- invalidFabricBindExh tooltip [69-16](#)
- inventories
  - managing [59-3](#)
  - viewing details for switches [7-24](#)
  - viewing details for VSANs [7-23](#)
  - viewing information [7-31](#)
  - viewing ISL information [7-28](#)
  - viewing module details [7-26](#)
  - viewing switch licenses [7-25](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- viewing zone information [7-30](#)
- Inventory tab
  - description [7-23](#)
- IOD. See in-order delivery
- IP-ACLs
  - wizard [5-22](#)
  - See also IPv4-ACLs; IPv6-ACLs
- IP addresses
  - management interfaces [2-2](#)
- IP connections
  - active mode [48-25](#)
  - initiating [48-25](#)
  - passive mode [48-25](#)
- IP domain names
  - configuring for digital certificates [43-6](#)
- IPFC
  - configuration guidelines [51-5](#)
  - description [51-5](#)
  - errors caused by configuration [69-8](#)
  - in-band access [2-12](#)
  - in-band management [2-17](#)
  - logging facility [63-2](#)
- IP filters
  - contents [42-2](#)
  - restricting IP traffic [42-1](#)
  - using IP-ACL Wizard (procedure) [42-5](#)
- IP routing
  - enabling [2-6, 2-10](#)
- IPsec
  - algorithms for authentication [44-6](#)
  - configuring with FCIP Wizard (procedure) [48-9](#)
  - crypto IPv4-ACLs [44-21 to 44-25](#)
  - default settings [44-39](#)
  - description [44-2](#)
  - digital certificate support [44-7 to 44-10](#)
  - enabling with FCIP Wizard (procedure) [44-10](#)
  - fabric setup requirements [44-4](#)
  - global lifetime values [44-37](#)
  - hardware compatibility [44-4](#)
  - licensing requirements [44-3](#)
  - maintenance [44-37](#)
  - prerequisites [44-3](#)
  - RFC implementations [44-1](#)
  - terminology [44-5](#)
  - transform sets [44-25](#)
  - transforms for encryption [44-6](#)
  - unsupported features [44-4](#)
  - viewing configuration (procedure) [44-11](#)
- IP security. See IPsec
- IPS modules
  - CDP support [52-10](#)
  - core dumps [B-2](#)
  - FCIP [48-2](#)
  - port modes [52-4, 53-1](#)
  - software upgrades [52-3](#)
  - supported features [52-1](#)
- IPS port mode
  - description [52-4](#)
- IPS ports [50-8](#)
  - modes [53-1](#)
  - multiple connections [50-53](#)
  - SPAN sources [62-3](#)
- IP storage services
  - default parameters [52-10](#)
- IP Storage services modules. See IPS modules
- IPv4
  - configuring Gigabit Ethernet interfaces [53-2](#)
  - default settings [53-6](#)
  - description [53-1](#)
  - transitioning to IPv6 [54-15](#)
- IPv4-ACLs
  - adding entries [42-7](#)
  - applying to interfaces [42-9, 42-10](#)
  - configuration guidelines [42-2](#)
  - creating complex IPv4-ACLs (procedure) [42-6](#)
  - creating with IP-ACL Wizard (procedure) [42-5](#)
  - crypto [44-21 to 44-25](#)
  - crypto map entries [44-28](#)



***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- example configuration [42-11](#)
- FabricWare support [D-2](#)
- guidelines for Gigabit Ethernet interfaces [53-6](#)
- reading dump logs [42-8](#)
- removing entries [42-8](#)
- IPv4 addresses
  - configuring fcalias members [30-20](#)
  - configuring IPv6 and IPV6 protocol stacks [54-13](#)
  - IPv6 protocol stacks [54-10](#)
- IPv4 default gateways
  - configuring [2-10, 12-11, 51-3](#)
  - configuring mgmt0 interfaces [20-23](#)
  - description [51-3](#)
  - static routes (tip) [51-4](#)
- IPv4 default networks
  - description [51-4](#)
- IPv6
  - address types [54-3](#)
  - configuring addressing [54-11](#)
  - configuring IPv4 and IPv6 addresses [54-13](#)
  - configuring management interfaces [51-3](#)
  - default settings [54-15](#)
  - description [54-1 to 54-11](#)
  - dual IPv4 and IPv6 protocol stack applications, figure [54-11](#)
  - dual IPv4 and IPv6 protocol stacks [54-10](#)
  - dual IPv4 and IPv6 protocol stack technique, figure [54-10](#)
  - enabling routing [54-11](#)
  - enhancements over IPv4 [54-1](#)
  - ICMP [54-6](#)
  - IPv6-ACL guidelines [54-14](#)
  - neighbor discovery [54-7](#)
  - path MTU discovery [54-7](#)
  - router advertisement messages [54-9](#)
  - router discovery [54-9](#)
  - stateless autoconfiguration [54-9](#)
  - static routes [54-13](#)
  - transitioning from IPv4 [54-15](#)
  - IPv6-ACLs
    - guidelines for IPv6 [54-14](#)
  - IPv6 addresses
    - configuring [54-11](#)
    - configuring fcalias members [30-2, 30-20](#)
    - configuring IPv4 and IPV6 protocol stacks [54-13](#)
    - formats [54-2](#)
    - link-local type [54-4](#)
    - multicast type [54-5](#)
    - prefix format [54-3](#)
    - unicast type [54-3](#)
  - IPv6 neighbor discovery
    - advertisement messages [54-7](#)
    - description [54-7](#)
    - neighbor solicitation message, figure [54-8](#)
    - solicitation messages [54-7](#)
  - IPv6 routing
    - enabling [54-11](#)
  - IPv6 static routes
    - configuring [54-13](#)
  - IQN
    - formats [50-8](#)
  - IQNs
    - formats [50-8](#)
  - ISCSI
    - enforcing access control [50-27](#)
  - iSCSI
    - access control [50-24 to 50-28](#)
    - add initiator to zone database [50-25](#)
    - advanced VSAN membershipadvanced VSAN membership [50-24](#)
    - checking for WWN conflicts [50-19](#)
    - compatible drivers [50-2](#)
    - configuring [50-1, 50-1 to ??, 50-4, ?? to 50-56](#)
    - configuring AAA authentication [50-28, 50-29](#)
    - configuring ACLs [50-26](#)
    - configuring VRRP [50-54](#)
    - creating virtual targets [50-10](#)
    - default parameters [50-75](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- discovery phase [50-27](#)
- drivers [50-2](#)
- enabling [50-4](#)
- error [50-15](#)
- Fabric Manager Client support [5-2](#)
- Fibre Channel targets [50-7 to 50-13](#)
- Gigabit Ethernet ports [52-4, 53-1](#)
- GW flagiSCSI
  - gateway device [50-16](#)
- HA with host without multi-path software [50-51](#)
- initiator idle timeout
  - initiator idle timeout
    - iSCSIinitiator idle timeout
      - configuring with Fabric Manager [50-16](#)
- initiator name [50-30](#)
- initiator targets [50-6](#)
- IPS module support [52-2](#)
- IQNs [50-14](#)
- login redirect [50-37](#)
- LUN mapping for targets [50-62 to ??](#)
- MPS-14/2 module support [52-2](#)
- multiple IPS ports [50-53](#)
- PortChannel-based high availability [50-55](#)
- PortChannel-based high availabilityEthernet
  - PortChannel-based high availability [50-55](#)
- protocol [50-2](#)
- requests and responses [50-3](#)
- restrict an initiator to a specific user name for CHAP authentication [50-30](#)
- routing [50-2](#)
- routing modes chart
  - routing modes chart for iSCSI [50-34](#)
- session creation [50-27](#)
- session limits [50-15](#)
- statically mapped initiators [50-35](#)
- tables in Fabric Manager [50-19](#)
- targets in Device Manager [50-9](#)
- transparent initiator mode [50-15](#)
- transparent mode initiator [50-58 to ??](#)
- users with local authentication [50-30](#)
- using iSCSI Wizard (procedure) [50-5 to 50-7](#)
- VSAN membership [50-22](#)
- VSAN membership example [50-23](#)
- VSAN membership for iSCSI interfaces [50-22, 50-23](#)
- wizard [5-22](#)
- zone name [50-7](#)
- iSCSI authentication
  - configuring [50-28, 50-43](#)
  - configuring RADIUS (procedure) [50-31](#)
  - external RADIUS servers [50-57](#)
  - global override [50-29](#)
  - local authentication [50-30](#)
  - mechanisms [50-29](#)
  - restricting on initiators [50-30](#)
  - scenarios [50-56](#)
  - setup guidelines [50-56](#)
- iSCSI-based access control [50-26](#)
- iSCSI devices
  - example membership in VSANs [50-23](#)
- iscsi-gw [50-20](#)
- iSCSI high availability
  - configuring [50-50 to 50-56](#)
- ISCSI hosts
  - VSAN membership [50-22](#)
- iSCSI hosts
  - initiator identification [50-14](#)
  - initiator presentation modes [50-14](#)
  - initiator presentation modesinitiator presentation modes [50-14](#)
- iSCSI initiators
  - configuring static IP address mapping [50-18](#)
  - dynamic mapping [50-17](#)
  - idle timeout [50-16](#)
  - making dynamic WWN mapping static [50-19](#)
  - proxy mode [50-20](#)
  - statically mapped (procedure) [50-18](#)
  - static mapping [50-17](#)
  - transparent mode [50-15](#)
  - WWN assignments [50-17](#)
- iSCSI interfaces

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- configuring [50-14, 50-14 to ??](#)
- configuring listener ports [50-32](#)
- configuring listener ports iSCSI
  - listener port [50-32](#)
- configuring QoS [50-32](#)
- configuring routing mode [50-33 to ??](#)
- configuring routing modes iSCSI
  - configuring routing modes routing modes [50-33](#)
- configuring TCP tuning parameters [50-32](#)
- creating [50-5](#)
- creating iSCSI
  - creating interfaces [50-5](#)
- SPAN sources [62-3](#)
- VSAN membership [50-23](#)
- iSCSI LUs [50-8](#)
- iSCSI protocol [50-1](#)
- iSCSI server load balancing [50-35](#)
- iSCSI Server Load Balancing. See [iSLB](#)
- iSCSI sessions
  - authentication iSCSI
    - session authentication authentication
      - iSCSI session [50-28](#)
- iSCSI targets
  - advertising [50-12](#)
  - dynamic importing [50-8](#)
  - dynamic mapping [50-8](#)
  - examples [50-12](#)
  - secondary access [50-52](#)
  - static importing [50-10](#)
  - static importing static mapping iSCSI targets
    - static mapping [50-10](#)
  - transparent failover [50-50](#)
- iSLB
  - activating zones [50-41, 50-42](#)
  - auto-zoning [50-46](#)
  - CFS support [13-2](#)
  - committing configuration changes committing configuration changes
    - iSLB [50-48](#)
  - configuration distribution [50-46 to ??, 50-47](#)
  - configuration limits [50-36](#)
  - configuration prerequisites [50-36](#)
  - configuring [50-35](#)
  - configuring initiators and targets [50-41](#)
  - configuring VRRP [50-45](#)
  - configuring with Device Manager [50-37](#)
  - configuring zones [50-41, 50-42](#)
  - default settings [50-76](#)
  - distributing configuration using CF [50-46](#)
  - dynamic initiator mapping [50-40](#)
  - enabling configuration distribution [50-47](#)
  - initiator WWN assignment [50-35](#)
  - load balancing algorithm [50-45 to ??](#)
  - maximum initiators [50-36](#)
  - static initiator configuration initiator configuration
    - static iSLB [50-35](#)
  - VSAN membership [50-40](#)
  - zone set activation failed [50-42](#)
- iSLB
  - default settings [50-76](#)
- iSLB auto-zone feature [50-36](#)
- iSLB initiators [50-37](#)
  - activating zones [50-42](#)
  - assigning WWNs [50-39](#)
  - configuring [50-39 to 50-43](#)
  - configuring load balancing metrics [50-40](#)
  - configuring zones [50-42](#)
  - dynamic initiator mapping [50-40](#)
  - VSAN membership [50-40](#)
- iSLB initiator targets
  - activating zones [50-42](#)
  - configuring zones [50-42](#)
  - description [50-41](#)
- iSLB sessions
  - authentication [50-43](#)
  - authentication iSLB
    - sessions authentication [50-43](#)
  - maximum per IPS ports iSLB

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- maximum sessions per IPS port [50-36](#)
- iSLB with CFS distribution [50-36](#)
- ISLs
  - graph past 24 hours performance [7-21](#)
  - performance statistics [8-1](#)
  - PortChannel links [23-1](#)
  - statistics [60-3](#)
  - viewing detailed inventory information [7-28](#)
  - viewing performance information [7-15](#)
- iSMS servers
  - enabling [50-71](#)
- iSNS
  - CFS support [13-2](#)
  - client registration [50-72](#)
  - cloud discovery [50-73](#)
  - configuring [50-73](#)
  - configuring servers [50-71 to 50-73](#)
  - description [50-67](#)
  - ESI [50-72](#)
- iSNS cloud discovery
  - automatic [50-75](#)
  - CFS distribution [50-75](#)
  - description [50-73](#)
  - enabling [50-74](#)
  - initiating on-demand [50-74](#)
- iSNS profiles
  - creating [50-68](#)
- iSNS servers
  - configuration distribution [50-71](#)
  - configuring ESI retry count [50-72](#)
  - enabling [50-71](#)
  - example scenario [50-70](#)
- isolated VSANs
  - description [26-8](#)
  - displaying membership [26-9](#)
- IVR
  - activating topologies [29-17](#)
  - AF IDs [29-15](#)
  - auto-topology [29-6](#)
  - border switch [29-4](#)
  - border switch, guidelines [29-15](#)
  - border switch configuration guidelines [29-15](#)
  - border switches [29-4](#)
  - configuring (procedure) [29-15](#)
  - configuring logging levels [29-21](#)
  - configuring without auto topology [29-13](#)
  - configuring without IVR NAT [29-13](#)
  - current VSANs [29-3](#)
  - database merge guidelines [29-31](#)
  - default settings [29-34](#)
  - default zone policy [29-22](#)
  - description [29-2](#)
  - domain ID configuration guidelines [29-14](#)
  - domain ID guidelines [29-14](#)
  - edge switch [29-4](#)
  - edge switches [29-4](#)
  - edge VSANs [29-3](#)
  - Fabric Manager Client support [5-2](#)
  - features [29-3](#)
  - Fibre Channel header modifications [29-4](#)
  - FICON support [B-2](#)
  - interoperability [29-7](#)
  - logging [29-21](#)
  - modifying [29-9](#)
  - native VSANs [29-3](#)
  - paths [29-3](#)
  - persistent FC IDs [29-19](#)
  - read-only zoning [29-31](#)
  - SDV limitations [27-8](#)
  - service groups [B-2](#)
  - sharing resources [29-2](#)
  - terminology [29-3](#)
  - transit VSAN configuration guidelines [29-14](#)
  - transit VSANs [29-3](#)
  - virtual domains [29-18](#)
  - VSAN topologies [29-6](#)
  - wizard [5-21](#)
  - zone communication [29-22](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- zones [29-3, 29-22 to ??](#)
  - zone sets [29-3](#)
  - Zone Wizard [29-7](#)
  - IVR databases
    - merge guidelines [29-31](#)
  - IVR logging
    - configuring levels [29-21](#)
  - IVR NAT
    - auto-topology [29-6](#)
    - border switch, guidelines [29-10](#)
    - configuration guidelines [29-10](#)
    - description [29-5](#)
    - load balancing [29-5](#)
    - modifying (procedure) [29-12](#)
    - transit VSANs, guidelines [29-10](#)
  - IVR persistent FC IDs
    - configuring [29-20](#)
    - persistent [29-19](#)
  - IVR topologies
    - CFS support [13-2](#)
    - clearing manual entries [29-17](#)
    - creating manually [29-15](#)
    - manually activating [29-17](#)
    - migrating from automatic mode to user-configured mode [29-18](#)
    - recovering [29-29](#)
  - IVR virtual domains
    - configuring [29-19](#)
    - description [29-18](#)
  - IVR zones
    - activating with force option [29-26](#)
    - automatic creation [29-23](#)
    - clearing database [29-31](#)
    - configuring [29-24 to ??](#)
    - configuring LUNs [29-30](#)
    - configuring QoS attributes [29-30](#)
    - configuring with IVR Zone Wizard [29-7](#)
    - description [29-3, 29-22](#)
    - differences with zones (table) [29-22](#)
    - downgrading considerations [29-31](#)
    - LUN zoning [29-30](#)
    - maximum number of members [29-4](#)
    - maximum number of zones [29-4](#)
    - recovering the full database [29-28](#)
    - renaming [29-30](#)
  - IVR zone sets
    - configuring [29-24 to ??](#)
    - description [29-3, 29-22](#)
    - downgrading considerations [29-31](#)
    - maximum number [29-4](#)
    - renaming [29-30](#)
- 
- ## J
- Java
    - execution failures [69-6](#)
    - java.lang.ArrayIndexOutOfBoundsException  
errorArrayIndexOutOfBoundsException error [69-7](#)
  - Java RMI
    - ports used [2-39](#)
  - Java Runtime Environment. See JRE
  - Java Web Start
    - checking installation [69-3](#)
    - clearing the cache [69-6](#)
    - Fabric Manager support [2-19](#)
    - hangs on the download dialog [69-5](#)
    - not detected [69-4](#)
    - running from command line [69-5](#)
    - setting up on \*.jnlp files [69-5](#)
  - jitter
    - configuring estimated maximum in FCIP profiles [48-21](#)
  - JNLP
    - verifying settings [69-3](#)
  - JRE
    - Fabric Manager requirements [7-4](#)
  - jumbo frames. See MTUs

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

## K

### keepalive timeouts

configuring in FCIP profiles [48-19](#)

### kernel core dumps

configuring [B-3](#)

### kickstart images

description [15-2](#)

KICKSTART variable [15-1](#)

selecting for supervisor modules [15-2](#)

### Konqueror

configuring for Java Web Start [69-5](#)

## L

### latency

forwarding [50-33](#)

### LEDs

beacon mode states [20-14](#)

speed [20-14](#)

### license key files

description [10-2](#)

installing [10-10](#)

obtaining [10-9](#)

updating [10-9](#)

### licenses

backing up files [B-1](#)

claim certificate [10-2](#)

description [10-1](#)

displaying information [10-16](#)

enterprise package [10-4](#)

expiry alerts [10-15](#)

extended BB\_credits [20-22, 22-15](#)

Fabric Manager [69-23](#)

Fabric Manager Server [10-17](#)

Fabric Manager Server package [10-6](#)

factory-installed [10-9](#)

feature-based [10-3](#)

features supported (table) [10-4](#)

grace period alerts [10-15](#)

grace period expiration [10-15](#)

high availability [10-8](#)

identifying features in use [10-13](#)

installation options [10-8](#)

installing manually [10-9](#)

installing using Device Manager [10-12](#)

installing using License Wizard [10-11](#)

installing with License Wizard [10-11](#)

key files [10-9 to 10-13](#)

mainframe package [10-6](#)

module-based [10-3](#)

moving between switches [B-1](#)

obtaining [10-9](#)

on-demand port activation [11-1](#)

One-Click License Install failed [69-9](#)

PAK [10-2](#)

SAN extension package [10-5](#)

Storage Services Enabler package [10-7](#)

terminology [10-1](#)

transferring between switches [10-16](#)

uninstalling [10-14](#)

unsupported features [B-1](#)

updating [10-14](#)

viewing in Device Manager [10-16](#)

viewing in Fabric Manager [10-16](#)

viewing in Fabric Manager Web Services [10-17](#)

viewing switch information [7-25](#)

viewing with Fabric Manager Web Server (procedure) [10-17](#)

wizard [5-22](#)

### limits

description (table) [i-lxx, E-1](#)

line cards. See switching modules; services modules

### link costs

configuring for FSPF [32-7](#)

description [32-6](#)

linkFailCreditLossB2B tooltip [69-16](#)

linkFailCreditLoss tooltip [69-16](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- linkFailDebounceTimeout tooltip [69-16](#)
- linkFailLineCardPortShutdown tooltip [69-16](#)
- linkFailLinkReset tooltip [69-16](#)
- linkFailLIPF8Rcvd tooltip [69-16](#)
- linkFailLIPRcvdB2B tooltip [69-16](#)
- linkFailLossOfSignal tooltip [69-16](#)
- linkFailLossOfSync tooltip [69-16](#)
- linkFailLRRcvdB2B tooltip [69-16](#)
- linkFailNOSRcvd tooltip [69-16](#)
- linkFailOLSRcvd tooltip [69-16](#)
- linkFailOPNyRETB2B tooltip [69-16](#)
- linkFailOPNyTMOB2B tooltip [69-16](#)
- linkFailPortInitFail tooltip [69-16](#)
- linkFailPortUnusable tooltip [69-16](#)
- linkFailRxQOverFlow tooltip [69-16](#)
- linkFailTooManyINTR tooltip [69-16](#)
- link failures
  - protection against [17-1](#)
  - reason codes [C-1](#)
  - recovering [67-1](#)
- linkFailure tooltip [69-16](#)
- Link Incident Records. See LIRs
- link-local addresses
  - description [54-4](#)
  - format, figure [54-4](#)
- link redundancy
  - Ethernet PortChannel aggregation [52-9](#)
- Linux [2-31](#)
  - Fabric Manager support [2-19](#)
  - installing Fabric Manager Web Services [7-4](#)
  - install scripts [2-31](#)
- LIRs
  - description [36-27](#)
- load balancing [50-35, 50-37](#)
  - attributes [26-11](#)
  - attributes for VSANs [26-5](#)
  - configuring [26-11](#)
  - description [23-4, 26-11](#)
  - FSPF (example) [48-5](#)
  - PortChannels [23-1](#)
  - PortChannels (example) [48-5](#)
  - weighted [50-40](#)
- load metric [50-40](#)
- lock the fabric [50-48](#)
- log files
  - configuring [63-6](#)
  - default names [63-6](#)
  - description [70-3](#)
  - sizes [63-6](#)
- logging
  - default settings [63-11](#)
  - disabling [63-3](#)
  - enabling [63-3](#)
  - message severity levels [63-3](#)
- logical unit numbers. See LUNs
- logins
  - failure recovery [69-6](#)
  - SSH [41-4](#)
  - Telnet [41-4](#)
- logs
  - increasing log window size [69-10](#)
  - RMON [61-18](#)
  - SNMP events [40-12](#)
  - viewing information [7-56](#)
  - viewing using Device Manager [59-4](#)
  - viewing using Fabric Manager Web Server [59-3](#)
- loopbackDiagFailure tooltip [69-17](#)
- loopbackIsolation tooltip [69-17](#)
- loopback tests
  - configuring frequency [B-3](#)
  - external [70-7](#)
- loops
  - monitoring [B-3](#)
- LUN [50-8](#)
  - trespass for storage port failover [50-53](#)
- LUN mapping [50-52](#)
  - iSCSI [50-62 to ??](#)
- LUNs

## Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

- explicit access control [50-20](#)
- IVR zoning [29-30](#)
- mapping and assignment [50-20](#)

### LUN zoning

- configuring [30-37](#)
- description [30-36](#)

### LUs [50-7, 50-8](#)

- Display Unselected VSAN Members default [5-19](#)
- Expand Loops default [5-19](#)
- Expand Multiple Links default [5-19](#)
- Layout New Devices Automatically default [5-19](#)
- Open New Device Manager Each Time default [5-19](#)
- Override Preferences for Non-default Layout default [5-19](#)
- Select Switch or Link from Table default [5-19](#)
- Use Quick Layout when Switch has  $\geq 30$  End Devices default [5-19](#)

## M

### MAC addresses

- configuring secondary [37-6, 68-23](#)

### mainframe package licenses

- description [10-6](#)

### mainframes

- FICON parameters [36-22](#)
- VSAN clock [36-22](#)

### management

- role-based [5-21](#)

### management access

- configuring in-band [2-8 to 2-12](#)
- configuring out-of-band [2-4 to 2-8](#)
- description [2-12](#)
- in-band [2-3](#)
- out-of-band [2-3](#)

### management interfaces

- configuring [20-23, 20-24, 51-3](#)
- configuring for IPv6 [51-3](#)
- default settings [20-26](#)
- features [20-24](#)
- IP addresses [2-2](#)
- See also mgmt0 interfaces

### management protocols

- supported (table) [2-15](#)

### map preferences

- Automatically Save Layout default [5-19](#)
- Detach Overview Window default [5-19](#)
- Display End Device Labels default [5-19](#)
- Display End Devices default [5-19](#)

### maps

- black squares [69-13](#)
- brown squares [69-13](#)
- clearing license orange X [69-23](#)
- clearing topologies [69-21](#)
- color definitions [69-13](#)
- default preferences [5-19](#)
- freezing the layout look [69-12](#)
- green squares with mode [69-13](#)
- grouping end devices [5-20](#)
- highlighting [5-14](#)
- icon descriptions [5-12](#)
- light gray squares [69-13](#)
- module warnings [69-13](#)
- no squares [69-13](#)
- orange crosses [69-13](#)
- orange squares with mode [69-13](#)
- purging down elements [5-15](#)
- red crosses [69-13](#)
- red line through switches [69-13](#)
- red squares [69-13](#)
- refreshing [5-15](#)
- saving [5-14](#)
- shows two switches when only one [69-12](#)
- tab descriptions [5-13](#)
- upgrade software without losing map settings [69-18](#)
- viewing large [5-14](#)
- Visio diagrams [5-15](#)

### maps module failuresmaps



***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- fan failuresmaps
  - power supply failures [69-13](#)
- maximum retransmissions
  - configuring in FCIP profiles [48-19](#)
- McAfee Internet Suite 6.0 Professional
  - Device Manager installation failures [69-7](#)
  - Fabric Manager installation failures [69-7](#)
- McData
  - native interop mode [37-8](#)
- MD5 authentication
  - IKE [44-7](#)
  - IPsec [44-6](#)
  - VRRP [51-12](#)
- merged fabrics
  - autoreconfigured [25-7](#)
- merge status conflictsiSLB
  - merge status conflictsCFS
    - merge status conflicts [50-49](#)
- Message Authentication Code using AES. See AES-XCBC-MAC
- Message Digest 5. See MD5 authentication
- messages
  - selecting severity level [7-44](#)
- mgmt0
  - out-of-band management [2-17](#)
- mgmt0 interfaces
  - configuring [12-10, 20-23, 20-24](#)
  - configuring out-of-band access [2-6](#)
  - default settings [20-26](#)
  - features [20-24](#)
  - local IPv4 routing [51-5](#)
  - out-of-band access [2-12](#)
- Microsoft Challenge Handshake Authentication Protocol. See MSCHAP
- minimum retransmit timeouts
  - configuring in FCIP profiles [48-19](#)
- modems
  - configuring settings [B-1](#)
- module configurations
  - preserving [B-2](#)
  - purging [B-2](#)
  - saving to NVRAM [19-7](#)
- modules
  - configuring message logging [63-5](#)
  - connecting to [B-2](#)
  - displaying temperatures [18-11](#)
  - preserving the configuration [19-7](#)
  - replacing [15-15](#)
  - resetting [19-5](#)
  - state descriptions [19-4](#)
  - temperature monitoring [18-10](#)
  - verifying status [12-2, 19-3](#)
- module tests
  - configuring [B-3](#)
- monitoring traffic
  - SPAN [62-6](#)
- Mozilla
  - configuring for Java Web Start [69-5](#)
- MPS-14/2 modules [50-1, 50-2, 50-3, 50-5, 50-20, 50-27](#)
  - CDP support [52-10](#)
  - configuring extended BB\_credits [20-22](#)
  - FCIP [48-2](#)
  - port modes [52-4, 53-1](#)
  - software upgrades [52-3](#)
  - supported features [52-1](#)
- MSCHAP
  - description [41-25](#)
- MTU frame sizes
  - configuring Gigabit Ethernet interfaces [52-5](#)
- MTUs
  - configuring frame sizes [53-3](#)
  - configuring size
    - path discovery for IPv6 [54-7](#)
- multicast addresses
  - IPv6 alternative to broadcast addresses [54-6](#)
  - IPv6 format, figure [54-5](#)
  - IPv6 solicited-node format, figure [54-6](#)
- multicast root switches

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- configuring [32-14](#)
- description [32-14](#)
- multi-path software example [50-51](#)
- multiple fabrics [59-3](#)
  - managing [69-23](#)
- multiple VSANs
  - configuring [51-7](#)
- Multiprotocol Services modules. See MPS-14/2 modules
- mutual CHAP authentication
  - configuring for iSCSI [50-30](#)
  - configuring for iSLB [50-43](#)
  - configuring for iSLBI [50-43](#)

## N

- name servers
  - displaying database entries [34-3](#)
  - interoperability [37-10](#)
  - LUN information [35-1](#)
  - proxy feature [34-2](#)
  - registering proxies [34-2](#)
  - rejecting duplicate pWWNs [34-3](#)
- NASB
  - configuring (procedure) [58-5](#)
  - default settings [58-6](#)
- NAT. See IVR NAT
- native VSANs
  - description [29-3](#)
- Network-Accelerated Serverless Backup. See NASB.
- Network Address Translation. See IVR NAT
- network administrator roles
  - FabricWare [D-2](#)
- network administrators
  - additional roles [41-3](#)
  - permissions [41-3](#)
- network monitoring
  - device discovery [59-1](#)
  - mapping topologies [59-1](#)
- network operator roles

- FabricWare [D-2](#)
- network operators
  - permissions [41-3](#)
- Network Time Protocol. See NTP
- NICs
  - manually specifying for Device Manager [69-20](#)
  - manually specifying for Fabric Manager Client [69-20](#)
  - manually specifying for Fabric Manager Server [69-20](#)
- NL ports
  - hard zoning [30-25](#)
  - interface modes [20-7](#)
  - zone enforcement [30-25](#)
- node world wide names. See nWWNs
- nondisruptive upgrades
  - methods [15-5](#)
- None authentication [50-28](#)
- nonparticipating codes
  - description [20-10](#)
- nonParticipating tooltip [69-17](#)
- nonvolatile storage
  - bootflash: [16-2](#)
- notifications
  - adding forwards [7-43](#)
  - conditions for sending [7-53](#)
  - removing forwards [7-44](#)
- NPIV
  - configuring [B-2](#)
- NP links [21-3](#)
- N-Port identifier virtualization. See NPIV
- N ports
  - hard zoning [30-25](#)
  - zone enforcement [30-25](#)
  - zone membership [30-2](#)
  - See also Nx ports
- NL ports
  - See also Nx ports
- NP-ports [21-3](#)
- NPV
  - wizard [5-22](#)

## Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

- NPV, configuring [21-7](#)
  - NPV mode [21-3](#)
  - ntop freeware
    - batch files [9-5](#)
    - modifying launch scripts [9-5](#)
  - NTP
    - CFS support [13-2](#)
    - configuration guidelines [12-5](#)
    - configuring [12-4 to 12-10](#)
    - configuring CFS distribution [12-8](#)
    - configuring with CFS [12-8](#)
    - logging facility [63-2](#)
    - time-stamp option [48-25](#)
  - NTP peers
    - deleting [12-7](#)
    - editing [12-6](#)
  - NTP servers
    - configuring [2-7](#)
    - deleting [12-7](#)
    - editing [12-6](#)
  - nWWNs
    - DPVM [28-1](#)
  - Nx ports
    - FCS support [65-1](#)
    - See also N ports; NL ports
- 
- O**
- offline tooltip [69-17](#)
  - OHMS
    - configuring [B-3](#)
    - description [70-6](#)
  - ohmsExtLBTest tooltip [69-17](#)
  - On-Demand Port activation license
    - acquiring for ports [11-6](#)
    - checking status of licenses [11-4](#)
    - configuring [11-4 to ??](#)
    - description [11-1](#)
    - making ports eligible [11-5](#)
  - port licensing [11-2](#)
  - port naming conventions [11-2](#)
  - Online Certificate Status Protocol. See OSCP
  - Online Health Management System. See OHMS
  - Opera
    - configuring for Java Web Start [69-5](#)
  - operational states
    - configuring on Fibre Channel interfaces [20-12](#)
    - description [20-7](#)
  - OSCP
    - support [43-5](#)
  - other tooltip [69-17](#)
  - out-of-band access
    - mgmt0 interfaces [2-12](#)
  - out-of-band management
    - configuring [2-4, 2-10](#)
    - Ethernet connection [2-17](#)
  - out-of-service interfaces
    - description [22-7](#)
  - overlay VSANs
    - configuring [51-6](#)
    - description [51-6](#)
  - oversubscription
    - diagnosing with Device Manager [68-14](#)
    - disabling restrictions [22-24](#)
    - enabling restrictions [22-25](#)
    - Generation 2 switching modules [22-23](#)
    - ratios [22-23](#)
- 
- P**
- PAA
    - description [68-2](#)
    - troubleshooting tools [68-2](#)
  - PAA-2s
    - Cisco Traffic Analyzer [9-3](#)
    - description [9-2](#)
  - PAAs
    - compared with PAA-2s [9-3](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

packets

discarding in FCIP [48-25](#)

parentDown tooltip [69-17](#)

pass-thru routing mode [50-33, 50-34](#)

passwords

administrator [2-2](#)

assigning using Fabric Manager [5-21](#)

DHCHAP [45-7, 45-8](#)

recovering [7-39](#)

setting administrator default [2-4, 2-9](#)

path MTUs. See PMTUs

pcAnyWhere

replacing with DirectX [69-6](#)

stopping [69-6](#)

PDU [50-33](#)

peerFCIPPortClosedConnection tooltip [69-17](#)

peerFCIPPortResetConnection tooltip [69-17](#)

performance

configuring collections [7-50](#)

customizing reports [7-33](#)

custom monitoring [7-21](#)

data [8-3](#)

event triggers [8-2](#)

graphs [60-6](#)

historical monitoring [60-4](#)

host-optimized port groups [60-6](#)

ISL statistics (procedure) [60-3](#)

monitoring [8-1](#)

monitoring in Device Manager (procedure) [60-1](#)

per-port monitoring (procedure) [60-2](#)

real-time monitoring [60-1](#)

summary reports [60-6](#)

tables [60-6](#)

using thresholds [8-2, 60-4](#)

viewing future predictions [7-20](#)

viewing summaries [7-13](#)

performance buffers

configuring [20-21](#)

description [20-21](#)

performance collections

adding [7-50](#)

configuring thresholds [7-53](#)

removing [7-51](#)

Performance Manager

architecture [8-1](#)

authentication [4-4](#)

configuring data collection [8-3](#)

configuring flows [8-3](#)

configuring with Traffic Analyzer [60-9](#)

creating collections [60-4](#)

creating flows [60-4](#)

data collection [8-2](#)

data interpolation [8-2](#)

description [2-15](#)

shows as disabled service [69-6](#)

thresholds [60-4](#)

using thresholds [8-2](#)

verifying collections [3-3](#)

viewing reports [60-5](#)

wizard for configuring [60-5](#)

Performance Manager reports

exporting as CSV [60-8](#)

exporting as XML [60-7](#)

generating top 10 [60-7](#)

viewing events [60-6](#)

viewing graphs [60-6](#)

viewing host-optimized port group performance [60-6](#)

viewing summary reports [60-6](#)

viewing tables [60-6](#)

Performance tab

description [7-12](#)

persistent domain ID

FICON VSANs [47-3](#)

persistent FC IDs

configuring [25-17](#)

description [25-17, 29-19](#)

enabling [25-17](#)

purging [25-21](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- Ping Tool
  - troubleshooting tools [68-7](#)
- PKI
  - enrollment support [43-4](#)
- PLOGI
  - name server [34-3](#)
- PMTUs
  - configuring in FCIP profiles [48-20](#)
- polling periods
  - changing [3-7](#)
- port addresses
  - FICON [36-11](#)
- Port Analyzer Adapters. See PAAs
- Port Analyzer Adapters 2. See PAA-2s
- portBindFailure tooltip [69-17](#)
- portBlocked tooltip [69-17](#)
- PortChannel
  - interfaces [50-12](#)
  - subinterfaces [50-12](#)
- portChannelMembersDown tooltip [69-17](#)
- PortChannel modes
  - description [23-11](#)
- PortChannel Protocol
  - autocreation [23-18](#)
  - configuring autocreation [23-19](#)
  - converting autocreated groups to manually configured [23-19](#)
  - creating channel group [23-17](#)
  - description [23-16](#)
  - enabling autocreation [23-19](#)
- PortChannels
  - 32-port switching module configuration guidelines [23-2](#)
  - adding interfaces [23-13, 23-14](#)
  - administratively down [20-10](#)
  - comparison with trunking [23-3](#)
  - compatibility checks [23-14](#)
  - compatibility with DHCPAP [45-3](#)
  - configuration guidelines [23-8](#)
  - configuring [23-6 to ??](#)
  - configuring auto-create [2-11](#)
  - configuring for FCIP high availability [48-5](#)
  - configuring using Device Manager [6-7](#)
  - creation dialog box too small [69-8](#)
  - default settings [23-20](#)
  - deleting [23-12](#)
  - deleting interfaces [23-16](#)
  - description [23-1](#)
  - down states [C-2](#)
  - examples [23-2](#)
  - FICON support [36-5](#)
  - forcing interface additions [23-15](#)
  - Generation 2 switching module interfaces [22-17](#)
  - high availability [17-1](#)
  - incompatible modes [C-2](#)
  - incompatible remote switch [C-2](#)
  - incompatible speeds [C-2](#)
  - in-order guarantee [32-17](#)
  - interface states [23-14](#)
  - interoperability [37-9](#)
  - IQN formats [50-8](#)
  - link changes [32-17](#)
  - link failures [32-3](#)
  - load balancing [23-4](#)
  - load balancing (example) [48-5](#)
  - logging facility [63-2](#)
  - member combinations [52-9](#)
  - misconfiguration error detection [23-8](#)
  - redundancy [48-7](#)
  - reserving ports for FICON [36-13](#)
  - SPAN sources [62-3](#)
  - verifying configurations [23-20](#)
  - wizard [5-21](#)
- portFabricBindFailure tooltip [69-17](#)
- portGracefulShutdown tooltip [69-17](#)
- port groups
  - assigning extended BB\_credits [20-22](#)
  - description [22-2](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- Generation 2 Fibre Channel switching modules [22-2](#)
- host-optimized performance [60-6](#)
- port indexes
  - description [22-16](#)
- port modes
  - auto [20-7](#)
  - description [20-3 to 20-7](#)
  - IPS [52-4, 53-1](#)
- port rate limiting
  - configuring [66-11](#)
  - default [66-12](#)
  - description [66-11](#)
  - hardware restrictions [66-11](#)
- port rate modes
  - configuring [22-22](#)
  - dedicated [22-6](#)
  - description [22-4](#)
  - oversubscribed [22-6](#)
  - shared [22-6](#)
  - See also rate modes
- ports
  - aggregation [17-1](#)
  - disabling using Device Manager [6-7](#)
  - enabling using Device Manager [6-7](#)
  - on-demand port activation licensing [11-1](#)
  - virtual E [48-2](#)
  - VSAN membership [26-7](#)
- Port Security
  - wizard [5-22](#)
- port security
  - activating [46-10](#)
  - activation [46-3](#)
  - activation rejection [46-11](#)
  - auto-learning [46-2](#)
  - CFS support [13-2](#)
  - cleaning up databases [46-24](#)
  - compatibility with DHCHAP [45-3](#)
  - configuration guidelines [46-3](#)
  - configuring CFS distribution [46-19 to 46-21](#)
  - deactivating [46-10](#)
  - default settings [46-25](#)
  - deleting entries from database (procedure) [46-18](#)
  - disabling [46-9](#)
  - displaying settings (procedure) [46-13](#)
  - displaying statistics (procedure) [46-13](#)
  - displaying violations (procedure) [46-13](#)
  - enabling [46-9](#)
  - enforcement mechanisms [46-2](#)
  - fabric binding comparison [47-1](#)
  - forcing activation [46-11](#)
  - license requirement [46-2](#)
  - manual configuration guidelines [46-4](#)
  - preventing unauthorized accesses [46-1](#)
  - unauthorized accesses prevented [46-1](#)
  - WWN identification [46-17](#)
- port security auto-learning
  - description [46-2](#)
  - device authorization [46-15](#)
  - disabling [46-15](#)
  - distributing configuration [46-20](#)
  - enabling [46-14](#)
  - guidelines for configuring with CFS [46-3](#)
  - guidelines for configuring without CFS [46-4](#)
- port security databases
  - cleaning up [46-24](#)
  - copying [46-23](#)
  - copying active to config (procedure) [46-12](#)
  - deleting [46-24](#)
  - interactions [46-22](#)
  - manual configuration guidelines [46-4](#)
  - merge guidelines [46-21](#)
  - reactivating [46-12](#)
  - scenarios [46-22](#)
- port speeds
  - configuring [20-12](#)
  - configuring on Generation 2 switching module interfaces [22-21](#)
- port swapping. See FICON port swapping

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- port tracking
    - default settings [67-6](#)
    - description [67-1](#)
    - enabling [67-3](#)
    - guidelines [67-2](#)
    - monitoring ports in a VSAN [67-6](#)
    - multiple ports [67-5](#)
    - shutting down ports forcefully [67-6](#)
  - portVsanMismatchIsolation tooltip [69-17](#)
  - port world wide names. See pWWNs
  - power cycling
    - modules [19-6](#)
  - powering off
    - switching modules [19-8](#)
  - power supplies
    - configuration guidelines [18-5 to 18-7](#)
    - configuring modes [18-4](#)
    - configuring power attributes [18-5](#)
    - default state [18-12](#)
    - displaying configuration [18-5](#)
  - power usage
    - displaying [18-3](#)
  - preferences
    - Confirm Deletion default [5-18](#)
    - default [5-18](#)
    - Device Manager [6-8](#)
    - Export Tables with Format default [5-18](#)
    - Fabric Manager Clients [5-18](#)
    - Show CFS Warnings default [5-18](#)
    - Show Device Name by default [5-18](#)
    - Show End Device Using default [5-18](#)
    - Show Shortened iSCSI Names default [5-18](#)
    - Show Timestamps as Date/Time default [5-18](#)
    - Show WorldWideName (WWN) Vendor default [5-18](#)
    - Telnet Path default [5-18](#)
    - Use Secure Shell instead of Telnet default [5-18](#)
  - preshared keys
    - RADIUS [41-8](#)
    - TACACS+ [41-15](#)
  - principal switches
    - assigning domain ID [25-10](#)
  - processes
    - nondisruptive restarts [17-1](#)
    - restartability [17-3](#)
  - product IDs
    - displaying [18-1](#)
  - promiscuous mode
    - configuring Gigabit Ethernet interfaces [52-6, 53-4](#)
  - protocol [50-1](#)
  - Protocol Analyzer
    - description [68-2](#)
    - troubleshooting tools [68-2](#)
    - using for troubleshooting [68-3](#)
  - protocols
    - analyzing [68-17](#)
    - VRRP [50-8](#)
  - proxies
    - registering for name servers [34-2](#)
  - proxy initiator
    - configuring iSCSI
      - configuring proxy initiator [50-21](#)
  - proxy initiator mode [50-14, 50-25](#)
    - configuring [50-20](#)
    - zoning [50-22](#)
  - proxy initiator mode iSCSI
    - proxy initiator mode [50-20](#)
  - Public Key Infrastructure. See PKI
  - pWWNs
    - configuring fc aliases members [30-20](#)
    - converting dynamic to static [50-19](#)
    - DPVM [28-1](#)
    - rejecting duplicates [34-3](#)
    - zone membership [30-2](#)
- 
- Q**
- QoS
    - class maps [66-6](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- comparison with VSANs [66-5](#)
- control traffic support [66-3](#)
- creating class maps [66-7](#)
- data traffic support [66-4 to 66-10](#)
- default settings [66-12](#)
- description [66-1](#)
- DSCP value [48-28](#)
- DWRR queues [66-8](#)
- enabling control traffic [66-3](#)
- example data traffic configuration [66-10](#)
- logging facilities [63-2](#)
- port rate limiting [66-11](#)
- service policies [66-8](#)
- wizard [5-22](#)

#### QoS values

- configuring [50-32](#)

## R

#### R\_A\_TOV

- default setting [68-25](#)
- modifying [68-15](#)

#### RADIUS [50-57](#)

- AAA authentication [50-28, 50-43](#)
- AAA protocols [41-1](#)
- CFS merge guidelines [41-24](#)
- CFS support [13-2](#)
- clearing configuration distribution sessions [41-24](#)
- configuring an iSCSI RADIUS server/iSCSI
  - configuring a RADIUS server [50-31](#)
- configuring Cisco ACS [41-26 to 41-30](#)
- configuring test idle timer [41-11](#)
- configuring test user name [41-11](#)
- default settings [41-31](#)
- description [41-7](#)
- discarding configuration distribution changes [41-23](#)
- enabling configuration distribution [41-22](#)
- FabricWare support [D-2](#)
- setting preshared keys [41-8](#)

- specifying server at user login [41-12](#)
- specifying time-out [41-9](#)
- starting a distribution session [41-22](#)

#### rate limiting

- default settings [66-12](#)

#### rate modes

- configuring on Generation 2 switching module interfaces [22-22](#)

See also port rate modes

- rcfInProgress tooltip [69-17](#)

#### RCFs

- description [25-3](#)
- incoming [25-6](#)
- rejecting incoming [25-7](#)

#### read-only zones

- configuration guidelines [30-38](#)
- configuring [30-39](#)
- default settings [30-45](#)
- description [30-38](#)

#### reason codes

- description [20-8](#)
- description (table) [C-1](#)

receive buffer groups. See buffer groups

#### receive data field sizes

- configuring [20-13](#)

reconfigure fabric frames. See RCFs

- recovering passwords [39-19](#)

#### recovery

- from powered-down state [22-17](#)
- passwords [7-39](#)

#### Red Hat Linux

- Fabric Manager Server [3-1](#)

#### redundancy

- Ethernet PortChannels [48-6, 48-7](#)
- Fibre Channel PortChannels [48-7](#)
- VRRP [48-6](#)
- VSANs [26-4](#)

#### redundancy states

- value descriptions [17-4](#)



***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- redundant physical links
  - example (figure) [32-3](#)
- Registered Link Incident Reports. See RLIRs
- Registered State Change Notifications. See RSCNs
- reloading
  - switches [19-5](#)
- remote AAA server
  - delayed authentication [4-2](#)
- Remote Capture Protocol. See RPCAP
- remote file systems
  - accessing [B-2](#)
- remote SPAN
  - configuring [B-2](#)
- Resource Allocation Time Out Value. See R\_A\_TOV
- Resource Manager Essentials. See RME
- resources
  - management [2-17](#)
- retransmitting intervals
  - configuring for FSPF [32-9](#)
  - description [32-8](#)
- RLIRs
  - description [36-27](#)
  - displaying information (procedure) [36-27](#)
- RME
  - support [1-6](#)
- RMON
  - alarms [61-1](#)
  - configuring using Threshold Manager [61-1](#)
  - default settings [61-19](#)
  - defining an event (procedure) [61-17](#)
  - description [61-1](#)
  - enabling alarms [61-2](#)
  - enabling alarms (procedure) [61-8, 61-10, 61-14](#)
  - events [61-1](#)
  - setting alarms (procedure) [61-3, 61-4, 61-5](#)
  - viewing alarms (procedure) [61-18](#)
  - viewing logs (procedure) [61-18](#)
- role-based management
  - controlling access [5-21](#)
- roles
  - adding web services roles [7-48](#)
  - CFS support [13-2](#)
  - default permissions [41-3](#)
  - deleting (procedure) [39-3](#)
  - privileges [5-21](#)
  - removing web services roles [7-50](#)
  - user profiles [41-3](#)
- round-trip response time
  - monitoring [9-3](#)
- route costs
  - computing [32-6](#)
- router discovery
  - IPv6 [54-9](#)
- routing
  - multicast [32-14](#)
  - See also broadcast routing
  - See also IP routing
- RPCAP
  - Ethernet communication [68-18](#)
- RRD
  - configuring database [7-54](#)
- rsa1 key pairs
  - generating [39-15](#)
- RSA key-pairs
  - deleting [43-16](#)
  - description [43-2](#)
  - exporting [43-5, 43-14](#)
  - generating [43-6](#)
  - importing [43-5, 43-14](#)
  - multiple [43-4](#)
- rsa key pairs
  - generating [39-15](#)
- RSCNs [50-16](#)
  - clearing statistics [34-7](#)
  - default settings [34-8](#)
  - description [34-5](#)
  - displaying information [34-5](#)
  - logging facility [63-2](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- multiple port IDs [34-6](#)
- RSCN timers
  - CFS support [13-2](#)
- RSPAN
  - configuring [B-2](#)
- running configuration files
  - saving to startup configuration file [16-8](#)
- runtime checks
  - static routes [32-12](#)

## S

- SACKs
  - configuring in FCIP profiles [48-20](#)
- SAN extension package licenses
  - description [10-5](#)
- SAN extension tuner
  - configuring [49-2, B-2](#)
  - data patterns [49-3](#)
  - default settings [49-6](#)
  - description [49-1](#)
  - license requirements [49-3](#)
  - tuning guidelines [49-2](#)
- SAN operating system. See Cisco MDS SAN-OS
- SANTap
  - creating CVTs [57-4](#)
  - creating DVTs [57-6, 57-9](#)
  - default settings [57-10](#)
  - deleting CVT [57-5](#)
  - deleting DVTs [57-8](#)
  - description [57-1 to 57-3](#)
  - enabling [57-3](#)
- SAs
  - establishing between IPsec peers [44-28](#)
  - lifetime negotiations [44-30](#)
  - refreshing [44-20](#)
  - setting lifetime [44-31](#)
- scalability
  - VSANs [26-4](#)

- schedulers. See command schedulers
- SCP
  - support [2-15](#)
- scripts
  - FMServer.sh [2-31](#)
- SCSI
  - displaying LUN discovery results [35-3](#)
  - monitoring frame counts [9-3](#)
  - monitoring I/Os per second [9-3](#)
  - monitoring read throughput [9-3](#)
  - monitoring traffic throughput [9-3](#)
  - routing requests [50-2](#)
  - traffic reports [68-3](#)
- SCSI flow configuration clients
  - description [55-3](#)
- SCSI flow data path support
  - description [55-3](#)
- SCSI flow managers
  - description [55-2](#)
- SCSI flow services
  - CFS support [13-2](#)
  - configuring [55-3 to ??, 55-3 to 55-6](#)
  - configuring (procedure) [55-4](#)
  - default settings [55-8](#)
  - description [55-1](#)
  - functional architecture (figure) [55-2](#)
- SCSI flow configuration clients [55-3](#)
- SCSI flow data path support [55-3](#)
- SCSI flow managers [55-2](#)
- SCSI flow statistics
  - clearing (procedure) [55-8](#)
  - default settings [55-8](#)
  - description [55-6](#)
  - enabling [55-7](#)
- SCSI LUNs
  - customized discovery [35-2](#)
  - discovering targets [35-1](#)
  - displaying information [35-3](#)
  - starting discoveries [35-2](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- SCSI sessions
  - monitoring status [9-3](#)
- SCSI traffic
  - analysis [68-2](#)
  - analyzing at LUN level [68-2](#)
- SD port mode
  - description [20-6](#)
  - interface modes [20-6](#)
- SD ports
  - bidirectional traffic [62-12](#)
  - characteristics [62-5](#)
  - Cisco Traffic Analyzer [9-4](#)
  - configuring [20-12](#)
  - configuring for SPAN monitoring [62-6](#)
  - monitoring bidirectional traffic [62-12](#)
- SDV
  - IVR limitations [27-8](#)
- secondary MAC addresses
  - configuring [37-6](#)
- Secure Hash Algorithm. See SHA-1
- Secure Shell Protocol
  - See SSH
- Secure Shell Protocol. See SSH
- security
  - accounting [41-3](#)
  - managing on the switch [41-1](#)
- security associations. See SAs
- security control
  - local [41-2](#)
  - remote [41-2](#), [41-14](#)
  - remote AAA servers [41-7](#)
- security parameter index. See SPI
- selective acknowledgments. See SACKs
- sensors
  - temperature monitoring [18-10](#)
- serial console ports
  - accessing switches [2-12](#)
- serial IDs
  - description [64-24](#)
- serial numbers
  - displaying [18-1](#), [18-3](#)
- server groups
  - configuring [41-20](#)
- service policies
  - defining [66-8](#)
  - enforcement [66-8](#)
- services
  - restarting [7-39](#)
  - starting [7-39](#)
  - stopping [7-39](#)
- services modules
  - description [19-3](#)
  - managing [19-1](#)
  - power cycling [19-6](#)
  - replacing [15-15](#)
  - resetting [19-5](#)
  - state descriptions [19-4](#)
  - verifying status [19-3](#)
- setup command
  - using [2-12](#)
- SFPs
  - displaying transmitter types [20-16](#)
  - not present reason codes [C-1](#)
  - transmitter types [20-16](#)
- SFTP
  - support [2-15](#)
- SHA-1
  - IKE [44-7](#)
  - IPsec [44-6](#)
- shared rate mode
  - description [22-6](#)
  - migrating from dedicated rate mode [22-19](#)
  - migrating to dedicated rate mode [22-19](#)
  - oversubscription [22-23](#)
- shell scripts
  - \$HOME/.cisco\_mds9000/bin directory [69-4](#)
  - DeviceManager.sh [69-4](#)
  - FabricManager.sh [69-4](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- for uninstalling Fabric Manager [2-40](#)
- shortcuts
  - not visible on desktops [69-4](#)
- site IDs
  - description [64-23](#)
- small computer system interface. See SCSI
- SMARTnet
  - Call Home AutoNotify registration [64-2](#)
- SMTP
  - assigning contact names [64-4](#)
  - server address [64-11](#)
- SNMP
  - access control [40-2](#)
  - access groups [40-3](#)
  - adding communities [40-7](#)
  - assigning contact [40-2](#)
  - assigning location [40-2](#)
  - configuring event security [40-12](#)
  - configuring event security (procedure) [40-12](#)
  - configuring notification target users [40-11](#)
  - creating users [40-4](#)
  - default settings [40-13](#)
  - deleting communities [40-7](#)
  - deleting community strings (procedure) [40-8](#)
  - enabling access [2-6](#)
  - enabling SNMP notifications [40-10](#)
  - encryption-based privacy [40-4](#)
  - FICON control [36-22](#)
  - group-based access [40-3](#)
  - modifying users [40-4](#)
  - port used [2-39](#)
  - proxy services [2-14](#)
  - read-only access [40-7](#)
  - read-write access [40-7](#)
  - security features [41-2](#)
  - server contact name [64-3](#)
  - users with multiple roles (procedure) [40-6](#)
  - user synchronization with CLI [40-3](#)
  - Version 3 security features [40-1, 40-2](#)
  - versions supported [40-1](#)
  - viewing event log [40-12](#)
  - See also SNMPv1; SNMPv2c; SNMPv3
- SNMP\_TRAP
  - port used [2-39](#)
- SNMP community strings
  - configuring [2-9](#)
- SNMP manager
  - FCS [65-2](#)
- SNMP preferences
  - Enable Audible Alert when Event Received default [5-19](#)
  - Retry request 1 time(s) after 5 sec timeout default [5-19](#)
  - Trace SNMP packets in Log default [5-19](#)
- SNMPv1
  - community strings [40-2](#)
  - description [40-2](#)
  - FabricWare support [D-2](#)
  - support [2-16](#)
  - See also SNMP
- SNMPv2
  - community strings [40-2](#)
  - FabricWare support [D-2](#)
- SNMPv2c
  - configuring notifications [40-9](#)
  - description [40-2](#)
  - support [2-16](#)
  - See also SNMP
- SNMPv3
  - assigning multiple roles [40-6](#)
  - CLI user managementSNMPv3
    - AAA integration [40-2](#)
  - configuring notifications [40-10](#)
  - description [40-2](#)
  - enforcing message encryption [40-5](#)
  - restricting switch access [40-3](#)
  - security features [40-2](#)
  - specifying cisco-av-pair [41-13](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- support [2-16](#)
- See also SNMP [40-2](#)
- software configuration
  - overview [1-6 to 1-9](#)
- software images
  - default settings [15-16](#)
  - selecting for supervisor modules [15-2](#)
  - space requirements [15-4](#)
  - synchronizing [17-4](#)
  - upgrade prerequisites [15-3 to 15-5](#)
  - upgrading SAN-OS images [15-1](#)
  - variables [15-1](#)
- software installation
  - Software Installation Wizard [15-8](#)
- software upgrades
  - disruptive [15-5](#)
  - mechanisms [15-5](#)
  - nondisruptive [17-1](#)
  - Software Installation Wizard [15-8](#)
- soft zoning
  - description [30-25](#)
  - See also zoning
- Solaris [2-31](#)
  - Fabric Manager Server [3-1](#)
  - installing Fabric Manager Web Services [7-4](#)
  - install scripts [2-31](#)
- source IDs
  - Call Home event format [64-24](#)
  - exchange based [23-5](#)
  - flow based [23-4](#)
  - in-order delivery [32-15](#)
  - path selection [26-11](#)
- SPAN
  - configuration guidelines [62-6](#)
  - configuring [62-6 to 62-10](#)
  - configuring Fibre Channel analyzers [62-11](#)
  - configuring on switch ports [9-4](#)
  - conversion behavior [62-9](#)
  - default settings [62-13](#)
  - description [62-2](#)
  - egress sources [62-2](#)
  - Fibre Channel analyzers [62-10](#)
  - filters [62-5](#)
  - monitoring traffic [9-1, 62-2](#)
  - SD ports [62-5](#)
  - sessions [62-5](#)
  - sources [62-4](#)
  - sources for monitoring [62-2](#)
  - VSAN sources [62-4](#)
- SPAN destination port mode. See SD port mode
- SPAN filters
  - description [62-5](#)
  - guidelines [62-5](#)
- SPAN ports
  - viewing detailed traffic information [7-19](#)
- SPAN sessions
  - deleting using Device Manager [62-9](#)
  - description [62-5](#)
  - VSAN filters [62-5](#)
- SPAN sources
  - editing with Device Manager [62-8](#)
  - egress [62-2](#)
  - ingress [62-2](#)
  - interface types [62-3](#)
  - IPS ports [62-3](#)
  - VSANs configuration guidelines [62-4](#)
- SPAN traffic
  - real-time analysis [68-2](#)
- SPAN tunnel port mode. See ST port mode
- special frames
  - enabling for FCIP [48-24](#)
- SPF
  - computational hold times [32-4](#)
- SPI
  - configuring virtual routers [51-12](#)
- srcPortNotBound tooltip [69-17](#)
- SSH
  - default service [39-17](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- enabling [2-7, 2-10](#)
- FabricWare support [D-2](#)
- host key pair [39-15](#)
- logins [41-4](#)
- port used [2-39](#)
- support [2-15](#)
- SSH key pair
  - overwriting [39-17](#)
- SSH sessions
  - message logging [63-3](#)
- SSI boot images
  - configuring [B-2](#)
- SSL certificates
  - using with Fabric Manager Web Services [7-5](#)
- SSMs
  - configuring Intelligent Storage Services [57-1](#)
  - default settings [19-13](#)
  - disabling Intelligent Storage Services (procedure) [55-5, 58-3](#)
  - enabling Intelligent Storage Services (procedure) [55-3, 58-2](#)
  - Fibre Channel write acceleration [56-1 to 56-3](#)
  - managing [B-2](#)
  - NASB [58-1 to 58-7](#)
  - provisioning [58-2](#)
  - provisioning Intelligent Storage Services (procedure) [55-3](#)
  - SANTap [57-1 to ??](#)
  - SCSI flow services [55-1 to 55-8](#)
  - SCSI flow statistics [55-1 to 55-8](#)
- standby supervisor modules
  - boot alert [15-14](#)
  - boot variable version [15-14](#)
  - copying image to [B-2](#)
  - managing bootflash: [15-14](#)
  - monitoring [17-2](#)
  - synchronizing [17-4](#)
- startup configuration files
  - saving running configuration file [16-8](#)
  - unlocking [B-2](#)
- statically imported iSCSI targets [50-52](#)
- static iSLB initiator
  - converting [50-40](#)
- static mapped iSCSI target/iSCSI
  - static mapped target [50-27](#)
- static mapping [50-39](#)
- static routes
  - configuring [2-6](#)
  - runtime checks [32-12](#)
- static WWN mapping [50-25](#)
- statistics
  - SCSI I/O [9-3](#)
  - supervisor modules [19-4](#)
- storage devices
  - access control [30-1](#)
  - performance statistics [8-1](#)
  - permanent [16-2](#)
  - temporary [16-2](#)
- Storage Services Enabler package licenses
  - description [10-7](#)
- storage traffic
  - viewing performance information [7-16](#)
- store-and-forward routing mode [50-33, 50-34](#)
- ST port mode
  - description [20-6](#)
  - interface modes [20-6](#)
  - limitations [20-6](#)
- ST ports
  - interface modes [20-6](#)
- subnet masks
  - configuring mgmt0 interfaces [20-23](#)
  - configuring switches [2-2](#)
  - default setting [19-13](#)
  - initial configuration [2-6, 2-10](#)
- subnets
  - requirements [52-6, 53-5](#)
- summary reports
  - description [7-1](#)
- Sun JRE

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- Fabric Manager support [2-19](#)
- Supervisor-1 modules
  - selecting software images [15-2](#)
- Supervisor-2 modules
  - description [1-2](#)
  - Generation 1 chassis [15-15](#)
  - select software images [15-2](#)
  - USB ports [1-2](#)
- supervisor modules
  - active state [19-5](#)
  - capturing local traffic [68-18](#)
  - default settings [19-12](#)
  - description [1-2, 19-1](#)
  - high availability [17-1](#)
  - managing standby bootflash: [15-14](#)
  - manual switchovers [17-2](#)
  - redundancy [17-1](#)
  - replacing [15-14, 15-15](#)
  - resetting [19-5](#)
  - standby boot alert [15-14](#)
  - standby state [17-4, 19-5](#)
  - standby supervisor boot variable version [15-14](#)
  - state descriptions [17-4, 19-4](#)
  - statistics [19-4](#)
  - switchover mechanisms [17-2](#)
  - switchovers after failures [17-1](#)
  - synchronizing [17-3](#)
  - upgrading a dual supervisor switch [B-1](#)
  - verifying status [19-3](#)
  - viewing using Device Manager [6-7](#)

See also Supervisor 1 modules; Supervisor 2 modules
- suspendedByMode tooltip [69-17](#)
- suspendedBySpeed tooltip [69-17](#)
- suspendedByWWN tooltip [69-17](#)
- swFailure tooltip [69-17](#)
- Switched Port Analyzer. See SPAN
- switches
  - accessing [2-12](#)
  - comparing configurations [68-4](#)
  - displaying power usage [18-3](#)
  - displaying serial numbers [18-3](#)
  - initial setup [2-2](#)
  - internal states [17-4](#)
  - reloading [19-5](#)
  - starting [2-1](#)
  - starting up [B-1](#)
  - status of device health [68-3](#)
  - upgrading with dual supervisors [B-1](#)
  - viewing license information [7-25](#)
- switching modules
  - description [19-3](#)
  - managing [19-1](#)
  - power cycling [19-6](#)
  - powering off [19-8](#)
  - preserving configuration [19-7](#)
  - replacing [15-15](#)
  - resetting [19-5](#)
  - state descriptions [19-4](#)
  - verifying status [19-3](#)
  - viewing using Device Manager [6-7](#)
- switch management
  - architecture [2-16](#)
  - in-band [2-17, 51-5](#)
  - out-of-band [2-17](#)
- switch names
  - assigning [12-1](#)
- switchover mechanism
  - warm state [19-5](#)
- switchovers
  - characteristics [17-2](#)
  - guidelines [17-3](#)
  - initiating manually [17-2](#)
  - supervisor modules [17-1](#)
  - VRRP [48-6](#)
- switch port interfaces
  - configuring default [2-11](#)
- switch ports
  - configuring attribute default values [20-16](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- configuring trunk modes [2-11](#)
- switch priorities
  - configuring [25-5](#)
  - default [25-5](#)
  - description [25-5](#)
- switch security
  - default settings [39-23, 41-30](#)
- sWWNs
  - configuring for fabric binding [47-3](#)
- syslog
  - CFS support [13-2](#)
  - port used [2-39](#)
  - viewing information [7-10](#)
  - viewing registration information [7-42](#)
  - viewing with Events tab [7-8](#)
- syslog servers
  - verifying using Fabric Manager Web Services [63-10](#)
- system health
  - default settings [70-7](#)
  - initiating [B-3](#)
- system images
  - description [15-2](#)
  - selecting for supervisor modules [15-2](#)
  - SYSTEM variable [15-1](#)
- system messages
  - configuring log files [63-6](#)
  - configuring logging [63-3](#)
  - configuring logging servers [63-7](#)
  - default settings [63-11](#)
  - monitoring [63-1](#)
  - severity levels [63-3](#)
  - viewing [7-10](#)
  - viewing from Device Manager [63-11](#)
  - viewing from Fabric Manager Web Server [63-11](#)
  - viewing using Device Manager [59-4](#)
  - viewing using Fabric Manager Web Server [59-3](#)
  - viewing with Events tab [7-8](#)
- system processes
  - displaying [70-1](#)

---

## T

- tables
  - filtering [7-3](#)
  - navigating [7-3](#)
  - searching for information [7-3](#)
- TACACS+
  - AAA authentication [50-43](#)
  - AAA protocols [41-1](#)
  - CFS merge guidelines [41-24](#)
  - CFS support [13-2](#)
  - clearing configuration distribution sessions [41-24](#)
  - configuring Cisco ACS [41-26 to 41-30](#)
  - default settings [41-31](#)
  - description [41-14](#)
  - discarding configuration distribution changes [41-23](#)
  - displaying server statistics [41-18](#)
  - enabling configuration distribution [41-22](#)
  - global keys [41-15](#)
  - setting default server encryption [41-15](#)
  - setting default server timeout [41-15](#)
  - setting preshared key [41-15](#)
  - specifying server at login [41-18](#)
  - starting a distribution session [41-22](#)
  - validating [41-17](#)
- tape acceleration
  - FICON [36-33 to 36-37](#)
- target discovery [50-72](#)
- TCP connections
  - FCIP profiles [48-4](#)
  - specifying number [48-25](#)
- TCP parameters
  - configuring in FCIP profiles [48-19 to ??](#)
- TCP ports
  - IPv4-ACLs [42-3](#)
- TCP tuning parameters [50-32](#)
- Telnet
  - default service [39-14](#)
  - enabling [2-7, 2-10](#)



***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- logins [41-4](#)
- port used [2-39](#)
- support [2-15](#)
- Telnet server connections
  - description [12-11](#)
  - disabling [12-11](#)
- Telnet sessions
  - message logging [63-3](#)
- temperatures
  - displaying [18-11](#)
  - major thresholds [18-10](#)
  - minor thresholds [18-10](#)
  - monitoring hardware [18-10](#)
- templates
  - creating for custom reports [7-33](#)
  - modifying custom report templates [7-36](#)
- TE port mode
  - classes of service [20-6](#)
  - description [20-6](#)
- TE ports
  - fabric binding checking [47-2](#)
  - FCS support [65-1, 65-2](#)
  - FSPF topologies [32-2](#)
  - interoperability [37-9](#)
  - recovering from link isolations [30-27](#)
  - SPAN sources [62-3](#)
  - trunking restrictions [24-1](#)
- terminals
  - configuring settings [B-1](#)
- TFTP
  - port used [2-39](#)
  - support [2-15](#)
- Threshold Manager
  - configuring RMON [61-1](#)
- thresholds
  - baselines for performance [8-2](#)
- time
  - configuring [12-3](#)
- time delays
  - setting [B-2](#)
- timeouts
  - configuring with Fabric Manager [68-15](#)
- time out values. See TOVs
- timers
  - configuring [68-15](#)
- timer values
  - modifying [68-14](#)
- timestamps
  - FICON host control [36-22](#)
- time zones
  - configuring [12-3](#)
- TL port mode
  - classes of service [20-5](#)
  - description [20-5](#)
- TL ports
  - ALPA caches [20-19](#)
  - configuring [20-12, 20-19](#)
  - description [20-18](#)
  - FCS [65-1, 65-2](#)
  - FCS support [65-1, 65-2](#)
  - logging facility [63-2](#)
  - SPAN sources [62-3](#)
- tools
  - software configuration [1-5](#)
- tooManyInvalidFLOGIs tooltip [69-17](#)
- topologies
  - clearing maps [69-21](#)
  - mapping [59-1](#)
- topology map
  - mapping multiple fabrics [59-3](#)
- topology maps
  - custom [59-2](#)
  - description [59-1](#)
  - enclosures [59-3](#)
  - saving custom layouts (procedure) [59-2](#)
- tovMismatch tooltip [69-17](#)
- TOVs
  - configuring across all VSANs [37-2](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- configuring for a VSAN [37-3](#)
- default settings [37-13, 68-25](#)
- interoperability [37-9](#)
- ranges [37-2, 68-14](#)
- traceroute
  - description [68-7](#)
  - troubleshooting connectivity [68-7](#)
- tracked ports
  - binding operationally [67-3](#)
- traffic
  - local captures [68-19](#)
  - managing using Cisco Traffic Analyzer [9-2](#)
  - monitoring using Cisco Traffic Analyzer [9-2](#)
  - remote captures [68-18, 68-19](#)
  - text-based captures [68-18](#)
  - viewing captured frames [68-20](#)
- Traffic Analyzer. See Cisco Traffic Analyzer
- traffic isolation
  - VSANs [26-4](#)
- transform sets
  - description [44-25](#)
- transient failure [50-16](#)
- transit VSANs
  - configuration guidelines [29-10](#)
  - description [29-3, 29-17](#)
  - IVR configuration guidelines [29-14](#)
- translative loop port mode. See TL port mode
- transparent initiator mode [50-14](#)
- transparent initiator mode iSCSI
  - transparent initiator mode [50-20](#)
- traps
  - viewing registration information [7-42](#)
- Triple DES. See 3DEC encryption
- troubleshooting
  - analyzing switch health [68-3](#)
  - analyzing zone merges [68-8](#)
  - CTC [48-18](#)
  - Fabric Manager tools [5-22](#)
  - locating other switches [68-13](#)
  - monitoring oversubscription [68-14](#)
  - show tech command [68-9](#)
  - testing end-to-end connectivity [68-5](#)
  - tools [68-1](#)
  - using Fabric Configuration tool (procedure) [68-4](#)
  - using Ping Tool [68-7](#)
  - using traceroute (procedure) [68-7](#)
  - with Cisco Traffic Analyzer [68-2](#)
  - with Protocol Analyzer [68-3](#)
- troubleshooting reports
  - Cisco Traffic Analyzer [68-2](#)
- trunk-allowed VSAN lists
  - description [24-4 to 24-6](#)
- trunking
  - comparison with PortChannels [23-3](#)
  - configuration guidelines [24-2](#)
  - configuring modes [24-3](#)
  - configuring using Device Manager [6-7](#)
  - default settings [24-6](#)
  - description [24-1](#)
  - interoperability [37-9](#)
  - link state [24-3](#)
  - merging traffic [24-2](#)
  - restrictions [24-1](#)
- trunking E port mode. See TE port mode
- trunking mode
  - FCIP interface [48-4](#)
- trunking ports
  - associated with VSANs [26-8](#)
- trunking protocol
  - default settings [24-6](#)
  - default state [24-2](#)
  - description [24-2](#)
  - detecting port isolation [24-2](#)
- trunk mode
  - configuring [24-3](#)
  - default settings [24-6](#)
  - status [24-3](#)
- trunkNotFullyActive tooltip [69-18](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

## trust points

- creating [43-8](#)
- description [43-2](#)
- multiple [43-3](#)
- saving configuration across reboots [43-14](#)

## U

### UDP ports

- IPv4-ACLs [42-3](#)

### UDP traffic

- blocking [2-14](#)

### unique area FC IDs

- configuring [25-19](#)
- description [25-19](#)

### UNIX

- install scripts [2-31](#)
- launching Fabric Manager Web Services [7-7](#)

### UNIX issues

- parent menus disappear [69-11](#)
- too many open files error [69-11](#)
- web browser cannot find web server [69-11](#)

### upgradeInProgress tooltip [69-18](#)

upgrades. See disruptive upgrades; nondisruptive upgrades; software upgrades

### upgrading

- switches [B-1](#)

### user accounts

- creating additional at setup [2-5](#)

### User-based roles

- FabricWare support [D-2](#)

### user IDs

- authentication [41-3](#)

### user profiles

- role information [41-3](#)

### users

- adding [7-47](#)
- CFS support [13-2](#)
- default [2-3](#)

deleting (procedure) [39-14](#)

removing [7-48](#)

SNMP support [40-4](#)

## V

vendor-specific attributes. See VSAs

### VE ports

- description [48-2](#)
- FCIP [48-2](#)

virtual E ports. See VE ports

virtual Fibre Channel host [50-3](#)

### virtual ISLs

- description [48-2](#)

Virtual LANs. See VLANs

virtual LANs. See VLANs

virtual router IDs. See VR IDs

Virtual Router Redundancy Protocol. See VRRP

Virtual Router Redundancy Protocol protocols

- Virtual Router Redundancy [50-35](#)

### virtual routers

- adding [51-10](#)
- adding primary IP addresses [51-11](#)
- authentication [51-12](#)
- default settings [51-13](#)
- deleting [51-10](#)
- initiating [51-11](#)
- setting priorities [51-11](#)

virtual SANs. See VSANs

### Visio diagrams

- saving maps as [5-15](#)

### VLANs

- configuring on Gigabit Ethernet subinterfaces [53-5](#)
- description [52-6, 53-4](#)

### volatile:

- description [16-2](#)

### VR IDs

- description [51-9](#)
- mapping [51-9](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

## VRRP 50-35

- algorithm for selecting Gigabit Ethernet interfaces 50-45 to ??
- backup switches 51-9
- configuring advertisement time intervals 51-11
- configuring for Gigabit Ethernet interfaces 52-9
- configuring for iSLB 50-45
- configuring virtual routers 51-10
- default settings 51-13
- description 51-9, 52-8
- group members 52-8
- initiating virtual routers 51-11
- IQN formats 50-8
- iSCSI parameter change impact 50-45
- iSLB 50-43 to ??
- logging facility 63-2
- master switches 51-9
- MD5 authentication 51-12
- primary IP address 51-11
- priority preemption 51-11
- security authentication 51-12
- setting priorities 51-11
- setting priority 51-11
- simple text authentication 51-12

## VRRP group 50-23

## VRRP-I f iSCSI login redirect 50-37

## VSAN IDs

- allowed list 24-6
- description 26-5
- multiplexing traffic 20-6
- range 26-4
- VSAN membership 26-4

## vsanInactive tooltip 69-18

## VSAN interfaces

- configuring 20-24
- creating 20-25
- description 20-24

## VSAN membership

- iSCSI hosts 50-22

## iSCSI hosts

- VSAN membership for hosts 50-22

## iSCSI interfaces 50-23

## vsanMismatchIsolation tooltip 69-18

## VSANs

- advantages 26-3
- allowed-active 24-1
- allowed list 62-4
- broadcast addresses 32-14
- clocks 36-22
- comparison with QoS 66-5
- comparison with zones (table) 26-4
- compatibility with DHCHAP 45-3
- configuring 26-6 to ??
- configuring allowed-active lists 24-6
- configuring FSPF 32-4
- configuring multiple IPv4 subnets 51-7
- configuring trunk-allowed lists 24-4 to 24-6
- default settings 26-12
- default VSANs 26-8
- deleting 26-9
- description 26-1 to 26-4
- domain ID automatic reconfiguration 25-8
- example membership for iSCSI devices 50-23
- fabric optimization for FICON 36-3
- FC IDs 26-1
- FCS 65-1
- FCS support 65-1
- features 26-1
- FICON-enabled 26-12
- flow statistics 8-3
- FSPF connectivity 32-2
- gateway switches 51-4
- interop mode 37-9
- IP routing 42-1
- IPv4 static routing 51-6
- iSLB 50-40
- iSLB initiators 50-40
- isolated 26-8

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- load balancing [26-11](#)
- load balancing attributes [26-5](#)
- mismatches [20-10, C-2](#)
- multiple zones [30-5](#)
- names [26-5](#)
- name server [34-2](#)
- operational states [26-9](#)
- overlaid routes [51-6](#)
- port membership [26-7](#)
- port tracking [67-6](#)
- Rules and features [39-4](#)
- SPAN filters [62-5](#)
- SPAN source [62-4](#)
- SPAN sources [62-4](#)
- states [26-5](#)
- suspending for FICON [36-19](#)
- TE port mode [20-6](#)
- timer configuration [37-3](#)
- traffic isolation [26-3](#)
- traffic routing between [51-1](#)
- transit [29-17](#)
- trunk-allowed [24-1](#)
- trunking ports [26-8](#)
- VRRP [51-9](#)
- wizard [5-21](#)

VSAN trunking. See trunking

VSA

- communicating attributes [41-13](#)
- protocol options [41-13](#)

## W

window management

- configuring in FCIP profiles [48-20](#)

Windows

- Fabric Manager Server [3-1](#)
- Fabric Manager support [2-19](#)
- installing Fabric Manager Web Services [7-4](#)

Windows issues

- blue screen [69-10](#)
- Device Manager window content disappears [69-11](#)
- Fabric Manager window content disappears [69-11](#)
- icons disappear from desktop [69-11](#)
- printing causes an application crash [69-10](#)
- SCP/SFTP failures [69-11](#)
- text fields are too small [69-10](#)
- Windows XP hangs [69-10](#)

Windows workstations

- modifying [2-14](#)

wizards

- DPVM Wizard [5-22](#)
- FCIP Wizard [5-21](#)
- IP ACL Wizard [5-22](#)
- iSCSI Wizard [5-22](#)
- IVR Zone Wizard [5-21](#)
- License Install Wizard [5-22](#)
- NPV Wizard [5-22](#)
- PortChannel Wizard [5-21](#)
- Port Security Wizard [5-22](#)
- QoS Wizard [5-22](#)
- Quick Config Wizard [30-7](#)
- Software Install Wizard [5-22](#)
- VSAN Wizard [5-21](#)
- Zone Edit Tool Wizard [5-21](#)

world wide names. See WWNs

WWNs

- configuring [37-5, 68-23](#)
- displaying configurations [68-24](#)
- displaying information [37-6](#)
- link initialization [37-6](#)
- port security [46-17](#)
- secondary MAC addresses [37-6](#)
- static binding [50-20](#)
- suspended connection [C-2](#)
- suspended connections [20-10](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

---

**X**

## XML

support [2-16](#)

## XRC

FICON support [36-5](#)

---

**Z**

## zone aliases

conversion to device aliases [31-5](#)

## zone attribute groups

cloning [30-31](#)

## zone configurations

test for compatibility [68-8](#)

## zone databases

migrating a non-MDS database [30-32](#)

## zone members

adding to zones [30-14](#)

converting to pWWN members [30-23](#)

displaying information [30-19](#)

zoneMergeFailureIsolation tooltip [69-18](#)

## zone policies

configuring [2-11](#)

zoneRemoteNoRespIsolation tooltip [69-18](#)

## zones

access control [30-16](#)

adding zone members [30-14](#)

analyzing merges [68-8](#)

assigning LUNs to storage subsystems [30-38](#)

backing up (procedure) [30-29](#)

changing from enhanced zones [30-41](#)

cloning [30-31](#)

compact for downgrading [30-44](#)

comparison with device aliases (table) [31-2](#)

comparison with VSANs (table) [26-4](#)

configuring [30-10 to 30-24](#)

configuring aliases [30-20](#)

configuring and activating for iSLB [50-41](#)

configuring broadcasting [30-35](#)

configuring fcalias [30-20](#)

default policies [30-2](#)

default settings [30-45](#)

differences with IVR zones (table) [29-22](#)

displayed as bold [69-9](#)

editing full zone databases [30-11](#)

enforcing restrictions [30-25](#)

exporting databases [30-27](#)

features [30-1, 30-3](#)

importing databases [30-27](#)

iSLB [50-41, 50-42](#)

IVR communication [29-22](#)

logging facility [63-3](#)

LUN-based [30-36](#)

membership using pWWNs [26-4](#)

merge failures [20-10](#)

read-only for IVR [29-31](#)

renaming [30-30](#)

restoring (procedure) [30-29](#)

troubleshooting tools [5-22](#)

viewing information [30-39](#)

viewing inventory information [7-30](#)

wizard [5-21](#)

See also default zones

See also enhanced zones

See also hard zoning; soft zoning

See also LUN zoning

See also read-only zones

See also zoning; zone sets

## zone server databases

clearing [30-32](#)

## zone sets

activating [30-17](#)

cloning [30-31](#)

configuring [30-15 to 30-20](#)

considerations [30-5](#)

copying [30-28](#)

creating [30-16](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***

- default settings [30-45](#)
- distributing configuration [30-25](#)
- enabling distribution [30-25](#)
- exporting [30-27](#)
- exporting databases [30-27](#)
- features [30-1](#)
- importing [30-27](#)
- importing databases [30-27](#)
- one-time distribution [30-26](#)
- recovering from link isolations [30-27](#)
- renaming [30-30](#)
- viewing information [30-39](#)
- See also active zone sets
- See also active zone sets; full zone sets
- See also zones; zoning

zone traffic priorities

- description [30-33](#)

zoning

- configuring broadcasting [30-35](#)
- description [30-1](#)
- example [30-2](#)
- FabricWare support [D-2](#)
- implementation [30-3](#)
- Quick Config Wizard [30-7 to 30-10](#)

See also LUN zoning

See also zones; zone sets

zoning based access control

- configuring for iSCSI [50-25](#)

- configuring for iSCSIiSCSI

- configuring zoning based access control [50-25](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)***