Preface vi

New in Cisco TelePresence Content Server Release 7.1 vi

Related Documentation vii

Obtaining Documentation and Submitting a Service Request vii

CHAPTER 1

The Management Tab 1-1

Server Overview 1-2

Cluster Overview 1-6

Server Logs 1-7

Transcoding Queue 1-8

Edit Recordings 1-9

Edit Recording 1-9

Open Content Editor 1-15

Manage Outputs 1-17

Import Recordings 1-25

Create Recording 1-27

Recording Aliases 1-33

Adding or Editing Recording Aliases 1-34

Categories 1-40

Adding and Editing Categories 1-41

Templates 1-41

Adding or Editing Templates 1-42

Media Server Configurations 1-49

Windows Media Streaming Server 1-51

QuickTime or Darwin Streaming Server 1-54

Wowza Media Server for Flash 1-58

Cisco Video Streamer Server 1-61

Media Experience Engine 3500 Server 1-61

Show and Share Server 1-62

Podcast Producer Server 1-63

iTunes U Server 1-64

Call Configurations 1-65

Adding and Editing Call Configurations 1-66
Site Settings 1-67
View all gatekeeper registrations 1-81
View all SIP registrations 1-83
Upload language pack 1-85
Groups and Users 1-86
Adding and Editing Groups and Users 1-89
Creating Automatic Personal Recording Aliases 1-91
Windows Server 1-92

CHAPTER 2 **Cisco TelePresence Content Server Integration with VBrick** 2-1
Integration Overview 2-1
What is the Cisco TelePresence Content Server 2-1
What is VBrick DME 2-2
Prerequisites 2-2
Limitations 2-3
Configuring Cisco TelePresence Content Server 2-3
Configuring Media Server for VBrick VoD 2-3
Configuring Template for VBrick VoD 2-5
Configuring Recording Alias for VBrick VoD 2-7
Configuring Media Server for VBrick Live 2-8
Configuring Template for VBrick Live 2-10
Configuring Recording Alias for VBrick Live 2-12
Installing vBrick DME (Software only version) 2-13
Related Documentation 2-14
Disclaimers and Notices 2-14
Obtaining Documentation and Submitting a Service Request 2-15
2-16

CHAPTER 3 **Configuring a Cisco Unified Communications Manager SIP Trunk with a Cisco TelePresence Content Server** 3-17
CUCM Integration with Content Server 7.0 3-17
Cisco Content Server Standalone 3-17
SIP Route pattern Configuration Setting: 3-21
Configuring Route Patterns Using Route Group/ Route List 3-25
Cisco Content Server Cluster Configuration 3-35
Region configuration on CUCM 3-37
CUCM Configuration Setting on Content Server 3-37

CHAPTER 4 **Content Server VM with BE6K** 4-1
Introduction 4-1
Content Server VM with BE6K Features: 4-1
UI changes on Content Server for BE6K solution 4-2
Management Tab 4-2

APPENDIX 5 **Supported Platforms, Browsers, and Plug-ins** 5-1

CHAPTER 6 **Creating and Managing a Content Server Cluster** 6-1
About Content Server Clusters 6-2
System Requirements 6-4
Important Guidelines 6-5
Setting up a Content Server Cluster 6-6
Overview of the Process 6-6
Content Server Cluster Prerequisites 6-6
Configure the External SQL Server Database 6-7
Add an SQL Server Instance 6-7
Configure the SQL Server Instance 6-8
Create a Special User on the SQL Server 6-9
Configure the NAS 6-10
Manage the Windows Active Directory Domain 6-10
Choose or Create a Domain Account to Access the NAS Share 6-10
Set up a Share on the NAS 6-10
Set Permissions and Security Settings on the Share 6-11
About Creating a Content Server Cluster 6-12
The Order of Content Servers Added to the Cluster 6-12
Content Server Wizard Options 6-13
User Accounts for the Content Server Wizard 6-13
Before Running the Content Server Wizard 6-14
Create a New Content Server Cluster 6-14
Add a Content Server to an Existing Cluster 6-16
Configure Gatekeeper Registration for H.323 Cluster 6-17
Configure Gatekeeper Registration for SIP Cluster 6-18
Configure Domain Authentication 6-18
Configure Network Load Balancing (NLB) 6-18
Configure a Load Balancer 6-20
Set up a Loopback Adapter on Each Content Server in Cluster 6-21
Enter the Cluster Virtual IP Address as the Frontend Address on the Content Server 6-21

Managing a Content Server Cluster 6-22
Access Cluster Administrative Pages 6-22
View Cluster Status 6-23
Edit Information for Each Content Server in Cluster 6-24
Edit Information Common to All Content Servers in Cluster 6-24
Generate a Cluster Settings File 6-26
Update Load Balancer Configuration 6-26
Update Cluster Settings 6-27
Update the Password for MYDOMAIN\Content Server_NAS_USER Account 6-27
Change the MYDOMAIN\Content Server_NAS_USER Account to Another Domain Account 6-28
Change the Location of the Media Files to a Different NAS Share 6-28
Removing a Content Server from the Cluster 6-29
Using TMS to Schedule Calls on a Content Server Cluster 6-30
Backing Up and Restoring the Content Server Cluster 6-31
Backing Up Clustered Content Servers 6-31
Backing Up the External MS SQL Database 6-31
Backing Up Media on the NAS/External Streaming Server 6-31
Upgrading the Cluster to a New Software Version 6-32
Upgrading the External Microsoft SQL Server 6-32

CHAPTER 7 **The My Recordings Tab 7-1**
Edit Recordings 7-1
Edit Recording 7-2
Open Content Editor 7-5
Manage Outputs 7-8
Create Recording 7-16
Edit Recording Aliases 7-17

CHAPTER 8 **Understanding Distribution Outputs 8-1**
Configuring Automatic Upload to Cisco Media Experience Engine 3500, Cisco Show and Share, Podcast Producer or iTunes U 8-1
Uploading Existing Recordings to Cisco Media Experience Engine 3500, Cisco Show and Share, Podcast Producer or iTunes U 8-2
Understanding the Difference between Distribution Outputs and Streaming Servers 8-3

CHAPTER 9 **Maintaining the Content Server 9-1**
Backing Up the Content Server 9-1

Before Backing Up 9-1
Performing a Manual Backup 9-2
Configuring a Scheduled Backup 9-2
Restoring Files 9-3
Before Restoring 9-3
Restoring from a Backup 9-3
Performing a Software Reimage 9-4
Reimage Instructions 9-5
Task 1: Clear the hard drive and install the software 9-5
Task 2: Install the license files 9-7
Task 3: Configure the basic settings 9-8
Restoring Files After a Software Reimage 9-8
Restore Files on a Reimaged Standalone Content Server 9-9
Restore Files on a Reimaged Content Server with Network Attached Storage 9-9
Restore Files on a Reimaged Content Server in a Cluster 9-10
Shutting Down and Powering Off the Content Server 9-11
Securing the Content Server 9-12

APPENDIX 10 **Port Information** 10-1

CHAPTER 11 **Premium Resolution** 11-1
Configuring and Using the Premium Resolution Features 11-1

CHAPTER 12 **Understanding Recording Aliases** 12-1

CHAPTER 13 **Setting Up External Media Storage** 13-1
Changing the Local Storage Location to NAS 13-1
Reverting NAS Storage Location to the Default 13-3
Changing NAS Storage to New Location 13-3
Managing the Domain Account for NAS Access 13-4

CHAPTER 14 **Using Cisco TMS with the Content Server** 14-1
Configuring the Content Server for Use by TMS 14-1
Using TMS to Schedule Recording Sessions 14-2

CHAPTER 15 **The View Recordings Tab** 15-1
Watching a Recording in the Content Server Web Interface 15-1

Watching a Downloaded Output on Your Computer 15-2
Watching a Downloaded Recording on a Portable Device 15-3
Sending a Link to the Recording to Others 15-3

CHAPTER 16 **Configuration for Smart Card Login** 16-1
Smart Card Configuration with TCS 16-1
Limitation 16-5
Workaround 16-5