Preface

This preface describes the audience, organization, and convention of the Cisco Wireless LAN Controller System Messages Guide. It also provides information on how to obtain related documentation.

This chapter contains the following sections:

- Audience, page iii
- Organization, page iii
- Conventions, page iv
- Related Documentation, page iv
- Obtaining Documentation and Submitting a Service Request, page v

Audience

This publication is designed for the installer and user with a working knowledge of Cisco Wireless LAN Controllers. Users of this publication might also include network administrators and other people responsible for setting up and maintaining these devices.

Organization

This publication is organized into the following chapters:

Title	Description
1	Describes how to read a system or error message.
2	Contains new and changed system or error messages that first appear in a particular software release.
3	Contains message descriptions and recovery procedures.

Text Part Number:

Conventions

Screen examples use the following conventions:

Convention	Description
boldface font	Commands and keywords are in **boldface**.
italic font	Arguments for which you supply values are in *italics*.
[ ]	Elements in square brackets are optional.
{ x | y | z }	Alternative keywords are grouped in braces and separated by vertical bars.
[x | y | z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
`screen` font	Terminal sessions and information the system displays are in `screen` font.
`boldface screen` font	Information you must enter is in **`boldface screen`** font.
italic screen font	Arguments for which you supply values are in *italic screen* font.
——→	`This pointer highlights an important line of text in an example.`
^	The symbol ^ represents the key labeled Control—for example, the key combination ^D in a screen display means hold down the Control key while you press the D key.
< >	Nonprinting characters, such as passwords are in angle brackets.

Notes use the following conventions:

Note Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the publication.

Related Documentation

These documents provide complete information about the Cisco Unified Wireless Network Solution:

- *Quick Start Guide: Cisco 2000 Series Wireless LAN Controllers*
- *Quick Start Guide: Cisco 2100 Series Wireless LAN Controllers*
- *Quick Start Guide: Cisco 4400 Series Wireless LAN Controllers*
- *Cisco Wireless LAN Controller Command Reference*

- *Cisco Wireless Control System Configuration Guide*
- *Quick Start Guide: Cisco Wireless Control System*
- Quick start guide and hardware installation guide for your specific lightweight access point

  Click this link to browse to user documentation for the Cisco Unified Wireless Network Solution:

  http://www.cisco.com/en/US/products/hw/wireless/tsd_products_support_category_home.html

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.