

E Commands

- end, on page 2
- eraseconfig, on page 3
- exec, on page 4
- exit, on page 5
- export-config, on page 6

end

end

Description: Exit to the exec mode

Command Mode: exec : Exec Mode

Command Path:

```
# end
```

eraseconfig

eraseconfig [setup]

Description: Erase config and reboot

Syntax:

setup	(Optional) Clean setup

Command Mode: exec : Exec Mode

Command Path:

```
# eraseconfig [setup]
```

exec

exec

Description: Exec Mode

Command Mode: None

exit

exit

説明： 現在のモードを終了する

コマンド モード exec：Exec モード

コマンド パス：

```
# exit
```

export-config

export-config <WORD>

Description: Export Configuration

Syntax:

WORD	Filename(absolute path)

Command Mode: exec : Exec Mode

Command Path:

```
# export-config <WORD>
```

翻訳について
このドキュメントは、米国シスコ発行ドキュメントの参考和訳です。リンク情報につきましては、日本語版掲載時点で、英語版にアップデートがあり、リンク先のページが移動/変更されている場合がありますことをご了承ください。あくまでも参考和訳となりますので、正式な内容については米国サイトのドキュメントを参照ください。