

S Commands

- schedule, on page 19
- scheduler, on page 20
- show aaa authentication, on page 21
- show aaa groups, on page 22
- show aaa sessions, on page 23
- show access-list, on page 24
- show accounting log, on page 25
- show acllog deny l2 flow, on page 26
- show acllog deny l2 flow tenant vrf, on page 27
- show acllog deny l2 flow tenant vrf detail, on page 28
- show acllog deny l2 pkt, on page 29
- show acllog deny l2 pkt tenant vrf, on page 30
- show acllog deny l2 pkt tenant vrf detail, on page 31
- show acllog deny l3 flow, on page 32
- show acllog deny l3 flow tenant vrf, on page 33
- show acllog deny l3 flow tenant vrf detail, on page 34
- show acllog deny l3 pkt, on page 36
- show acllog deny l3 pkt tenant vrf, on page 37
- show acllog deny l3 pkt tenant vrf detail, on page 38
- show acllog permit l2 flow tenant vrf, on page 40
- show acllog permit l2 flow tenant vrf detail, on page 41
- show acllog permit l2 pkt tenant vrf, on page 42
- show acllog permit l2 pkt tenant vrf detail, on page 43
- show acllog permit l3 flow tenant vrf, on page 45
- show acllog permit l3 flow tenant vrf detail, on page 46
- show acllog permit l3 pkt tenant vrf, on page 48
- show acllog permit l3 pkt tenant vrf detail, on page 49
- show analytics, on page 51
- show application, on page 52
- show audits, on page 53
- show audits tenant, on page 54
- show audits tenant application, on page 55
- show audits tenant application epg, on page 56

- show audits tenant application esg, on page 57
- show audits tenant bridge-domain, on page 58
- show audits tenant bridge-domain detail, on page 59
- show audits tenant bridge-domain first-hop-security binding-table, on page 60
- show audits tenant bridge-domain first-hop-security statistics arp, on page 61
- show audits tenant bridge-domain first-hop-security statistics dhcpv4, on page 62
- show audits tenant bridge-domain first-hop-security statistics dhcpv6, on page 63
- show audits tenant bridge-domain first-hop-security statistics neighbor-discovery, on page 64
- show audits tenant dnsservergroup, on page 65
- show audits tenant dnsservergroup server, on page 66
- show audits tenant dnsservergroup server domain, on page 67
- show audits tenant interface bridge-domain, on page 68
- show audits tenant interface bridge-domain detail, on page 69
- show audits tenant interface bridge-domain first-hop-security binding-table, on page 70
- show audits tenant interface bridge-domain first-hop-security statistics arp, on page 71
- show audits tenant interface bridge-domain first-hop-security statistics dhcpv4, on page 72
- show audits tenant interface bridge-domain first-hop-security statistics dhcpv6, on page 73
- show audits tenant interface bridge-domain first-hop-security statistics neighbor-discovery, on page 74
- show audits tenant multicast-route-maps, on page 75
- show audits tenant vrf, on page 76
- show audits tenant vrf acllog l2, on page 77
- show audits tenant vrf acllog l3, on page 78
- show audits tenant vrf detail, on page 80
- show audits tenant vrf external-l3 bgp, on page 81
- show audits tenant vrf external-l3 bgp node, on page 82
- show audits tenant vrf external-l3 eigrp, on page 83
- show audits tenant vrf external-l3 eigrp detail, on page 84
- show audits tenant vrf external-l3 epg, on page 85
- show audits tenant vrf external-l3 epg detail, on page 86
- show audits tenant vrf external-l3 interfaces, on page 87
- show audits tenant vrf external-l3 interfaces detail, on page 88
- show audits tenant vrf external-l3 ospf, on page 89
- show audits tenant vrf external-l3 ospf detail, on page 90
- show audits tenant vrf external-l3 scale, on page 91
- show audits tenant vrf external-l3 scale detail, on page 92
- show audits tenant vrf external-l3 static-route, on page 93
- show audits tenant vrf external-l3 static-route detail, on page 94
- show audits tenant vrf external-l3 static-route node, on page 95
- show audits tenant vrf external-l3 static-route node detail, on page 96
- show audits tenant vrf ipv6multicast, on page 97
- show audits tenant vrf multicast, on page 98
- show bridge-domain, on page 99
- show bridge-domain detail, on page 100
- show bridge-domain first-hop-security binding-table, on page 101
- show bridge-domain first-hop-security statistics arp, on page 102

- show bridge-domain first-hop-security statistics dhcpv4, on page 103
- show bridge-domain first-hop-security statistics dhcpv6, on page 104
- show bridge-domain first-hop-security statistics neighbor-discovery, on page 105
- show callhome, on page 106
- show callhome common destination-profile, on page 107
- show callhome common query-profile, on page 108
- show callhome common transport-email, on page 109
- show catalog, on page 110
- show cli command, on page 111
- show cli list, on page 112
- show cli manpage, on page 113
- show cli path, on page 114
- show clock, on page 115
- show cloudave, on page 116
- show cloudsec summary, on page 117
- show communication ciphers, on page 118
- show communication controller, on page 119
- show communication http, on page 120
- show communication https, on page 121
- show communication performance, on page 122
- show communication performance config, on page 123
- show communication performance results, on page 124
- show communication shellinabox, on page 125
- show communication ssh-service, on page 126
- show communication telnet, on page 127
- show communication web-requests, on page 128
- show contract-type, on page 129
- show contract, on page 130
- show controller, on page 131
- show controller detail, on page 132
- show cores, on page 133
- show cores status, on page 134
- show debug counter, on page 135
- show debug log, on page 136
- show deployment endpoint node, on page 137
- show discoveryissues, on page 138
- show discoveryissues node, on page 139
- show dns-address, on page 140
- show dns-domain, on page 141
- show dot1q-tunnel, on page 142
- show dwdm interface, on page 143
- show endpoints, on page 144
- show endpoints leaf interface ethernet, on page 145
- show endpoints leaf interface port-channel, on page 146
- show endpoints vpc, on page 147
- show epg, on page 148

- show epg detail, on page 149
- show esg, on page 150
- show esg detail, on page 151
- show events, on page 152
- show events controller, on page 153
- show events controller detail, on page 154
- show events leaf, on page 155
- show events leaf fex, on page 156
- show events Leaf fex module, on page 157
- show events Leaf interface ethernet, on page 158
- show events Leaf interface fc, on page 159
- show events leaf interface fcportchannel, on page 160
- show events leaf interface l3instance, on page 161
- show events leaf interface mgmt, on page 162
- show events leaf interface portchannel, on page 163
- show events Leaf interface tunnel, on page 164
- show events Leaf interface vethernet, on page 165
- show events leaf inventory chassis, on page 166
- show events leaf inventory fans, on page 167
- show events leaf inventory module, on page 168
- show events leaf inventory module fabricport, on page 169
- show events leaf inventory module leafport, on page 170
- show events leaf inventory powersupply, on page 171
- show events leaf inventory supervisor, on page 172
- show events Leaf protocol, on page 173
- show events Leaf vpc, on page 174
- show events leaf vrf, on page 175
- show events spine, on page 176
- show events spine interface ethernet, on page 177
- show events spine interface l3instance, on page 178
- show events spine interface mgmt, on page 179
- show events spine interface tunnel, on page 180
- show events spine inventory chassis, on page 181
- show events spine inventory fabric, on page 182
- show events spine inventory fans, on page 183
- show events spine inventory module, on page 184
- show events spine inventory module fabricport, on page 185
- show events spine inventory powersupply, on page 186
- show events spine inventory supervisor, on page 187
- show events spine inventory system, on page 188
- show events spine protocol, on page 189
- show events spine vrf, on page 190
- show events tenant, on page 191
- show events tenant application, on page 192
- show events tenant application epg, on page 193
- show events tenant application esg, on page 194

- show events tenant bridge-domain, on page 195
- show events tenant bridge-domain detail, on page 196
- show events tenant bridge-domain first-hop-security binding-table, on page 197
- show events tenant bridge-domain first-hop-security statistics arp, on page 198
- show events tenant bridge-domain first-hop-security statistics dhcpv4, on page 199
- show events tenant bridge-domain first-hop-security statistics dhcpv6, on page 200
- show events tenant bridge-domain first-hop-security statistics neighbor-discovery, on page 201
- show events tenant dnsservergroup, on page 202
- show events tenant dnsservergroup server, on page 203
- show events tenant dnsservergroup server domain, on page 204
- show events tenant endpoints, on page 205
- show events tenant endpoints leaf interface ethernet, on page 206
- show events tenant endpoints leaf interface port-channel, on page 207
- show events tenant endpoints vpc, on page 208
- show events tenant interface bridge-domain, on page 209
- show events tenant interface bridge-domain detail, on page 210
- show events tenant interface bridge-domain first-hop-security binding-table, on page 211
- show events tenant interface bridge-domain first-hop-security statistics arp, on page 212
- show events tenant interface bridge-domain first-hop-security statistics dhcpv4, on page 213
- show events tenant interface bridge-domain first-hop-security statistics dhcpv6, on page 214
- show events tenant interface bridge-domain first-hop-security statistics neighbor-discovery, on page 215
- show events tenant multicast-route-maps, on page 216
- show events tenant vrf, on page 217
- show events tenant vrf acllog l2, on page 218
- show events tenant vrf acllog l3, on page 219
- show events tenant vrf detail, on page 221
- show events tenant vrf external-l3 bgp, on page 222
- show events tenant vrf external-l3 bgp node, on page 223
- show events tenant vrf external-l3 eigrp, on page 224
- show events tenant vrf external-l3 eigrp detail, on page 225
- show events tenant vrf external-l3 epg, on page 226
- show events tenant vrf external-l3 epg detail, on page 227
- show events tenant vrf external-l3 interfaces, on page 228
- show events tenant vrf external-l3 interfaces detail, on page 229
- show events tenant vrf external-l3 ospf, on page 230
- show events tenant vrf external-l3 ospf detail, on page 231
- show events tenant vrf external-l3 route-map, on page 232
- show events tenant vrf external-l3 route-map detail, on page 233
- show events tenant vrf external-l3 scale, on page 234
- show events tenant vrf external-l3 scale detail, on page 235
- show events tenant vrf external-l3 static-route, on page 236
- show events tenant vrf external-l3 static-route detail, on page 237
- show events tenant vrf external-l3 static-route node, on page 238
- show events tenant vrf external-l3 static-route node detail, on page 239
- show events tenant vrf ipv6multicast, on page 240

- show events tenant vrf multicast, on page 241
- show external-l2 epg, on page 242
- show external-l2 epg name, on page 243
- show external-l2 epg tenant, on page 244
- show external-l3 bgp, on page 245
- show external-l3 bgp tenant, on page 246
- show external-l3 bgp tenant vrf, on page 247
- show external-l3 bgp tenant vrf node, on page 248
- show external-l3 eigrp, on page 249
- show external-l3 eigrp detail, on page 250
- show external-l3 eigrp node, on page 251
- show external-l3 eigrp node detail, on page 252
- show external-l3 eigrp tenant, on page 253
- show external-l3 eigrp tenant detail, on page 254
- show external-l3 eigrp tenant vrf, on page 255
- show external-l3 eigrp tenant vrf detail, on page 256
- show external-l3 eigrp tenant vrf node, on page 257
- show external-l3 eigrp tenant vrf node detail, on page 258
- show external-l3 epg, on page 259
- show external-l3 epg detail, on page 260
- show external-l3 epg name, on page 261
- show external-l3 epg name detail, on page 262
- show external-l3 epg tenant, on page 263
- show external-l3 epg tenant detail, on page 264
- show external-l3 epg tenant vrf, on page 265
- show external-l3 epg tenant vrf detail, on page 266
- show external-l3 interfaces, on page 267
- show external-l3 interfaces detail, on page 268
- show external-l3 interfaces node, on page 269
- show external-l3 interfaces node detail, on page 270
- show external-l3 interfaces tenant, on page 271
- show external-l3 interfaces tenant detail, on page 272
- show external-l3 interfaces tenant vrf, on page 273
- show external-l3 interfaces tenant vrf detail, on page 274
- show external-l3 interfaces tenant vrf node, on page 275
- show external-l3 interfaces tenant vrf node detail, on page 276
- show external-l3 ospf, on page 277
- show external-l3 ospf detail, on page 278
- show external-l3 ospf node, on page 279
- show external-l3 ospf node detail, on page 280
- show external-l3 ospf tenant, on page 281
- show external-l3 ospf tenant detail, on page 282
- show external-l3 ospf tenant vrf, on page 283
- show external-l3 ospf tenant vrf detail, on page 284
- show external-l3 ospf tenant vrf node, on page 285
- show external-l3 ospf tenant vrf node detail, on page 286

- show external-l3 route-map, on page 287
- show external-l3 route-map detail, on page 288
- show external-l3 route-map name, on page 289
- show external-l3 route-map name detail, on page 290
- show external-l3 route-map tenant, on page 291
- show external-l3 route-map tenant detail, on page 292
- show external-l3 route-map tenant vrf, on page 293
- show external-l3 route-map tenant vrf detail, on page 294
- show external-l3 route-map tenant vrf node, on page 295
- show external-l3 route-map tenant vrf node detail, on page 296
- show external-l3 scale, on page 297
- show external-l3 scale detail, on page 298
- show external-l3 scale node, on page 299
- show external-l3 scale node detail, on page 300
- show external-l3 scale tenant, on page 301
- show external-l3 scale tenant detail, on page 302
- show external-l3 scale tenant vrf, on page 303
- show external-l3 scale tenant vrf detail, on page 304
- show external-l3 scale tenant vrf node, on page 305
- show external-l3 scale tenant vrf node detail, on page 306
- show external-l3 static-route, on page 307
- show external-l3 static-route detail, on page 308
- show external-l3 static-route node, on page 309
- show external-l3 static-route node detail, on page 310
- show external-l3 static-route tenant, on page 311
- show external-l3 static-route tenant detail, on page 312
- show external-l3 static-route tenant vrf, on page 313
- show external-l3 static-route tenant vrf detail, on page 314
- show external-l3 static-route tenant vrf node, on page 315
- show external-l3 static-route tenant vrf node detail, on page 316
- show fabric-discovery-health, on page 317
- show fabric-recovery checker, on page 318
- show fabric-recovery status, on page 319
- show faults, on page 320
- show faults controller, on page 322
- show faults controller detail, on page 323
- show faults l4l7-cluster, on page 324
- show faults l4l7-graph, on page 325
- show faults leaf, on page 326
- show faults leaf fex, on page 327
- show faults leaf fex module, on page 328
- show faults leaf interface ethernet, on page 329
- show faults leaf interface fc, on page 330
- show faults leaf interface fcportchannel, on page 331
- show faults leaf interface l3instance, on page 332
- show faults leaf interface mgmt, on page 333

- show faults leaf interface portchannel, on page 334
- show faults leaf interface tunnel, on page 335
- show faults leaf interface vethernet, on page 336
- show faults leaf inventory chassis, on page 337
- show faults leaf inventory fans, on page 338
- show faults leaf inventory module, on page 339
- show faults leaf inventory module fabricport, on page 340
- show faults leaf inventory module leafport, on page 341
- show faults leaf inventory powersupply, on page 342
- show faults leaf inventory supervisor, on page 343
- show faults leaf protocol, on page 344
- show faults leaf vpc, on page 345
- show faults leaf vrf, on page 346
- show faults microsoft domain, on page 347
- show faults microsoft domain name, on page 348
- show faults microsoft domain name hyperv, on page 349
- show faults microsoft domain name port-group, on page 350
- show faults microsoft domain name scvmm, on page 351
- show faults microsoft domain name vm, on page 352
- show faults microsoft domain name vm name, on page 353
- show faults quota, on page 354
- show faults redhat domain, on page 355
- show faults redhat domain name, on page 356
- show faults redhat domain name epg, on page 357
- show faults redhat domain name rhev, on page 358
- show faults spine, on page 359
- show faults spine interface ethernet, on page 360
- show faults spine interface l3instance, on page 361
- show faults spine interface mgmt, on page 362
- show faults spine interface tunnel, on page 363
- show faults spine inventory chassis, on page 364
- show faults spine inventory fabric, on page 365
- show faults spine inventory fans, on page 366
- show faults spine inventory module, on page 367
- show faults spine inventory module fabricport, on page 368
- show faults spine inventory powersupply, on page 369
- show faults spine inventory supervisor, on page 370
- show faults spine inventory system, on page 371
- show faults spine protocol, on page 372
- show faults spine vrf, on page 373
- show faults tenant, on page 374
- show faults tenant アプリケーション, on page 375
- show faults tenant application epg, on page 376
- show faults tenant application esg, on page 377
- show faults tenant bridge-domain, on page 378
- show faults tenant bridge-domain detail, on page 379

- show faults tenant bridge-domain first-hop-security binding-table, on page 380
- show faults tenant bridge-domain first-hop-security statistics arp, on page 381
- show faults tenant bridge-domain first-hop-security statistics dhcpv4, on page 382
- show faults tenant bridge-domain first-hop-security statistics dhcpv6, on page 383
- show faults tenant bridge-domain first-hop-security statistics neighbor-discovery, on page 384
- show faults tenant dnsservergroup, on page 385
- show faults tenant dnsservergroup server, on page 386
- show faults tenant dnsservergroup server domain, on page 387
- show faults tenant interface bridge-domain, on page 388
- show faults tenant interface bridge-domain detail, on page 389
- show faults tenant interface bridge-domain first-hop-security binding-table, on page 390
- show faults tenant interface bridge-domain first-hop-security statistics arp, on page 391
- show faults tenant interface bridge-domain first-hop-security statistics dhcpv4, on page 392
- show faults tenant interface bridge-domain first-hop-security statistics dhcpv6, on page 393
- show faults tenant interface bridge-domain first-hop-security statistics neighbor-discovery, on page 394
- show faults tenant multicast-route-maps, on page 395
- show faults tenant vrf, on page 396
- show faults tenant vrf acllog l2, on page 397
- show faults tenant vrf acllog l3, on page 398
- show faults tenant vrf detail, on page 400
- show faults tenant vrf external-l3 bgp, on page 401
- show faults tenant vrf external-l3 bgp node, on page 402
- show faults tenant vrf external-l3 eigrp, on page 403
- show faults tenant vrf external-l3 eigrp detail, on page 404
- show faults tenant vrf external-l3 epg, on page 405
- show faults tenant vrf external-l3 epg detail, on page 406
- show faults tenant vrf external-l3 interfaces, on page 407
- show faults tenant vrf external-l3 interfaces detail, on page 408
- show faults tenant vrf external-l3 ospf, on page 409
- show faults tenant vrf external-l3 ospf detail, on page 410
- show faults tenant vrf external-l3 scale, on page 411
- show faults tenant vrf external-l3 scale detail, on page 412
- show faults tenant vrf external-l3 static-route, on page 413
- show faults tenant vrf external-l3 static-route detail, on page 414
- show faults tenant vrf external-l3 static-route node, on page 415
- show faults tenant vrf external-l3 static-route node detail, on page 416
- show faults tenant vrf ipv6multicast, on page 417
- show faults tenant vrf multicast, on page 418
- show faults vmware domain, on page 419
- show faults vmware domain name, on page 420
- show faults vmware domain name epg, on page 421
- show faults vmware domain name esx, on page 422
- show faults vmware domain name port-group, on page 423
- show faults vmware domain name trunk-portgroup, on page 424
- show faults vmware domain name vcenter, on page 425

- show faults vmware domain name vm, on page 426
- show faults vmware domain name vm name, on page 427
- show fips, on page 428
- show fips status, on page 429
- show firmware compat matrix, on page 430
- show firmware repository, on page 431
- show firmware repository detail, on page 432
- show firmware upgrade scheduler-status, on page 433
- show firmware upgrade scheduler-status switch-group, on page 434
- show firmware upgrade status, on page 435
- show firmware upgrade status controller-group, on page 436
- show firmware upgrade status controller-group detail, on page 437
- show firmware upgrade status detail, on page 438
- show firmware upgrade status standby-apic, on page 439
- show firmware upgrade status standby-apic detail, on page 440
- show firmware upgrade status switch-group, on page 441
- show firmware upgrade status switch-group detail, on page 442
- show flow exporter, on page 443
- show flow exporter infra, on page 444
- show flow exporter tenant, on page 445
- show flow monitor, on page 446
- show flow monitor infra, on page 447
- show flow monitor tenant, on page 448
- show flow node-policy, on page 449
- show flow node-policy detail, on page 450
- show flow record, on page 451
- show flow record infra, on page 452
- show flow record tenant, on page 453
- show flow vm-exporter, on page 454
- show health, on page 455
- show health leaf, on page 456
- show health leaf fex, on page 457
- show health leaf fex module, on page 458
- show health leaf interface ethernet, on page 459
- show health leaf interface fc, on page 460
- show health leaf interface fcportchannel, on page 461
- show health leaf interface l3instance, on page 462
- show health leaf interface mgmt, on page 463
- show health leaf interface portchannel, on page 464
- show health leaf interface tunnel, on page 465
- show health leaf interface vethernet, on page 466
- show health leaf inventory chassis, on page 467
- show health leaf inventory fans, on page 468
- show health leaf inventory module, on page 469
- show health leaf inventory module fabricport, on page 470
- show health Leaf inventory module leafport, on page 471

- show health leaf inventory powersupply, on page 472
- show health leaf inventory supervisor, on page 473
- show health leaf protocol, on page 474
- show health leaf vpc, on page 475
- show health leaf vrf, on page 476
- show health spine, on page 477
- show health spine interface ethernet, on page 478
- show healthpine interface l3instance, on page 479
- show health spine interface mgmt, on page 480
- show health spine interface tunnel, on page 481
- show health spine inventory chassis, on page 482
- show health spine inventory fabric, on page 483
- show health spine inventory fans, on page 484
- show health spine inventory module, on page 485
- show health spine inventory module fabricport, on page 486
- show health spine inventory powersupply, on page 487
- show health spine inventory supervisor, on page 488
- show health spine inventory system, on page 489
- show health spine protocol, on page 490
- show health spine vrf, on page 491
- show health tenant, on page 492
- show health tenant application, on page 493
- show health tenant application epg, on page 494
- show health tenant application esg, on page 495
- show health tenant bridge-domain, on page 496
- show health tenant bridge-domain detail, on page 497
- show health tenant bridge-domain first-hop-security binding-table, on page 498
- show health tenant bridge-domain first-hop-security statistics arp, on page 499
- show health tenant bridge-domain first-hop-security statistics dhcpv4, on page 500
- show health tenant bridge-domain first-hop-security statistics dhcpv6, on page 501
- show health tenant bridge-domain first-hop-security statistics neighbor-discovery, on page 502
- show health tenant dnsservergroup, on page 503
- show health tenant dnsservergroup server, on page 504
- show health tenant dnsservergroup server domain, on page 505
- show health tenant interface bridge-domain, on page 506
- show health tenant interface bridge-domain detail, on page 507
- show health tenant interface bridge-domain first-hop-security binding-table, on page 508
- show health tenant interface bridge-domain first-hop-security statistics arp, on page 509
- show health tenant interface bridge-domain first-hop-security statistics dhcpv4, on page 510
- show health tenant interface bridge-domain first-hop-security statistics dhcpv6, on page 511
- show health tenant interface bridge-domain first-hop-security statistics neighbor-discovery, on page 512
- show health tenant multicast-route-maps, on page 513
- show health tenant vrf, on page 514
- show health tenant vrf acllog l2, on page 515
- show health tenant vrf acllog l3, on page 516

- show health tenant vrf detail, on page 518
- show health tenant vrf external-l3 bgp, on page 519
- show health tenant vrf external-l3 bgp node, on page 520
- show health tenant vrf external-l3 eigrp, on page 521
- show health tenant vrf external-l3 eigrp detail, on page 522
- show health tenant vrf external-l3 epg, on page 523
- show health tenant vrf external-l3 epg detail, on page 524
- show health tenant vrf external-l3 interfaces, on page 525
- show health tenant vrf external-l3 interfaces detail, on page 526
- show health tenant vrf external-l3 ospf, on page 527
- show health tenant vrf external-l3 ospf detail, on page 528
- show health tenant vrf external-l3 scale, on page 529
- show health tenant vrf external-l3 scale detail, on page 530
- show health tenant vrf external-l3 static-route, on page 531
- show health tenant vrf external-l3 static-route detail, on page 532
- show health tenant vrf external-l3 static-route node, on page 533
- show health tenant vrf external-l3 static-route node detail, on page 534
- show health tenant vrf ipv6multicast, on page 535
- show health tenant vrf multicast, on page 536
- show inband-mgmt, on page 537
- show inband-mgmt controller, on page 538
- show inband-mgmt switch, on page 539
- show interface bridge-domain, on page 540
- show interface bridge-domain detail, on page 541
- show interface bridge-domain first-hop-security binding-table, on page 542
- show interface bridge-domain first-hop-security statistics arp, on page 543
- show interface bridge-domain first-hop-security statistics dhcpv4, on page 544
- show interface bridge-domain first-hop-security statistics dhcpv6, on page 545
- show interface bridge-domain first-hop-security statistics neighbor-discovery, on page 546
- show ip interface bridge-domain, on page 547
- show ipv6 interface bridge-domain, on page 548
- show l4l7-cluster, on page 549
- show l4l7-graph, on page 550
- show l4l7-package, on page 551
- show ldap-server, on page 552
- show license all, on page 553
- show license catalog, on page 554
- show license hostname, on page 555
- show license interval, on page 556
- show license status, on page 557
- show license summary, on page 558
- show license tech, on page 559
- show license transport-mode, on page 560
- show license udi, on page 561
- show license usage, on page 562
- show lldp, on page 563

- show locator-led, on page 564
- show locator-led status leaf, on page 565
- show locator-led status spine, on page 566
- show macsec interface, on page 567
- show macsec policy, on page 568
- show microsoft domain, on page 569
- show microsoft domain name, on page 570
- show microsoft domain name hyperv, on page 571
- show microsoft domain name port-group, on page 572
- show microsoft domain name scvmm, on page 573
- show microsoft domain name vm, on page 574
- show microsoft domain name vm name, on page 575
- show microsoft vm, on page 576
- show monitor access, on page 577
- show monitor access filter-group, on page 578
- show monitor access session, on page 579
- show monitor fabric, on page 580
- show monitor fabric filter-group, on page 581
- show monitor fabric session, on page 582
- show monitor summary, on page 583
- show monitor tenant, on page 584
- show monitor virtual, on page 585
- show name-alias tenant, on page 586
- show name-alias tenant acl, on page 587
- show name-alias tenant application, on page 588
- show name-alias tenant application epg, on page 589
- show name-alias tenant bridge-domain, on page 590
- show name-alias tenant contract, on page 591
- show name-alias tenant contract subject, on page 592
- show name-alias tenant l3out, on page 593
- show name-alias tenant vrf, on page 594
- show ntpq, on page 595
- show oob-mgmt, on page 596
- show oob-mgmt controller, on page 597
- show oob-mgmt switch, on page 598
- show pd-recovery status, on page 599
- show policy-map, on page 600
- show policy-map type data-plane, on page 601
- show policy-map type qos, on page 602
- show port-channel leaf, on page 603
- show port-channel map, on page 604
- show port-channel map leaf, on page 605
- show pwd-rules, on page 606
- show quota, on page 607
- show radius-server, on page 608
- show redhat domain, on page 609

- show redhat domain name, on page 610
- show redhat domain name epg, on page 611
- show redhat domain name rhev, on page 612
- show resource, on page 613
- show resource conflict encap-vlan epg, on page 614
- show resource conflict encap-vlan epg node, on page 615
- show role, on page 616
- show rsa-server, on page 617
- show running-config, on page 618
- show sessions, on page 619
- show sessions controller, on page 620
- show sessions controller detail, on page 621
- show sessions leaf, on page 622
- show sessions spine, on page 623
- show snapshot active, on page 624
- show snapshot files, on page 625
- show snapshot jobs, on page 626
- show snmp, on page 627
- show snmp clientgroups, on page 628
- show snmp community, on page 629
- show snmp engineid, on page 630
- show snmp hosts, on page 631
- show snmp summary, on page 632
- show snmp users, on page 633
- show stats, on page 634
- show stats granularity communication controller, on page 635
- show stats granularity leaf, on page 636
- show stats granularity leaf fex, on page 637
- show stats granularity leaf fex module, on page 638
- show stats granularity leaf interface ethernet, on page 639
- show stats granularity leaf interface fc, on page 640
- show stats granularity leaf interface fcportchannel, on page 641
- show stats granularity leaf interface mgmt, on page 642
- show stats granularity leaf interface portchannel, on page 643
- show stats granularity leaf interface vethernet, on page 644
- show stats granularity leaf inventory chassis, on page 645
- show stats granularity leaf inventory fans, on page 646
- show stats granularity leaf inventory powersupply, on page 647
- show stats granularity leaf inventory supervisor, on page 648
- show stats granularity spine, on page 649
- show stats granularity spine interface ethernet, on page 650
- show stats granularity spine interface mgmt, on page 651
- show stats granularity spine inventory chassis, on page 652
- show stats granularity spine inventory fabric, on page 653
- show stats granularity spine inventory fans, on page 654
- show stats granularity spine inventory module, on page 655

- show stats granularity spine inventory powersupply, on page 656
- show stats granularity spine inventory supervisor, on page 657
- show stats granularity spine inventory system, on page 658
- show stats granularity tenant, on page 659
- show stats granularity tenant application, on page 660
- show stats granularity tenant application epg, on page 661
- show stats granularity tenant application esg, on page 662
- show stats granularity tenant dnsservergroup, on page 663
- show stats granularity tenant dnsservergroup server, on page 664
- show stats granularity tenant dnsservergroup server domain, on page 665
- show stats粒度 tenant dot1q-tunnel, on page 666
- show stats granularity tenant multicast-route-maps, on page 667
- show stats granularity tenant vrf, on page 668
- show stats granularity tenant vrf acllog l2, on page 669
- show stats granularity tenant vrf acllog l3, on page 670
- show stats granularity tenant vrf detail, on page 672
- show stats granularity tenant vrf external-l3 bgp, on page 673
- show stats granularity tenant vrf external-l3 bgp node, on page 674
- show stats granularity tenant vrf external-l3 eigrp, on page 675
- show stats granularity tenant vrf external-l3 eigrp detail, on page 676
- show stats granularity tenant vrf external-l3 epg, on page 677
- show stats granularity tenant vrf external-l3 epg detail, on page 678
- show stats granularity tenant vrf external-l3 interfaces, on page 679
- show stats granularity tenant vrf external-l3 interfaces detail, on page 680
- show stats granularity tenant vrf external-l3 ospf, on page 681
- show stats granularity tenant vrf external-l3 ospf detail, on page 682
- show stats granularity tenant vrf external-l3 scale, on page 683
- show stats granularity tenant vrf external-l3 scale detail, on page 684
- show stats granularity tenant vrf external-l3 static-route, on page 685
- show stats granularity tenant vrf external-l3 static-route detail, on page 686
- show stats granularity tenant vrf external-l3 static-route node, on page 687
- show stats granularity tenant vrf external-l3 static-route node detail, on page 688
- show stats granularity tenant vrf ipv6multicast, on page 689
- show stats granularity tenant vrf multicast, on page 690
- show switch, on page 691
- show switch detail, on page 692
- show tacacs-server, on page 693
- show techsupport all, on page 694
- show techsupport controllers, on page 695
- show techsupport host, on page 696
- show techsupport switch, on page 697
- show tenant, on page 698
- show tenant access-list, on page 699
- show tenant application, on page 700
- show tenant application endpoints, on page 701
- show tenant application endpoints leaf interface ethernet, on page 702

- show tenant application endpoints leaf interface port-channel, on page 703
- show tenant application endpoints vpc, on page 704
- show tenant application epg, on page 705
- show tenant application epg detail, on page 706
- show tenant application epg endpoints, on page 707
- show tenant application epg endpoints leaf interface ethernet, on page 708
- show tenant application epg endpoints leaf interface port-channel, on page 709
- show tenant application epg endpoints vpc, on page 710
- show tenant application esg, on page 711
- show tenant application esg detail, on page 712
- show tenant application esg endpoints, on page 713
- show tenant bridge-domain, on page 714
- show tenant bridge-domain detail, on page 715
- show tenant bridge-domain first-hop-security binding-table, on page 716
- show tenant bridge-domain first-hop-security statistics arp, on page 717
- show tenant bridge-domain first-hop-security statistics dhcpv4, on page 718
- show tenant bridge-domain first-hop-security statistics dhcpv6, on page 719
- show tenant bridge-domain first-hop-security statistics neighbor-discovery, on page 720
- show tenant contract-type, on page 721
- show tenant contract, on page 722
- show tenant detail, on page 723
- show tenant dnsservergroup, on page 724
- show tenant dnsservergroup server, on page 725
- show tenant dnsservergroup server domain, on page 726
- show tenant dot1q-tunnel, on page 727
- show tenant endpoints, on page 728
- show tenant endpoints leaf interface ethernet, on page 729
- show tenant endpoints leaf interface port-channel, on page 730
- show tenant endpoints vpc, on page 731
- show tenant epg, on page 732
- show tenant epg detail, on page 733
- show tenant esg, on page 734
- show tenant esg detail, on page 735
- show tenant external-l2 epg, on page 736
- show tenant interface bridge-domain, on page 737
- show tenant interface bridge-domain detail, on page 738
- show tenant interface bridge-domain first-hop-security binding-table, on page 739
- show tenant interface bridge-domain first-hop-security statistics arp, on page 740
- show tenant interface bridge-domain first-hop-security statistics dhcpv4, on page 741
- show tenant interface bridge-domain first-hop-security statistics dhcpv6, on page 742
- show tenant interface bridge-domain first-hop-security statistics neighbor-discovery, on page 743
- show tenant ip interface bridge-domain, on page 744
- show tenant ipv6 interface bridge-domain, on page 745
- show tenant multicast-route-maps, on page 746
- show tenant policy-map, on page 747
- show tenant policy-map type data-plane, on page 748

- show tenant policy-map type qos, on page 749
- show tenant vrf, on page 750
- show tenant vrf acllog l2, on page 751
- show tenant vrf acllog l3, on page 752
- show tenant vrf detail, on page 754
- show tenant vrf external-l3 bgp, on page 755
- show tenant vrf external-l3 bgp node, on page 756
- show tenant vrf external-l3 eigrp, on page 757
- show tenant vrf external-l3 eigrp detail, on page 758
- show tenant vrf external-l3 epg, on page 759
- show tenant vrf external-l3 epg detail, on page 760
- show tenant vrf external-l3 interfaces, on page 761
- show tenant vrf external-l3 interfaces detail, on page 762
- show tenant vrf external-l3 ospf, on page 763
- show tenant vrf external-l3 ospf detail, on page 764
- show tenant vrf external-l3 route-map, on page 765
- show tenant vrf external-l3 route-map detail, on page 766
- show tenant vrf external-l3 scale, on page 767
- show tenant vrf external-l3 scale detail, on page 768
- show tenant vrf external-l3 static-route, on page 769
- show tenant vrf external-l3 static-route detail, on page 770
- show tenant vrf external-l3 static-route node, on page 771
- show tenant vrf external-l3 static-route node detail, on page 772
- show tenant vrf ipv6multicast, on page 773
- show tenant vrf multicast, on page 774
- show track-ipsla, on page 775
- show track-objects, on page 776
- show Troubleshooting session, on page 777
- show troubleshoot session atomiccounter, on page 778
- show troubleshoot session audit, on page 779
- show troubleshoot session contracts, on page 780
- show troubleshoot session deployments, on page 781
- show troubleshoot session events, on page 782
- show troubleshoot session faults, on page 783
- show troubleshoot session latency, on page 784
- show Troubleshooting session monitor, on page 785
- show troubleshoot session reports, on page 786
- show troubleshoot session statistics, on page 787
- show troubleshoot session topology, on page 788
- show troubleshoot session traceroute, on page 789
- show troubleshoot sessions, on page 790
- show upgrade-timeline controller, on page 791
- show upgrade-timeline summary, on page 792
- show upgrade-timeline switch, on page 793
- show upgradeissues controller, on page 794
- show username, on page 795

- show username detail, on page 796
- show versions, on page 797
- show vlan-domain, on page 798
- show vmware domain, on page 799
- show vmware domain name, on page 800
- show vmware domain name epg, on page 801
- show vmware domain name esx, on page 802
- show vmware domain name port-group, on page 803
- show vmware domain name trunk-portgroup, on page 804
- show vmware domain name vcenter, on page 805
- show vmware domain name vm, on page 806
- show vmware domain name vm name, on page 807
- show vmware vm, on page 808
- show vpc, on page 809
- show vpc map Leaf, on page 810
- show vrf, on page 811
- show vrf detail, on page 812
- show vsan-domain, on page 813
- sr-upgrade, on page 814
- sr-version, on page 815
- switch-group, on page 816
- switch, on page 817
- syslog, on page 818

schedule

schedule <WORD>

Description: Assign a scheduler

Syntax:

WORD	scheduler name (Max Size 64)

Command Mode: switch-group : Create switch firmware upgrade policy

Command Path:

```
# configure [['terminal', 't']]
(config)# firmware
(config-firmware)# switch-group <WORD>
(config-firmware-switch)# schedule <WORD>
```

scheduler

scheduler pause

Description: Pause maintenance policy scheduler

Syntax:

pause	Pause maintenance policy scheduler

Command Mode: switch-group : Create switch firmware upgrade policy

Command Path:

```
# configure [['terminal', 't']]
(config)# firmware
(config-firmware)# switch-group <WORD>
(config-firmware-switch)# scheduler pause
```

show aaa authentication

show aaa authentication

Description: Show AAA Authentication information

Command Mode: exec : Exec Mode

Command Path:

```
# show aaa authentication
```

show aaa groups

show aaa groups

説明： AAA グループ情報を表示します。

コマンド モード exec：Exec モード

コマンド パス：

```
# show aaa groups
```

show aaa sessions

show aaa sessions

Description: Active User Sessions

Command Mode: exec : Exec Mode

Command Path:

```
# show aaa sessions
```

show access-list

show access-list WORD

説明：アクセスリスト情報を表示する

構文：

WORD	フィルタするコントラクトの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show access-list WORD
```

show accounting log

show accounting log

Description: CLI configuration command logs

Command Mode: exec : Exec Mode

Command Path:

```
# show accounting log
```

NOTE:

This command displays only those changes made using the command line interface (CLI). It does not display changes made using the GUI or the API. To view all changes made in the Management Information Tree, use the **show audit detail** command.

show acllog deny l2 flow

show acllog deny l2 flow

説明： l3 フロー情報

コマンド モード exec：Exec モード

コマンド パス：

```
# show acllog deny l2 flow
```

show acllog deny l2 flow tenant vrf

show acllog deny l2 flow tenant <WORD> vrf [vlan <NUMBER>] [srcIntf <srcintf>] <WORD>

説明：テナント VRF 情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
<1-4094>	（オプション）カプセル化 VLAN。数値の範囲は 1 ～ 4094
srcintf	（オプション）送信元インターフェイス
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show acllog deny l2 flow tenant <WORD> vrf [vlan <NUMBER>] [srcIntf <srcintf>] <WORD>
```

show acllog deny l2 flow tenant vrf detail

show acllog deny l2 flow tenant <WORD> vrf [vlan <NUMBER>] [srcIntf <srcintf>] <WORD> detail [srcpctag <WORD>] [dstpctag <WORD>] [srcEpgName <WORD>] [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]

Description: detail information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
srcintf	(Optional) source Interface
WORD	Name of the VRF to filter on (Max Size 64)
WORD	(Optional) PC Tag (Max Size None)
WORD	(Optional) PC Tag (Max Size None)
WORD	(Optional) Epg Name (Max Size None)
WORD	(Optional) Epg Name (Max Size None)
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)

Command Mode: exec : Exec Mode

Command Path:

```
# show acllog deny l2 flow tenant <WORD> vrf [vlan <NUMBER>] [srcIntf <srcintf>] <WORD>
 detail [srcpctag <WORD>] [dstpctag <WORD>] [srcEpgName <WORD>] [dstEpgName <WORD>]
[srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [dstmac <E.E.E
EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]
```

show acllog deny l2 pkt

show acllog deny l2 pkt

説明： Pkt コマンド

コマンド モード exec：Exec モード

コマンド パス：

```
# show acllog deny l2 pkt
```

show acllog deny l2 pkt tenant vrf

show acllog deny l2 pkt tenant <WORD> vrf <WORD> [start-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [vlan <NUMBER>] [srcintf <srcintf>] [pktlen <NUMBER>]

説明：Vrf 名

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	（オプション）イベント アクティビティ（時間間隔）
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	（オプション）イベント アクティビティ（時間間隔）
<1-4094>	（オプション）カプセル化 VLAN。数値の範囲は 1 ～ 4094
srcintf	（オプション）送信元インターフェイス
<1-65535>	（オプション）パケット長。数値範囲は =1 ～ =65535

コマンド モード exec：Exec モード

コマンド パス：

```
# show acllog deny l2 pkt tenant <WORD> vrf <WORD> [start-time time-stamp
<YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [vlan <NUMBER>]
[srcintf <srcintf>] [pktlen <NUMBER>]
```

show acllog deny l2 pkt tenant vrf detail

show acllog deny l2 pkt tenant <WORD> vrf <WORD> [start-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [vlan <NUMBER>] [srcintf <srcintf>] [pktlen <NUMBER>] detail [srcpctag <WORD>] [dstpctag <WORD>] [srcEpgName <WORD>] [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]

Description: Detail information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the vrf to filter on (Max Size 64)
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	(Optional) Event activity in time interval
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	(Optional) Event activity in time interval
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
srcintf	(Optional) Source Interface
<1-65535>	(Optional) packet length. Number range from=1 to=65535
WORD	(Optional) PC Tag (Max Size None)
WORD	(Optional) PC Tag (Max Size None)
WORD	(Optional) Epg Name (Max Size None)
WORD	(Optional) Epg Name (Max Size None)
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)

Command Mode: exec : Exec Mode

Command Path:

```
# show acllog deny l2 pkt tenant <WORD> vrf <WORD> [start-time time-stamp
<YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [vlan <NUMBER>]
[srcintf <srcintf>] [pktlen <NUMBER>] detail [srcpctag <WORD>] [dstpctag <WORD>]
[srcEpgName <WORD>] [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE
 EEEE.EEEE.EEEE >] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]
```

show acllog deny l3 flow

show acllog deny l3 flow

Description: l3 flow information

Command Mode: exec : Exec Mode

Command Path:

```
# show acllog deny l3 flow
```

show acllog deny l3 flow tenant vrf

show acllog deny l3 flow tenant <WORD> vrf [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D or A:B::C:D>] [protocol <Protocol>] [srcport <SrcPort>] [dstport <DstPort>] [srcintf <srcintf>] <WORD>

説明：テナント VRF 情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
ABCD または *A:B::C:D*	（オプション）i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
ABCD または *A:B::C:D*	（オプション）i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
[プロトコル（Protocol）]	（オプション）プロトコル
SrcPort	（オプション）送信元ポート
DstPort	（オプション）接続先ポート
srcintf	（オプション）送信元インターフェイス
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show acllog deny l3 flow tenant <WORD> vrf [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D
 or A:B::C:D>] [protocol <Protocol>] [srcport <SrcPort>] [dstport <DstPort>] [srcintf
<srcintf>] <WORD>
```

show acllog deny l3 flow tenant vrf detail

show acllog deny l3 flow tenant <WORD> vrf [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D or A:B::C:D>] [protocol <Protocol>] [srcport <SrcPort>] [dstport <DstPort>] [srcintf <srcintf>] <WORD> detail [srcpctag <WORD>] [dstpctag <WORD>] [srcEpgName <WORD>] [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]

Description: detail information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
A.B.C.D or A:B::C:D	(Optional) IP address in format i.i.i.i or IPv6 address in format xxxx:xxxx, xxxx::xx
A.B.C.D or A:B::C:D	(Optional) IP address in format i.i.i.i or IPv6 address in format xxxx:xxxx, xxxx::xx
Protocol	(Optional) Protocol
SrcPort	(Optional) source port
DstPort	(Optional) destination port
srcintf	(Optional) source interface
WORD	Name of the VRF to filter on (Max Size 64)
WORD	(Optional) PC Tag (Max Size None)
WORD	(Optional) PC Tag (Max Size None)
WORD	(Optional) Epg Name (Max Size None)
WORD	(Optional) Epg Name (Max Size None)
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)

Command Mode: exec : Exec Mode

Command Path:

```
# show acllog deny l3 flow tenant <WORD> vrf [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D
 or A:B::C:D>] [protocol <Protocol>] [srcport <SrcPort>] [dstport <DstPort>] [srcintf
<srcintf>] <WORD> detail [srcpctag <WORD>] [dstpctag <WORD>] [srcEpgName <WORD>]
[dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE
```

```
>] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]
```

show acllog deny l3 pkt

show acllog deny l3 pkt

説明： Pkt コマンド

コマンド モード exec：Exec モード

コマンド パス：

```
# show acllog deny l3 pkt
```

show acllog deny l3 pkt tenant vrf

show acllog deny l3 pkt tenant <WORD> vrf <WORD> [start-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [protocol <protocol>] [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D or A:B::C:D>] [srcport <NUMBER>] [dstport <NUMBER>] [srcintf <srcintf>] [pktlen <NUMBER>]

説明：Vrf 名

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	（オプション）イベント アクティビティ（時間間隔）
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	（オプション）イベント アクティビティ（時間間隔）
protocol	（オプション）プロトコル
ABCD または *A:B::C:D*	（オプション）i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
ABCD または *A:B::C:D*	（オプション）i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
<0-65535>	（オプション）送信元ポート。数値範囲は =0 ～ =65535
<0-65535>	（オプション）接続先ポート。数値範囲は =0 ～ =65535
srcintf	（オプション）送信元インターフェイス
<1-65535>	（オプション）パケット長。数値範囲は =1 ～ =65535

コマンド モード exec：Exec モード

コマンド パス：

```
# show acllog deny l3 pkt tenant <WORD> vrf <WORD> [start-time time-stamp
<YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [protocol
<protocol>] [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D or A:B::C:D>] [srcport <NUMBER>]
 [dstport <NUMBER>] [srcintf <srcintf>] [pktlen <NUMBER>]
```

show acllog deny l3 pkt tenant vrf detail

show acllog deny l3 pkt tenant <WORD> vrf <WORD> [start-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [protocol <protocol>] [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D or A:B::C:D>] [srcport <NUMBER>] [dstport <NUMBER>] [srcintf <srcintf>] [pktlen <NUMBER>] detail [srcpctag <WORD>] [dstpctag <WORD>] [srcEpgName <WORD>] [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]

Description: Detail information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the vrf to filter on (Max Size 64)
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	(Optional) Event activity in time interval
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	(Optional) Event activity in time interval
protocol	(Optional) protocol
A.B.C.D or A:B::C:D	(Optional) IP address in format i.i.i.i or IPv6 address in format xxxx:xxxx, xxxx::xx
A.B.C.D or A:B::C:D	(Optional) IP address in format i.i.i.i or IPv6 address in format xxxx:xxxx, xxxx::xx
<0-65535>	(Optional) Source port. Number range from=0 to=65535
<0-65535>	(Optional) Destination port. Number range from=0 to=65535
srcintf	(Optional) source Interface
<1-65535>	(Optional) packet length. Number range from=1 to=65535
WORD	(Optional) PC Tag (Max Size None)
WORD	(Optional) PC Tag (Max Size None)
WORD	(Optional) Epg Name (Max Size None)
WORD	(Optional) Epg Name (Max Size None)
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)

E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)

Command Mode: exec : Exec Mode

Command Path:

```
# show acllog deny l3 pkt tenant <WORD> vrf <WORD> [start-time time-stamp
<YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [protocol
<protocol>] [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D or A:B::C:D>] [srcport <NUMBER>]
 [dstport <NUMBER>] [srcintf <srcintf>] [pktlen <NUMBER>] detail [srcpctag <WORD>]
[dstpctag <WORD>] [srcEpgName <WORD>] [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE
 EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE
 EEEE.EEEE.EEEE >]
```

show acllog permit l2 flow tenant vrf

show acllog permit l2 flow tenant <WORD> vrf [vlan <NUMBER>] [srcintf <srcintf>] <WORD>

Description: tenant vrf information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
srcintf	(Optional) source interface
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show acllog permit l2 flow tenant <WORD> vrf [vlan <NUMBER>] [srcintf <srcintf>] <WORD>
```

show acllog permit l2 flow tenant vrf detail

show acllog permit l2 flow tenant <WORD> vrf [vlan <NUMBER>] [srcintf <srcintf>] <WORD> detail [srcpctag <WORD>] [dstpctag <WORD>] [srcEpgName <WORD>] [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]

Description: detail information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
srcintf	(Optional) source interface
WORD	Name of the VRF to filter on (Max Size 64)
WORD	(Optional) PC Tag (Max Size None)
WORD	(Optional) PC Tag (Max Size None)
WORD	(Optional) Epg Name (Max Size None)
WORD	(Optional) Epg Name (Max Size None)
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)

Command Mode: exec : Exec Mode

Command Path:

```
# show acllog permit l2 flow tenant <WORD> vrf [vlan <NUMBER>] [srcintf <srcintf>] <WORD>
 detail [srcpctag <WORD>] [dstpctag <WORD>] [srcEpgName <WORD>] [dstEpgName <WORD>]
[srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [dstmac <E.E.E
EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]
```

show acllog permit l2 pkt tenant vrf

show acllog permit l2 pkt tenant <WORD> vrf <WORD> [start-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [vlan <NUMBER>] [srcintf <srcintf>] [pktlen <NUMBER>]

Description: Vrf Name

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the vrf to filter on (Max Size 64)
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	(Optional) Event activity in time interval
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	(Optional) Event activity in time interval
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
srcintf	(Optional) source Interface
<1-65535>	(Optional) packet length. Number range from=1 to=65535

Command Mode: exec : Exec Mode

Command Path:

```
# show acllog permit l2 pkt tenant <WORD> vrf <WORD> [start-time time-stamp
<YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [vlan <NUMBER>]
[srcintf <srcintf>] [pktlen <NUMBER>]
```

show acllog permit l2 pkt tenant vrf detail

show acllog permit l2 pkt tenant <WORD> vrf <WORD> [start-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [vlan <NUMBER>] [srcintf <srcintf>] [pktlen <NUMBER>] detail [srcpctag <WORD>] [dstpctag <WORD>] [srcEpgName <WORD>] [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]

説明：詳細情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	（オプション）イベント アクティビティ（時間間隔）
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	（オプション）イベント アクティビティ（時間間隔）
<1-4094>	（オプション）カプセル化 VLAN。数値の範囲は 1 ～ 4094
srcintf	（オプション）送信元インターフェイス
<1-65535>	（オプション）パケット長。数値範囲は =1 ～ =65535
WORD	（オプション）PC タグ（最大サイズなし）
WORD	（オプション）PC タグ（最大サイズなし）
WORD	（オプション）Epg 名（最大サイズなし）
WORD	（オプション）Epg 名（最大サイズなし）
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）

コマンド モード exec：Exec モード

コマンド パス：

```
# show acllog permit l2 pkt tenant <WORD> vrf <WORD> [start-time time-stamp
<YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [vlan <NUMBER>]
[srcintf <srcintf>] [pktlen <NUMBER>] detail [srcpctag <WORD>] [dstpctag <WORD>]
```

```
[srcEpgName <WORD>] [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE
 EEEE.EEEE.EEEE >] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]
```

show acllog permit l3 flow tenant vrf

show acllog permit l3 flow tenant <WORD> vrf [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D or A:B::C:D>] [protocol <Protocol>] [srcport <SrcPort>] [dstport <DstPort>] [srcintf <srcintf>] <WORD>

説明：テナント VRF 情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
ABCD または *A:B::C:D*	（オプション）i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
ABCD または *A:B::C:D*	（オプション）i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
[プロトコル（Protocol）]	（オプション）プロトコル
SrcPort	（オプション）送信元ポート
DstPort	（オプション）接続先ポート
srcintf	（オプション）送信元インターフェイス
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show acllog permit l3 flow tenant <WORD> vrf [srcip <A.B.C.D or A:B::C:D>] [dstip
<A.B.C.D or A:B::C:D>] [protocol <Protocol>] [srcport <SrcPort>] [dstport <DstPort>]
[srcintf <srcintf>] <WORD>
```

show acllog permit l3 flow tenant vrf detail

show acllog permit l3 flow tenant <WORD> vrf [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D or A:B::C:D>] [protocol <Protocol>] [srcport <SrcPort>] [dstport <DstPort>] [srcintf <srcintf>] <WORD> detail [srcpctag <WORD>] [dstpctag <WORD>] [srcEpgName <WORD>] [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]

説明：詳細情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
ABCD または *A:B::C:D*	（オプション）i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
ABCD または *A:B::C:D*	（オプション）i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
[プロトコル（Protocol）]	（オプション）プロトコル
SrcPort	（オプション）送信元ポート
DstPort	（オプション）接続先ポート
srcintf	（オプション）送信元インターフェイス
WORD	フィルタする VRF の名前（最大サイズ 64）
WORD	（オプション）PC タグ（最大サイズなし）
WORD	（オプション）PC タグ（最大サイズなし）
WORD	（オプション）Epg 名（最大サイズなし）
WORD	（オプション）Epg 名（最大サイズなし）
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）

コマンド モード exec：Exec モード

コマンド パス：

```
# show acllog permit l3 flow tenant <WORD> vrf [srcip <A.B.C.D or A:B::C:D>] [dstip
<A.B.C.D or A:B::C:D>] [protocol <Protocol>] [srcport <SrcPort>] [dstport <DstPort>]
[srcintf <srcintf>] <WORD> detail [srcpctag <WORD>] [dstpctag <WORD>] [srcEpgName <WORD>]
 [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE
>] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]
```

show acllog permit l3 pkt tenant vrf

show acllog permit l3 pkt tenant <WORD> vrf <WORD> [start-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [protocol <protocol>] [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D or A:B::C:D>] [srcport <NUMBER>] [dstport <NUMBER>] [srcintf <srcintf>] [pktlen <NUMBER>]

Description: Vrf Name

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the vrf to filter on (Max Size 64)
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	(Optional) Event activity in time interval
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	(Optional) Event activity in time interval
protocol	(Optional) protocol
A.B.C.D or A:B::C:D	(Optional) IP address in format i.i.i.i or IPv6 address in format xxxx:xxxx, xxxx::xx
A.B.C.D or A:B::C:D	(Optional) IP address in format i.i.i.i or IPv6 address in format xxxx:xxxx, xxxx::xx
<0-65535>	(Optional) Source port. Number range from=0 to=65535
<0-65535>	(Optional) Destination port. Number range from=0 to=65535
srcintf	(Optional) source Interface
<1-65535>	(Optional) packet length. Number range from=1 to=65535

Command Mode: exec : Exec Mode

Command Path:

```
# show acllog permit l3 pkt tenant <WORD> vrf <WORD> [start-time time-stamp
<YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [protocol
<protocol>] [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D or A:B::C:D>] [srcport <NUMBER>]
 [dstport <NUMBER>] [srcintf <srcintf>] [pktlen <NUMBER>]
```

show acllog permit l3 pkt tenant vrf detail

show acllog permit l3 pkt tenant <WORD> vrf <WORD> [start-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [protocol <protocol>] [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D or A:B::C:D>] [srcport <NUMBER>] [dstport <NUMBER>] [srcintf <srcintf>] [pktlen <NUMBER>] detail [srcpctag <WORD>] [dstpctag <WORD>] [srcEpgName <WORD>] [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]

Description: Detail information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the vrf to filter on (Max Size 64)
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	(Optional) Event activity in time interval
time-stamp <YYYY-MM-DDTHR:MIN:SEC>	(Optional) Event activity in time interval
protocol	(Optional) protocol
A.B.C.D or A:B::C:D	(Optional) IP address in format i.i.i.i or IPv6 address in format xxxx:xxxx, xxxx::xx
A.B.C.D or A:B::C:D	(Optional) IP address in format i.i.i.i or IPv6 address in format xxxx:xxxx, xxxx::xx
<0-65535>	(Optional) Source port. Number range from=0 to=65535
<0-65535>	(Optional) Destination port. Number range from=0 to=65535
srcintf	(Optional) source Interface
<1-65535>	(Optional) packet length. Number range from=1 to=65535
WORD	(Optional) PC Tag (Max Size None)
WORD	(Optional) PC Tag (Max Size None)
WORD	(Optional) Epg Name (Max Size None)
WORD	(Optional) Epg Name (Max Size None)
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)

E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)

Command Mode: exec : Exec Mode

Command Path:

```
# show acllog permit l3 pkt tenant <WORD> vrf <WORD> [start-time time-stamp
<YYYY-MM-DDTHR:MIN:SEC>] [end-time time-stamp <YYYY-MM-DDTHR:MIN:SEC>] [protocol
<protocol>] [srcip <A.B.C.D or A:B::C:D>] [dstip <A.B.C.D or A:B::C:D>] [srcport <NUMBER>]
 [dstport <NUMBER>] [srcintf <srcintf>] [pktlen <NUMBER>] detail [srcpctag <WORD>]
[dstpctag <WORD>] [srcEpgName <WORD>] [dstEpgName <WORD>] [srcmac <E.E.E EE-EE-EE-EE-EE-EE
 EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [dstmac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE
 EEEE.EEEE.EEEE >]
```

show analytics

show analytics

説明： 分析クラスタ構成を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show analytics
```

show application

show application WORD

説明：アプリケーション プロファイル情報を表示する

構文：

WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show application WORD
```

show audits

show audits [id <log-id>] [action action<action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] <scope>

Description: Show audit-log information

Syntax:

<*log-id*>	(Optional) Log ID
action<*action-type*>	(Optional) Object action indicator
<*user-name*>	(Optional) Name of user
<*num-minutes*>	(Optional) Logs created in time interval. Number range from 1 to 59
<*num-hours*>	(Optional) Logs created in time interval. Number range from 1 to 23
<*num-days*>	(Optional) Logs created in time interval. Number range from 1 to 999
<*YYYY-MM-DDTHR:MIN:SEC*>	(Optional) Logs created in time interval
end-time <*YYYY-MM-DDTHR:MIN:SEC*>	(Optional) Logs created in time interval
detail	(Optional) Detailed audit-log information. Displays what was modified and displays the old and new settings.
<*scope*>	command scope

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action action<action-type>] [user <user-name>] [last-minutes
 <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] <scope>
```

show audits tenant

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD

Description: Show Tenants Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD
```

show audits tenant application

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD

Description: Show Application Profiles Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD
```

show audits tenant application epg

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD epg WORD

Description: Show Application EPG Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)
WORD	Name of the AEPG to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD epg WORD
```

show audits tenant application esg

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD esg WORD

Description: Show Show Endpoint Security Group Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)
WORD	Name of the ESG to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD esg WORD
```

show audits tenant bridge-domain

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD

Description: Show Bridge-domain Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD
```

show audits tenant bridge-domain detail

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD detail

説明：ブリッジ ドメインの詳細情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD detail
```

show audits tenant bridge-domain first-hop-security binding-table

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security binding-table

説明：ブリッジドメイン バインド テーブル情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD
first-hop-security binding-table
```

show audits tenant bridge-domain first-hop-security statistics arp

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security statistics arp

説明：ブリッジドメイン ファースト ホップ セキュリティ ARP 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD
first-hop-security statistics arp
```

show audits tenant bridge-domain first-hop-security statistics dhcpv4

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security statistics dhcpv4

Description: Show Bridge-domain First Hop Security DHCPv4 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD
first-hop-security statistics dhcpv4
```

show audits tenant bridge-domain first-hop-security statistics dhcpv6

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security statistics dhcpv6

Description: Show Bridge-domain First Hop Security DHCPv6 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD
first-hop-security statistics dhcpv6
```

show audits tenant bridge-domain first-hop-security statistics neighbor-discovery

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security statistics neighbor-discovery

説明：ブリッジドメイン ファースト ホップ セキュリティ ネイバー探索統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD
first-hop-security statistics neighbor-discovery
```

show audits tenant dnsservergroup

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD

説明：DNS サーバ グループ情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタする DNS サーバ グループの名前（最大サイズ 16）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD
```

show audits tenant dnsservergroup server

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD server WORD

説明：Dns サーバ情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタする DNS サーバ グループの名前（最大サイズ 16）
WORD	最終的にフィルタするサーバの IP

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD server WORD
```

show audits tenant dnsservergroup server domain

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD server WORD domain WORD

説明：dnsドメイン情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタする DNS サーバ グループの名前（最大サイズ 16）
WORD	最終的にフィルタするサーバの IP
WORD	最終的にフィルタするドメイン（最大サイズ 512）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD server WORD
 domain WORD
```

show audits tenant interface bridge-domain

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD

説明：ブリッジドメイン情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
```

show audits tenant interface bridge-domain detail

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD detail

説明：ブリッジ ドメインの詳細情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
detail
```

show audits tenant interface bridge-domain first-hop-security binding-table

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security binding-table

説明：ブリッジドメイン バインド テーブル情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
first-hop-security binding-table
```

show audits tenant interface bridge-domain first-hop-security statistics arp

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security statistics arp

Description: Show Bridge-domain First Hop Security ARP Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
first-hop-security statistics arp
```

show audits tenant interface bridge-domain first-hop-security statistics dhcpv4

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security statistics dhcpv4

Description: Show Bridge-domain First Hop Security DHCPv4 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
first-hop-security statistics dhcpv4
```

show audits tenant interface bridge-domain first-hop-security statistics dhcpv6

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security statistics dhcpv6

Description: Show Bridge-domain First Hop Security DHCPv6 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
first-hop-security statistics dhcpv6
```

show audits tenant interface bridge-domain first-hop-security statistics neighbor-discovery

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security statistics neighbor-discovery

Description: Show Bridge-domain First Hop Security Neighbor Discovery Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
first-hop-security statistics neighbor-discovery
```

show audits tenant multicast-route-maps

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD multicast-route-maps

説明：テナントごとにマルチキャスト ルートマップを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD multicast-route-maps
```

show audits tenant vrf

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD

Description: Show VRF Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD
```

show audits tenant vrf acllog l2

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD acllog <permitDrop> l2 flow vlan <NUMBER> srcintf <srcintf>

Description: L2 flow stats

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
permitDrop	permitDrop
flow	flowi stats
vlan	vlan info
<*vlan*>	<vlan>. Number range from=0 to=9223372036854775807
srcintf	source interface
<*srcintf*>	<srcintf>

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD acllog <permitDrop>
l2 flow vlan <NUMBER> srcintf <srcintf>
```

show audits tenant vrf acllog l3

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD acllog <permitDrop> l3 flow srcpctag <srcpctag> dstpctag <dstpctag> srcepgname <srcepgname> dstepgname <dstepgname> srcip <A.B.C.D or A:B::C:D> dstip <A.B.C.D or A:B::C:D> proto <proto> srcport <srcport> dstport <dstport> srcintf <srcintf>

説明：L3 フロー統計情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
permitDrop	permitDrop
flow	フロー統計
srcpctag	送信元 PC タグ
<*srcpctag*>	<srcpctag>
dstpctag	宛先 PC タグ
<*dstpctag*>	<dstpctag>
srcepgname	送信元 epg 名
<*srcepgname*>	<srcepgname>
dstepgname	宛先 epg 名
<*dstepgname*>	<dstepgname>
srcip	source ip
ABCD または *A:B::C:D*	i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
dstip	宛先 IP
ABCD または *A:B::C:D*	i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
proto	protocol
<*proto*>	<proto>
srcport	送信元ポート

<*srcport*>	<srcport>
dstport	宛先ポート
<*dstport*>	<dstport>
srcintf	送信元インターフェイス
<*srcintf*>	<srcintf>

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD acllog <permitDrop>
l3 flow srcpctag <srcpctag> dstpctag <dstpctag> srcepgname <srcepgname> dstepgname
<dstepgname> srcip <A.B.C.D or A:B::C:D> dstip <A.B.C.D or A:B::C:D> proto <proto> srcport
 <srcport> dstport <dstport> srcintf <srcintf>
```

show audits tenant vrf detail

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD detail

説明：VRF の詳細ビューを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD detail
```

show audits tenant vrf external-l3 bgp

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 bgp

説明：BGP ピアのコマンドを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 bgp
```

show audits tenant vrf external-l3 bgp node

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 bgp node <101-4000>

Description: node to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
<101-4000>	Leaf Range or Leaf Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 bgp node
<101-4000>
```

show audits tenant vrf external-l3 eigrp

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 eigrp

Description: Show external l3 EIGRP

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 eigrp
```

show audits tenant vrf external-l3 eigrp detail

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 eigrp detail

説明：内部の詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 eigrp
detail
```

show audits tenant vrf external-l3 epg

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 epg <epgName>

説明：external-l3 epgs のコマンドを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<epgName>	フィルタする EPG 名

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 epg <epgName>
```

show audits tenant vrf external-l3 epg detail

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 epg <epgName> detail

Description: external-l3 epg in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
<epgName>	Name of the EPG to filter on

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 epg <epgName>
 detail
```

show audits tenant vrf external-l3 interfaces

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 interfaces

説明：テナント <tenant> vrf <vrf> 外部 l3 インターフェイスを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 interfaces
```

show audits tenant vrf external-l3 interfaces detail

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 interfaces detail

説明：インターフェイスの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 interfaces
 detail
```

show audits tenant vrf external-l3 ospf

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 ospf

説明： IPv4 および IPv6 外部 l3 OSPF 構成のコマンドを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 ospf
```

show audits tenant vrf external-l3 ospf detail

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 ospf detail

説明：内部の詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 ospf detail
```

show audits tenant vrf external-l3 scale

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 scale

Description: scale command

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 scale
```

show audits tenant vrf external-l3 scale detail

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 scale detail

Description: Show scale details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 scale
detail
```

show audits tenant vrf external-l3 static-route

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route

Description: Show command for external-l3 static routes

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route
```

show audits tenant vrf external-l3 static-route detail

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route detail

Description: static-route in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route
 detail
```

show audits tenant vrf external-l3 static-route node

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route node

説明：フィルタするノード

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
arg	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route
 node
```

show audits tenant vrf external-l3 static-route node detail

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route node detail

Description: static-route in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
arg	Leaf Range or Leaf Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route
 node detail
```

show audits tenant vrf ipv6multicast

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD ipv6multicast

Description: Show ipv6 multicast configuration per VRF

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD ipv6multicast
```

show audits tenant vrf multicast

show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD multicast

説明：VRF ごとにマルチキャスト構成を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show audits [id <log-id>] [action <action-type>] [user <user-name>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD multicast
```

show bridge-domain

show bridge-domain WORD

説明：ブリッジドメイン情報を表示する

構文：

WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show bridge-domain WORD
```

show bridge-domain detail

show bridge-domain WORD detail

説明：ブリッジ ドメインの詳細情報を表示する

構文：

WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show bridge-domain WORD detail
```

show bridge-domain first-hop-security binding-table

show bridge-domain WORD first-hop-security binding-table

説明：ブリッジドメイン バインド テーブル情報を表示する

構文：

WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show bridge-domain WORD first-hop-security binding-table
```

show bridge-domain first-hop-security statistics arp

show bridge-domain WORD first-hop-security statistics arp

Description: Show Bridge-domain First Hop Security ARP Statistics

Syntax:

WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show bridge-domain WORD first-hop-security statistics arp
```

show bridge-domain first-hop-security statistics dhcpv4

show bridge-domain WORD first-hop-security statistics dhcpv4

説明：ブリッジドメイン ファースト ホップ セキュリティ DHCPv4 統計情報を表示する

構文：

WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show bridge-domain WORD first-hop-security statistics dhcpv4
```

show bridge-domain first-hop-security statistics dhcpv6

show bridge-domain WORD first-hop-security statistics dhcpv6

Description: Show Bridge-domain First Hop Security DHCPv6 Statistics

Syntax:

WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show bridge-domain WORD first-hop-security statistics dhcpv6
```

show bridge-domain first-hop-security statistics neighbor-discovery

show bridge-domain WORD first-hop-security statistics neighbor-discovery

Description: Show Bridge-domain First Hop Security Neighbor Discovery Statistics

Syntax:

WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show bridge-domain WORD first-hop-security statistics neighbor-discovery
```

show callhome

callhome common の表示

説明：callhome のコマンドを表示する

構文：

共通	共通の

コマンド モード exec：Exec モード

コマンド パス：

```
# show callhome common
```

show callhome common destination-profile

show callhome common destination-profile

Description: Show command for callhome destination-profile

Syntax:

common	Common

Command Mode: exec : Exec Mode

Command Path:

```
# show callhome common destination-profile
```

show callhome common query-profile

show callhome common query-profile

説明：callhome destination-profile のコマンドを表示する

構文：

共通	共通の

コマンド モード exec：Exec モード

コマンド パス：

```
# show callhome common query-profile
```

show callhome common transport-email

show callhome common transport-email

説明：callhome transport-email のコマンドを表示する

構文：

共通	共通の

コマンド モード exec：Exec モード

コマンド パス：

```
# show callhome common transport-email
```

show catalog

show catalog

説明： カタログ情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show catalog
```

show cli command

show cli command <WORD> [mode <mode-name>]

説明：コマンドの構文を表示する

構文：

WORD	一重引用符で囲まれたコマンド名パターン
<*mode-name*>	（オプション）一重引用符で囲まれたモード名パターン
details	（オプション）コマンドの詳細を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show cli command <WORD> [mode <mode-name>]
```

show cli list

show cli list [mode <mode-name>]

説明：すべての CLI 関連コマンドを表示する

構文：

<*mode-name*>	（オプション）一重引用符で囲まれたモード名パターン
details	（オプション）コマンドの詳細を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show cli list [mode <mode-name>]
```

show cli manpage

show cli manpage <WORD> [mode <mode-name>]

説明：コマンド ManPage を表示する

構文：

WORD	一重引用符で囲まれたコマンド名パターン
<*mode-name*>	（オプション）一重引用符で囲まれたモード名パターン
details	（オプション）コマンドの詳細を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show cli manpage <WORD> [mode <mode-name>]
```

show cli path

show cli path <WORD> [mode <mode-name>]

説明：コマンドのパスを表示する

構文：

WORD	一重引用符で囲まれたコマンド名パターン
<*mode-name*>	（オプション）一重引用符で囲まれたモード名パターン
details	（オプション）コマンドの詳細を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show cli path <WORD> [mode <mode-name>]
```

show clock

show clock

Description: Show clock information

Command Mode: exec : Exec Mode

Command Path:

```
# show clock
```

show cloudave

show cloudave

説明： クラウド AVE 情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show cloudave
```

show cloudsec summary

show cloudsec summary

説明：cloudsec ポリシーの簡単な概要を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show cloudsec summary
```

show communication ciphers

show communication ciphers

説明：HTTPS サービス暗号スイートのリスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show communication ciphers
```

show communication controller

show communication controller node-id

説明：nginx web-requests のコマンドを表示する

構文：

node-id	node-id

コマンド モード exec：Exec モード

コマンド パス：

```
# show communication controller node-id
```

show communication http

show communication http

Description: HTTP service settings

Command Mode: exec : Exec Mode

Command Path:

```
# show communication http
```

show communication https

show communication https

説明： HTTPS サービス設定

コマンド モード exec：Exec モード

コマンド パス：

```
# show communication https
```

show communication performance

show communication performance

説明：パフォーマンス データのコマンドを表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show communication performance
```

show communication performance config

show communication performance config

Description: Show command for performance configuration

Command Mode: exec : Exec Mode

Command Path:

```
# show communication performance config
```

show communication performance results

show communication performance results

Description: Show command for performance results

Command Mode: exec : Exec Mode

Command Path:

```
# show communication performance results
```

show communication shellinabox

show communication shellinabox

Description: Shellinabox service settings

Command Mode: exec : Exec Mode

Command Path:

```
# show communication shellinabox
```

show communication ssh-service

show communication ssh-service

説明： SSH サービス設定

コマンド モード exec：Exec モード

コマンド パス：

```
# show communication ssh-service
```

show communication telnet

show communication telnet

Description: Telnet service settings

Command Mode: exec : Exec Mode

Command Path:

```
# show communication telnet
```

show communication web-requests

show communication web-requests

説明：最後の Web リクエストのステータス

コマンド モード exec：Exec モード

コマンド パス：

```
# show communication web-requests
```

show contract-type

show contract-type WORD

説明：タイプに基づいてコントラクト情報を表示する

構文：

WORD	ホワイトリスト（許可）またはブラックリスト（拒否）またはコントラクト oob-mgmt タイプ

コマンド モード exec：Exec モード

コマンド パス：

```
# show contract-type WORD
```

show contract

show contract WORD

Description: Show Contracts Information

Syntax:

WORD	Name of the Contract to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show contract WORD
```

show controller

show controller

説明： コントローラ情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show controller
```

show controller detail

show controller detail [id <node-id>]

Description: Detailed controller information

Syntax:

node-id	(Optional) Optional Serial number

Command Mode: exec : Exec Mode

Command Path:

```
# show controller detail [id <node-id>]
```

show cores

show cores

説明： すべてのコア ダンプを表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show cores
```

show cores status

show cores status

Description: Show exported core status

Command Mode: exec : Exec Mode

Command Path:

```
# show cores status
```

show debug counter

show debug <node-name> <process> counter <counterTopics>

Description: Show Counter information

Syntax:

<*node-name*>	Node name
<*process*>	Process name
<*counterTopics*>	Counter Topics

Command Mode: exec : Exec Mode

Command Path:

```
# show debug <node-name> <process> counter <counterTopics>
```

show debug log

show debug <node-name> <process> log

説明：ログ レベル情報を表示する

構文：

<node-name>	ノード名
<process>	プロセス名

コマンド モード exec：Exec モード

コマンド パス：

```
# show debug <node-name> <process> log
```

show deployment endpoint node

show deployment endpoint node <WORD>

説明：ノード id

構文：

WORD	リーフ数（最大サイズ 4000）番号の範囲 0 ～ =9223372036854775807

コマンド モード exec：Exec モード

コマンド パス：

```
# show deployment endpoint node <WORD>
```

show discoveryissues

show discoveryissues

説明： ファブリック検出の問題を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show discoveryissues
```

show discoveryissues node

show discoveryissues node <NUMBER>

Description: Enter node Id

Syntax:

<*node-id*>	Enter node id. Number range from=0 to=9223372036854775807

Command Mode: exec : Exec Mode

Command Path:

```
# show discoveryissues node <NUMBER>
```

show dns-address

show dns-address

Description: Show dns address information

Command Mode: exec : Exec Mode

Command Path:

```
# show dns-address
```

show dns-domain

show dns-domain

説明： dnsドメイン情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show dns-domain
```

show dot1q-tunnel

show dot1q-tunnel WORD

説明：Dot1q-tunnel 情報を表示する

構文：

WORD	フィルタする AEPG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show dot1q-tunnel WORD
```

show dwdm interface

show dwdm interface switch <101-4000>

説明：インターフェイス

構文：

スイッチ	スイッチ
<101-4000>	スイッチ ID

コマンド モード exec：Exec モード

コマンド パス：

```
# show dwdm interface switch <101-4000>
```

show endpoints

show endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>]

説明：IP エンドポイントを表示する

構文：

type	（オプション）エンドポイント タイプ
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）
<1-4094>	（オプション）カプセル化 VLAN。数値の範囲は 1 ～ 4094
A.B.C.D	（オプション）i.i.i.i 形式の IP ユニキャスト アドレス
A:B::C:D	（オプション）xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス

コマンド モード exec：Exec モード

コマンド パス：

```
# show endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE
EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>]
```

show endpoints leaf interface ethernet

show endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface ethernet ethernet [<fex>/]<slot>/<port>

Description: Show IP endpoints on an interface ethernet

Syntax:

type	(Optional) Endpoint Type
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
A.B.C.D	(Optional) IP Unicast address in format i.i.i.i
A:B::C:D	(Optional) IPv6 address in format xxxx:xxxx, xxxx::xx
WORD	Leaf Number (Max Size 4000). Number range from=0 to=9223372036854775807
ethernet [<fex>/]<slot>/<port>	Ethernet Range

Command Mode: exec : Exec Mode

Command Path:

```
# show endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE
EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface
 ethernet ethernet [<fex>/]<slot>/<port>
```

show endpoints leaf interface port-channel

show endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface port-channel <WORD> [fex <NUMBER>]

説明：インターフェイス ポートチャネルで IP エンドポイントを表示する

構文：

type	（オプション）エンドポイント タイプ
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）
<1-4094>	（オプション）カプセル化 VLAN。数値の範囲は 1 ～ 4094
A.B.C.D	（オプション）i.i.i.i 形式の IP ユニキャスト アドレス
A:B::C:D	（オプション）xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
WORD	リーフ数（最大サイズ 4000）番号の範囲 0 ～ =9223372036854775807
WORD	ポート チャネル名（最大サイズ 64）
<101-199>	（オプション）FEX id。=101 ～ =199 までの範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE
EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface
 port-channel <WORD> [fex <NUMBER>]
```

show endpoints vpc

show endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] vpc context <WORD> <WORD> interface vpc <WORD> [fex <fex>]

Description: Show IP endpoints on vpc

Syntax:

type	(Optional) Endpoint Type
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
A.B.C.D	(Optional) IP Unicast address in format i.i.i.i
A:B::C:D	(Optional) IPv6 address in format xxxx:xxxx, xxxx::xx
context	VPC Context
WORD	First VPC leaf (Max Size 4000). Number range from=0 to=9223372036854775807
WORD	Second VPC leaf (Max Size 4000). Number range from=0 to=9223372036854775807
interface	VPC Interface name
vpc	VPC Interface name
WORD	VPC Name (Max Size 64)
fex	(Optional) Fex Id. Number range from=101 to=199

Command Mode: exec : Exec Mode

Command Path:

```
# show endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE
EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] vpc context <WORD>
<WORD> interface vpc <WORD> [fex <fex>]
```

show epg

show epg WORD

説明：アプリケーション EPG 情報を表示する

構文：

WORD	フィルタする AEPG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show epg WORD
```

show epg detail

show epg WORD detail

Description: Show detailed view of Application EPg

Syntax:

WORD	Name of the AEPG to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show epg WORD detail
```

show esg

show esg WORD

説明：エンドポイント セキュリティ グループ情報を表示する

構文：

WORD	フィルタする ESG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show esg WORD
```

show esg detail

show esg WORD detail

Description: Show detailed view of Endpoint Security Group

Syntax:

WORD	Name of the ESG to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show esg WORD detail
```

show events

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] <scope>

説明：イベント情報を表示する

構文：

<event-code>	（オプション）イベント コード
<event-ID>	（オプション）イベント ID
<event-value>	（オプション）原因
last-minutes <num-minutes>	（オプション）イベント アクティビティ（時間間隔）数値の範囲は =1 ～ =59
last-hours <num-hours>	（オプション）イベント アクティビティ（時間間隔）数値の範囲は =1 ～ =23
last-days <num-days>	（オプション）イベント アクティビティ（時間間隔）数値の範囲は =1 ～ =999
start-time <YYYY-MM-DDTHR:MIN:SEC>	（オプション）イベント アクティビティ（時間間隔）
end-time <YYYY-MM-DDTHR:MIN:SEC>	（オプション）イベント アクティビティ（時間間隔）
detail	（任意）イベントの詳細情報。
<scope>	コマンド範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] <scope>
```

show events controller

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] controller

Description: Show controller information

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] controller
```

show events controller detail

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] controller detail [id <node-id>]

Description: Detailed controller information

Syntax:

node-id	(Optional) Optional Serial number

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] controller detail [id <node-id>]
```

show events leaf

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId>

Description: Show command for leaf

Syntax:

<*leafId*>	Leaf id

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId>
```

show events leaf fex

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> fex <fexNum>

説明：拡張シャーシ情報を表示する

構文：

<*leafId*>	リーフ id
<*fexNum*>	FEX 番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> fex <fexNum>
```

show events Leaf fex module

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> fex <fexNum> module <lcSlot>

説明：インベントリ モジュール情報を表示する

構文：

<*leafId*>	リーフ id
<*fexNum*>	FEX 番号を入力してください
<*lcSlot*>	モジュール番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> fex <fexNum> module <lcSlot>
```

show events Leaf interface ethernet

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface ethernet <phyInt>

説明：イーサネット IEEE 802.3z

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface ethernet <phyInt>
```

show events Leaf interface fc

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface fc <phyInt>

説明：ファイバ チャネル プロトコル

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface fc <phyInt>
```

show events leaf interface fcportchannel

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface fcportchannel <portChan>

説明：FC ポート チャネル インターフェイス

構文：

<*leafId*>	リーフ id
<*portChan*>	<Port channel number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface fcportchannel
<portChan>
```

show events leaf interface l3instance

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface l3instance <l3Inst>

Description: L3 instance

Syntax:

<*leafId*>	Leaf id
<*l3Inst*>	<L3 instance number>

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface l3instance <l3Inst>
```

show events leaf interface mgmt

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface mgmt <mgmtPort>

説明：管理インターフェイス

構文：

<*leafId*>	リーフ id
<*mgmtPort*>	<Management interface number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface mgmt <mgmtPort>
```

show events leaf interface portchannel

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface portchannel <portChan>

説明：ポート チャネル インターフェイス

構文：

<*leafId*>	リーフ id
<*portChan*>	<Port channel number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface portchannel <portChan>
```

show events Leaf interface tunnel

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface tunnel <tunnelPort>

説明：トンネル インターフェイス

構文：

<*leafId*>	リーフ id
<*tunnelPort*>	<Tunnel interface number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface tunnel <tunnelPort>
```

show events Leaf interface vethernet

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface vethernet <phyInt>

説明：vethernet ID

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface vethernet <phyInt>
```

show events leaf inventory chassis

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory chassis

説明：インベントリ シャーシ情報を表示する

構文：

<leafId>	リーフ id

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory chassis
```

show events leaf inventory fans

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory fans <ftSlot>

Description: Show inventory fan information

Syntax:

<*leafId*>	Leaf id
<*ftSlot*>	pls enter fan tray number

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory fans <ftSlot>
```

show events leaf inventory module

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory module <lcSlot>

Description: Show inventory module information

Syntax:

<*leafId*>	Leaf id
<*lcSlot*>	please enter the module number

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory module <lcSlot>
```

show events leaf inventory module fabricport

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory module <lcSlot> fabricport <fabPort>

Description: Show information for fabric port

Syntax:

<*leafId*>	Leaf id
<*lcSlot*>	please enter the module number
<*fabPort*>	pls enter the fabric port number

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory module <lcSlot>
fabricport <fabPort>
```

show events leaf inventory module leafport

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory module <lcSlot> leafport <leafPort>

説明：リーフ ポートの情報を表示する

構文：

<*leafId*>	リーフ id
<*lcSlot*>	モジュール番号を入力してください
<*leafPort*>	リーフ ポート番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory module <lcSlot>
leafport <leafPort>
```

show events leaf inventory powersupply

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory powersupply <psuSlot>

Description: Show inventory power supply information

Syntax:

<*leafId*>	Leaf id
<*psuSlot*>	pls enter the powersupply number

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory powersupply <psuSlot>
```

show events leaf inventory supervisor

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory supervisor <supMod>

説明：スーパーバイザ モジュールの情報を表示する

構文：

<*leafId*>	リーフ id
<*supMod*>	スーパーバイザ モジュール番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory supervisor <supMod>
```

show events Leaf protocol

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> protocol <protName>

説明：プロトコルのコマンドを表示する

構文：

<*leafId*>	リーフ id
<*protName*>	プロトコル名

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> protocol <protName>
```

show events Leaf vpc

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> vpc <vpcPort>

説明：仮想ポート チャネル情報

構文：

<*leafId*>	リーフ id
<*vpcPort*>	仮想ポート チャネル番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> vpc <vpcPort>
```

show events leaf vrf

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> vrf <vrfPort>

Description: Vrf information

Syntax:

<*leafId*>	Leaf id
<*vrfPort*>	pls enter vrf name

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> vrf <vrfPort>
```

show events spine

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId>

Description: Show command for spine

Syntax:

<*leafId*>	Leaf id

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId>
```

show events spine interface ethernet

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> interface ethernet <phyInt>

説明：イーサネット IEEE 802.3z

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> interface ethernet <phyInt>
```

show events spine interface l3instance

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> interface l3instance <l3Inst>

Description: L3 instance

Syntax:

<*leafId*>	Leaf id
<*l3Inst*>	<L3 instance number>

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> interface l3instance <l3Inst>
```

show events spine interface mgmt

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> interface mgmt <mgmtPort>

説明：管理インターフェイス

構文：

<*leafId*>	リーフ id
<*mgmtPort*>	<Management interface number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> interface mgmt <mgmtPort>
```

show events spine interface tunnel

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> interface tunnel <tunnelPort>

Description: Tunnel Interface

Syntax:

<*leafId*>	Leaf id
<*tunnelPort*>	<Tunnel interface number>

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> interface tunnel <tunnelPort>
```

show events spine inventory chassis

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory chassis

説明：インベントリ シャーシ情報を表示する

構文：

<leafId>	リーフ id

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory chassis
```

show events spine inventory fabric

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory fabric <fcMod>

説明： ファブリック モジュールの情報を表示する

構文：

<*leafId*>	リーフ id
<*fcMod*>	ファブリック モジュール番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory fabric <fcMod>
```

show events spine inventory fans

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory fans <ftSlot>

説明：インベントリ ファン情報を表示する

構文：

<*leafId*>	リーフ id
<*ftSlot*>	pls enter fan tray number

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory fans <ftSlot>
```

show events spine inventory module

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory module <lcSlot>

説明：インベントリ モジュール情報を表示する

構文：

<*leafId*>	リーフ id
<*lcSlot*>	モジュール番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory module <lcSlot>
```

show events spine inventory module fabricport

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory module <lcSlot> fabricport <fabPort>

説明： ファブリック ポートの情報を表示します。

構文：

<*leafId*>	リーフ id
<*lcSlot*>	モジュール番号を入力してください
<*fabPort*>	pls はファブリックポート番号を入力します

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory module <lcSlot>
fabricport <fabPort>
```

show events spine inventory powersupply

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory powersupply <psuSlot>

説明：インベントリ電源情報を表示する

構文：

<*leafId*>	リーフ id
<*psuSlot*>	電源番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory powersupply <psuSlot>
```

show events spine inventory supervisor

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory supervisor <supMod>

Description: Show information for supervisor module

Syntax:

<*leafId*>	Leaf id
<*supMod*>	pls enter the supervisor module number

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory supervisor <supMod>
```

show events spine inventory system

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory system <sysMod>

説明：システム モジュールの情報を表示する

構文：

<*leafId*>	リーフ id
<*sysMod*>	システム モジュール番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory system <sysMod>
```

show events spine protocol

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> protocol <protName>

説明：プロトコルのコマンドを表示する

構文：

<*leafId*>	リーフ id
<*protName*>	プロトコル名

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> protocol <protName>
```

show events spine vrf

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> vrf <vrfPort>

説明：VRF 情報

構文：

<leafId>	リーフ id
<vrfPort>	VRF 名を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> vrf <vrfPort>
```

show events tenant

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD

説明：テナント情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD
```

show events tenant application

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD

Description: Show Application Profiles Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD
```

show events tenant application epg

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD epg WORD

説明：アプリケーション EPG 情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）
WORD	フィルタする AEPG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD epg WORD
```

show events tenant application esg

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD esg WORD

Description: Show Show Endpoint Security Group Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)
WORD	Name of the ESG to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD esg WORD
```

show events tenant bridge-domain

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD

Description: Show Bridge-domain Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD
```

show events tenant bridge-domain detail

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD detail

説明：ブリッジ ドメインの詳細情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD detail
```

show events tenant bridge-domain first-hop-security binding-table

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security binding-table

Description: Show Bridge-domain Binding Table Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD
first-hop-security binding-table
```

show events tenant bridge-domain first-hop-security statistics arp

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security statistics arp

説明：ブリッジドメイン ファースト ホップ セキュリティ ARP 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD
first-hop-security statistics arp
```

show events tenant bridge-domain first-hop-security statistics dhcpv4

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security statistics dhcpv4

Description: Show Bridge-domain First Hop Security DHCPv4 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD
first-hop-security statistics dhcpv4
```

show events tenant bridge-domain first-hop-security statistics dhcpv6

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security statistics dhcpv6

Description: Show Bridge-domain First Hop Security DHCPv6 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD
first-hop-security statistics dhcpv6
```

show events tenant bridge-domain first-hop-security statistics neighbor-discovery

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security statistics neighbor-discovery

Description: Show Bridge-domain First Hop Security Neighbor Discovery Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD
first-hop-security statistics neighbor-discovery
```

show events tenant dnsservergroup

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD

Description: Show Dns Server Group Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the dns server group we eventually want to filter on (Max Size 16)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD
```

show events tenant dnsservergroup server

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD server WORD

Description: Show Dns Server Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the dns server group we eventually want to filter on (Max Size 16)
WORD	IP of server we eventually want to filter on (Max Size None)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD server WORD
```

show events tenant dnsservergroup server domain

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD server WORD domain WORD

説明：dnsドメイン情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタする DNS サーバ グループの名前（最大サイズ 16）
WORD	最終的にフィルタするサーバの IP
WORD	最終的にフィルタするドメイン（最大サイズ 512）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD server WORD
 domain WORD
```

show events tenant endpoints

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>]

説明：IP エンドポイントを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
type	（オプション）エンドポイント タイプ
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）
<1-4094>	（オプション）カプセル化 VLAN。数値の範囲は 1 ～ 4094
A.B.C.D	（オプション）i.i.i.i 形式の IP ユニキャスト アドレス
A:B::C:D	（オプション）xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD endpoints [type <type>] [mac
<E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>]
 [ipv6 <A:B::C:D>]
```

show events tenant endpoints leaf interface ethernet

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface ethernet ethernet [<fex>/]<slot>/<port>

説明：インターフェイスイーサネット上の IP エンドポイントを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
type	（オプション）エンドポイント タイプ
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）
<1-4094>	（オプション）カプセル化 VLAN。数値の範囲は 1 ～ 4094
A.B.C.D	（オプション）i.i.i.i 形式の IP ユニキャスト アドレス
A:B::C:D	（オプション）xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
WORD	リーフ数（最大サイズ 4000）番号の範囲 0 ～ =9223372036854775807
ethernet [<fex>/]<slot>/<port>	イーサネット範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD endpoints [type <type>] [mac
<E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>]
 [ipv6 <A:B::C:D>] leaf <WORD> interface ethernet ethernet [<fex>/]<slot>/<port>
```

show events tenant endpoints leaf interface port-channel

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface port-channel <WORD> [fex <NUMBER>]

説明：インターフェイス ポートチャネルで IP エンドポイントを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
type	（オプション）エンドポイント タイプ
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）
<1-4094>	（オプション）カプセル化 VLAN。数値の範囲は 1 ～ 4094
A.B.C.D	（オプション）i.i.i.i 形式の IP ユニキャスト アドレス
A:B::C:D	（オプション）xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
WORD	リーフ数（最大サイズ 4000）番号の範囲 0 ～ =9223372036854775807
WORD	ポート チャネル名（最大サイズ 64）
<101-199>	（オプション）FEX id。=101 ～ =199 までの範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD endpoints [type <type>] [mac
<E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>]
 [ipv6 <A:B::C:D>] leaf <WORD> interface port-channel <WORD> [fex <NUMBER>]
```

show events tenant endpoints vpc

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] vpc context <WORD> <WORD> interface vpc <WORD> [fex <fex>]

Description: Show IP endpoints on vpc

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
type	(Optional) Endpoint Type
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
A.B.C.D	(Optional) IP Unicast address in format i.i.i.i
A:B::C:D	(Optional) IPv6 address in format xxxx:xxxx, xxxx::xx
context	VPC Context
WORD	First VPC leaf (Max Size 4000). Number range from=0 to=9223372036854775807
WORD	Second VPC leaf (Max Size 4000). Number range from=0 to=9223372036854775807
interface	VPC Interface name
vpc	VPC Interface name
WORD	VPC Name (Max Size 64)
fex	(Optional) Fex Id. Number range from=101 to=199

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD endpoints [type <type>] [mac
<E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>]
 [ipv6 <A:B::C:D>] vpc context <WORD> <WORD> interface vpc <WORD> [fex <fex>]
```

show events tenant interface bridge-domain

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD

Description: Show Bridge-domain Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
```

show events tenant interface bridge-domain detail

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD detail

説明：ブリッジ ドメインの詳細情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
detail
```

show events tenant interface bridge-domain first-hop-security binding-table

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security binding-table

説明：ブリッジドメイン バインド テーブル情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
first-hop-security binding-table
```

show events tenant interface bridge-domain first-hop-security statistics arp

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security statistics arp

説明：ブリッジドメイン ファースト ホップ セキュリティ ARP 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
first-hop-security statistics arp
```

show events tenant interface bridge-domain first-hop-security statistics dhcpv4

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security statistics dhcpv4

説明：ブリッジドメイン ファースト ホップ セキュリティ DHCPv4 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
first-hop-security statistics dhcpv4
```

show events tenant interface bridge-domain first-hop-security statistics dhcpv6

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security statistics dhcpv6

説明：ブリッジドメイン ファースト ホップ セキュリティ DHCPv6 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
first-hop-security statistics dhcpv6
```

show events tenant interface bridge-domain first-hop-security statistics neighbor-discovery

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security statistics neighbor-discovery

Description: Show Bridge-domain First Hop Security Neighbor Discovery Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD
first-hop-security statistics neighbor-discovery
```

show events tenant multicast-route-maps

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD multicast-route-maps

Description: Show multicast route-maps per Tenant

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD multicast-route-maps
```

show events tenant vrf

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD

説明：VRF 情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD
```

show events tenant vrf acllog l2

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD acllog <permitDrop> l2 flow vlan <NUMBER> srcintf <srcintf>

説明：L2 フロー統計情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
permitDrop	permitDrop
flow	フロー統計
vlan	VLAN の情報
<*vlan*>	<vlan>. 番号の範囲 0 ～ =9223372036854775807
srcintf	送信元インターフェイス
<*srcintf*>	<srcintf>

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD acllog <permitDrop>
l2 flow vlan <NUMBER> srcintf <srcintf>
```

show events tenant vrf acllog l3

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD acllog <permitDrop> l3 flow srcpctag <srcpctag> dstpctag <dstpctag> srcepgname <srcepgname> dstepgname <dstepgname> srcip <A.B.C.D or A:B::C:D> dstip <A.B.C.D or A:B::C:D> proto <proto> srcport <srcport> dstport <dstport> srcintf <srcintf>

Description: L3 flow stats

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
permitDrop	permitDrop
flow	flow stats
srcpctag	source pc tag
<*srcpctag*>	<srcpctag>
dstpctag	destination pc tag
<*dstpctag*>	<dstpctag>
srcepgname	source epg name
<*srcepgname*>	<srcepgname>
dstepgname	destination epg name
<*dstepgname*>	<dstepgname>
srcip	source ip
A.B.C.D or A:B::C:D	IP address in format i.i.i.i or IPv6 address in format xxxx:xxxx, xxxx::xx
dstip	destination ip
A.B.C.D or A:B::C:D	IP address in format i.i.i.i or IPv6 address in format xxxx:xxxx, xxxx::xx
proto	protocol
<*proto*>	<proto>
srcport	source port
<*srcport*>	<srcport>

dstport	destination port
<*dstport*>	<dstport>
srcintf	source interface
<*srcintf*>	<srcintf>

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD acllog <permitDrop>
l3 flow srcpctag <srcpctag> dstpctag <dstpctag> srcepgname <srcepgname> dstepgname
<dstepgname> srcip <A.B.C.D or A:B::C:D> dstip <A.B.C.D or A:B::C:D> proto <proto> srcport
 <srcport> dstport <dstport> srcintf <srcintf>
```

show events tenant vrf detail

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD detail

Description: Show detailed view of VRF

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD detail
```

show events tenant vrf external-l3 bgp

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 bgp

説明：BGP ピアのコマンドを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 bgp
```

show events tenant vrf external-l3 bgp node

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 bgp node <101-4000>

Description: node to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
<101-4000>	Leaf Range or Leaf Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 bgp node
<101-4000>
```

show events tenant vrf external-l3 eigrp

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 eigrp

Description: Show external l3 EIGRP

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 eigrp
```

show events tenant vrf external-l3 eigrp detail

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 eigrp detail

Description: Show interanl details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 eigrp
detail
```

show events tenant vrf external-l3 epg

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 epg <epgName>

説明：external-l3 epgs のコマンドを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<*epgName*>	フィルタする EPG 名

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 epg <epgName>
```

show events tenant vrf external-l3 epg detail

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 epg <epgName> detail

説明：external-l3 epg の詳細と動作ステータス

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<epgName>	フィルタする EPG 名

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 epg <epgName>
 detail
```

show events tenant vrf external-l3 interfaces

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 interfaces

Description: Show tenant <tenant> vrf <vrf> external l3 interfaces

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 interfaces
```

show events tenant vrf external-l3 interfaces detail

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 interfaces detail

説明：インターフェイスの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 interfaces
 detail
```

show events tenant vrf external-l3 ospf

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 ospf

Description: Show command for IPv4 and IPv6 external l3 OSPF configuration

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 ospf
```

show events tenant vrf external-l3 ospf detail

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 ospf detail

説明：内部の詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 ospf detail
```

show events tenant vrf external-l3 route-map

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 route-map [name <l3out name>]

Description: Show command for external-l3 route-map

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
<l3out name>	(Optional) Name of the route-map to filter on

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 route-map
 [name <l3out name>]
```

show events tenant vrf external-l3 route-map detail

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 route-map [name <l3out name>] detail

説明：動作ステータスを記載した external-l3 ルートマップを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<l3out name>	（オプション）フィルタするルートマップの名前

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 route-map
 [name <l3out name>] detail
```

show events tenant vrf external-l3 scale

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 scale

説明：スケール コマンド

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 scale
```

show events tenant vrf external-l3 scale detail

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 scale detail

Description: Show scale details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 scale
detail
```

show events tenant vrf external-l3 static-route

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route

Description: Show command for external-l3 static routes

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route
```

show events tenant vrf external-l3 static-route detail

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route detail

説明：スタティックルートの詳細と動作ステータス

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route
 detail
```

show events tenant vrf external-l3 static-route node

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route node

説明：フィルタするノード

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
arg	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route
 node
```

show events tenant vrf external-l3 static-route node detail

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route node detail

説明：スタティックルートの詳細と動作ステータス

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
arg	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route
 node detail
```

show events tenant vrf ipv6multicast

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD ipv6multicast

説明：VRF ごとに ipv6 マルチキャスト構成を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD ipv6multicast
```

show events tenant vrf multicast

show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD multicast

説明：VRF ごとにマルチキャスト構成を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show events [code <event-code>] [id <event-ID>] [cause <event-value>] [last-minutes
<NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD multicast
```

show external-l2 epg

show external-l2 epg

説明：external-l2 epgs のコマンドを表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l2 epg
```

show external-l2 epg name

show external-l2 epg name WORD

Description: EPG name to filter on

Syntax:

WORD	Name of the EPG to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l2 epg name WORD
```

show external-l2 epg tenant

show external-l2 epg tenant WORD

Description: tenant to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l2 epg tenant WORD
```

show external-l3 bgp

show external-l3 bgp

説明：BGP ピアのコマンドを表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 bgp
```

show external-l3 bgp tenant

show external-l3 bgp tenant <WORD>

説明：フィルタするテナント

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 bgp tenant <WORD>
```

show external-l3 bgp tenant vrf

show external-l3 bgp tenant <WORD> vrf WORD

Description: vrf to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 bgp tenant <WORD> vrf WORD
```

show external-l3 bgp tenant vrf node

show external-l3 bgp tenant <WORD> vrf WORD node <101-4000>

説明：フィルタするノード

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<101-4000>	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 bgp tenant <WORD> vrf WORD node <101-4000>
```

show external-l3 eigrp

show external-l3 eigrp

説明：external-l3 eigrp のコマンドを表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 eigrp
```

show external-l3 eigrp detail

show external-l3 eigrp detail

説明：内部の詳細を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 eigrp detail
```

show external-l3 eigrp node

show external-l3 eigrp node <101-4000>

Description: Node(s) to filter on

Syntax:

<101-4000>	Node Range or Node Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 eigrp node <101-4000>
```

show external-l3 eigrp node detail

show external-l3 eigrp node <101-4000> detail

Description: Show interanl details

Syntax:

<101-4000>	Node Range or Node Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 eigrp node <101-4000> detail
```

show external-l3 eigrp tenant

show external-l3 eigrp tenant <WORD>

Description: Tenant(s) to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 eigrp tenant <WORD>
```

show external-l3 eigrp tenant detail

show external-l3 eigrp tenant <WORD> detail

Description: Show interanl details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 eigrp tenant <WORD> detail
```

show external-l3 eigrp tenant vrf

show external-l3 eigrp tenant <WORD> vrf WORD

Description: Vrf(s) to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF(s) to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 eigrp tenant <WORD> vrf WORD
```

show external-l3 eigrp tenant vrf detail

show external-l3 eigrp tenant <WORD> vrf WORD detail

Description: Show interanl details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF(s) to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 eigrp tenant <WORD> vrf WORD detail
```

show external-l3 eigrp tenant vrf node

show external-l3 eigrp tenant <WORD> vrf WORD node <101-4000>

説明： フィルタリングするノード

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<101-4000>	ノード名リストのノード範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 eigrp tenant <WORD> vrf WORD node <101-4000>
```

show external-l3 eigrp tenant vrf node detail

show external-l3 eigrp tenant <WORD> vrf WORD node <101-4000> detail

Description: Show interanl details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF(s) to filter on (Max Size 64)
<101-4000>	Node Range or Node Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 eigrp tenant <WORD> vrf WORD node <101-4000> detail
```

show external-l3 epg

show external-l3 epg

Description: Show command for external-l3 epgs

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 epg
```

show external-l3 epg detail

show external-l3 epg detail

説明：external-l3 epg の詳細と動作ステータス

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 epg detail
```

show external-l3 epg name

show external-l3 epg name <epgName>

Description: EPG name to filter on

Syntax:

<*epgName*>	Name of the EPG to filter on

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 epg name <epgName>
```

show external-l3 epg name detail

show external-l3 epg name <epgName> detail

Description: external-l3 epg in detail with operational status

Syntax:

<*epgName*>	Name of the EPG to filter on

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 epg name <epgName> detail
```

show external-l3 epg tenant

show external-l3 epg tenant <WORD>

Description: tenant to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 epg tenant <WORD>
```

show external-l3 epg tenant detail

show external-l3 epg tenant <WORD> detail

Description: external-l3 epg in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 epg tenant <WORD> detail
```

show external-l3 epg tenant vrf

show external-l3 epg tenant <WORD> vrf WORD

Description: vrf to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 epg tenant <WORD> vrf WORD
```

show external-l3 epg tenant vrf detail

show external-l3 epg tenant <WORD> vrf WORD detail

Description: external-l3 epg in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 epg tenant <WORD> vrf WORD detail
```

show external-l3 interfaces

show external-l3 interfaces

Description: Show command for external-l3 interfaces

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 interfaces
```

show external-l3 interfaces detail

show external-l3 interfaces detail

説明：インターフェイスの詳細を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 interfaces detail
```

show external-l3 interfaces node

show external-l3 interfaces node <101-4000>

説明： フィルタリングするノード

構文：

<101-4000>	ノード名リストのノード範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 interfaces node <101-4000>
```

show external-l3 interfaces node detail

show external-l3 interfaces node <101-4000> detail

説明：インターフェイスの詳細を表示する

構文：

<101-4000>	ノード名リストのノード範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 interfaces node <101-4000> detail
```

show external-l3 interfaces tenant

show external-l3 interfaces tenant <WORD>

説明：フィルタするテナント

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 interfaces tenant <WORD>
```

show external-l3 interfaces tenant detail

show external-l3 interfaces tenant <WORD> detail

説明：インターフェイスの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 interfaces tenant <WORD> detail
```

show external-l3 interfaces tenant vrf

show external-l3 interfaces tenant <WORD> vrf WORD

Description: Vrf(s) to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF(s) to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 interfaces tenant <WORD> vrf WORD
```

show external-l3 interfaces tenant vrf detail

show external-l3 interfaces tenant <WORD> vrf WORD detail

説明：インターフェイスの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 interfaces tenant <WORD> vrf WORD detail
```

show external-l3 interfaces tenant vrf node

show external-l3 interfaces tenant <WORD> vrf WORD node <101-4000>

Description: Node(s) to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF(s) to filter on (Max Size 64)
<101-4000>	Node Range or Node Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 interfaces tenant <WORD> vrf WORD node <101-4000>
```

show external-l3 interfaces tenant vrf node detail

show external-l3 interfaces tenant <WORD> vrf WORD node <101-4000> detail

説明：インターフェイスの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<101-4000>	ノード名リストのノード範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 interfaces tenant <WORD> vrf WORD node <101-4000> detail
```

show external-l3 ospf

show external-l3 ospf

Description: Show command for external-l3 ospf

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 ospf
```

show external-l3 ospf detail

show external-l3 ospf detail

Description: Show internal details

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 ospf detail
```

show external-l3 ospf node

show external-l3 ospf node <101-4000>

説明： フィルタリングするノード

構文：

<101-4000>	ノード名リストのノード範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 ospf node <101-4000>
```

show external-l3 ospf node detail

show external-l3 ospf node <101-4000> detail

説明：内部の詳細を表示する

構文：

<101-4000>	ノード名リストのノード範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 ospf node <101-4000> detail
```

show external-l3 ospf tenant

show external-l3 ospf tenant <WORD>

Description: Tenant(s) to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 ospf tenant <WORD>
```

show external-l3 ospf tenant detail

show external-l3 ospf tenant <WORD> detail

説明：内部の詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 ospf tenant <WORD> detail
```

show external-l3 ospf tenant vrf

show external-l3 ospf tenant <WORD> vrf WORD

説明：フィルタする Vrf

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 ospf tenant <WORD> vrf WORD
```

show external-l3 ospf tenant vrf detail

show external-l3 ospf tenant <WORD> vrf WORD detail

Description: Show internal details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF(s) to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 ospf tenant <WORD> vrf WORD detail
```

show external-l3 ospf tenant vrf node

show external-l3 ospf tenant <WORD> vrf WORD node <101-4000>

説明： フィルタリングするノード

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<101-4000>	ノード名リストのノード範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 ospf tenant <WORD> vrf WORD node <101-4000>
```

show external-l3 ospf tenant vrf node detail

show external-l3 ospf tenant <WORD> vrf WORD node <101-4000> detail

説明：内部の詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<101-4000>	ノード名リストのノード範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 ospf tenant <WORD> vrf WORD node <101-4000> detail
```

show external-l3 route-map

show external-l3 route-map

説明：external-l3 route-map のコマンドの表示

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 route-map
```

show external-l3 route-map detail

show external-l3 route-map detail

説明：動作ステータスを記載した詳細のルートマップ

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 route-map detail
```

show external-l3 route-map name

show external-l3 route-map name <l3out name>

説明：フィルタするルートマップ名

構文：

<l3out name>	フィルタするルートマップの名前

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 route-map name <l3out name>
```

show external-l3 route-map name detail

show external-l3 route-map name <l3out name> detail

説明：動作ステータスを記載した詳細のルートマップ

構文：

<l3out name>	フィルタするルートマップの名前

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 route-map name <l3out name> detail
```

show external-l3 route-map tenant

show external-l3 route-map tenant <WORD>

Description: tenant to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 route-map tenant <WORD>
```

show external-l3 route-map tenant detail

show external-l3 route-map tenant <WORD> detail

説明：動作ステータスを記載した詳細のルートマップ

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 route-map tenant <WORD> detail
```

show external-l3 route-map tenant vrf

show external-l3 route-map tenant <WORD> vrf WORD

Description: vrf to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 route-map tenant <WORD> vrf WORD
```

show external-l3 route-map tenant vrf detail

show external-l3 route-map tenant <WORD> vrf WORD detail

説明：動作ステータスを記載した詳細のルートマップ

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 route-map tenant <WORD> vrf WORD detail
```

show external-l3 route-map tenant vrf node

show external-l3 route-map tenant <WORD> vrf WORD node

Description: node to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
arg	Leaf Range or Leaf Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 route-map tenant <WORD> vrf WORD node
```

show external-l3 route-map tenant vrf node detail

show external-l3 route-map tenant <WORD> vrf WORD node detail

説明：動作ステータスを記載した詳細のルートマップ

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
arg	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 route-map tenant <WORD> vrf WORD node detail
```

show external-l3 scale

show external-l3 scale

Description: Show command for external-l3 scale

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 scale
```

show external-l3 scale detail

show external-l3 scale detail

説明：スケールの詳細を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 scale detail
```

show external-l3 scale node

show external-l3 scale node <101-4000>

説明： フィルタリングするノード

構文：

<101-4000>	ノード名リストのノード範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 scale node <101-4000>
```

show external-l3 scale node detail

show external-l3 scale node <101-4000> detail

説明：スケールの詳細を表示する

構文：

<101-4000>	ノード名リストのノード範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 scale node <101-4000> detail
```

show external-l3 scale tenant

show external-l3 scale tenant <WORD>

説明：フィルタするテナント

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 scale tenant <WORD>
```

show external-l3 scale tenant detail

show external-l3 scale tenant <WORD> detail

説明：スケールの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 scale tenant <WORD> detail
```

show external-l3 scale tenant vrf

show external-l3 scale tenant <WORD> vrf WORD

Description: Vrf(s) to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF(s) to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 scale tenant <WORD> vrf WORD
```

show external-l3 scale tenant vrf detail

show external-l3 scale tenant <WORD> vrf WORD detail

Description: Show scale details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF(s) to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 scale tenant <WORD> vrf WORD detail
```

show external-l3 scale tenant vrf node

show external-l3 scale tenant <WORD> vrf WORD node <101-4000>

説明： フィルタリングするノード

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<101-4000>	ノード名リストのノード範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 scale tenant <WORD> vrf WORD node <101-4000>
```

show external-l3 scale tenant vrf node detail

show external-l3 scale tenant <WORD> vrf WORD node <101-4000> detail

説明：スケールの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<101-4000>	ノード名リストのノード範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 scale tenant <WORD> vrf WORD node <101-4000> detail
```

show external-l3 static-route

show external-l3 static-route

Description: Show command for external-l3 static routes

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 static-route
```

show external-l3 static-route detail

show external-l3 static-route detail

説明：スタティックルートの詳細と動作ステータス

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 static-route detail
```

show external-l3 static-route node

show external-l3 static-route node

Description: node to filter on

Syntax:

arg	Leaf Range or Leaf Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 static-route node
```

show external-l3 static-route node detail

show external-l3 static-route node detail

説明：スタティックルートの詳細と動作ステータス

構文：

arg	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 static-route node detail
```

show external-l3 static-route tenant

show external-l3 static-route tenant <WORD>

Description: tenant to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 static-route tenant <WORD>
```

show external-l3 static-route tenant detail

show external-l3 static-route tenant <WORD> detail

説明：スタティックルートの詳細と動作ステータス

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 static-route tenant <WORD> detail
```

show external-l3 static-route tenant vrf

show external-l3 static-route tenant <WORD> vrf WORD

説明：フィルタする VRF

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 static-route tenant <WORD> vrf WORD
```

show external-l3 static-route tenant vrf detail

show external-l3 static-route tenant <WORD> vrf WORD detail

説明：スタティックルートの詳細と動作ステータス

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 static-route tenant <WORD> vrf WORD detail
```

show external-l3 static-route tenant vrf node

show external-l3 static-route tenant <WORD> vrf WORD node

説明：フィルタするノード

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
arg	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show external-l3 static-route tenant <WORD> vrf WORD node
```

show external-l3 static-route tenant vrf node detail

show external-l3 static-route tenant <WORD> vrf WORD node detail

Description: static-route in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
arg	Leaf Range or Leaf Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show external-l3 static-route tenant <WORD> vrf WORD node detail
```

show fabric-discovery-health

show fabric-discovery-health

Description: Show health of fabric discovery

Command Mode: exec : Exec Mode

Command Path:

```
# show fabric-discovery-health
```

show fabric-recovery checker

show fabric-recovery checker moDn [detail]

Description: To show the recovery checker status

Syntax:

moDn	Optional Dn
detail	(Optional) detail

Command Mode: exec : Exec Mode

Command Path:

```
# show fabric-recovery checker moDn [detail]
```

show fabric-recovery status

show fabric-recovery status

Description: Show fabric recovery status

Command Mode: exec : Exec Mode

Command Path:

```
# show fabric-recovery status
```

show faults

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes/no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] <scope>

説明：障害情報を表示する

構文：

history	（オプション）履歴情報
<*fault-code*>	（オプション）障害コード
<*fault-ID*>	（オプション）障害 ID
<*yes/no*>	（オプション）確認応答ステータス
<*lc-state*>	（オプション）ライフサイクル ステータス
<*severity-value*>	（オプション）重大度
<*severity-value*>	（オプション）最小の重大度
<*fault-type*>	（オプション）タイプ
<*fault-value*>	（オプション）原因
last-minutes <*num-minutes*>	（オプション）障害のアクティビティ（時間間隔）数値の範囲は =1 ～ =59
last-hours <*num-hours*>	（任意）時間間隔の障害アクティビティ。数値の範囲は=1 ～ =23
last-days <*num-days*>	（オプション）時間間隔の障害アクティビティ。数値の範囲は =1 ～ =999
start-time <*YYYY-MM-DDTHR:MIN:SEC*>	（オプション）時間間隔の障害アクティビティ
end-time <*YYYY-MM-DDTHR:MIN:SEC*>	（オプション）時間間隔の障害アクティビティ
detail	（オプション）障害の詳細情報
<*scope*>	コマンド範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes/no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time end-time <YYYY-MM-DDTHR:MIN:SEC>]
 [detail] <scope>
```

show faults controller

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] controller

説明： コントローラ情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] controller
```

show faults controller detail

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] controller detail [id <node-id>]

説明：コントローラの詳細情報

構文：

node-id	（任意）オプションのシリアル番号

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] controller
 detail [id <node-id>]
```

show faults l4l7-cluster

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] l4l7-cluster [tenant <Tenant Name>] [cluster <Device Cluster Name>]

説明：L4 L7 デバイス情報を表示する

構文：

テナント名	（オプション）テナント名
デバイス クラスタ名	（オプション）デバイスの名前

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail]
l4l7-cluster [tenant <Tenant Name>] [cluster <Device Cluster Name>]
```

show faults l4l7-graph

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] l4l7-graph [tenant <Tenant Name>] [graph <Graph Name>]

Description: Show L4 L7 Graph information

Syntax:

<*Tenant Name*>	(Optional) Name of Tenant
<*Graph Name*>	(Optional) Name of Graph

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] l4l7-graph
 [tenant <Tenant Name>] [graph <Graph Name>]
```

show faults leaf

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId>

説明：リーフのコマンドを表示する

構文：

<*leafId*>	リーフ id

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId>
```

show faults leaf fex

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> fex <fexNum>

Description: Show extended chassis information

Syntax:

<*leafId*>	Leaf id
<*fexNum*>	pls enter fex number

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> fex <fexNum>
```

show faults leaf fex module

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> fex <fexNum> module <lcSlot>

Description: Show inventory module information

Syntax:

<*leafId*>	Leaf id
<*fexNum*>	pls enter fex number
<*lcSlot*>	please enter the module number

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> fex <fexNum> module <lcSlot>
```

show faults leaf interface ethernet

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface ethernet <phyInt>

説明：イーサネット IEEE 802.3z

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> interface ethernet <phyInt>
```

show faults leaf interface fc

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface fc <phyInt>

説明：ファイバ チャネル プロトコル

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> interface fc <phyInt>
```

show faults leaf interface fcportchannel

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface fcportchannel <portChan>

説明：FC ポート チャネル インターフェイス

構文：

<*leafId*>	リーフ id
<*portChan*>	<Port channel number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> interface fcportchannel <portChan>
```

show faults leaf interface l3instance

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface l3instance <l3Inst>

説明：L3 インスタンス

構文：

<*leafId*>	リーフ id
<*l3Inst*>	<L3 instance number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> interface l3instance <l3Inst>
```

show faults leaf interface mgmt

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface mgmt <mgmtPort>

説明：管理インターフェイス

構文：

<*leafId*>	リーフ id
<*mgmtPort*>	<Management interface number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> interface mgmt <mgmtPort>
```

show faults leaf interface portchannel

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface portchannel <portChan>

説明：ポート チャネル インターフェイス

構文：

<*leafId*>	リーフ id
<*portChan*>	<Port channel number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> interface portchannel <portChan>
```

show faults leaf interface tunnel

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface tunnel <tunnelPort>

説明：トンネル インターフェイス

構文：

<*leafId*>	リーフ id
<*tunnelPort*>	<Tunnel interface number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> interface tunnel <tunnelPort>
```

show faults leaf interface vethernet

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> interface vethernet <phyInt>

Description: vethernet ID

Syntax:

<*leafId*>	Leaf id
<*phyInt*>	<slot or chassis-number/port or slot number>

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> interface vethernet <phyInt>
```

show faults leaf inventory chassis

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory chassis

説明：インベントリ シャーシ情報を表示する

構文：

<*leafId*>	リーフ id

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> inventory chassis
```

show faults leaf inventory fans

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory fans <ftSlot>

説明：インベントリ ファン情報を表示する

構文：

<*leafId*>	リーフ id
<*ftSlot*>	pls enter fan tray number

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> inventory fans <ftSlot>
```

show faults leaf inventory module

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory module <lcSlot>

説明：インベントリ モジュール情報を表示する

構文：

<*leafId*>	リーフ id
<*lcSlot*>	モジュール番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> inventory module <lcSlot>
```

show faults leaf inventory module fabricport

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory module <lcSlot> fabricport <fabPort>

説明： ファブリック ポートの情報を表示します。

構文：

<*leafId*>	リーフ id
<*lcSlot*>	モジュール番号を入力してください
<*fabPort*>	pls はファブリックポート番号を入力します

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> inventory module <lcSlot> fabricport <fabPort>
```

show faults leaf inventory module leafport

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory module <lcSlot> leafport <leafPort>

説明：リーフ ポートの情報を表示する

構文：

<*leafId*>	リーフ id
<*lcSlot*>	モジュール番号を入力してください
<*leafPort*>	リーフ ポート番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> inventory module <lcSlot> leafport <leafPort>
```

show faults leaf inventory powersupply

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory powersupply <psuSlot>

説明：インベントリ電源情報を表示する

構文：

<*leafId*>	リーフ id
<*psuSlot*>	電源番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> inventory powersupply <psuSlot>
```

show faults leaf inventory supervisor

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> inventory supervisor <supMod>

Description: Show information for supervisor module

Syntax:

<*leafId*>	Leaf id
<*supMod*>	pls enter the supervisor module number

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> inventory supervisor <supMod>
```

show faults leaf protocol

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> protocol <protName>

Description: Show command for protocol

Syntax:

<*leafId*>	Leaf id
<*protName*>	Protocol name

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> protocol <protName>
```

show faults leaf vpc

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> vpc <vpcPort>

説明：仮想ポート チャネル情報

構文：

<*leafId*>	リーフ id
<*vpcPort*>	仮想ポート チャネル番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> vpc <vpcPort>
```

show faults leaf vrf

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId> vrf <vrfPort>

Description: Vrf information

Syntax:

<leafId>	Leaf id
<vrfPort>	pls enter vrf name

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf
<leafId> vrf <vrfPort>
```

show faults microsoft domain

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft domain

説明：Microsoft ドメイン情報の表示

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft
 domain
```

show faults microsoft domain name

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft domain name <WORD>

Description: Microsoft domain name

Syntax:

WORD	Microsoft domain name

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft
 domain name <WORD>
```

show faults microsoft domain name hyperv

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft domain name <WORD> hyperv <WORD>

Description: Show Microsoft Hypervisor information

Syntax:

WORD	Microsoft domain name
WORD	HyperV hostname

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft
 domain name <WORD> hyperv <WORD>
```

show faults microsoft domain name port-group

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft domain name <WORD> port-group

Description: Show Microsoft port group information

Syntax:

WORD	Microsoft domain name

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft
 domain name <WORD> port-group
```

show faults microsoft domain name scvmm

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft domain name <WORD> scvmm <hostname|ip>

説明：Microsoft SCVMM 情報を表示する

構文：

WORD	Microsoft ドメイン名
<*hostname*|*ip*>	SCVMM ホスト名または IP

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft
 domain name <WORD> scvmm <hostname|ip>
```

show faults microsoft domain name vm

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft domain name <WORD> vm

説明：Microsoft VM 情報を表示する

構文：

WORD	Microsoft ドメイン名

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft
 domain name <WORD> vm
```

show faults microsoft domain name vm name

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft domain name <WORD> vm name <WORD>

説明：Microsoft VM の詳細情報を表示する

構文：

WORD	Microsoft ドメイン名
WORD	VM 名

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] microsoft
 domain name <WORD> vm name <WORD>
```

show faults quota

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] quota

Description: Show Quotas Information

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] quota
```

show faults redhat domain

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] redhat domain

Description: Show Redhat domain information

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] redhat
 domain
```

show faults redhat domain name

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] redhat domain name <name>

説明：Redhat ドメイン名

構文：

<*name*>	Redhat ドメイン名

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] redhat
 domain name <name>
```

show faults redhat domain name epg

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] redhat domain name <name> epg

説明：Redhat ドメイン EPG の詳細を表示する

構文：

<*name*>	Redhat ドメイン名

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] redhat
 domain name <name> epg
```

show faults redhat domain name rhev

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] redhat domain name <name> rhev <hostname|ip>

Description: RHEV ip or hostname

Syntax:

<*name*>	Redhat domain name
<*hostname*|*ip*>	rhev hostname or IP

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] redhat
 domain name <name> rhev <hostname|ip>
```

show faults spine

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId>

Description: Show command for spine

Syntax:

<leafId>	Leaf id

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId>
```

show faults spine interface ethernet

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> interface ethernet <phyInt>

説明：イーサネット IEEE 802.3z

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> interface ethernet <phyInt>
```

show faults spine interface l3instance

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> interface l3instance <l3Inst>

Description: L3 instance

Syntax:

<*leafId*>	Leaf id
<*l3Inst*>	<L3 instance number>

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> interface l3instance <l3Inst>
```

show faults spine interface mgmt

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> interface mgmt <mgmtPort>

Description: Management interface

Syntax:

<*leafId*>	Leaf id
<*mgmtPort*>	<Management interface number>

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> interface mgmt <mgmtPort>
```

show faults spine interface tunnel

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> interface tunnel <tunnelPort>

Description: Tunnel Interface

Syntax:

<*leafId*>	Leaf id
<*tunnelPort*>	<Tunnel interface number>

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> interface tunnel <tunnelPort>
```

show faults spine inventory chassis

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory chassis

説明：インベントリ シャーシ情報を表示する

構文：

<*leafId*>	リーフ id

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> inventory chassis
```

show faults spine inventory fabric

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory fabric <fcMod>

説明： ファブリック モジュールの情報を表示する

構文：

<*leafId*>	リーフ id
<*fcMod*>	ファブリック モジュール番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> inventory fabric <fcMod>
```

show faults spine inventory fans

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory fans <ftSlot>

Description: Show inventory fan information

Syntax:

<*leafId*>	Leaf id
<*ftSlot*>	pls enter fan tray number

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> inventory fans <ftSlot>
```

show faults spine inventory module

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory module <lcSlot>

Description: Show inventory module information

Syntax:

<*leafId*>	Leaf id
<*lcSlot*>	please enter the module number

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> inventory module <lcSlot>
```

show faults spine inventory module fabricport

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory module <lcSlot> fabricport <fabPort>

説明： ファブリック ポートの情報を表示します。

構文：

<*leafId*>	リーフ id
<*lcSlot*>	モジュール番号を入力してください
<*fabPort*>	pls はファブリックポート番号を入力します

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> inventory module <lcSlot> fabricport <fabPort>
```

show faults spine inventory powersupply

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory powersupply <psuSlot>

説明：インベントリ電源情報を表示する

構文：

<*leafId*>	リーフ id
<*psuSlot*>	電源番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> inventory powersupply <psuSlot>
```

show faults spine inventory supervisor

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory supervisor <supMod>

説明：スーパーバイザ モジュールの情報を表示する

構文：

<*leafId*>	リーフ id
<*supMod*>	スーパーバイザ モジュール番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> inventory supervisor <supMod>
```

show faults spine inventory system

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> inventory system <sysMod>

Description: Show information for system module

Syntax:

<*leafId*>	Leaf id
<*sysMod*>	pls enter the system module number

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> inventory system <sysMod>
```

show faults spine protocol

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> protocol <protName>

Description: Show command for protocol

Syntax:

<*leafId*>	Leaf id
<*protName*>	Protocol name

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> protocol <protName>
```

show faults spine vrf

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId> vrf <vrfPort>

説明：VRF 情報

構文：

<*leafId*>	リーフ id
<*vrfPort*>	VRF 名を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine
<leafId> vrf <vrfPort>
```

show faults tenant

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD

説明：テナント情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD
```

show faults tenant アプリケーション

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD

説明：アプリケーション プロファイル情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD application WORD
```

show faults tenant application epg

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD epg WORD

説明：アプリケーション EPG 情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）
WORD	フィルタする AEPG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD application WORD epg WORD
```

show faults tenant application esg

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD application WORD esg WORD

説明：エンドポイント セキュリティ グループ情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）
WORD	フィルタする ESG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD application WORD esg WORD
```

show faults tenant bridge-domain

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD

Description: Show Bridge-domain Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD bridge-domain WORD
```

show faults tenant bridge-domain detail

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD detail

Description: Show Bridge-domain Detailed Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD bridge-domain WORD detail
```

show faults tenant bridge-domain first-hop-security binding-table

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security binding-table

Description: Show Bridge-domain Binding Table Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD bridge-domain WORD first-hop-security binding-table
```

show faults tenant bridge-domain first-hop-security statistics arp

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security statistics arp

説明：ブリッジドメイン ファースト ホップ セキュリティ ARP 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD bridge-domain WORD first-hop-security statistics arp
```

show faults tenant bridge-domain first-hop-security statistics dhcpv4

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security statistics dhcpv4

説明：ブリッジドメイン ファースト ホップ セキュリティ DHCPv4 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD bridge-domain WORD first-hop-security statistics dhcpv4
```

show faults tenant bridge-domain first-hop-security statistics dhcpv6

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security statistics dhcpv6

Description: Show Bridge-domain First Hop Security DHCPv6 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD bridge-domain WORD first-hop-security statistics dhcpv6
```

show faults tenant bridge-domain first-hop-security statistics neighbor-discovery

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD bridge-domain WORD first-hop-security statistics neighbor-discovery

説明：ブリッジドメイン ファースト ホップ セキュリティ ネイバー探索統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD bridge-domain WORD first-hop-security statistics neighbor-discovery
```

show faults tenant dnsservergroup

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD

Description: Show Dns Server Group Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the dns server group we eventually want to filter on (Max Size 16)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD dnsservergroup WORD
```

show faults tenant dnsservergroup server

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD server WORD

Description: Show Dns Server Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the dns server group we eventually want to filter on (Max Size 16)
WORD	IP of server we eventually want to filter on (Max Size None)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD dnsservergroup WORD server WORD
```

show faults tenant dnsservergroup server domain

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD dnsservergroup WORD server WORD domain WORD

説明：dnsドメイン情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタする DNS サーバ グループの名前（最大サイズ 16）
WORD	最終的にフィルタするサーバの IP
WORD	最終的にフィルタするドメイン（最大サイズ 512）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD dnsservergroup WORD server WORD domain WORD
```

show faults tenant interface bridge-domain

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD

Description: Show Bridge-domain Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD interface bridge-domain WORD
```

show faults tenant interface bridge-domain detail

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD detail

説明：ブリッジ ドメインの詳細情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD interface bridge-domain WORD detail
```

show faults tenant interface bridge-domain first-hop-security binding-table

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security binding-table

説明：ブリッジドメイン バインド テーブル情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD interface bridge-domain WORD first-hop-security binding-table
```

show faults tenant interface bridge-domain first-hop-security statistics arp

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security statistics arp

説明：ブリッジドメイン ファースト ホップ セキュリティ ARP 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD interface bridge-domain WORD first-hop-security statistics arp
```

show faults tenant interface bridge-domain first-hop-security statistics dhcpv4

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security statistics dhcpv4

Description: Show Bridge-domain First Hop Security DHCPv4 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD interface bridge-domain WORD first-hop-security statistics dhcpv4
```

show faults tenant interface bridge-domain first-hop-security statistics dhcpv6

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security statistics dhcpv6

Description: Show Bridge-domain First Hop Security DHCPv6 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD interface bridge-domain WORD first-hop-security statistics dhcpv6
```

show faults tenant interface bridge-domain first-hop-security statistics neighbor-discovery

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD interface bridge-domain WORD first-hop-security statistics neighbor-discovery

説明：ブリッジドメイン ファースト ホップ セキュリティ ネイバー探索統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD interface bridge-domain WORD first-hop-security statistics neighbor-discovery
```

show faults tenant multicast-route-maps

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD multicast-route-maps

説明：テナントごとにマルチキャスト ルートマップを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD multicast-route-maps
```

show faults tenant vrf

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD

Description: Show VRF Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD
```

show faults tenant vrf acllog l2

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD acllog <permitDrop> l2 flow vlan <NUMBER> srcintf <srcintf>

説明：L2 フロー統計情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
permitDrop	permitDrop
flow	フロー統計
vlan	VLAN の情報
<*vlan*>	<vlan>. 番号の範囲 0 ～ =9223372036854775807
srcintf	送信元インターフェイス
<*srcintf*>	<srcintf>

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD acllog <permitDrop> l2 flow vlan <NUMBER> srcintf <srcintf>
```

show faults tenant vrf acllog l3

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD acllog <permitDrop> l3 flow srcpctag <srcpctag> dstpctag <dstpctag> srcepgname <srcepgname> dstepgname <dstepgname> srcip <A.B.C.D or A:B::C:D> dstip <A.B.C.D or A:B::C:D> proto <proto> srcport <srcport> dstport <dstport> srcintf <srcintf>

説明：L3 フロー統計情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
permitDrop	permitDrop
flow	フロー統計
srcpctag	送信元 PC タグ
<*srcpctag*>	<srcpctag>
dstpctag	宛先 PC タグ
<*dstpctag*>	<dstpctag>
srcepgname	送信元 epg 名
<*srcepgname*>	<srcepgname>
dstepgname	宛先 epg 名
<*dstepgname*>	<dstepgname>
srcip	source ip
ABCD または *A:B::C:D*	i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
dstip	宛先 IP
ABCD または *A:B::C:D*	i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
proto	protocol
<*proto*>	<proto>

srcport	送信元ポート
<*srcport*>	<srcport>
dstport	宛先ポート
<*dstport*>	<dstport>
srcintf	送信元インターフェイス
<*srcintf*>	<srcintf>

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD acllog <permitDrop> l3 flow srcpctag <srcpctag> dstpctag <dstpctag>
srcepgname <srcepgname> dstepgname <dstepgname> srcip <A.B.C.D or A:B::C:D> dstip <A.B.C.D
 or A:B::C:D> proto <proto> srcport <srcport> dstport <dstport> srcintf <srcintf>
```

show faults tenant vrf detail

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD detail

Description: Show detailed view of VRF

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD detail
```

show faults tenant vrf external-l3 bgp

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 bgp

Description: Show command for BGP peers

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 bgp
```

show faults tenant vrf external-l3 bgp node

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 bgp node <101-4000>

説明：フィルタするノード

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<101-4000>	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 bgp node <101-4000>
```

show faults tenant vrf external-l3 eigrp

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 eigrp

Description: Show external l3 EIGRP

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 eigrp
```

show faults tenant vrf external-l3 eigrp detail

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 eigrp detail

Description: Show interanl details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 eigrp detail
```

show faults tenant vrf external-l3 epg

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 epg <epgName>

説明：external-l3 epgs のコマンドを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<*epgName*>	フィルタする EPG 名

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 epg <epgName>
```

show faults tenant vrf external-l3 epg detail

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 epg <epgName> detail

Description: external-l3 epg in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
<*epgName*>	Name of the EPG to filter on

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 epg <epgName> detail
```

show faults tenant vrf external-l3 interfaces

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 interfaces

説明：テナント <tenant> vrf <vrf> 外部 l3 インターフェイスを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 interfaces
```

show faults tenant vrf external-l3 interfaces detail

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 interfaces detail

説明：インターフェイスの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 interfaces detail
```

show faults tenant vrf external-l3 ospf

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 ospf

説明： IPv4 および IPv6 外部 l3 OSPF 構成のコマンドを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 ospf
```

show faults tenant vrf external-l3 ospf detail

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 ospf detail

Description: Show internal details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 ospf detail
```

show faults tenant vrf external-l3 scale

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 scale

Description: scale command

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 scale
```

show faults tenant vrf external-l3 scale detail

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 scale detail

説明：スケールの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 scale detail
```

show faults tenant vrf external-l3 static-route

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route

Description: Show command for external-l3 static routes

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 static-route
```

show faults tenant vrf external-l3 static-route detail

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route detail

Description: static-route in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 static-route detail
```

show faults tenant vrf external-l3 static-route node

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route node

Description: node to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
arg	Leaf Range or Leaf Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 static-route node
```

show faults tenant vrf external-l3 static-route node detail

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD external-l3 static-route node detail

説明：スタティックルートの詳細と動作ステータス

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
arg	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD external-l3 static-route node detail
```

show faults tenant vrf ipv6multicast

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD ipv6multicast

説明：VRF ごとに ipv6 マルチキャスト構成を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD ipv6multicast
```

show faults tenant vrf multicast

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant WORD vrf WORD multicast

説明：VRF ごとにマルチキャスト構成を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] tenant
 WORD vrf WORD multicast
```

show faults vmware domain

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware domain

説明： VMware ドメイン情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware
 domain
```

show faults vmware domain name

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware domain name <name>

Description: VMware domain name

Syntax:

<*name*>	VMware domain name

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware
 domain name <name>
```

show faults vmware domain name epg

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware domain name <name> epg

説明：VMware ドメイン EPG の詳細を表示する

構文：

<*name*>	VMware ドメイン名

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware
 domain name <name> epg
```

show faults vmware domain name esx

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware domain name <name> esx <esx-ip>

Description: Show VMware ESX information

Syntax:

<*name*>	VMware domain name
<*esx-ip*>	ESX IP

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware
 domain name <name> esx <esx-ip>
```

show faults vmware domain name port-group

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware domain name <name> port-group

Description: Show VMware port group information

Syntax:

<name>	VMware domain name

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware
 domain name <name> port-group
```

show faults vmware domain name trunk-portgroup

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware domain name <name> trunk-portgroup [name <name>]

説明：VMware ドメイン トランク ポートグループの詳細を表示する

構文：

<*name*>	VMware ドメイン名
<*name*>	（オプション）トランク ポートグループ名

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware
 domain name <name> trunk-portgroup [name <name>]
```

show faults vmware domain name vcenter

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware domain name <name> vcenter <hostname|ip>

説明：VMware vCenter ip またはホスト名

構文：

<*name*>	VMware ドメイン名
<*hostname*|*ip*>	vCenter ホスト名または IP

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware
 domain name <name> vcenter <hostname|ip>
```

show faults vmware domain name vm

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware domain name <name> vm

Description: Show VMware VM information

Syntax:

<*name*>	VMware domain name

Command Mode: exec : Exec Mode

Command Path:

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware
 domain name <name> vm
```

show faults vmware domain name vm name

show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>] [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware domain name <name> vm name <vm-name>

説明：詳細な VMware VM 情報を表示する

構文：

<*name*>	VMware ドメイン名
<*vm-name*>	VM 名

コマンド モード exec：Exec モード

コマンド パス：

```
# show faults [history] [code <fault-code>] [id <fault-ID>] [ack <yes|no>] [lc <lc-state>]
 [severity <severity-value>] [min-severity <severity-value>] [type <fault-type>] [cause
 <fault-value>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>]
[start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] vmware
 domain name <name> vm name <vm-name>
```

show fips

show fips

説明： FIPS 情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show fips
```

show fips status

show fips status

Description: Show FIPS status

Command Mode: exec : Exec Mode

Command Path:

```
# show fips status
```

show firmware compat matrix

show firmware compat matrix <WORD>

Description: compatibility matrix for desired version

Syntax:

WORD	Desired Controller Version

Command Mode: exec : Exec Mode

Command Path:

```
# show firmware compat matrix <WORD>
```

show firmware repository

show firmware repository

説明：リポジトリに存在するファームウェア イメージを表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show firmware repository
```

show firmware repository detail

show firmware repository detail

説明： 詳細なリポジトリ

コマンド モード exec：Exec モード

コマンド パス：

```
# show firmware repository detail
```

show firmware upgrade scheduler-status

show firmware upgrade scheduler-status

説明： スケジューラのステータス情報

コマンド モード exec：Exec モード

コマンド パス：

```
# show firmware upgrade scheduler-status
```

show firmware upgrade scheduler-status switch-group

show firmware upgrade scheduler-status switch-group <WORD>

説明：目的のスイッチ グループのスケジューラ ステータス

構文：

WORD	目的のスイッチ グループのスケジューラ ステータス

コマンド モード exec：Exec モード

コマンド パス：

```
# show firmware upgrade scheduler-status switch-group <WORD>
```

show firmware upgrade status

show firmware upgrade status

Description: Upgrade status of all controllers and switches

Command Mode: exec : Exec Mode

Command Path:

```
# show firmware upgrade status
```

show firmware upgrade status controller-group

show firmware upgrade status controller-group

Description: Controller-group upgrade status

Command Mode: exec : Exec Mode

Command Path:

```
# show firmware upgrade status controller-group
```

show firmware upgrade status controller-group detail

show firmware upgrade status controller-group detail

説明： 詳細なアップグレード ステータス

コマンド モード exec：Exec モード

コマンド パス：

```
# show firmware upgrade status controller-group detail
```

show firmware upgrade status detail

show firmware upgrade status detail

Description: Detailed upgrade status information

Command Mode: exec : Exec Mode

Command Path:

```
# show firmware upgrade status detail
```

show firmware upgrade status standby-apic

show firmware upgrade status standby-apic

Description: standby-apic upgrade status

Command Mode: exec : Exec Mode

Command Path:

```
# show firmware upgrade status standby-apic
```

show firmware upgrade status standby-apic detail

show firmware upgrade status standby-apic detail

説明：詳細な standby-apic アップグレード ステータス

コマンド モード exec：Exec モード

コマンド パス：

```
# show firmware upgrade status standby-apic detail
```

show firmware upgrade status switch-group

show firmware upgrade status switch-group <WORD>

説明：スイッチグループのアップグレード ステータス

構文：

WORD	スイッチグループ名（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show firmware upgrade status switch-group <WORD>
```

show firmware upgrade status switch-group detail

show firmware upgrade status switch-group <WORD> detail

Description: Detailed upgrade status

Syntax:

WORD	switch-group name (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show firmware upgrade status switch-group <WORD> detail
```

show flow exporter

show flow exporter

説明： NetFlow エクスポータ情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show flow exporter
```

show flow exporter infra

show flow exporter infra WORD [detail]

Description: Show flow exporter infra information

Syntax:

WORD	Exporter Name
detail	(Optional) detail

Command Mode: exec : Exec Mode

Command Path:

```
# show flow exporter infra WORD [detail]
```

show flow exporter tenant

show flow exporter tenant <WORD> WORD [detail]

説明：フロー エクスポータのテナント情報を表示する

構文：

WORD	オプションのテナント名
WORD	[エクスポータ名（Exporter Name）]
detail	（オプション）詳細

コマンド モード exec：Exec モード

コマンド パス：

```
# show flow exporter tenant <WORD> WORD [detail]
```

show flow monitor

show flow monitor

Description: Show Netflow Monitor Information

Command Mode: exec : Exec Mode

Command Path:

```
# show flow monitor
```

show flow monitor infra

show flow monitor infra WORD [detail]

Description: Show Netflow Monitor Information for infra

Syntax:

WORD	Optional Monitor Name
detail	(Optional) detail

Command Mode: exec : Exec Mode

Command Path:

```
# show flow monitor infra WORD [detail]
```

show flow monitor tenant

show flow monitor tenant <WORD> WORD [detail]

Description: Show Netflow Monitor Information for the specified tenant

Syntax:

WORD	Specify tenant name
WORD	Optional Monitor Name
detail	(Optional) detail

Command Mode: exec : Exec Mode

Command Path:

```
# show flow monitor tenant <WORD> WORD [detail]
```

show flow node-policy

show flow node-policy [name <WORD>]

Description: Show Netflow Node Policy Information

Syntax:

WORD	(Optional) Optional Node Policy Name

Command Mode: exec : Exec Mode

Command Path:

```
# show flow node-policy [name <WORD>]
```

show flow node-policy detail

show flow node-policy [name <WORD>] detail

説明：NetFlow ノード ポリシーの詳細情報を表示する

構文：

WORD	（オプション）オプションのノード ポリシー名

コマンド モード exec：Exec モード

コマンド パス：

```
# show flow node-policy [name <WORD>] detail
```

show flow record

show flow record

Description: Show Netflow record information

Command Mode: exec : Exec Mode

Command Path:

```
# show flow record
```

show flow record infra

show flow record infra WORD [detail]

説明：フロー レコード インフラ情報を表示する

構文：

WORD	レコード名
detail	（オプション）詳細

コマンド モード exec：Exec モード

コマンド パス：

```
# show flow record infra WORD [detail]
```

show flow record tenant

show flow record tenant [record-name <recordName>] <tenantName> WORD [detail]

Description: Show flow record tenant information

Syntax:

recordName	(Optional) Optional record name
tenantName	Optional tenant name
WORD	Record Name
detail	(Optional) detail

Command Mode: exec : Exec Mode

Command Path:

```
# show flow record tenant [record-name <recordName>] <tenantName> WORD [detail]
```

show flow vm-exporter

show flow vm-exporter WORD

説明：VM ネットワーキングの NetFlow エクスポータ情報を表示する

構文：

WORD	NetFlow エクスポータ名

コマンド モード exec：Exec モード

コマンド パス：

```
# show flow vm-exporter WORD
```

show health

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time end-time <YYYY-MM-DDTHR:MIN:SEC>] <scope>

Description: Show health score information

Syntax:

history	(Optional) Historical information
min-change <percentage change>	(Optional) Minimum change in health score percentage. Number range from=-100 to=9999
max-hs <maximum health-score>	(Optional) Maximum health score. Number range from=0 to=100
start-time <YYYY-MM-DDTHR:MIN:SEC>	(Optional) Health activity in time interval
end-time <YYYY-MM-DDTHR:MIN:SEC>	(Optional) Health activity in time interval
<scope>	command scope

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time end-time <YYYY-MM-DDTHR:MIN:SEC>] <scope>
```

show health leaf

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId>

説明：リーフのコマンドを表示する

構文：

<*leafId*>	リーフ id

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId>
```

show health leaf fex

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> fex <fexNum>

Description: Show extended chassis information

Syntax:

<*leafId*>	Leaf id
<*fexNum*>	pls enter fex number

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> fex <fexNum>
```

show health leaf fex module

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> fex <fexNum> module <lcSlot>

説明：インベントリ モジュール情報を表示する

構文：

<*leafId*>	リーフ id
<*fexNum*>	FEX 番号を入力してください
<*lcSlot*>	モジュール番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> fex <fexNum>
module <lcSlot>
```

show health leaf interface ethernet

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface ethernet <phyInt>

Description: Ethernet IEEE 802.3z

Syntax:

<*leafId*>	Leaf id
<*phyInt*>	<slot or chassis-number/port or slot number>

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface
ethernet <phyInt>
```

show health leaf interface fc

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface fc <phyInt>

説明：ファイバ チャネル プロトコル

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface fc
<phyInt>
```

show health leaf interface fcportchannel

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface fcportchannel <portChan>

説明：FC ポート チャネル インターフェイス

構文：

<*leafId*>	リーフ id
<*portChan*>	<Port channel number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface
fcportchannel <portChan>
```

show health leaf interface l3instance

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface l3instance <l3Inst>

説明：L3 インスタンス

構文：

<*leafId*>	リーフ id
<*l3Inst*>	<L3 instance number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface
l3instance <l3Inst>
```

show health leaf interface mgmt

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface mgmt <mgmtPort>

説明：管理インターフェイス

構文：

<*leafId*>	リーフ id
<*mgmtPort*>	<Management interface number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface mgmt
 <mgmtPort>
```

show health leaf interface portchannel

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface portchannel <portChan>

Description: Port channel interface

Syntax:

<*leafId*>	Leaf id
<*portChan*>	<Port channel number>

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface
portchannel <portChan>
```

show health leaf interface tunnel

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface tunnel <tunnelPort>

Description: Tunnel Interface

Syntax:

<*leafId*>	Leaf id
<*tunnelPort*>	<Tunnel interface number>

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface
tunnel <tunnelPort>
```

show health leaf interface vethernet

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface vethernet <phyInt>

説明：vethernet ID

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> interface
vethernet <phyInt>
```

show health leaf inventory chassis

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory chassis

説明：インベントリ シャーシ情報を表示する

構文：

<leafId>	リーフ id

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory
chassis
```

show health leaf inventory fans

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory fans <ftSlot>

Description: Show inventory fan information

Syntax:

<*leafId*>	Leaf id
<*ftSlot*>	pls enter fan tray number

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory fans
 <ftSlot>
```

show health leaf inventory module

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory module <lcSlot>

Description: Show inventory module information

Syntax:

<*leafId*>	Leaf id
<*lcSlot*>	please enter the module number

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory
module <lcSlot>
```

show health leaf inventory module fabricport

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory module <lcSlot> fabricport <fabPort>

Description: Show information for fabric port

Syntax:

<*leafId*>	Leaf id
<*lcSlot*>	please enter the module number
<*fabPort*>	pls enter the fabric port number

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory
module <lcSlot> fabricport <fabPort>
```

show health Leaf inventory module leafport

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory module <lcSlot> leafport <leafPort>

説明：リーフ ポートの情報を表示する

構文：

<*leafId*>	リーフ id
<*lcSlot*>	モジュール番号を入力してください
<*leafPort*>	リーフ ポート番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory
module <lcSlot> leafport <leafPort>
```

show health leaf inventory powersupply

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory powersupply <psuSlot>

Description: Show inventory power supply information

Syntax:

<*leafId*>	Leaf id
<*psuSlot*>	pls enter the powersupply number

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory
powersupply <psuSlot>
```

show health leaf inventory supervisor

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory supervisor <supMod>

Description: Show information for supervisor module

Syntax:

<*leafId*>	Leaf id
<*supMod*>	pls enter the supervisor module number

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> inventory
supervisor <supMod>
```

show health leaf protocol

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> protocol <protName>

Description: Show command for protocol

Syntax:

<*leafId*>	Leaf id
<*protName*>	Protocol name

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> protocol
<protName>
```

show health leaf vpc

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> vpc <vpcPort>

説明：仮想ポート チャネル情報

構文：

<*leafId*>	リーフ id
<*vpcPort*>	仮想ポート チャネル番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> vpc <vpcPort>
```

show health leaf vrf

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> vrf <vrfPort>

説明：VRF 情報

構文：

<*leafId*>	リーフ id
<*vrfPort*>	VRF 名を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] leaf <leafId> vrf <vrfPort>
```

show health spine

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId>

Description: Show command for spine

Syntax:

<*leafId*>	Leaf id

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId>
```

show health spine interface ethernet

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> interface ethernet <phyInt>

Description: Ethernet IEEE 802.3z

Syntax:

<*leafId*>	Leaf id
<*phyInt*>	<slot or chassis-number/port or slot number>

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> interface
ethernet <phyInt>
```

show healthpine interface l3instance

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> interface l3instance <l3Inst>

説明：L3 インスタンス

構文：

<*leafId*>	リーフ id
<*l3Inst*>	<L3 instance number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> interface
l3instance <l3Inst>
```

show health spine interface mgmt

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> interface mgmt <mgmtPort>

Description: Management interface

Syntax:

<*leafId*>	Leaf id
<*mgmtPort*>	<Management interface number>

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> interface
mgmt <mgmtPort>
```

show health spine interface tunnel

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> interface tunnel <tunnelPort>

Description: Tunnel Interface

Syntax:

<*leafId*>	Leaf id
<*tunnelPort*>	<Tunnel interface number>

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> interface
tunnel <tunnelPort>
```

show health spine inventory chassis

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory chassis

説明：インベントリ シャーシ情報を表示する

構文：

<*leafId*>	リーフ id

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory
chassis
```

show health spine inventory fabric

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory fabric <fcMod>

Description: Show information for fabric module

Syntax:

<*leafId*>	Leaf id
<*fcMod*>	pls enter the fabric module number

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory
fabric <fcMod>
```

show health spine inventory fans

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory fans <ftSlot>

Description: Show inventory fan information

Syntax:

<*leafId*>	Leaf id
<*ftSlot*>	pls enter fan tray number

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory
fans <ftSlot>
```

show health spine inventory module

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory module <lcSlot>

Description: Show inventory module information

Syntax:

<*leafId*>	Leaf id
<*lcSlot*>	please enter the module number

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory
module <lcSlot>
```

show health spine inventory module fabricport

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory module <lcSlot> fabricport <fabPort>

説明： ファブリック ポートの情報を表示します。

構文：

<*leafId*>	リーフ id
<*lcSlot*>	モジュール番号を入力してください
<*fabPort*>	pls はファブリックポート番号を入力します

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory
module <lcSlot> fabricport <fabPort>
```

show health spine inventory powersupply

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory powersupply <psuSlot>

説明：インベントリ電源情報を表示する

構文：

<*leafId*>	リーフ id
<*psuSlot*>	電源番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory
powersupply <psuSlot>
```

show health spine inventory supervisor

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory supervisor <supMod>

説明：スーパーバイザ モジュールの情報を表示する

構文：

<*leafId*>	リーフ id
<*supMod*>	スーパーバイザ モジュール番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory
supervisor <supMod>
```

show health spine inventory system

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory system <sysMod>

Description: Show information for system module

Syntax:

<*leafId*>	Leaf id
<*sysMod*>	pls enter the system module number

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> inventory
system <sysMod>
```

show health spine protocol

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> protocol <protName>

説明：プロトコルのコマンドを表示する

構文：

<*leafId*>	リーフ id
<*protName*>	プロトコル名

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> protocol
<protName>
```

show health spine vrf

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> vrf <vrfPort>

Description: Vrf information

Syntax:

<*leafId*>	Leaf id
<*vrfPort*>	pls enter vrf name

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] spine <leafId> vrf <vrfPort>
```

show health tenant

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD

説明：テナント情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD
```

show health tenant application

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD application WORD

Description: Show Application Profiles Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD application WORD
```

show health tenant application epg

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD application WORD epg WORD

説明：アプリケーション EPG 情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）
WORD	フィルタする AEPG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD application WORD
 epg WORD
```

show health tenant application esg

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD application WORD esg WORD

説明：エンドポイント セキュリティ グループ情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）
WORD	フィルタする ESG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD application WORD
 esg WORD
```

show health tenant bridge-domain

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain WORD

Description: Show Bridge-domain Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain
WORD
```

show health tenant bridge-domain detail

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain WORD detail

説明：ブリッジ ドメインの詳細情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain
WORD detail
```

show health tenant bridge-domain first-hop-security binding-table

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain WORD first-hop-security binding-table

説明：ブリッジドメイン バインド テーブル情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain
WORD first-hop-security binding-table
```

show health tenant bridge-domain first-hop-security statistics arp

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain WORD first-hop-security statistics arp

説明：ブリッジドメイン ファースト ホップ セキュリティ ARP 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain
WORD first-hop-security statistics arp
```

show health tenant bridge-domain first-hop-security statistics dhcpv4

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain WORD first-hop-security statistics dhcpv4

Description: Show Bridge-domain First Hop Security DHCPv4 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain
WORD first-hop-security statistics dhcpv4
```

show health tenant bridge-domain first-hop-security statistics dhcpv6

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain WORD first-hop-security statistics dhcpv6

説明：ブリッジドメイン ファースト ホップ セキュリティ DHCPv6 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain
WORD first-hop-security statistics dhcpv6
```

show health tenant bridge-domain first-hop-security statistics neighbor-discovery

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain WORD first-hop-security statistics neighbor-discovery

説明：ブリッジドメイン ファースト ホップ セキュリティ ネイバー探索統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD bridge-domain
WORD first-hop-security statistics neighbor-discovery
```

show health tenant dnsservergroup

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD dnsservergroup WORD

説明：DNS サーバ グループ情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタする DNS サーバ グループの名前（最大サイズ 16）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD dnsservergroup
WORD
```

show health tenant dnsservergroup server

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD dnsservergroup WORD server WORD

Description: Show Dns Server Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the dns server group we eventually want to filter on (Max Size 16)
WORD	IP of server we eventually want to filter on (Max Size None)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD dnsservergroup
WORD server WORD
```

show health tenant dnsservergroup server domain

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD dnsservergroup WORD server WORD domain WORD

Description: Show Dns Domain Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the dns server group we eventually want to filter on (Max Size 16)
WORD	IP of server we eventually want to filter on (Max Size None)
WORD	Domain we eventually want to filter on (Max Size 512)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD dnsservergroup
WORD server WORD domain WORD
```

show health tenant interface bridge-domain

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface bridge-domain WORD

説明：ブリッジドメイン情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface
bridge-domain WORD
```

show health tenant interface bridge-domain detail

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface bridge-domain WORD detail

Description: Show Bridge-domain Detailed Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface
bridge-domain WORD detail
```

show health tenant interface bridge-domain first-hop-security binding-table

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface bridge-domain WORD first-hop-security binding-table

説明：ブリッジドメイン バインド テーブル情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface
bridge-domain WORD first-hop-security binding-table
```

show health tenant interface bridge-domain first-hop-security statistics arp

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface bridge-domain WORD first-hop-security statistics arp

Description: Show Bridge-domain First Hop Security ARP Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface
bridge-domain WORD first-hop-security statistics arp
```

show health tenant interface bridge-domain first-hop-security statistics dhcpv4

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface bridge-domain WORD first-hop-security statistics dhcpv4

説明：ブリッジドメイン ファースト ホップ セキュリティ DHCPv4 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface
bridge-domain WORD first-hop-security statistics dhcpv4
```

show health tenant interface bridge-domain first-hop-security statistics dhcpv6

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface bridge-domain WORD first-hop-security statistics dhcpv6

説明：ブリッジドメイン ファースト ホップ セキュリティ DHCPv6 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface
bridge-domain WORD first-hop-security statistics dhcpv6
```

show health tenant interface bridge-domain first-hop-security statistics neighbor-discovery

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface bridge-domain WORD first-hop-security statistics neighbor-discovery

Description: Show Bridge-domain First Hop Security Neighbor Discovery Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD interface
bridge-domain WORD first-hop-security statistics neighbor-discovery
```

show health tenant multicast-route-maps

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD multicast-route-maps

説明：テナントごとにマルチキャスト ルートマップを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD
multicast-route-maps
```

show health tenant vrf

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD

説明：VRF 情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
```

show health tenant vrf acllog l2

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD acllog <permitDrop> l2 flow vlan <NUMBER> srcintf <srcintf>

Description: L2 flow stats

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
permitDrop	permitDrop
flow	flowi stats
vlan	vlan info
<*vlan*>	<vlan>. Number range from=0 to=9223372036854775807
srcintf	source interface
<*srcintf*>	<srcintf>

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD acllog
 <permitDrop> l2 flow vlan <NUMBER> srcintf <srcintf>
```

show health tenant vrf acllog l3

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD acllog <permitDrop> l3 flow srcpctag <srcpctag> dstpctag <dstpctag> srcepgname <srcepgname> dstepgname <dstepgname> srcip <A.B.C.D or A:B::C:D> dstip <A.B.C.D or A:B::C:D> proto <proto> srcport <srcport> dstport <dstport> srcintf <srcintf>

Description: L3 flow stats

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
permitDrop	permitDrop
flow	flow stats
srcpctag	source pc tag
<*srcpctag*>	<srcpctag>
dstpctag	destination pc tag
<*dstpctag*>	<dstpctag>
srcepgname	source epg name
<*srcepgname*>	<srcepgname>
dstepgname	destination epg name
<*dstepgname*>	<dstepgname>
srcip	source ip
A.B.C.D or A:B::C:D	IP address in format i.i.i.i or IPv6 address in format xxxx:xxxx, xxxx::xx
dstip	destination ip
A.B.C.D or A:B::C:D	IP address in format i.i.i.i or IPv6 address in format xxxx:xxxx, xxxx::xx
proto	protocol
<*proto*>	<proto>
srcport	source port
<*srcport*>	<srcport>

dstport	destination port
<*dstport*>	<dstport>
srcintf	source interface
<*srcintf*>	<srcintf>

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD acllog
 <permitDrop> l3 flow srcpctag <srcpctag> dstpctag <dstpctag> srcepgname <srcepgname>
dstepgname <dstepgname> srcip <A.B.C.D or A:B::C:D> dstip <A.B.C.D or A:B::C:D> proto
<proto> srcport <srcport> dstport <dstport> srcintf <srcintf>
```

show health tenant vrf detail

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD detail

説明：VRF の詳細ビューを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD detail
```

show health tenant vrf external-l3 bgp

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 bgp

説明：BGP ピアのコマンドを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 bgp
```

show health tenant vrf external-l3 bgp node

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 bgp node <101-4000>

Description: node to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
<101-4000>	Leaf Range or Leaf Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 bgp node <101-4000>
```

show health tenant vrf external-l3 eigrp

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 eigrp

Description: Show external l3 EIGRP

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 eigrp
```

show health tenant vrf external-l3 eigrp detail

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 eigrp detail

説明：内部の詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 eigrp detail
```

show health tenant vrf external-l3 epg

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 epg <epgName>

説明：external-l3 epgs のコマンドを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<epgName>	フィルタする EPG 名

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 epg <epgName>
```

show health tenant vrf external-l3 epg detail

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 epg <epgName> detail

Description: external-l3 epg in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
<epgName>	Name of the EPG to filter on

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 epg <epgName> detail
```

show health tenant vrf external-l3 interfaces

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 interfaces

説明：テナント <tenant> vrf <vrf> 外部 l3 インターフェイスを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 interfaces
```

show health tenant vrf external-l3 interfaces detail

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 interfaces detail

説明：インターフェイスの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 interfaces detail
```

show health tenant vrf external-l3 ospf

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 ospf

Description: Show command for IPv4 and IPv6 external l3 OSPF configuration

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 ospf
```

show health tenant vrf external-l3 ospf detail

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 ospf detail

Description: Show internal details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 ospf detail
```

show health tenant vrf external-l3 scale

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 scale

説明：スケール コマンド

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 scale
```

show health tenant vrf external-l3 scale detail

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 scale detail

説明：スケールの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 scale detail
```

show health tenant vrf external-l3 static-route

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 static-route

説明：external-l3 スタティック ルートのコマンドの表示

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 static-route
```

show health tenant vrf external-l3 static-route detail

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 static-route detail

Description: static-route in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 static-route detail
```

show health tenant vrf external-l3 static-route node

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 static-route node

説明：フィルタするノード

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
arg	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 static-route node
```

show health tenant vrf external-l3 static-route node detail

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD external-l3 static-route node detail

説明：スタティックルートの詳細と動作ステータス

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
arg	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
external-l3 static-route node detail
```

show health tenant vrf ipv6multicast

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD ipv6multicast

Description: Show ipv6 multicast configuration per VRF

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD
ipv6multicast
```

show health tenant vrf multicast

show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD multicast

Description: Show multicast configuration per VRF

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show health [history] [min-change <NUMBER>] [max-hs <NUMBER>] [start-time
<YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] tenant WORD vrf WORD multicast
```

show inband-mgmt

show inband-mgmt

説明：すべてのノードでインバンド管理 epgs を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show inband-mgmt
```

show inband-mgmt controller

show inband-mgmt controller <controller-id> [epg <WORD>]

Description: show inband mgmt epgs on the controller

Syntax:

<controller-id>	
WORD	(Optional) Epg Name of conusmer epg

Command Mode: exec : Exec Mode

Command Path:

```
# show inband-mgmt controller <controller-id> [epg <WORD>]
```

show inband-mgmt switch

show inband-mgmt switch <switch-id> [epg <WORD>]

Description: Show inband mgmt epgs on the node

Syntax:

<switch-id>	
WORD	(Optional) Epg Name

Command Mode: exec : Exec Mode

Command Path:

```
# show inband-mgmt switch <switch-id> [epg <WORD>]
```

show interface bridge-domain

show interface bridge-domain WORD

Description: Show Bridge-domain Information

Syntax:

WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show interface bridge-domain WORD
```

show interface bridge-domain detail

show interface bridge-domain WORD detail

説明：ブリッジ ドメインの詳細情報を表示する

構文：

WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show interface bridge-domain WORD detail
```

show interface bridge-domain first-hop-security binding-table

show interface bridge-domain WORD first-hop-security binding-table

説明：ブリッジドメイン バインド テーブル情報を表示する

構文：

WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show interface bridge-domain WORD first-hop-security binding-table
```

show interface bridge-domain first-hop-security statistics arp

show interface bridge-domain WORD first-hop-security statistics arp

Description: Show Bridge-domain First Hop Security ARP Statistics

Syntax:

WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show interface bridge-domain WORD first-hop-security statistics arp
```

show interface bridge-domain first-hop-security statistics dhcpv4

show interface bridge-domain WORD first-hop-security statistics dhcpv4

Description: Show Bridge-domain First Hop Security DHCPv4 Statistics

Syntax:

WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show interface bridge-domain WORD first-hop-security statistics dhcpv4
```

show interface bridge-domain first-hop-security statistics dhcpv6

show interface bridge-domain WORD first-hop-security statistics dhcpv6

Description: Show Bridge-domain First Hop Security DHCPv6 Statistics

Syntax:

WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show interface bridge-domain WORD first-hop-security statistics dhcpv6
```

show interface bridge-domain first-hop-security statistics neighbor-discovery

show interface bridge-domain WORD first-hop-security statistics neighbor-discovery

説明：ブリッジドメイン ファースト ホップ セキュリティ ネイバー探索統計情報を表示する

構文：

WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show interface bridge-domain WORD first-hop-security statistics neighbor-discovery
```

show ip interface bridge-domain

show ip interface bridge-domain WORD

Description: Show Bridge-domain Information

Syntax:

WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show ip interface bridge-domain WORD
```

show ipv6 interface bridge-domain

show ipv6 interface bridge-domain WORD

Description: Show Bridge-domain Information

Syntax:

WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show ipv6 interface bridge-domain WORD
```

show l4l7-cluster

show l4l7-cluster [tenant <Tenant Name>] [cluster <Device Cluster Name>]

説明：L4 L7 デバイス情報を表示する

構文：

テナント名	（オプション）テナント名
デバイス クラスタ名	（オプション）デバイスの名前

コマンド モード exec：Exec モード

コマンド パス：

```
# show l4l7-cluster [tenant <Tenant Name>] [cluster <Device Cluster Name>]
```

show l4l7-graph

show l4l7-graph [tenant <Tenant Name>] [graph <Graph Name>]

説明：L4 L7 グラフ情報を表示する

構文：

<*Tenant Name*>	（オプション）テナント名
<*Graph Name*>	（オプション）グラフの名前

コマンド モード exec：Exec モード

コマンド パス：

```
# show l4l7-graph [tenant <Tenant Name>] [graph <Graph Name>]
```

show l4l7-package

show l4l7-package

説明： L4 ～ L7 パッケージ情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show l4l7-package
```

show ldap-server

show ldap-server

Description: Show LDAP server information

Command Mode: exec : Exec Mode

Command Path:

```
# show ldap-server
```

show license all

show license all

説明： show license all

コマンド モード exec：Exec モード

コマンド パス：

```
# show license all
```

show license catalog

show license catalog

Description: Show license catalog

Command Mode: exec : Exec Mode

Command Path:

```
# show license catalog
```

show license hostname

show license hostname privacy

説明： ライセンスのホスト名を表示する

構文：

privacy	privacy

コマンド モード exec：Exec モード

コマンド パス：

```
# show license hostname privacy
```

show license interval

show license interval

Description: Display the license interval

Command Mode: exec : Exec Mode

Command Path:

```
# show license interval
```

show license status

show license status

Description: Show license status

Command Mode: exec : Exec Mode

Command Path:

```
# show license status
```

show license summary

show license summary

Description: Show license summary

Command Mode: exec : Exec Mode

Command Path:

```
# show license summary
```

show license tech

show license tech support

Description: Show license tech support

Syntax:

support	techsupport

Command Mode: exec : Exec Mode

Command Path:

```
# show license tech support
```

show license transport-mode

show license transport-mode

説明：スマート ライセンス転送モードを表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show license transport-mode
```

show license udi

show license udi

説明： デバイス udi を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show license udi
```

show license usage

show license usage

Description: Show license usage

Command Mode: exec : Exec Mode

Command Path:

```
# show license usage
```

show lldp

show lldp

Description: Show lldp neighbor information

Command Mode: exec : Exec Mode

Command Path:

```
# show lldp
```

show locator-led

show locator-led status

説明：locator-led のコマンドを表示する

構文：

status	locator-led status

コマンド モード exec：Exec モード

コマンド パス：

```
# show locator-led status
```

show locator-led status leaf

show locator-led status leaf

説明：フィルタするリーフ

構文：

status	locator-led status
arg	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show locator-led status leaf
```

show locator-led status spine

show locator-led status spine

Description: Spine to filter on

Syntax:

status	locator-led status
arg	Spine Range or Spine Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show locator-led status spine
```

show macsec interface

show macsec interface switch <101-4000>

説明：インターフェイス

構文：

スイッチ	スイッチ
<101-4000>	スイッチ ID

コマンド モード exec：Exec モード

コマンド パス：

```
# show macsec interface switch <101-4000>
```

show macsec policy

show macsec policy <WORD>

Description: Show macsec policies

Syntax:

WORD	Node Number (Max Size 4000). Number range from=0 to=9223372036854775807

Command Mode: exec : Exec Mode

Command Path:

```
# show macsec policy <WORD>
```

show microsoft domain

show microsoft domain

Description: Show Microsoft domain information

Command Mode: exec : Exec Mode

Command Path:

```
# show microsoft domain
```

show microsoft domain name

show microsoft domain name <WORD>

Description: Microsoft domain name

Syntax:

WORD	Microsoft domain name

Command Mode: exec : Exec Mode

Command Path:

```
# show microsoft domain name <WORD>
```

show microsoft domain name hyperv

show microsoft domain name <WORD> hyperv <WORD>

Description: Show Microsoft Hypervisor information

Syntax:

WORD	Microsoft domain name
WORD	HyperV hostname

Command Mode: exec : Exec Mode

Command Path:

```
# show microsoft domain name <WORD> hyperv <WORD>
```

show microsoft domain name port-group

show microsoft domain name <WORD> port-group

説明：Microsoft ポート グループ情報を表示する

構文：

WORD	Microsoft ドメイン名

コマンド モード exec：Exec モード

コマンド パス：

```
# show microsoft domain name <WORD> port-group
```

show microsoft domain name scvmm

show microsoft domain name <WORD> scvmm <hostname|ip>

説明：Microsoft SCVMM 情報を表示する

構文：

WORD	Microsoft ドメイン名
<*hostname*|*ip*>	SCVMM ホスト名または IP

コマンド モード exec：Exec モード

コマンド パス：

```
# show microsoft domain name <WORD> scvmm <hostname|ip>
```

show microsoft domain name vm

show microsoft domain name <WORD> vm

説明：Microsoft VM 情報を表示する

構文：

WORD	Microsoft ドメイン名

コマンド モード exec：Exec モード

コマンド パス：

```
# show microsoft domain name <WORD> vm
```

show microsoft domain name vm name

show microsoft domain name <WORD> vm name <WORD>

Description: Show detailed Microsoft VM information

Syntax:

WORD	Microsoft domain name
WORD	VM Name

Command Mode: exec : Exec Mode

Command Path:

```
# show microsoft domain name <WORD> vm name <WORD>
```

show microsoft vm

show microsoft vm [name <WORD>] [ip <A.B.C.D>] [mac <AA:BB:CC:DD:EE:FF>]

Description: Show Microsoft VM information

Syntax:

WORD	(Optional) Specify a VM name
A.B.C.D	(Optional) Specify a VM IP address
AA:BB:CC:DD:EE:FF	(Optional) Specify a VM MAC address

Command Mode: exec : Exec Mode

Command Path:

```
# show microsoft vm [name <WORD>] [ip <A.B.C.D>] [mac <AA:BB:CC:DD:EE:FF>]
```

show monitor access

show monitor access

説明：アクセス インターフェイスのモニタ セッション/フィルタグループを表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show monitor access
```

show monitor access filter-group

show monitor access filter-group filter-group_name

説明： アクセス インターフェイスのモニタ フィルタグループを表示する

構文：

filter-group_name	フィルタグループ名

コマンド モード exec：Exec モード

コマンド パス：

```
# show monitor access filter-group filter-group_name
```

show monitor access session

show monitor access session session_name

説明：アクセス インターフェイスのモニタ セッションを表示する

構文：

session_name	セッション名

コマンド モード exec：Exec モード

コマンド パス：

```
# show monitor access session session_name
```

show monitor fabric

show monitor fabric

説明：ファブリック インターフェイスのモニタ セッション/フィルタグループを表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show monitor fabric
```

show monitor fabric filter-group

show monitor fabric filter-group filter-group_name

説明：ファブリック インターフェイスのモニタ フィルタグループを表示する

構文：

filter-group_name	フィルタグループ名

コマンド モード exec：Exec モード

コマンド パス：

```
# show monitor fabric filter-group filter-group_name
```

show monitor fabric session

show monitor fabric session session_name

説明： ファブリック インターフェイスのモニタ セッションを表示する

構文：

session_name	セッション名

コマンド モード exec：Exec モード

コマンド パス：

```
# show monitor fabric session session_name
```

show monitor summary

show monitor summary

Description: Show brief summary of all non-virtual monitor sessions

Command Mode: exec : Exec Mode

Command Path:

```
# show monitor summary
```

show monitor tenant

show monitor tenant <tenant_name> session session_name

Description: Show monitor session for tenant

Syntax:

tenant_name	tenant
session	session
session_name	session name

Command Mode: exec : Exec Mode

Command Path:

```
# show monitor tenant <tenant_name> session session_name
```

show monitor virtual

show monitor virtual session WORD

Description: Show monitor session for virtual switches

Syntax:

session	session
WORD	Session name

Command Mode: exec : Exec Mode

Command Path:

```
# show monitor virtual session WORD
```

show name-alias tenant

show name-alias tenant WORD

Description: Show corresponding tenants for Alias

Syntax:

WORD	Name of the tenant Alias to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show name-alias tenant WORD
```

show name-alias tenant acl

show name-alias tenant WORD acl WORD

説明：エイリアスの ACL 名を表示する

構文：

WORD	フィルタするテナント エイリアスの名前（最大サイズ 63）
WORD	フィルタする ACL エイリアスの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show name-alias tenant WORD acl WORD
```

show name-alias tenant application

show name-alias tenant WORD application WORD

説明：エイリアスのアプリケーション名を表示する

構文：

WORD	フィルタするテナント エイリアスの名前（最大サイズ 63）
WORD	フィルタするアプリケーション エイリアスの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show name-alias tenant WORD application WORD
```

show name-alias tenant application epg

show name-alias tenant WORD application WORD epg WORD

Description: Show EndPoint Group Name for alias

Syntax:

WORD	Name of the tenant Alias to filter on (Max Size 63)
WORD	Name of the application Alias to filter on (Max Size 64)
WORD	Name of the epg Alias to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show name-alias tenant WORD application WORD epg WORD
```

show name-alias tenant bridge-domain

show name-alias tenant WORD bridge-domain WORD

説明：エイリアスのブリッジドメイン名を表示する

構文：

WORD	フィルタするテナント エイリアスの名前（最大サイズ 63）
WORD	フィルタするブリッジドメイン エイリアスの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show name-alias tenant WORD bridge-domain WORD
```

show name-alias tenant contract

show name-alias tenant WORD contract WORD

説明：エイリアスのコントラクト名を表示する

構文：

WORD	フィルタするテナント エイリアスの名前（最大サイズ 63）
WORD	フィルタするコントラクトの エイリアス名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show name-alias tenant WORD contract WORD
```

show name-alias tenant contract subject

show name-alias tenant WORD contract WORD subject WORD

説明：エイリアスのサブジェクト名を表示する

構文：

WORD	フィルタするテナント エイリアスの名前（最大サイズ 63）
WORD	フィルタするコントラクトの エイリアス名前（最大サイズ 64）
WORD	フィルタするサブジェクト エイリアスの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show name-alias tenant WORD contract WORD subject WORD
```

show name-alias tenant l3out

show name-alias tenant WORD l3out WORD

Description: Show L3out Name for alias

Syntax:

WORD	Name of the tenant Alias to filter on (Max Size 63)
WORD	Name of the L3out Alias to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show name-alias tenant WORD l3out WORD
```

show name-alias tenant vrf

show name-alias tenant WORD vrf WORD

説明：エイリアスの VRF 名を表示する

構文：

WORD	フィルタするテナント エイリアスの名前（最大サイズ 63）
WORD	フィルタする VRF エイリアスの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show name-alias tenant WORD vrf WORD
```

show ntpq

show ntpq

Description: Show ntpq information

Command Mode: exec : Exec Mode

Command Path:

```
# show ntpq
```

show oob-mgmt

show oob-mgmt

Description: Show Out of band Information

Command Mode: exec : Exec Mode

Command Path:

```
# show oob-mgmt
```

show oob-mgmt controller

show oob-mgmt controller <controller-id> [epg <WORD>]

説明：コントローラで oob mgmt epgs を表示し、1 つを入力する

構文：

<controller-id>	
WORD	（オプション）コンシューマ epg の Epg 名

コマンド モード exec：Exec モード

コマンド パス：

```
# show oob-mgmt controller <controller-id> [epg <WORD>]
```

show oob-mgmt switch

show oob-mgmt switch <switch-id> [epg <WORD>]

Description: Show oob mgmt epgs on the node, enter one

Syntax:

<switch-id>	
WORD	(Optional) Epg Name of conusmer epg

Command Mode: exec : Exec Mode

Command Path:

```
# show oob-mgmt switch <switch-id> [epg <WORD>]
```

show pd-recovery status

show pd-recovery status

説明：policymgr shards ステータスから policydist shard recovery を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show pd-recovery status
```

show policy-map

show policy-map

Description: Show policy maps

Command Mode: exec : Exec Mode

Command Path:

```
# show policy-map
```

show policy-map type data-plane

show policy-map type data-plane infra WORD [stats]

説明：データプレーン タイプ ポリシーマップ

構文：

infra	グローバル データプレーン ポリシー マップ
WORD	データプレーン タイプ ポリシーマップ（最大サイズ 64）
stats	（オプション）データプレーン ポリサー統計情報（使用可能な場合）

コマンド モード exec：Exec モード

コマンド パス：

```
# show policy-map type data-plane infra WORD [stats]
```

show policy-map type qos

show policy-map type qos WORD

説明：QOS タイプのポリシーマップ

構文：

WORD	QOS タイプ ポリシーマップ（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show policy-map type qos WORD
```

show port-channel leaf

show port-channel leaf WORD <port-channel-list>

説明：リーフ ポートチャネル情報を表示する

構文：

WORD	リーフ範囲またはリーフ名リスト
<*port-channel-list*>	ポート チャネル名

コマンド モード exec：Exec モード

コマンド パス：

```
# show port-channel leaf WORD <port-channel-list>
```

show port-channel map

show port-channel map <port-channel-list>

説明：ポートチャネル マッピングを表示する

構文：

<*port-channel-list*>	ポート チャネル名

コマンド モード exec：Exec モード

コマンド パス：

```
# show port-channel map <port-channel-list>
```

show port-channel map leaf

show port-channel map <port-channel-list> leaf WORD [fex <101-199>]

Description: Leaf

Syntax:

<port-channel-list>	port channel names
WORD	Leaf Range or Leaf Name List
<101-199>	(Optional) Fex ID

Command Mode: exec : Exec Mode

Command Path:

```
# show port-channel map <port-channel-list> leaf WORD [fex <101-199>]
```

show pwd-rules

show pwd-rules

説明： パスワード ルールを表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show pwd-rules
```

show quota

show quota

Description: Show Quotas Information

Command Mode: exec : Exec Mode

Command Path:

```
# show quota
```

show radius-server

show radius-server

説明： RADIUS サーバ情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show radius-server
```

show redhat domain

show redhat domain

説明： Redhat ドメイン情報の表示

コマンド モード exec：Exec モード

コマンド パス：

```
# show redhat domain
```

show redhat domain name

show redhat domain name <name>

Description: Redhat domain name

Syntax:

<*name*>	Redhat domain name

Command Mode: exec : Exec Mode

Command Path:

```
# show redhat domain name <name>
```

show redhat domain name epg

show redhat domain name <name> epg

Description: Show Redhat domain EPG details

Syntax:

<*name*>	Redhat domain name

Command Mode: exec : Exec Mode

Command Path:

```
# show redhat domain name <name> epg
```

show redhat domain name rhev

show redhat domain name <name> rhev <hostname|ip>

説明：RHEV ip またはホスト名

構文：

<*name*>	Redhat ドメイン名
<*hostname*|*ip*>	rhev ホスト名または IP

コマンド モード exec：Exec モード

コマンド パス：

```
# show redhat domain name <name> rhev <hostname|ip>
```

show resource

show resource conflict encap-vlan

説明：リソース情報を表示する

構文：

conflict	APIC でリソースの競合を表示する
encap-vlan	show resource conflicts of encap-vlan in APIC

コマンド モード exec：Exec モード

コマンド パス：

```
# show resource conflict encap-vlan
```

show resource conflict encap-vlan epg

show resource conflict encap-vlan epg <WORD>

Description: Epg Name

Syntax:

conflict	show resource conflicts in APIC
encap-vlan	show resource conflicts of encap-vlan in APIC
WORD	Epg Name

Command Mode: exec : Exec Mode

Command Path:

```
# show resource conflict encap-vlan epg <WORD>
```

show resource conflict encap-vlan epg node

show resource conflict encap-vlan epg <WORD> node <101-4000>

Description: Node ID

Syntax:

conflict	show resource conflicts in APIC
encap-vlan	show resource conflicts of encap-vlan in APIC
WORD	Epg Name
<101-4000>	Leaf ID

Command Mode: exec : Exec Mode

Command Path:

```
# show resource conflict encap-vlan epg <WORD> node <101-4000>
```

show role

show role

Description: Show information about AAA Roles

Command Mode: exec : Exec Mode

Command Path:

```
# show role
```

show rsa-server

show rsa-server

説明： RSA サーバ情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show rsa-server
```

show running-config

show running-config [all] <scope>

説明：実行コンフィギュレーションを表示する

構文：

all	（オプション）デフォルトで running-config を表示する
<*scope*>	コマンド範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show running-config [all] <scope>
```

show sessions

show sessions [id <log-id>] [action action<action-type>] [user <user-name>] [last-minutes <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] <scope>

Description: Show session-log information

Syntax:

<*log-id*>	(Optional) Log ID
action<*action-type*>	(Optional) Object action indicator
<*user-name*>	(Optional) Name of user
<*num-minutes*>	(Optional) Logs created in time interval. Number range from 1 to 59
<*num-hours*>	(Optional) Logs created in time interval. Number range from 1 to 23
<*num-days*>	(Optional) Logs created in time interval. Number range from 1 to 999
<*YYYY-MM-DDTHR:MIN:SEC*>	(Optional) Logs created in time interval
end-time <*YYYY-MM-DDTHR:MIN:SEC*>	(Optional) Logs created in time interval
detail	(Optional) Detailed session-log information. Displays the action trigger that shows why a login occurred.
<*scope*>	command scope

Command Mode: exec : Exec Mode

Command Path:

```
# show sessions [id <log-id>] [action action<action-type>] [user <user-name>] [last-minutes
 <NUMBER>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>]
 [end-time end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] <scope>
```

show sessions controller

show sessions [id <log-id>] [action <action-type>] [user <user-name>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] controller

説明： コントローラ情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show sessions [id <log-id>] [action <action-type>] [user <user-name>] [last-hours
<NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time
<YYYY-MM-DDTHR:MIN:SEC>] [detail] controller
```

show sessions controller detail

show sessions [id <log-id>] [action <action-type>] [user <user-name>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] controller detail [id <node-id>]

説明：コントローラの詳細情報

構文：

node-id	（任意）オプションのシリアル番号

コマンド モード exec：Exec モード

コマンド パス：

```
# show sessions [id <log-id>] [action <action-type>] [user <user-name>] [last-hours
<NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time
<YYYY-MM-DDTHR:MIN:SEC>] [detail] controller detail [id <node-id>]
```

show sessions leaf

show sessions [id <log-id>] [action <action-type>] [user <user-name>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId>

Description: Show command for leaf

Syntax:

<*leafId*>	Leaf id

Command Mode: exec : Exec Mode

Command Path:

```
# show sessions [id <log-id>] [action <action-type>] [user <user-name>] [last-hours
<NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time
<YYYY-MM-DDTHR:MIN:SEC>] [detail] leaf <leafId>
```

show sessions spine

show sessions [id <log-id>] [action <action-type>] [user <user-name>] [last-hours <NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time <YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId>

Description: Show command for spine

Syntax:

<*leafId*>	Leaf id

Command Mode: exec : Exec Mode

Command Path:

```
# show sessions [id <log-id>] [action <action-type>] [user <user-name>] [last-hours
<NUMBER>] [last-days <NUMBER>] [start-time <YYYY-MM-DDTHR:MIN:SEC>] [end-time
<YYYY-MM-DDTHR:MIN:SEC>] [detail] spine <leafId>
```

show snapshot active

show snapshot active job

説明：アクティブなスナップショット ジョブのコマンドを表示する

構文：

job	アクティブなスナップショット ジョブを表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show snapshot active job
```

show snapshot files

show snapshot files

Description: Show command for snapshot files

Command Mode: exec : Exec Mode

Command Path:

```
# show snapshot files
```

show snapshot jobs

show snapshot jobs <WORD>

説明：スナップショット ジョブのコマンドを表示する

構文：

WORD	スナップショット ポリシー名

コマンド モード exec：Exec モード

コマンド パス：

```
# show snapshot jobs <WORD>
```

show snmp

show snmp [policy <policy>]

Description: Show snmp policy information

Syntax:

policy	(Optional) SNMP policy name

Command Mode: exec : Exec Mode

Command Path:

```
# show snmp [policy <policy>]
```

show snmp clientgroups

show snmp [policy <policy>] clientgroups

説明：snmp クライアント グループ ポリシーを表示する

構文：

ポリシー	（オプション）SNMP ポリシー名

コマンド モード exec：Exec モード

コマンド パス：

```
# show snmp [policy <policy>] clientgroups
```

show snmp community

show snmp [policy <policy>] community

Description: Show snmp community information

Syntax:

policy	(Optional) SNMP policy name

Command Mode: exec : Exec Mode

Command Path:

```
# show snmp [policy <policy>] community
```

show snmp engineid

show snmp [policy <policy>] engineid

Description: Show snmp v3 engine-id

Syntax:

policy	(Optional) SNMP policy name

Command Mode: exec : Exec Mode

Command Path:

```
# show snmp [policy <policy>] engineid
```

show snmp hosts

show snmp [policy <policy>] hosts

説明：snmp trap hosts を表示する

構文：

ポリシー	（オプション）SNMP ポリシー名

コマンド モード exec：Exec モード

コマンド パス：

```
# show snmp [policy <policy>] hosts
```

show snmp summary

show snmp [policy <policy>] summary

説明： snmp summary を表示します

構文：

ポリシー	（オプション）SNMP ポリシー名

コマンド モード exec：Exec モード

コマンド パス：

```
# show snmp [policy <policy>] summary
```

show snmp users

show snmp [policy <policy>] users

Description: Show snmp v3 users

Syntax:

policy	(Optional) SNMP policy name

Command Mode: exec : Exec Mode

Command Path:

```
# show snmp [policy <policy>] users
```

show stats

show stats granularity <granularity-value> [history] [cumulative] tenant|leaf|spine

説明：統計情報を表示する

構文：

粒度	粒度値を選択します
<*granularity-value*>	<granularity-value>
history	（オプション）履歴統計情報
cumulative	（オプション）累積統計情報
テナント	コマンドの範囲
leaf	コマンドの範囲
spine	コマンド範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant|leaf|spine
```

show stats granularity communication controller

show stats granularity <granularity-value> [history] [cumulative] communication controller node-id

説明：nginx web-requests のコマンドを表示する

構文：

node-id	node-id

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] communication
controller node-id
```

show stats granularity leaf

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId>

説明：リーフのコマンドを表示する

構文：

<leafId>	リーフ id

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId>
```

show stats granularity leaf fex

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> fex <fexNum>

説明：拡張シャーシ情報を表示する

構文：

<*leafId*>	リーフ id
<*fexNum*>	FEX 番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> fex
<fexNum>
```

show stats granularity leaf fex module

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> fex <fexNum> module <lcSlot>

Description: Show inventory module information

Syntax:

<*leafId*>	Leaf id
<*fexNum*>	pls enter fex number
<*lcSlot*>	please enter the module number

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> fex
<fexNum> module <lcSlot>
```

show stats granularity leaf interface ethernet

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> interface ethernet <phyInt>

説明：イーサネット IEEE 802.3z

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> interface
 ethernet <phyInt>
```

show stats granularity leaf interface fc

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> interface fc <phyInt>

説明：ファイバ チャネル プロトコル

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> interface
 fc <phyInt>
```

show stats granularity leaf interface fcportchannel

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> interface fcportchannel <portChan>

Description: FC Port channel interface

Syntax:

<*leafId*>	Leaf id
<*portChan*>	<Port channel number>

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> interface
 fcportchannel <portChan>
```

show stats granularity leaf interface mgmt

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> interface mgmt <mgmtPort>

説明：管理インターフェイス

構文：

<*leafId*>	リーフ id
<*mgmtPort*>	<Management interface number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> interface
 mgmt <mgmtPort>
```

show stats granularity leaf interface portchannel

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> interface portchannel <portChan>

説明：ポート チャネル インターフェイス

構文：

<*leafId*>	リーフ id
<*portChan*>	<Port channel number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> interface
 portchannel <portChan>
```

show stats granularity leaf interface vethernet

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> interface vethernet <phyInt>

説明：vethernet ID

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> interface
 vethernet <phyInt>
```

show stats granularity leaf inventory chassis

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> inventory chassis

Description: Show inventory chassis information

Syntax:

<leafId>	Leaf id

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> inventory
 chassis
```

show stats granularity leaf inventory fans

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> inventory fans <ftSlot>

説明：インベントリ ファン情報を表示する

構文：

<*leafId*>	リーフ id
<*ftSlot*>	pls enter fan tray number

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> inventory
 fans <ftSlot>
```

show stats granularity leaf inventory powersupply

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> inventory powersupply <psuSlot>

Description: Show inventory power supply information

Syntax:

<*leafId*>	Leaf id
<*psuSlot*>	pls enter the powersupply number

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> inventory
 powersupply <psuSlot>
```

show stats granularity leaf inventory supervisor

show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> inventory supervisor <supMod>

Description: Show information for supervisor module

Syntax:

<*leafId*>	Leaf id
<*supMod*>	pls enter the supervisor module number

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] leaf <leafId> inventory
 supervisor <supMod>
```

show stats granularity spine

show stats granularity <granularity-value> [history] [cumulative] spine <leafId>

Description: Show command for spine

Syntax:

<leafId>	Leaf id

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] spine <leafId>
```

show stats granularity spine interface ethernet

show stats granularity <granularity-value> [history] [cumulative] spine <leafId> interface ethernet <phyInt>

説明：イーサネット IEEE 802.3z

構文：

<*leafId*>	リーフ id
<*phyInt*>	<slot or chassis-number/port or slot number>

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] spine <leafId>
interface ethernet <phyInt>
```

show stats granularity spine interface mgmt

show stats granularity <granularity-value> [history] [cumulative] spine <leafId> interface mgmt <mgmtPort>

Description: Management interface

Syntax:

<*leafId*>	Leaf id
<*mgmtPort*>	<Management interface number>

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] spine <leafId>
interface mgmt <mgmtPort>
```

show stats granularity spine inventory chassis

show stats granularity <granularity-value> [history] [cumulative] spine <leafId> inventory chassis

説明：インベントリ シャーシ情報を表示する

構文：

<leafId>	リーフ id

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] spine <leafId>
inventory chassis
```

show stats granularity spine inventory fabric

show stats granularity <granularity-value> [history] [cumulative] spine <leafId> inventory fabric <fcMod>

説明： ファブリック モジュールの情報を表示する

構文：

<*leafId*>	リーフ id
<*fcMod*>	ファブリック モジュール番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] spine <leafId>
inventory fabric <fcMod>
```

show stats granularity spine inventory fans

show stats granularity <granularity-value> [history] [cumulative] spine <leafId> inventory fans <ftSlot>

Description: Show inventory fan information

Syntax:

<*leafId*>	Leaf id
<*ftSlot*>	pls enter fan tray number

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] spine <leafId>
inventory fans <ftSlot>
```

show stats granularity spine inventory module

show stats granularity <granularity-value> [history] [cumulative] spine <leafId> inventory module <lcSlot>

Description: Show inventory module information

Syntax:

<*leafId*>	Leaf id
<*lcSlot*>	please enter the module number

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] spine <leafId>
inventory module <lcSlot>
```

show stats granularity spine inventory powersupply

show stats granularity <granularity-value> [history] [cumulative] spine <leafId> inventory powersupply <psuSlot>

説明：インベントリ電源情報を表示する

構文：

<*leafId*>	リーフ id
<*psuSlot*>	電源番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] spine <leafId>
inventory powersupply <psuSlot>
```

show stats granularity spine inventory supervisor

show stats granularity <granularity-value> [history] [cumulative] spine <leafId> inventory supervisor <supMod>

Description: Show information for supervisor module

Syntax:

<*leafId*>	Leaf id
<*supMod*>	pls enter the supervisor module number

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] spine <leafId>
inventory supervisor <supMod>
```

show stats granularity spine inventory system

show stats granularity <granularity-value> [history] [cumulative] spine <leafId> inventory system <sysMod>

説明：システム モジュールの情報を表示する

構文：

<*leafId*>	リーフ id
<*sysMod*>	システム モジュール番号を入力してください

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] spine <leafId>
inventory system <sysMod>
```

show stats granularity tenant

show stats granularity <granularity-value> [history] [cumulative] tenant WORD

Description: Show Tenants Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD
```

show stats granularity tenant application

show stats granularity <granularity-value> [history] [cumulative] tenant WORD application WORD

説明：アプリケーション プロファイル情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD application
 WORD
```

show stats granularity tenant application epg

show stats granularity <granularity-value> [history] [cumulative] tenant WORD application WORD epg WORD

Description: Show Application EPG Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)
WORD	Name of the AEPG to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD application
 WORD epg WORD
```

show stats granularity tenant application esg

show stats granularity <granularity-value> [history] [cumulative] tenant WORD application WORD esg WORD

Description: Show Show Endpoint Security Group Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)
WORD	Name of the ESG to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD application
 WORD esg WORD
```

show stats granularity tenant dnsservergroup

show stats granularity <granularity-value> [history] [cumulative] tenant WORD dnsservergroup WORD

Description: Show Dns Server Group Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the dns server group we eventually want to filter on (Max Size 16)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD
dnsservergroup WORD
```

show stats granularity tenant dnsservergroup server

show stats granularity <granularity-value> [history] [cumulative] tenant WORD dnsservergroup WORD server WORD

説明：Dns サーバ情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタする DNS サーバ グループの名前（最大サイズ 16）
WORD	最終的にフィルタするサーバの IP

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD
dnsservergroup WORD server WORD
```

show stats granularity tenant dnsservergroup server domain

show stats granularity <granularity-value> [history] [cumulative] tenant WORD dnsservergroup WORD server WORD domain WORD

Description: Show Dns Domain Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the dns server group we eventually want to filter on (Max Size 16)
WORD	IP of server we eventually want to filter on (Max Size None)
WORD	Domain we eventually want to filter on (Max Size 512)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD
dnsservergroup WORD server WORD domain WORD
```

show stats粒度 tenant dot1q-tunnel

show stats granularity <granularity-value> [history] [cumulative] tenant WORD dot1q-tunnel WORD

説明：Dot1q-tunnel 情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタするTnlEPG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD
dot1q-tunnel WORD
```

show stats granularity tenant multicast-route-maps

show stats granularity <granularity-value> [history] [cumulative] tenant WORD multicast-route-maps

Description: Show multicast route-maps per Tenant

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD
multicast-route-maps
```

show stats granularity tenant vrf

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD

Description: Show VRF Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
```

show stats granularity tenant vrf acllog l2

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD acllog <permitDrop> l2 flow vlan <NUMBER> srcintf <srcintf>

説明：L2 フロー統計情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
permitDrop	permitDrop
flow	フロー統計
vlan	VLAN の情報
<*vlan*>	<vlan>. 番号の範囲 0 ～ =9223372036854775807
srcintf	送信元インターフェイス
<*srcintf*>	<srcintf>

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 acllog <permitDrop> l2 flow vlan <NUMBER> srcintf <srcintf>
```

show stats granularity tenant vrf acllog l3

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD acllog <permitDrop> l3 flow srcpctag <srcpctag> dstpctag <dstpctag> srcepgname <srcepgname> dstepgname <dstepgname> srcip <A.B.C.D or A:B::C:D> dstip <A.B.C.D or A:B::C:D> proto <proto> srcport <srcport> dstport <dstport> srcintf <srcintf>

説明：L3 フロー統計情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
permitDrop	permitDrop
flow	フロー統計
srcpctag	送信元 PC タグ
<*srcpctag*>	<srcpctag>
dstpctag	宛先 PC タグ
<*dstpctag*>	<dstpctag>
srcepgname	送信元 epg 名
<*srcepgname*>	<srcepgname>
dstepgname	宛先 epg 名
<*dstepgname*>	<dstepgname>
srcip	source ip
ABCD または *A:B::C:D*	i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
dstip	宛先 IP
ABCD または *A:B::C:D*	i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
proto	protocol
<*proto*>	<proto>
srcport	送信元ポート
<*srcport*>	<srcport>

dstport	宛先ポート
<*dstport*>	<dstport>
srcintf	送信元インターフェイス
<*srcintf*>	<srcintf>

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 acllog <permitDrop> l3 flow srcpctag <srcpctag> dstpctag <dstpctag> srcepgname
<srcepgname> dstepgname <dstepgname> srcip <A.B.C.D or A:B::C:D> dstip <A.B.C.D or
A:B::C:D> proto <proto> srcport <srcport> dstport <dstport> srcintf <srcintf>
```

show stats granularity tenant vrf detail

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD detail

説明：VRF の詳細ビューを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 detail
```

show stats granularity tenant vrf external-l3 bgp

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 bgp

Description: Show command for BGP peers

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 bgp
```

show stats granularity tenant vrf external-l3 bgp node

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 bgp node <101-4000>

説明：フィルタするノード

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<101-4000>	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 bgp node <101-4000>
```

show stats granularity tenant vrf external-l3 eigrp

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 eigrp

Description: Show external l3 EIGRP

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 eigrp
```

show stats granularity tenant vrf external-l3 eigrp detail

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 eigrp detail

Description: Show interanl details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 eigrp detail
```

show stats granularity tenant vrf external-l3 epg

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 epg <epgName>

Description: Show command for external-l3 epgs

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
<*epgName*>	Name of the EPG to filter on

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 epg <epgName>
```

show stats granularity tenant vrf external-l3 epg detail

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 epg <epgName> detail

Description: external-l3 epg in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
<epgName>	Name of the EPG to filter on

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 epg <epgName> detail
```

show stats granularity tenant vrf external-l3 interfaces

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 interfaces

Description: Show tenant <tenant> vrf <vrf> external l3 interfaces

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 interfaces
```

show stats granularity tenant vrf external-l3 interfaces detail

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 interfaces detail

説明：インターフェイスの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 interfaces detail
```

show stats granularity tenant vrf external-l3 ospf

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 ospf

Description: Show command for IPv4 and IPv6 external l3 OSPF configuration

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 ospf
```

show stats granularity tenant vrf external-l3 ospf detail

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 ospf detail

Description: Show internal details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 ospf detail
```

show stats granularity tenant vrf external-l3 scale

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 scale

説明：スケール コマンド

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 scale
```

show stats granularity tenant vrf external-l3 scale detail

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 scale detail

説明：スケールの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 scale detail
```

show stats granularity tenant vrf external-l3 static-route

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 static-route

Description: Show command for external-l3 static routes

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 static-route
```

show stats granularity tenant vrf external-l3 static-route detail

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 static-route detail

Description: static-route in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 static-route detail
```

show stats granularity tenant vrf external-l3 static-route node

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 static-route node

Description: node to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
arg	Leaf Range or Leaf Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 static-route node
```

show stats granularity tenant vrf external-l3 static-route node detail

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD external-l3 static-route node detail

説明：スタティックルートの詳細と動作ステータス

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
arg	リーフ範囲またはリーフ名リスト

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 external-l3 static-route node detail
```

show stats granularity tenant vrf ipv6multicast

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD ipv6multicast

説明：VRF ごとに ipv6 マルチキャスト構成を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 ipv6multicast
```

show stats granularity tenant vrf multicast

show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD multicast

Description: Show multicast configuration per VRF

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show stats granularity <granularity-value> [history] [cumulative] tenant WORD vrf WORD
 multicast
```

show switch

show switch

説明： スイッチ情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show switch
```

show switch detail

show switch detail [id <switch-id>]

Description: Show switch detailed information

Syntax:

switch-id	(Optional) Optional switch id. Number range from=0 to=9223372036854775807

Command Mode: exec : Exec Mode

Command Path:

```
# show switch detail [id <switch-id>]
```

show tacacs-server

show tacacs-server

Description: Show tacacs server information

Command Mode: exec : Exec Mode

Command Path:

```
# show tacacs-server
```

show techsupport all

show techsupport all status

説明：すべてのテクニカルサポート ステータス

構文：

status	ステータス

コマンド モード exec：Exec モード

コマンド パス：

```
# show techsupport all status
```

show techsupport controllers

show techsupport controllers status

Description: Techsupport status for controllers

Syntax:

status	Status

Command Mode: exec : Exec Mode

Command Path:

```
# show techsupport controllers status
```

show techsupport host

show techsupport host <NUMBER> status

Description: Techsupport status for host

Syntax:

<*Odevid*>	Specify the host Odev ID. Number range from=0 to=9223372036854775807
status	Status

Command Mode: exec : Exec Mode

Command Path:

```
# show techsupport host <NUMBER> status
```

show techsupport switch

show techsupport switch switchId <switchId> status

Description: Techsupport status for switch

Syntax:

switchId <switchId>	switch id 101-4000 or range(s): 101-103,104
status	Status

Command Mode: exec : Exec Mode

Command Path:

```
# show techsupport switch switchId <switchId> status
```

show tenant

show tenant WORD

説明：テナント情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD
```

show tenant access-list

show tenant WORD access-list WORD

説明：アクセスリスト情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタするコントラクトの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD access-list WORD
```

show tenant application

show tenant WORD application WORD

Description: Show Application Profiles Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD application WORD
```

show tenant application endpoints

show tenant WORD application WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>]

説明：IP エンドポイントを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）
type	（オプション）エンドポイント タイプ
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）
<1-4094>	（オプション）カプセル化 VLAN。数値の範囲は 1 ～ 4094
A.B.C.D	（オプション）i.i.i.i 形式の IP ユニキャスト アドレス
A:B::C:D	（オプション）xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD application WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE
 EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>]
```

show tenant application endpoints leaf interface ethernet

show tenant WORD application WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface ethernet ethernet [<fex>/]<slot>/<port>

Description: Show IP endpoints on an interface ethernet

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)
type	(Optional) Endpoint Type
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
A.B.C.D	(Optional) IP Unicast address in format i.i.i.i
A:B::C:D	(Optional) IPv6 address in format xxxx:xxxx, xxxx::xx
WORD	Leaf Number (Max Size 4000). Number range from=0 to=9223372036854775807
ethernet [<fex>/]<slot>/<port>	Ethernet Range

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD application WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE
 EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>]
leaf <WORD> interface ethernet ethernet [<fex>/]<slot>/<port>
```

show tenant application endpoints leaf interface port-channel

show tenant WORD application WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface port-channel <WORD> [fex <NUMBER>]

Description: Show IP endpoints on an interface port-channel

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)
type	(Optional) Endpoint Type
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
A.B.C.D	(Optional) IP Unicast address in format i.i.i.i
A:B::C:D	(Optional) IPv6 address in format xxxx:xxxx, xxxx::xx
WORD	Leaf Number (Max Size 4000). Number range from=0 to=9223372036854775807
WORD	Port Channel Name (Max Size 64)
<101-199>	(Optional) Fex Id. Number range from=101 to=199

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD application WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE
 EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>]
leaf <WORD> interface port-channel <WORD> [fex <NUMBER>]
```

show tenant application endpoints vpc

show tenant WORD application WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] vpc context <WORD> <WORD> interface vpc <WORD> [fex <fex>]

説明：vpc の IP エンドポイントを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）
type	（オプション）エンドポイント タイプ
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）
<1-4094>	（オプション）カプセル化 VLAN。数値の範囲は 1 ～ 4094
A.B.C.D	（オプション）i.i.i.i 形式の IP ユニキャスト アドレス
A:B::C:D	（オプション）xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
コンテキスト	VPC コンテキスト
WORD	最初の VPC リーフ（最大サイズ 4000）。数字の範囲は 0 ～ =9223372036854775807
WORD	2 番目の VPC リーフ（最大サイズ 4000）。数字の範囲は 0 ～ =9223372036854775807
インターフェイス	VPC インターフェイス名
vpc	VPC インターフェイス名
WORD	VPC 名（最大サイズ 64）
fex	（オプション）FEX id。=101 ～ =199 までの範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD application WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE
 EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>]
vpc context <WORD> <WORD> interface vpc <WORD> [fex <fex>]
```

show tenant application epg

show tenant WORD application WORD epg WORD

説明：アプリケーション EPG 情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）
WORD	フィルタする AEPG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD application WORD epg WORD
```

show tenant application epg detail

show tenant WORD application WORD epg WORD detail

説明：アプリケーション EPg の詳細ビューを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）
WORD	フィルタする AEPG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD application WORD epg WORD detail
```

show tenant application epg endpoints

show tenant WORD application WORD epg WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>]

Description: Show IP endpoints

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)
WORD	Name of the AEPG to filter on (Max Size 64)
type	(Optional) Endpoint Type
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
A.B.C.D	(Optional) IP Unicast address in format i.i.i.i
A:B::C:D	(Optional) IPv6 address in format xxxx:xxxx, xxxx::xx

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD application WORD epg WORD endpoints [type <type>] [mac <E.E.E
EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>]
[ipv6 <A:B::C:D>]
```

show tenant application epg endpoints leaf interface ethernet

show tenant WORD application WORD epg WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface ethernet ethernet [<fex>/]<slot>/<port>

Description: Show IP endpoints on an interface ethernet

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)
WORD	Name of the AEPG to filter on (Max Size 64)
type	(Optional) Endpoint Type
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
A.B.C.D	(Optional) IP Unicast address in format i.i.i.i
A:B::C:D	(Optional) IPv6 address in format xxxx:xxxx, xxxx::xx
WORD	Leaf Number (Max Size 4000). Number range from=0 to=9223372036854775807
ethernet [<fex>/]<slot>/<port>	Ethernet Range

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD application WORD epg WORD endpoints [type <type>] [mac <E.E.E
EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>]
[ipv6 <A:B::C:D>] leaf <WORD> interface ethernet ethernet [<fex>/]<slot>/<port>
```

show tenant application epg endpoints leaf interface port-channel

show tenant WORD application WORD epg WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface port-channel <WORD> [fex <NUMBER>]

Description: Show IP endpoints on an interface port-channel

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)
WORD	Name of the AEPG to filter on (Max Size 64)
type	(Optional) Endpoint Type
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
A.B.C.D	(Optional) IP Unicast address in format i.i.i.i
A:B::C:D	(Optional) IPv6 address in format xxxx:xxxx, xxxx::xx
WORD	Leaf Number (Max Size 4000). Number range from=0 to=9223372036854775807
WORD	Port Channel Name (Max Size 64)
<101-199>	(Optional) Fex Id. Number range from=101 to=199

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD application WORD epg WORD endpoints [type <type>] [mac <E.E.E
EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>]
[ipv6 <A:B::C:D>] leaf <WORD> interface port-channel <WORD> [fex <NUMBER>]
```

show tenant application epg endpoints vpc

show tenant WORD application WORD epg WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] vpc context <WORD> <WORD> interface vpc <WORD> [fex <fex>]

Description: Show IP endpoints on vpc

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the application we eventually want to filter on (Max Size 64)
WORD	Name of the AEPG to filter on (Max Size 64)
type	(Optional) Endpoint Type
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
A.B.C.D	(Optional) IP Unicast address in format i.i.i.i
A:B::C:D	(Optional) IPv6 address in format xxxx:xxxx, xxxx::xx
context	VPC Context
WORD	First VPC leaf (Max Size 4000). Number range from=0 to=9223372036854775807
WORD	Second VPC leaf (Max Size 4000). Number range from=0 to=9223372036854775807
interface	VPC Interface name
vpc	VPC Interface name
WORD	VPC Name (Max Size 64)
fex	(Optional) Fex Id. Number range from=101 to=199

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD application WORD epg WORD endpoints [type <type>] [mac <E.E.E
EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>]
[ipv6 <A:B::C:D>] vpc context <WORD> <WORD> interface vpc <WORD> [fex <fex>]
```

show tenant application esg

show tenant WORD application WORD esg WORD

説明：エンドポイント セキュリティ グループ情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）
WORD	フィルタする ESG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD application WORD esg WORD
```

show tenant application esg detail

show tenant WORD application WORD esg WORD detail

説明：エンドポイント セキュリティ グループの詳細なビューを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）
WORD	フィルタする ESG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD application WORD esg WORD detail
```

show tenant application esg endpoints

show tenant WORD application WORD esg WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>]

説明：IP エンドポイントを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	最終的にフィルタするアプリケーションの名前（最大サイズ 64）
WORD	フィルタする ESG の名前（最大サイズ 64）
type	（オプション）エンドポイント タイプ
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）
<1-4094>	（オプション）カプセル化 VLAN。数値の範囲は 1 ～ 4094
A.B.C.D	（オプション）i.i.i.i 形式の IP ユニキャスト アドレス
A:B::C:D	（オプション）xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD application WORD esg WORD endpoints [type <type>] [mac <E.E.E
EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>]
[ipv6 <A:B::C:D>]
```

show tenant bridge-domain

show tenant WORD bridge-domain WORD

説明：ブリッジドメイン情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD bridge-domain WORD
```

show tenant bridge-domain detail

show tenant WORD bridge-domain WORD detail

説明：ブリッジ ドメインの詳細情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD bridge-domain WORD detail
```

show tenant bridge-domain first-hop-security binding-table

show tenant WORD bridge-domain WORD first-hop-security binding-table

説明：ブリッジドメイン バインド テーブル情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD bridge-domain WORD first-hop-security binding-table
```

show tenant bridge-domain first-hop-security statistics arp

show tenant WORD bridge-domain WORD first-hop-security statistics arp

説明：ブリッジドメイン ファースト ホップ セキュリティ ARP 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD bridge-domain WORD first-hop-security statistics arp
```

show tenant bridge-domain first-hop-security statistics dhcpv4

show tenant WORD bridge-domain WORD first-hop-security statistics dhcpv4

Description: Show Bridge-domain First Hop Security DHCPv4 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD bridge-domain WORD first-hop-security statistics dhcpv4
```

show tenant bridge-domain first-hop-security statistics dhcpv6

show tenant WORD bridge-domain WORD first-hop-security statistics dhcpv6

Description: Show Bridge-domain First Hop Security DHCPv6 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD bridge-domain WORD first-hop-security statistics dhcpv6
```

show tenant bridge-domain first-hop-security statistics neighbor-discovery

show tenant WORD bridge-domain WORD first-hop-security statistics neighbor-discovery

Description: Show Bridge-domain First Hop Security Neighbor Discovery Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD bridge-domain WORD first-hop-security statistics neighbor-discovery
```

show tenant contract-type

show tenant WORD contract-type WORD

説明：タイプに基づいてコントラクト情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ホワイトリスト（許可）またはブラックリスト（拒否）またはコントラクト oob-mgmt タイプ

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD contract-type WORD
```

show tenant contract

show tenant WORD contract WORD

説明：コントラクト情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタするコントラクトの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD contract WORD
```

show tenant detail

show tenant WORD detail

Description: Show detailed view of tenant

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD detail
```

show tenant dnsservergroup

show tenant WORD dnsservergroup WORD

Description: Show Dns Server Group Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the dns server group we eventually want to filter on (Max Size 16)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD dnsservergroup WORD
```

show tenant dnsservergroup server

show tenant WORD dnsservergroup WORD server WORD

Description: Show Dns Server Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the dns server group we eventually want to filter on (Max Size 16)
WORD	IP of server we eventually want to filter on (Max Size None)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD dnsservergroup WORD server WORD
```

show tenant dnsservergroup server domain

show tenant WORD dnsservergroup WORD server WORD domain WORD

Description: Show Dns Domain Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the dns server group we eventually want to filter on (Max Size 16)
WORD	IP of server we eventually want to filter on (Max Size None)
WORD	Domain we eventually want to filter on (Max Size 512)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD dnsservergroup WORD server WORD domain WORD
```

show tenant dot1q-tunnel

show tenant WORD dot1q-tunnel WORD

説明：Dot1q-tunnel 情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタするTnlEPG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD dot1q-tunnel WORD
```

show tenant endpoints

show tenant WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>]

Description: Show IP endpoints

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
type	(Optional) Endpoint Type
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
A.B.C.D	(Optional) IP Unicast address in format i.i.i.i
A:B::C:D	(Optional) IPv6 address in format xxxx:xxxx, xxxx::xx

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE
 EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>]
```

show tenant endpoints leaf interface ethernet

show tenant WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface ethernet ethernet [<fex>/]<slot>/<port>

Description: Show IP endpoints on an interface ethernet

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
type	(Optional) Endpoint Type
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
A.B.C.D	(Optional) IP Unicast address in format i.i.i.i
A:B::C:D	(Optional) IPv6 address in format xxxx:xxxx, xxxx::xx
WORD	Leaf Number (Max Size 4000). Number range from=0 to=9223372036854775807
ethernet [<fex>/]<slot>/<port>	Ethernet Range

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE
 EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface
 ethernet ethernet [<fex>/]<slot>/<port>
```

show tenant endpoints leaf interface port-channel

show tenant WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface port-channel <WORD> [fex <NUMBER>]

説明：インターフェイス ポートチャネルで IP エンドポイントを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
type	（オプション）エンドポイント タイプ
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	（オプション）MAC アドレス（オプション 1）MAC アドレス（オプション 2）MAC アドレス（オプション 3）MAC アドレス（オプション 4）
<1-4094>	（オプション）カプセル化 VLAN。数値の範囲は 1 ～ 4094
A.B.C.D	（オプション）i.i.i.i 形式の IP ユニキャスト アドレス
A:B::C:D	（オプション）xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
WORD	リーフ数（最大サイズ 4000）番号の範囲 0 ～ =9223372036854775807
WORD	ポート チャネル名（最大サイズ 64）
<101-199>	（オプション）FEX id。=101 ～ =199 までの範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE
 EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] leaf <WORD> interface
 port-channel <WORD> [fex <NUMBER>]
```

show tenant endpoints vpc

show tenant WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] vpc context <WORD> <WORD> interface vpc <WORD> [fex <fex>]

Description: Show IP endpoints on vpc

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
type	(Optional) Endpoint Type
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)
<1-4094>	(Optional) Encapsulation Vlan. Number range from=1 to=4094
A.B.C.D	(Optional) IP Unicast address in format i.i.i.i
A:B::C:D	(Optional) IPv6 address in format xxxx:xxxx, xxxx::xx
context	VPC Context
WORD	First VPC leaf (Max Size 4000). Number range from=0 to=9223372036854775807
WORD	Second VPC leaf (Max Size 4000). Number range from=0 to=9223372036854775807
interface	VPC Interface name
vpc	VPC Interface name
WORD	VPC Name (Max Size 64)
fex	(Optional) Fex Id. Number range from=101 to=199

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD endpoints [type <type>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE
 EEEE.EEEE.EEEE >] [vlan <NUMBER>] [ip <A.B.C.D>] [ipv6 <A:B::C:D>] vpc context <WORD>
<WORD> interface vpc <WORD> [fex <fex>]
```

show tenant epg

show tenant WORD epg WORD

Description: Show Application EPG Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the AEPG to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD epg WORD
```

show tenant epg detail

show tenant WORD epg WORD detail

説明：アプリケーション EPg の詳細ビューを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする AEPG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD epg WORD detail
```

show tenant esg

show tenant WORD esg WORD

Description: Show Endpoint Security Group Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the ESG to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD esg WORD
```

show tenant esg detail

show tenant WORD esg WORD detail

説明：エンドポイント セキュリティ グループの詳細なビューを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする ESG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD esg WORD detail
```

show tenant external-l2 epg

show tenant WORD external-l2 epg WORD

説明：external-l2 epgs のコマンドを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする EPG の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD external-l2 epg WORD
```

show tenant interface bridge-domain

show tenant WORD interface bridge-domain WORD

Description: Show Bridge-domain Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD interface bridge-domain WORD
```

show tenant interface bridge-domain detail

show tenant WORD interface bridge-domain WORD detail

Description: Show Bridge-domain Detailed Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD interface bridge-domain WORD detail
```

show tenant interface bridge-domain first-hop-security binding-table

show tenant WORD interface bridge-domain WORD first-hop-security binding-table

Description: Show Bridge-domain Binding Table Information

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD interface bridge-domain WORD first-hop-security binding-table
```

show tenant interface bridge-domain first-hop-security statistics arp

show tenant WORD interface bridge-domain WORD first-hop-security statistics arp

Description: Show Bridge-domain First Hop Security ARP Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD interface bridge-domain WORD first-hop-security statistics arp
```

show tenant interface bridge-domain first-hop-security statistics dhcpv4

show tenant WORD interface bridge-domain WORD first-hop-security statistics dhcpv4

説明：ブリッジドメイン ファースト ホップ セキュリティ DHCPv4 統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD interface bridge-domain WORD first-hop-security statistics dhcpv4
```

show tenant interface bridge-domain first-hop-security statistics dhcpv6

show tenant WORD interface bridge-domain WORD first-hop-security statistics dhcpv6

Description: Show Bridge-domain First Hop Security DHCPv6 Statistics

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD interface bridge-domain WORD first-hop-security statistics dhcpv6
```

show tenant interface bridge-domain first-hop-security statistics neighbor-discovery

show tenant WORD interface bridge-domain WORD first-hop-security statistics neighbor-discovery

説明：ブリッジドメイン ファースト ホップ セキュリティ ネイバー探索統計情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD interface bridge-domain WORD first-hop-security statistics
neighbor-discovery
```

show tenant ip interface bridge-domain

show tenant WORD ip interface bridge-domain WORD

説明：インターフェイス BD の IP プロパティのコマンドを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	ブリッジドメインの名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD ip interface bridge-domain WORD
```

show tenant ipv6 interface bridge-domain

show tenant WORD ipv6 interface bridge-domain WORD

Description: Show command for IP properties on interface BD

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the bridge-domain (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD ipv6 interface bridge-domain WORD
```

show tenant multicast-route-maps

show tenant WORD multicast-route-maps

説明：テナントごとにマルチキャスト ルートマップを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD multicast-route-maps
```

show tenant policy-map

show tenant WORD policy-map

説明：ポリシー マップを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD policy-map
```

show tenant policy-map type data-plane

show tenant WORD policy-map type data-plane WORD [stats]

説明：データプレーン タイプ ポリシーマップ

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	データプレーン タイプ ポリシーマップ（最大サイズ 64）
stats	（オプション）データプレーン ポリサー統計情報（使用可能な場合）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD policy-map type data-plane WORD [stats]
```

show tenant policy-map type qos

show tenant WORD policy-map type qos WORD

説明：QOS タイプのポリシーマップ

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	QOS タイプ ポリシーマップ（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD policy-map type qos WORD
```

show tenant vrf

show tenant WORD vrf WORD

説明：VRF 情報を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD
```

show tenant vrf acllog l2

show tenant WORD vrf WORD acllog <permitDrop> l2 flow vlan <NUMBER> srcintf <srcintf>

説明：L2 フロー統計情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
permitDrop	permitDrop
flow	フロー統計
vlan	VLAN の情報
<*vlan*>	<vlan>. 番号の範囲 0 ～ =9223372036854775807
srcintf	送信元インターフェイス
<*srcintf*>	<srcintf>

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD acllog <permitDrop> l2 flow vlan <NUMBER> srcintf <srcintf>
```

show tenant vrf acllog l3

show tenant WORD vrf WORD acllog <permitDrop> l3 flow srcpctag <srcpctag> dstpctag <dstpctag> srcepgname <srcepgname> dstepgname <dstepgname> srcip <A.B.C.D or A:B::C:D> dstip <A.B.C.D or A:B::C:D> proto <proto> srcport <srcport> dstport <dstport> srcintf <srcintf>

説明：L3 フロー統計情報

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
permitDrop	permitDrop
flow	フロー統計
srcpctag	送信元 PC タグ
<*srcpctag*>	<srcpctag>
dstpctag	宛先 PC タグ
<*dstpctag*>	<dstpctag>
srcepgname	送信元 epg 名
<*srcepgname*>	<srcepgname>
dstepgname	宛先 epg 名
<*dstepgname*>	<dstepgname>
srcip	source ip
ABCD または *A:B::C:D*	i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
dstip	宛先 IP
ABCD または *A:B::C:D*	i.i.i.i 形式の IP アドレスまたは xxxx:xxxx、xxxx::xx 形式の IPv6 アドレス
proto	protocol
<*proto*>	<proto>
srcport	送信元ポート
<*srcport*>	<srcport>

dstport	宛先ポート
<*dstport*>	<dstport>
srcintf	送信元インターフェイス
<*srcintf*>	<srcintf>

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD acllog <permitDrop> l3 flow srcpctag <srcpctag> dstpctag
<dstpctag> srcepgname <srcepgname> dstepgname <dstepgname> srcip <A.B.C.D or A:B::C:D>
dstip <A.B.C.D or A:B::C:D> proto <proto> srcport <srcport> dstport <dstport> srcintf
<srcintf>
```

show tenant vrf detail

show tenant WORD vrf WORD detail

説明：VRF の詳細ビューを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD detail
```

show tenant vrf external-l3 bgp

show tenant WORD vrf WORD external-l3 bgp

Description: Show command for BGP peers

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD vrf WORD external-l3 bgp
```

show tenant vrf external-l3 bgp node

show tenant WORD vrf WORD external-l3 bgp node <101-4000>

Description: node to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
<101-4000>	Leaf Range or Leaf Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD vrf WORD external-l3 bgp node <101-4000>
```

show tenant vrf external-l3 eigrp

show tenant WORD vrf WORD external-l3 eigrp

Description: Show external l3 EIGRP

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD vrf WORD external-l3 eigrp
```

show tenant vrf external-l3 eigrp detail

show tenant WORD vrf WORD external-l3 eigrp detail

説明：内部の詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD external-l3 eigrp detail
```

show tenant vrf external-l3 epg

show tenant WORD vrf WORD external-l3 epg <epgName>

Description: Show command for external-l3 epgs

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
<*epgName*>	Name of the EPG to filter on

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD vrf WORD external-l3 epg <epgName>
```

show tenant vrf external-l3 epg detail

show tenant WORD vrf WORD external-l3 epg <epgName> detail

説明：external-l3 epg の詳細と動作ステータス

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<*epgName*>	フィルタする EPG 名

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD external-l3 epg <epgName> detail
```

show tenant vrf external-l3 interfaces

show tenant WORD vrf WORD external-l3 interfaces

Description: Show tenant <tenant> vrf <vrf> external l3 interfaces

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD vrf WORD external-l3 interfaces
```

show tenant vrf external-l3 interfaces detail

show tenant WORD vrf WORD external-l3 interfaces detail

説明：インターフェイスの詳細を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD external-l3 interfaces detail
```

show tenant vrf external-l3 ospf

show tenant WORD vrf WORD external-l3 ospf

説明： IPv4 および IPv6 外部 l3 OSPF 構成のコマンドを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD external-l3 ospf
```

show tenant vrf external-l3 ospf detail

show tenant WORD vrf WORD external-l3 ospf detail

Description: Show internal details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD vrf WORD external-l3 ospf detail
```

show tenant vrf external-l3 route-map

show tenant WORD vrf WORD external-l3 route-map [name <l3out name>]

説明：external-l3 route-map のコマンドの表示

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<l3out name>	（オプション）フィルタするルートマップの名前

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD external-l3 route-map [name <l3out name>]
```

show tenant vrf external-l3 route-map detail

show tenant WORD vrf WORD external-l3 route-map [name <l3out name>] detail

説明：動作ステータスを記載した external-l3 ルートマップを表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）
<l3out name>	（オプション）フィルタするルートマップの名前

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD external-l3 route-map [name <l3out name>] detail
```

show tenant vrf external-l3 scale

show tenant WORD vrf WORD external-l3 scale

説明：スケール コマンド

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD external-l3 scale
```

show tenant vrf external-l3 scale detail

show tenant WORD vrf WORD external-l3 scale detail

Description: Show scale details

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD vrf WORD external-l3 scale detail
```

show tenant vrf external-l3 static-route

show tenant WORD vrf WORD external-l3 static-route

説明：external-l3 スタティック ルートのコマンドの表示

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD external-l3 static-route
```

show tenant vrf external-l3 static-route detail

show tenant WORD vrf WORD external-l3 static-route detail

説明：スタティックルートの詳細と動作ステータス

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD external-l3 static-route detail
```

show tenant vrf external-l3 static-route node

show tenant WORD vrf WORD external-l3 static-route node

Description: node to filter on

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
arg	Leaf Range or Leaf Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD vrf WORD external-l3 static-route node
```

show tenant vrf external-l3 static-route node detail

show tenant WORD vrf WORD external-l3 static-route node detail

Description: static-route in detail with operational status

Syntax:

WORD	Name of the tenant to filter on (Max Size 63)
WORD	Name of the VRF to filter on (Max Size 64)
arg	Leaf Range or Leaf Name List

Command Mode: exec : Exec Mode

Command Path:

```
# show tenant WORD vrf WORD external-l3 static-route node detail
```

show tenant vrf ipv6multicast

show tenant WORD vrf WORD ipv6multicast

説明：VRF ごとに ipv6 マルチキャスト構成を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD ipv6multicast
```

show tenant vrf multicast

show tenant WORD vrf WORD multicast

説明：VRF ごとにマルチキャスト構成を表示する

構文：

WORD	フィルタするテナントの名前（最大サイズ 63）
WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show tenant WORD vrf WORD multicast
```

show track-ipsla

show track-ipsla

Description: Show ipsla object ID details

Command Mode: exec : Exec Mode

Command Path:

```
# show track-ipsla
```

show track-objects

show track-objects

Description: Show track object ID details

Command Mode: exec : Exec Mode

Command Path:

```
# show track-objects
```

show Troubleshooting session

show troubleshoot session <session_name>

説明：セッションを表示する

構文：

session_name	セッション名

コマンド モード exec：Exec モード

コマンド パス：

```
# show troubleshoot session <session_name>
```

show troubleshoot session atomiccounter

show troubleshoot session <session_name> atomiccounter

説明：アトミック カウンタを表示します。

構文：

session_name	セッション名

コマンド モード exec：Exec モード

コマンド パス：

```
# show troubleshoot session <session_name> atomiccounter
```

show troubleshoot session audit

show troubleshoot session <session_name> audit

Description: Show audit

Syntax:

session_name	Session name

Command Mode: exec : Exec Mode

Command Path:

```
# show troubleshoot session <session_name> audit
```

show troubleshoot session contracts

show troubleshoot session <session_name> contracts

Description: Show contracts

Syntax:

session_name	Session name

Command Mode: exec : Exec Mode

Command Path:

```
# show troubleshoot session <session_name> contracts
```

show troubleshoot session deployments

show troubleshoot session <session_name> deployments

説明：展開の変更を表示する

構文：

session_name	セッション名

コマンド モード exec：Exec モード

コマンド パス：

```
# show troubleshoot session <session_name> deployments
```

show troubleshoot session events

show troubleshoot session <session_name> events

説明：イベントを表示する

構文：

session_name	セッション名

コマンド モード exec：Exec モード

コマンド パス：

```
# show troubleshoot session <session_name> events
```

show troubleshoot session faults

show troubleshoot session <session_name> faults

Description: Show faults

Syntax:

session_name	Session name

Command Mode: exec : Exec Mode

Command Path:

```
# show troubleshoot session <session_name> faults
```

show troubleshoot session latency

show troubleshoot session <session_name> latency

説明： 遅延統計を表示します。

構文：

session_name	セッション名

コマンド モード exec：Exec モード

コマンド パス：

```
# show troubleshoot session <session_name> latency
```

show Troubleshooting session monitor

show troubleshoot session <session_name> monitor

説明：モニタを表示する

構文：

session_name	セッション名

コマンド モード exec：Exec モード

コマンド パス：

```
# show troubleshoot session <session_name> monitor
```

show troubleshoot session reports

show troubleshoot session <session_name> reports

説明：レポートを表示する

構文：

session_name	セッション名

コマンド モード exec：Exec モード

コマンド パス：

```
# show troubleshoot session <session_name> reports
```

show troubleshoot session statistics

show troubleshoot session <session_name> statistics

説明：統計情報を表示する

構文：

session_name	セッション名

コマンド モード exec：Exec モード

コマンド パス：

```
# show troubleshoot session <session_name> statistics
```

show troubleshoot session topology

show troubleshoot session <session_name> topology

Description: Show topology

Syntax:

session_name	Session name

Command Mode: exec : Exec Mode

Command Path:

```
# show troubleshoot session <session_name> topology
```

show troubleshoot session traceroute

show troubleshoot session <session_name> traceroute

説明：traceroute を表示する

構文：

session_name	セッション名

コマンド モード exec：Exec モード

コマンド パス：

```
# show troubleshoot session <session_name> traceroute
```

show troubleshoot sessions

show troubleshoot sessions

説明： セッションを表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show troubleshoot sessions
```

show upgrade-timeline controller

show upgrade-timeline controller

Description: show upgrade-timeline for controller

Command Mode: exec : Exec Mode

Command Path:

```
# show upgrade-timeline controller
```

show upgrade-timeline summary

show upgrade-timeline summary

Description: show upgrade-timeline summary

Command Mode: exec : Exec Mode

Command Path:

```
# show upgrade-timeline summary
```

show upgrade-timeline switch

show upgrade-timeline switch <NUMBER>

説明：スイッチのアップグレード タイムラインを表示する

構文：

switchId <switchId>	スイッチ ID。番号の範囲は = 101 ～ = 4000

コマンド モード exec：Exec モード

コマンド パス：

```
# show upgrade-timeline switch <NUMBER>
```

show upgradeissues controller

show upgradeissues controller

説明： APIC コントローラのアップグレード情報を表示する。

コマンド モード exec：Exec モード

コマンド パス：

```
# show upgradeissues controller
```

show username

show username <WORD>

説明：ユーザー情報を表示する

構文：

WORD	ユーザー名

コマンド モード exec：Exec モード

コマンド パス：

```
# show username <WORD>
```

show username detail

show username <WORD> detail

Description: Show user information

Syntax:

WORD	User name

Command Mode: exec : Exec Mode

Command Path:

```
# show username <WORD> detail
```

show versions

show versions

Description: Show version information

Command Mode: exec : Exec Mode

Command Path:

```
# show versions
```

show vlan-domain

show vlan-domain [name <arg>] [vlan] [leaf <arg>] [detail]

説明：vlan-domain のコマンドを表示する

構文：

arg	（オプション）VLAN ドメイン名
<vlan-range>	（オプション）1 ～ 4094 のVLAN ID。または 1 ～ 5、10 や 2 ～ 5、7 ～ 19 などのような範囲
arg	（オプション）リーフ ID。番号の範囲は = 101 ～ = 4000
detail	（オプション）vlan-domain の具体的な MO を使用した詳細

コマンド モード exec：Exec モード

コマンド パス：

```
# show vlan-domain [name <>] [vlan] [leaf <>] [detail]
```

show vmware domain

show vmware domain

説明： VMware ドメイン情報を表示する

コマンド モード exec：Exec モード

コマンド パス：

```
# show vmware domain
```

show vmware domain name

show vmware domain name <name>

説明：VMware ドメイン名

構文：

<*name*>	VMware ドメイン名

コマンド モード exec：Exec モード

コマンド パス：

```
# show vmware domain name <name>
```

show vmware domain name epg

show vmware domain name <name> epg

説明：VMware ドメイン EPG の詳細を表示する

構文：

<*name*>	VMware ドメイン名

コマンド モード exec：Exec モード

コマンド パス：

```
# show vmware domain name <name> epg
```

show vmware domain name esx

show vmware domain name <name> esx <esx-ip>

Description: Show VMware ESX information

Syntax:

<*name*>	VMware domain name
<*esx-ip*>	ESX IP

Command Mode: exec : Exec Mode

Command Path:

```
# show vmware domain name <name> esx <esx-ip>
```

show vmware domain name port-group

show vmware domain name <name> port-group

Description: Show VMware port group information

Syntax:

<*name*>	VMware domain name

Command Mode: exec : Exec Mode

Command Path:

```
# show vmware domain name <name> port-group
```

show vmware domain name trunk-portgroup

show vmware domain name <name> trunk-portgroup [name <name>]

Description: Show VMware domain trunk portgroup details

Syntax:

<*name*>	VMware domain name
<*name*>	(Optional) trunk portgroup name

Command Mode: exec : Exec Mode

Command Path:

```
# show vmware domain name <name> trunk-portgroup [name <name>]
```

show vmware domain name vcenter

show vmware domain name <name> vcenter <hostname|ip>

Description: VMware vCenter ip or hostname

Syntax:

<*name*>	VMware domain name
<*hostname*|*ip*>	vCenter hostname or IP

Command Mode: exec : Exec Mode

Command Path:

```
# show vmware domain name <name> vcenter <hostname|ip>
```

show vmware domain name vm

show vmware domain name <name> vm

Description: Show VMware VM information

Syntax:

<*name*>	VMware domain name

Command Mode: exec : Exec Mode

Command Path:

```
# show vmware domain name <name> vm
```

show vmware domain name vm name

show vmware domain name <name> vm name <vm-name>

説明：詳細な VMware VM 情報を表示する

構文：

<*name*>	VMware ドメイン名
<*vm-name*>	VM 名

コマンド モード exec：Exec モード

コマンド パス：

```
# show vmware domain name <name> vm name <vm-name>
```

show vmware vm

show vmware vm [name <WORD>] [ip <A.B.C.D>] [mac <E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]

Description: Show VMware VM information

Syntax:

WORD	(Optional) Specify a VM name
A.B.C.D	(Optional) IP address in format i.i.i.i
E.E.E EE-EE-EE-EE-EE-EE EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE	(Optional) MAC address (Option 1) MAC address (Option 2) MAC address (Option 3) MAC address (Option 4)

Command Mode: exec : Exec Mode

Command Path:

```
# show vmware vm [name <WORD>] [ip <A.B.C.D>] [mac <E.E.E EE-EE-EE-EE-EE-EE
EE:EE:EE:EE:EE:EE EEEE.EEEE.EEEE >]
```

show vpc

show vpc map <vpc-list>

説明：vpc マッピングを表示する

構文：

マップ	名前別のマップ
<*vpc-list*>	vpc 名

コマンド モード exec：Exec モード

コマンド パス：

```
# show vpc map <vpc-list>
```

show vpc map Leaf

show vpc map <vpc-list> leaf WORD [fex <NUMBER>]

説明：リーフ

構文：

マップ	名前別のマップ
<vpc-list>	vpc 名
WORD	リーフ範囲またはリーフ名リスト
<101-199>	（オプション）FEX ID。=101 ～ =199 までの範囲

コマンド モード exec：Exec モード

コマンド パス：

```
# show vpc map <vpc-list> leaf WORD [fex <NUMBER>]
```

show vrf

show vrf WORD

説明：VRF 情報を表示する

構文：

WORD	フィルタする VRF の名前（最大サイズ 64）

コマンド モード exec：Exec モード

コマンド パス：

```
# show vrf WORD
```

show vrf detail

show vrf WORD detail

Description: Show detailed view of VRF

Syntax:

WORD	Name of the VRF to filter on (Max Size 64)

Command Mode: exec : Exec Mode

Command Path:

```
# show vrf WORD detail
```

show vsan-domain

show vsan-domain [name <arg>] [detail]

説明：vsan ドメインのコマンドを表示する

構文：

arg	CWM
detail	（オプション）Vsan ドメイン名の詳細な情報

コマンド モード exec：Exec モード

コマンド パス：

```
# show vsan-domain [name <>] [detail]
```

sr-upgrade

sr-upgrade

Description: Check for SR Upgrade

Command Mode: switch-group : Create switch firmware upgrade policy

Command Path:

```
# configure [['terminal', 't']]
(config)# firmware
(config-firmware)# switch-group <WORD>
(config-firmware-switch)# sr-upgrade
```

sr-version

sr-version <version>

Description: Set target SR version

Syntax:

<*version*>	SR version

Command Mode: switch-group : Create switch firmware upgrade policy

Command Path:

```
# configure [['terminal', 't']]
(config)# firmware
(config-firmware)# switch-group <WORD>
(config-firmware-switch)# sr-version <version>
```

switch-group

switch-group <WORD>

説明：スイッチ ファームウェア アップグレード ポリシーを作成する

構文：

WORD	スイッチグループ名（最大サイズ 64）

コマンド モード：ファームウェア：ファームウェア アップグレード構成モード

コマンド パス：

```
# configure [['terminal', 't']]
(config)# firmware
(config-firmware)# switch-group <WORD>
```

switch

switch

Description: Add switches to switch group

Syntax:

arg	

Command Mode: switch-group : Create switch firmware upgrade policy

Command Path:

```
# configure [['terminal', 't']]
(config)# firmware
(config-firmware)# switch-group <WORD>
(config-firmware-switch)# switch
```

syslog

syslog<common>

説明：Syslog ポリシー構成モード

構文：

共通	Syslog Src ポリシー名

コマンド モード：構成：構成モード

コマンド パス：

```
# configure [['terminal', 't']]
(config)# syslog <common>
```

翻訳について
このドキュメントは、米国シスコ発行ドキュメントの参考和訳です。リンク情報につきましては、日本語版掲載時点で、英語版にアップデートがあり、リンク先のページが移動/変更されている場合がありますことをご了承ください。あくまでも参考和訳となりますので、正式な内容については米国サイトのドキュメントを参照ください。