

## **Running Diagnostic Tests Using the GUI**

This chapter contains the following sections:

- About Quick Tests, page 1
- Running Quick Tests, page 1
- About Comprehensive Tests, page 2
- Running Comprehensive Tests, page 2
- About Quickmem Tests, page 2
- Running Quickmem Tests, page 3
- About Test Suites, page 3
- Running Tests in a Test Suite, page 3
- Saving Logs to an External USB Drive, page 4

### **About Quick Tests**

Quick tests performs a quick diagnostics of your server components to determine any hardware issues or failures. Depending on the Cisco UCS Server that you are using and the memory available on your server, these tests usually take 20 to 30 minutes to quickly test the overall functionality of your main subsystems.

### **Running Quick Tests**

#### Procedure

- **Step 1** In the Navigation pane, expand Diagnostic Tools.
- Step 2 Expand Tests.
- Step 3 Click Quick Tests.
- **Step 4** In the **Contents** pane, click **Run all Quick Tests**.

Note You can run all quick tests, or expand Quick Tests to choose individual options.

- Step 5 Click Tests log Summary to view all tests that are currently in the queue. The tests are run in the order as listed in the Test Suite table. The results are displayed in the Test Status area in the Contents pane.
  Step 6 To clear the system events log in the Contents pane, click Clear SEI.
- **Step 6** To clear the system events log, in the **Contents** pane, click **Clear SEL**.

# **About Comprehensive Tests**

Comprehensive tests can run for several hours or days. These tests run exhaustive burn-in tests on your server, such as stress tests. The tests are designed to test multiple hardware components and find issues that might be caused by multiple components on your server.

### **Running Comprehensive Tests**

You can customize comprehensive tests to diagnose specific conditions based on your requirements.

### Procedure

Step 1	In the Navigation pane, expand Diagnostic Tools.
Step 2	Expand Tests.
Step 3	Click Comprehensive Tests.
Step 4	In the Contents pane, click Run all comprehensive tests.NoteYou can run all comprehensive tests, or expand Comprehensive Tests to choose individual options.
Step 5	Click <b>Tests log Summary</b> to view all tests that are currently in the queue. The test is run in the order as listed in the <b>Test Suite</b> table. The results are displayed in the <b>Test Status</b> area in the <b>Contents</b> pane.
Step 6	To clear the system events log, in the Contents pane, click Clear SEL.

## **About Quickmem Tests**

Quickmem test performs a quick diagnostics of your server memory with different patterns, chunk sizes, and loops. Each pmem2 test in Quickmem Test has its own parameters (patterns, chunk size, loops, and size of memory).

## **Running Quickmem Tests**

#### Procedure

Step 1	In the Navigation pane, expand Diagnostic Tools.
Step 2	Expand Tests.
Step 3	Click Quickmem Tests.
Step 4	In the <b>Contents</b> pane, click <b>Run all quickmem tests</b> . <b>Note</b> You can run all quickmem tests, or expand <b>Quickmem Tests</b> to choose individual options.
Step 5	Click <b>Tests log Summary</b> to view all tests that are currently in the queue. The tests are run in the order as listed in the <b>Test Suite</b> table. The results are displayed in the <b>Test Status</b> area in the <b>Contents</b> pane.
Step 6	To clear the system events log, in the <b>Contents</b> pane, click <b>Clear SEL</b> .

### **About Test Suites**

You can run more than one test at the same time using a test suite. Each test that you select is run consecutively, and the results are displayed in the **Test Status** area in the **Contents** pane.

## **Running Tests in a Test Suite**



I

Note

Running tests in a suite is available from the GUI mode only.

#### **Procedure**

Step 1	In the Navigation pane, expand Diagnostic Tools.
Step 2	Click Test Suite.
Step 3	In the Contents pane, check the check box for the tests that you want to run in the suite.
Step 4	In the <b>Contents</b> pane, click <b>Run Tests Suite</b> . The tests are added to the <b>Test Suite</b> queue.
Step 5	In the Navigation pane, click Tests Log Summary to view the execution status of these

tests.

### Saving Logs to an External USB Drive

Perform this procedure to save the logs in an external USB drive.

#### **Before You Begin**

Ensure that you have a USB drive with adequate space available to save logs.

#### Procedure

- **Step 1** Plug the USB drive.
- Step 2 From the menu bar choose Virtual Media > Map Removable Disk.... Virtual Media - Map Removable Disk window is displayed.
- **Step 3** Select the USB disk drive from the drop-down list.
  - **Note** Ensure that the USB is not open or accessed by any other program on the computer. If the USB is being accessed, it mounts as a read only disk. You cannot save logs in a USB which is in read only mode.
- Step 4 Click Map Device.
- **Step 5** From the toolbar click **Save Logs** icon.
- Step 6 Click Yes Save window is displayed.
- Step 7 Enter the desired file name in File Name field.
- Step 8 Click Save.
- Step 9 Click OK. The logs are saved as \*.tar.gz file.

To view the saved file, first unmap the USB drive.

- Step 10 From the menu bar choose Virtual Media > Map Removable Disk....
- Step 11 Click Yes to confirm.

You can now access the saved log file in the USB drive.